

## MaxiDiag\_Ford\_V6.02 Function List (Note:For reference only)

## NOTES:

- This function is supported.      ※ This function may be supported, which depends on the actual condition of the vehicle.  
○ This function is not supported.    ▲ This function is the new feature in this version.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
(All MY05) Escape/Tribute/Maverick/Mariner	2.3L	DURATEC-HE / I4	2005	4X4	●	●	●
(All MY05) Escape/Tribute/Maverick/Mariner	2.3L	DURATEC-HE / I4	2005	ABS	●	●	●
(All MY05) Escape/Tribute/Maverick/Mariner	2.3L	DURATEC-HE / I4	2005	GEM	●	●	●
(All MY05) Escape/Tribute/Maverick/Mariner	2.3L	DURATEC-HE / I4	2005	IC	●	●	●
(All MY05) Escape/Tribute/Maverick/Mariner	2.3L	DURATEC-HE / I4	2005	PAM	●	●	●
(All MY05) Escape/Tribute/Maverick/Mariner	2.3L	DURATEC-HE / I4	2005	PCM	●	●	●
(All MY05) Escape/Tribute/Maverick/Mariner	2.3L	DURATEC-HE / I4	2005	RCM	●	●	●
(All MY05) Escape/Tribute/Maverick/Mariner	3.0L	4V	2005	4X4	●	●	●
(All MY05) Escape/Tribute/Maverick/Mariner	3.0L	4V	2005	ABS	●	●	●
(All MY05) Escape/Tribute/Maverick/Mariner	3.0L	4V	2005	GEM	●	●	●
(All MY05) Escape/Tribute/Maverick/Mariner	3.0L	4V	2005	IC	●	●	●
(All MY05) Escape/Tribute/Maverick/Mariner	3.0L	4V	2005	PAM	●	●	●
(All MY05) Escape/Tribute/Maverick/Mariner	3.0L	4V	2005	PCM	●	●	●
(All MY05) Escape/Tribute/Maverick/Mariner	3.0L	4V	2005	RCM	●	●	●
626 / 626 WAGON / TELSTAR	1.8L	FP	1997 - 2000	PCM	●	●	●
626 / 626 WAGON / TELSTAR	1.8L	FP	1999	ABS	●	●	●
626 / 626 WAGON / TELSTAR	1.8L	FP	2000	ABS/TCS	●	●	●
626 / 626 WAGON / TELSTAR	2.0L	FS	1997 - 1999	ABS	●	●	●
626 / 626 WAGON / TELSTAR	2.0L	FS	1997 - 2001	PCM	●	●	●
626 / 626 WAGON / TELSTAR	2.0L	FS	1998 - 2001	ABS/TCS	●	●	●
626 / 626 WAGON / TELSTAR	2.0L	RF-T	1997 - 2000	PCM	●	●	●
626 / 626 WAGON / TELSTAR	2.0L	RF-T	1999 - 2000	ABS	●	●	●
626 / 626 WAGON / TELSTAR	2.5L	KL	1997 - 2001	PCM	●	●	●
626 / 626 WAGON / TELSTAR	2.5L	KL	1998 - 2001	ABS/TCS	●	●	●
AEROSTAR	3.0L	Other	1996 - 1997	PCM	●	●	●
AEROSTAR	4.0L	Other	1996 - 1997	PCM	●	●	●
Aspire	1.3L	Other	1996 - 1997	PCM	●	●	●
Aspire	1.5L	Other	1997	PCM	●	●	●
Aviator	4.6L	4V	2003	VEMS	●	●	●
Aviator	4.6L	4V	2003 - 2005	4X4	●	●	●
Aviator	4.6L	4V	2003 - 2005	ABS/TCS	●	●	●
Aviator	4.6L	4V	2003 - 2005	DCSM	●	●	●
Aviator	4.6L	4V	2003 - 2005	DSM	●	●	●
Aviator	4.6L	4V	2003 - 2005	EATC	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Aviator	4.6L	4V	2003 - 2005	IC	●	●	●
Aviator	4.6L	4V	2003 - 2005	NAV	●	●	●
Aviator	4.6L	4V	2003 - 2005	PAM	●	●	●
Aviator	4.6L	4V	2003 - 2005	PCM	●	●	●
Aviator	4.6L	4V	2003 - 2005	PCSM	●	●	●
Aviator	4.6L	4V	2003 - 2005	RCM	●	●	●
Aviator	4.6L	4V	2003 - 2005	TPM	●	●	●
Aviator	4.6L	4V	2003 - 2005	VAPS	●	●	●
Aviator	4.6L	4V	2003 - 2005	VSM	●	●	●
B-Max	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2012	ABS	●	●	●
B-Max	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2012	ACM	●	●	●
B-Max	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2012	APIM	●	●	●
B-Max	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2012	BCMii	●	●	●
B-Max	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2012	DDM	●	●	●
B-Max	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2012	FCDIM	●	●	●
B-Max	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2012	FDSM	●	●	●
B-Max	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2012	GPSM	●	●	●
B-Max	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2012	GWM	●	●	●
B-Max	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2012	HVAC	●	●	●
B-Max	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2012	IPC	●	●	●
B-Max	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2012	PCM	●	●	●
B-Max	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2012	PDM	●	●	●
B-Max	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2012	PSCM	●	●	●
B-Max	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2012	RCM	●	●	●
B-Max	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2012	RFA	●	●	●
B-Max	1.25L	DURATEC 16V	2008	ABS	●	●	●
B-Max	1.25L	DURATEC 16V	2008	ACM	●	●	●
B-Max	1.25L	DURATEC 16V	2008	BCMii	●	●	●
B-Max	1.25L	DURATEC 16V	2008	FCDIM	●	●	●
B-Max	1.25L	DURATEC 16V	2008	HVAC	●	●	●
B-Max	1.25L	DURATEC 16V	2008	IPC	●	●	●
B-Max	1.25L	DURATEC 16V	2008	PCM	●	●	●
B-Max	1.25L	DURATEC 16V	2008	PSCM	●	●	●
B-Max	1.25L	DURATEC 16V	2008	RCM	●	●	●
B-Max	1.25L	DURATEC 16V	2008	RFA	●	●	●
B-Max	1.25L	DURATEC 16V	2008	SRM	●	●	●
B-Max	1.4L	DURATEC 16V	2008	SRM	●	●	●
B-Max	1.4L	DURATEC 16V	2008	TCM	●	●	●
B-Max	1.4L	DURATEC 16V	2008 - 2012	ABS	●	●	●
B-Max	1.4L	DURATEC 16V	2008 - 2012	ACM	●	●	●
B-Max	1.4L	DURATEC 16V	2008 - 2012	BCMii	●	●	●
B-Max	1.4L	DURATEC 16V	2008 - 2012	FCDIM	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
B-Max	1. 4L	DURATEC 16V	2008 - 2012	HVAC	●	●	●
B-Max	1. 4L	DURATEC 16V	2008 - 2012	IPC	●	●	●
B-Max	1. 4L	DURATEC 16V	2008 - 2012	PCM	●	●	●
B-Max	1. 4L	DURATEC 16V	2008 - 2012	PSCM	●	●	●
B-Max	1. 4L	DURATEC 16V	2008 - 2012	RCM	●	●	●
B-Max	1. 4L	DURATEC 16V	2008 - 2012	RFA	●	●	●
B-Max	1. 4L	DURATEC 16V	2012	APIM	●	●	●
B-Max	1. 4L	DURATEC 16V	2012	DDM	●	●	●
B-Max	1. 4L	DURATEC 16V	2012	FDSM	●	●	●
B-Max	1. 4L	DURATEC 16V	2012	GPSM	●	●	●
B-Max	1. 4L	DURATEC 16V	2012	GWM	●	●	●
B-Max	1. 4L	DURATEC 16V	2012	PDM	●	●	●
B-Max	1. 4L	Duratorq Turbo Diesel Common Rail Injection	2008	ABS	●	●	●
B-Max	1. 4L	Duratorq Turbo Diesel Common Rail Injection	2008	ACM	●	●	●
B-Max	1. 4L	Duratorq Turbo Diesel Common Rail Injection	2008	BCMii	●	●	●
B-Max	1. 4L	Duratorq Turbo Diesel Common Rail Injection	2008	FCDIM	●	●	●
B-Max	1. 4L	Duratorq Turbo Diesel Common Rail Injection	2008	HVAC	●	●	●
B-Max	1. 4L	Duratorq Turbo Diesel Common Rail Injection	2008	IPC	●	●	●
B-Max	1. 4L	Duratorq Turbo Diesel Common Rail Injection	2008	PCM	●	●	●
B-Max	1. 4L	Duratorq Turbo Diesel Common Rail Injection	2008	PSCM	●	●	●
B-Max	1. 4L	Duratorq Turbo Diesel Common Rail Injection	2008	RCM	●	●	●
B-Max	1. 4L	Duratorq Turbo Diesel Common Rail Injection	2008	RFA	●	●	●
B-Max	1. 4L	Duratorq Turbo Diesel Common Rail Injection	2008	SRM	●	●	●
B-Max	1. 5L	Duratorq Turbo Diesel Common Rail Injection	2012	ABS	●	●	●
B-Max	1. 5L	Duratorq Turbo Diesel Common Rail Injection	2012	ACM	●	●	●
B-Max	1. 5L	Duratorq Turbo Diesel Common Rail Injection	2012	APIM	●	●	●
B-Max	1. 5L	Duratorq Turbo Diesel Common Rail Injection	2012	BCMii	●	●	●
B-Max	1. 5L	Duratorq Turbo Diesel Common Rail Injection	2012	DDM	●	●	●
B-Max	1. 5L	Duratorq Turbo Diesel Common Rail Injection	2012	FCDIM	●	●	●
B-Max	1. 5L	Duratorq Turbo Diesel Common Rail Injection	2012	FDSM	●	●	●
B-Max	1. 5L	Duratorq Turbo Diesel Common Rail Injection	2012	GPSM	●	●	●
B-Max	1. 5L	Duratorq Turbo Diesel Common Rail Injection	2012	GWM	●	●	●
B-Max	1. 5L	Duratorq Turbo Diesel Common Rail Injection	2012	HVAC	●	●	●
B-Max	1. 5L	Duratorq Turbo Diesel Common Rail Injection	2012	IPC	●	●	●
B-Max	1. 5L	Duratorq Turbo Diesel Common Rail Injection	2012	PCM	●	●	●
B-Max	1. 5L	Duratorq Turbo Diesel Common Rail Injection	2012	PDM	●	●	●
B-Max	1. 5L	Duratorq Turbo Diesel Common Rail Injection	2012	PSCM	●	●	●
B-Max	1. 5L	Duratorq Turbo Diesel Common Rail Injection	2012	RCM	●	●	●
B-Max	1. 5L	Duratorq Turbo Diesel Common Rail Injection	2012	RFA	●	●	●
B-Max	1. 6L	DURATEC VCT	2008	SRM	●	●	●
B-Max	1. 6L	DURATEC VCT	2008 - 2012	ABS	●	●	●
B-Max	1. 6L	DURATEC VCT	2008 - 2012	ACM	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
B-Max	1.6L	DURATEC VCT	2008 - 2012	BCMii	●	●	●
B-Max	1.6L	DURATEC VCT	2008 - 2012	FCDIM	●	●	●
B-Max	1.6L	DURATEC VCT	2008 - 2012	HVAC	●	●	●
B-Max	1.6L	DURATEC VCT	2008 - 2012	IPC	●	●	●
B-Max	1.6L	DURATEC VCT	2008 - 2012	PCM	●	●	●
B-Max	1.6L	DURATEC VCT	2008 - 2012	PSCM	●	●	●
B-Max	1.6L	DURATEC VCT	2008 - 2012	RCM	●	●	●
B-Max	1.6L	DURATEC VCT	2008 - 2012	RFA	●	●	●
B-Max	1.6L	DURATEC VCT	2012	APIM	●	●	●
B-Max	1.6L	DURATEC VCT	2012	DDM	●	●	●
B-Max	1.6L	DURATEC VCT	2012	FDSM	●	●	●
B-Max	1.6L	DURATEC VCT	2012	GPSM	●	●	●
B-Max	1.6L	DURATEC VCT	2012	GWM	●	●	●
B-Max	1.6L	DURATEC VCT	2012	PDM	●	●	●
B-Max	1.6L	DURATEC VCT	2012	TCM	●	●	●
B-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2008	ABS	●	●	●
B-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2008	ACM	●	●	●
B-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2008	BCMii	●	●	●
B-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2008	FCDIM	●	●	●
B-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2008	HVAC	●	●	●
B-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2008	IPC	●	●	●
B-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2008	PCM	●	●	●
B-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2008	PSCM	●	●	●
B-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2008	RCM	●	●	●
B-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2008	RFA	●	●	●
B-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2008	SRM	●	●	●
B-Max	1.6L	TDCi ECO II	2012	ABS	●	●	●
B-Max	1.6L	TDCi ECO II	2012	ACM	●	●	●
B-Max	1.6L	TDCi ECO II	2012	APIM	●	●	●
B-Max	1.6L	TDCi ECO II	2012	BCMii	●	●	●
B-Max	1.6L	TDCi ECO II	2012	DDM	●	●	●
B-Max	1.6L	TDCi ECO II	2012	FCDIM	●	●	●
B-Max	1.6L	TDCi ECO II	2012	FDSM	●	●	●
B-Max	1.6L	TDCi ECO II	2012	GPSM	●	●	●
B-Max	1.6L	TDCi ECO II	2012	GWM	●	●	●
B-Max	1.6L	TDCi ECO II	2012	HVAC	●	●	●
B-Max	1.6L	TDCi ECO II	2012	IPC	●	●	●
B-Max	1.6L	TDCi ECO II	2012	PCM	●	●	●
B-Max	1.6L	TDCi ECO II	2012	PDM	●	●	●
B-Max	1.6L	TDCi ECO II	2012	PSCM	●	●	●
B-Max	1.6L	TDCi ECO II	2012	RCM	●	●	●
B-Max	1.6L	TDCi ECO II	2012	RFA	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
B-Series / Bravo / Fighter / Courier / Ranger / Everest / Endeavour	2. 2L	F2	1996 - Other	PCM	●	●	●
B-Series / Bravo / Fighter / Courier / Ranger / Everest / Endeavour	2. 5L	WL	2001	PCM	●	●	●
B-Series / Bravo / Fighter / Courier / Ranger / Everest / Endeavour	2. 5L	WL	2001 - 2002	ABS	●	●	●
B-Series / Bravo / Fighter / Courier / Ranger / Everest / Endeavour	2. 5L	WL_T	2001 - 2005	ABS	●	●	●
B-Series / Bravo / Fighter / Courier / Ranger / Everest / Endeavour	2. 5L	WL_T	2001 - 2005	PCM	●	●	●
B-Series / Bravo / Fighter / Courier / Ranger / Everest / Endeavour	2. 6L	G6	1996 - 1999	PCM	●	●	●
B-Series / Bravo / Fighter / Courier / Ranger / Everest / Endeavour	2. 6L	G6	1999	ABS	●	●	●
B-Series / Bravo / Fighter / Courier / Ranger / Everest / Endeavour	2. 9L	W9	2002	ABS	●	●	●
BONGO / BONGO BRAWNY / SPECTRON	1. 8L	F8	1999	ABS	●	●	●
BONGO / BONGO BRAWNY / SPECTRON	1. 8L	F8	1999 - 2002	PCM	●	●	●
BONGO / BONGO BRAWNY / SPECTRON	1. 8L	F8	2002	ABS/TCS	●	●	●
BONGO / BONGO BRAWNY / SPECTRON	1. 8L	F8	2002	TCM	●	●	●
BONGO / BONGO BRAWNY / SPECTRON	1. 8L	L8	2010	ABS	●	●	●
BONGO / BONGO BRAWNY / SPECTRON	1. 8L	L8	2010	IC	●	●	●
BONGO / BONGO BRAWNY / SPECTRON	1. 8L	L8	2010	PCM	●	●	●
BONGO / BONGO BRAWNY / SPECTRON	1. 8L	L8	2010	TCM	●	●	●
BONGO / BONGO BRAWNY / SPECTRON	2. 0L	RF-T	2003 - 2007	ABS/TCS	●	●	●
BONGO / BONGO BRAWNY / SPECTRON	2. 0L	RF-T	2003 - 2007	PCM	●	●	●
BONGO / BONGO BRAWNY / SPECTRON	2. 0L	RF-T	2003 - 2007	TCM	●	●	●
BONGO / BONGO BRAWNY / SPECTRON	2. 2L	R2	1999	ABS	●	●	●
BONGO / BONGO BRAWNY / SPECTRON	2. 2L	R2	1999	PCM	●	●	●
BONGO BRAWNY / ECONOVAN / MAZDA E-SERIES	1. 8L	F8	1999	ABS	●	●	●
BONGO BRAWNY / ECONOVAN / MAZDA E-SERIES	1. 8L	F8	1999	PCM	●	●	●
BONGO BRAWNY / ECONOVAN / MAZDA E-SERIES	2. 0L	FE	1997 - 1999	ABS	●	●	●
BONGO BRAWNY / ECONOVAN / MAZDA E-SERIES	2. 0L	FE	1997 - 2002	PCM	●	●	●
BONGO BRAWNY / ECONOVAN / MAZDA E-SERIES	2. 0L	FE	2002	ABS/TCS	●	●	●
BONGO BRAWNY / ECONOVAN / MAZDA E-SERIES	2. 0L	FE	2002	TCM	●	●	●
BONGO BRAWNY / ECONOVAN / MAZDA E-SERIES	2. 2L	R2	1999	ABS	●	●	●
BONGO BRAWNY / ECONOVAN / MAZDA E-SERIES	2. 2L	R2	1999	PCM	●	●	●
BONGO BRAWNY / ECONOVAN / MAZDA E-SERIES	2. 5L	WL	1999	ABS	●	●	●
BONGO BRAWNY / ECONOVAN / MAZDA E-SERIES	2. 5L	WL	1999	PCM	●	●	●
BT-50 / Ranger	2. 2L	F2	2007	ABS/TCS	●	●	●
BT-50 / Ranger	2. 2L	F2	2007	PCM	●	●	●
BT-50 / Ranger	2. 2L	F2	2007	RCM	●	●	●
BT-50 / Ranger	2. 5L	L5	2012	ABS	●	●	●
BT-50 / Ranger	2. 5L	L5	2012	PCM	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
BT-50 / Ranger	2.5L	WL	2007	ABS/TCS	●	●	●
BT-50 / Ranger	2.5L	WL	2007	PCM	●	●	●
BT-50 / Ranger	2.5L	WL	2007	RCM	●	●	●
BT-50 / Ranger	2.5L	WL-CD	2007	ABS/TCS	●	●	●
BT-50 / Ranger	2.5L	WL-CD	2007	PCM	●	●	●
BT-50 / Ranger	2.5L	WL-CD	2007	RCM	●	●	●
BT-50 / Ranger	2.5L	WL-CD	2007	TCM	●	●	●
BT-50 / Ranger	2.6L	G6	2007	ABS/TCS	●	●	●
BT-50 / Ranger	2.6L	G6	2007	PCM	●	●	●
BT-50 / Ranger	2.6L	G6	2007	RCM	●	●	●
BT-50 / Ranger	3.0L	WE-CD	2007	ABS/TCS	●	●	●
BT-50 / Ranger	3.0L	WE-CD	2007	PCM	●	●	●
BT-50 / Ranger	3.0L	WE-CD	2007	RCM	●	●	●
BT-50 / Ranger	3.0L	WE-CD	2007	TCM	●	●	●
BT-50 / Ranger	4.0L	V6 SOHC	2007	ABS/TCS	●	●	●
BT-50 / Ranger	4.0L	V6 SOHC	2007	ESOF	●	●	●
BT-50 / Ranger	4.0L	V6 SOHC	2007	PCM	●	●	●
BT-50 / Ranger	4.0L	V6 SOHC	2007	RCM	●	●	●
Bantam	1.3L	Zetec Rocam	2001 - 2006	PCM	●	●	●
Bantam	1.4L	Duratorq Turbo Diesel Common Rail Injection	2009	IC	●	●	●
Bantam	1.4L	Duratorq Turbo Diesel Common Rail Injection	2009	PCM	●	●	●
Bantam	1.4L	Duratorq Turbo Diesel Common Rail Injection	2009	RCM	●	●	●
Bantam	1.6L	Zetec Rocam	2001 - 2006	PCM	●	●	●
Blackwood	5.4L	4V	2002 - 2003	ABS/TCS	●	●	●
Blackwood	5.4L	4V	2002 - 2003	DSM	●	●	●
Blackwood	5.4L	4V	2002 - 2003	EATC	●	●	●
Blackwood	5.4L	4V	2002 - 2003	GEM	●	●	●
Blackwood	5.4L	4V	2002 - 2003	HEC	●	●	●
Blackwood	5.4L	4V	2002 - 2003	LTM	●	●	●
Blackwood	5.4L	4V	2002 - 2003	PAM	●	●	●
Blackwood	5.4L	4V	2002 - 2003	PCM	●	●	●
Blackwood	5.4L	4V	2002 - 2003	RAP	●	●	●
Blackwood	5.4L	4V	2002 - 2003	RASM	●	●	●
Blackwood	5.4L	4V	2002 - 2003	RCM	●	●	●
Blue Bird C-Class Vision	6.8L	3V	2012	PCM	●	●	●
Bronco	5.0L	Other	1996	PCM	●	●	●
Bronco	5.8L	Other	1996	PCM	●	●	●
C-MAX	2.0L	Full Hybrid Electric Vehicle	2013 - 2014	ABS	●	●	●
C-MAX	2.0L	Full Hybrid Electric Vehicle	2013 - 2014	ACM	●	●	●
C-MAX	2.0L	Full Hybrid Electric Vehicle	2013 - 2014	APIM	●	●	●
C-MAX	2.0L	Full Hybrid Electric Vehicle	2013 - 2014	BECM	●	●	●
C-MAX	2.0L	Full Hybrid Electric Vehicle	2013 - 2014	DDM	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
C-MAX	2.0L	Full Hybrid Electric Vehicle	2013 - 2014	GWM	●	●	●
C-MAX	2.0L	Full Hybrid Electric Vehicle	2013 - 2014	HVAC	●	●	●
C-MAX	2.0L	Full Hybrid Electric Vehicle	2013 - 2014	IPC	●	●	●
C-MAX	2.0L	Full Hybrid Electric Vehicle	2013 - 2014	PAM	●	●	○
C-MAX	2.0L	Full Hybrid Electric Vehicle	2013 - 2014	PSCM	●	●	●
C-MAX	2.0L	Full Hybrid Electric Vehicle	2013 - 2014	RFA	●	●	●
C-MAX	2.0L	Full Hybrid Electric Vehicle	2014	FCIM	●	●	●
C-MAX	2.0L	Full Hybrid Electric Vehicle	2014	GPSM	●	●	●
C-MAX	2.0L	Full Hybrid Electric Vehicle	2014	RGTM	●	●	●
C-MAX	2.0L	PHEV	2013 - 2014	ABS	●	●	●
C-MAX	2.0L	PHEV	2013 - 2014	ACM	●	●	●
C-MAX	2.0L	PHEV	2013 - 2014	APIM	●	●	●
C-MAX	2.0L	PHEV	2013 - 2014	BECM	●	●	●
C-MAX	2.0L	PHEV	2013 - 2014	DDM	●	●	●
C-MAX	2.0L	PHEV	2013 - 2014	GFM	●	●	●
C-MAX	2.0L	PHEV	2013 - 2014	GWM	●	●	●
C-MAX	2.0L	PHEV	2013 - 2014	HVAC	●	●	●
C-MAX	2.0L	PHEV	2013 - 2014	IPC	●	●	●
C-MAX	2.0L	PHEV	2013 - 2014	PAM	●	●	○
C-MAX	2.0L	PHEV	2013 - 2014	PSCM	●	●	●
C-MAX	2.0L	PHEV	2013 - 2014	RFA	●	●	●
C-MAX	2.0L	PHEV	2013 - 2014	SOBDM	●	●	●
C-MAX	2.0L	PHEV	2013 - 2014	TCU#1	●	●	●
C-MAX	2.0L	PHEV	2014	FCIM	●	●	●
C-MAX	2.0L	PHEV	2014	GPSM	●	●	●
C-MAX	2.0L	PHEV	2014	RGTM	●	●	●
CAPELLA / CAPELLA W / TELSTAR / TELSTAR W	1.8L	FP	1997 - 1999	PCM	●	●	●
CAPELLA / CAPELLA W / TELSTAR / TELSTAR W	1.8L	FP	1999	ABS	●	●	●
CAPELLA / CAPELLA W / TELSTAR / TELSTAR W	2.0L	FS	1997 - 1999	PCM	●	●	●
CAPELLA / CAPELLA W / TELSTAR / TELSTAR W	2.0L	FS	1999	ABS	●	●	●
CAPELLA / CAPELLA W / TELSTAR / TELSTAR W	2.0L	RF	1997	PCM	●	●	●
CAPELLA / CAPELLA W / TELSTAR / TELSTAR W	2.5L	KL	1999	ABS	●	●	●
CF/LCF	4.5L	Direct Injection - Turbo	2006 - 2009	ABS	●	●	●
CF/LCF	4.5L	Direct Injection - Turbo	2006 - 2009	TCM	●	●	●
Cargo	7.3L	ECOTORQ	2004	PCM	●	●	●
Cargo	Other	ISBe	2009 - 2012	TBM	●	●	●
Cargo	Other	ISBe	2012	HEC	●	●	●
Cargo	Other	ISBe	2012	RKE	●	●	●
Cargo	Other	ISCe	2009 - 2012	TBM	●	●	●
Cargo	Other	ISCe	2012	HEC	●	●	●
Cargo	Other	ISCe	2012	RKE	●	●	●
Cargo	Other	Mechanical	2009 - 2012	TBM	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Cargo	Other	Mechanical	2012	HEC	●	●	●
Cargo	Other	Mechanical	2012	RKE	●	●	●
Continental	4. 6L	4V	1995 - 2002	ABS/TCS	●	●	●
Continental	4. 6L	4V	1995 - 2002	ACM	●	●	●
Continental	4. 6L	4V	1995 - 2002	CPM	●	●	●
Continental	4. 6L	4V	1995 - 2002	DDM	●	●	●
Continental	4. 6L	4V	1995 - 2002	DSM	●	●	●
Continental	4. 6L	4V	1995 - 2002	EATC	●	●	●
Continental	4. 6L	4V	1995 - 2002	LCM	●	●	●
Continental	4. 6L	4V	1995 - 2002	PCM	●	●	●
Continental	4. 6L	4V	1995 - 2002	VDM	●	●	●
Continental	4. 6L	4V	1995 - 2002	VIC	●	●	●
Continental	4. 6L	4V	1996 - 1997	IAB	●	●	●
Continental	4. 6L	4V	1996 - 2000	RESCU	●	●	●
Continental	4. 6L	4V	1998	ECS	●	●	●
Continental	4. 6L	4V	1998 - 2002	NGSC	●	●	●
Continental	4. 6L	4V	1999 - 2002	RCM	●	●	●
Contour	2. 0L	GFP	1996 - 2000	ABS/TCS	●	●	●
Contour	2. 0L	GFP	1996 - 2000	PCM	●	●	●
Contour	2. 0L	GFP	1998	PATS	●	●	●
Contour	2. 0L	GFP	1998 - 2000	CSM	●	●	●
Contour	2. 0L	GFP	1999 - 2000	RCM	●	●	●
Contour	2. 0L	Zetec	1996 - 2000	ABS/TCS	●	●	●
Contour	2. 0L	Zetec	1996 - 2000	PCM	●	●	●
Contour	2. 0L	Zetec	1998	PATS	●	●	●
Contour	2. 0L	Zetec	1998 - 2000	CSM	●	●	●
Contour	2. 0L	Zetec	1999 - 2000	RCM	●	●	●
Contour	2. 5L	Duratec-VE	1996 - 2000	ABS/TCS	●	●	●
Contour	2. 5L	Duratec-VE	1996 - 2000	PCM	●	●	●
Contour	2. 5L	Duratec-VE	1998	PATS	●	●	●
Contour	2. 5L	Duratec-VE	1998 - 2000	CSM	●	●	●
Contour	2. 5L	Duratec-VE	1999 - 2000	RCM	●	●	●
Contour	2. 5L	H0	1998	PATS	●	●	●
Contour	2. 5L	H0	1998 - 2000	ABS/TCS	●	●	●
Contour	2. 5L	H0	1998 - 2000	CSM	●	●	●
Contour	2. 5L	H0	1998 - 2000	PCM	●	●	●
Contour	2. 5L	H0	1999 - 2000	RCM	●	●	●
Cougar	2. 0L	Zetec	1998 - 2002	ABS/TCS	●	●	●
Cougar	2. 0L	Zetec	1998 - 2002	CSM	●	●	●
Cougar	2. 0L	Zetec	1998 - 2002	HEC	●	●	●
Cougar	2. 0L	Zetec	1998 - 2002	IAB	●	●	●
Cougar	2. 0L	Zetec	1998 - 2002	PCM	●	●	●



Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Cougar	2.5L	Duratec-VE	1998 - 2002	ABS/TCS	●	●	●
Cougar	2.5L	Duratec-VE	1998 - 2002	CSM	●	●	●
Cougar	2.5L	Duratec-VE	1998 - 2002	HEC	●	●	●
Cougar	2.5L	Duratec-VE	1998 - 2002	IAB	●	●	●
Cougar	2.5L	Duratec-VE	1998 - 2002	PCM	●	●	●
Cougar	2.5L	Duratec-VE	2001	ABS	●	●	●
Cougar	2.5L	Duratec-VE	2001	IC	●	●	●
Cougar	2.5L	Duratec-VE	2001	MC	●	●	●
Cougar	2.5L	Duratec-VE	2001	REM	●	●	●
Cougar	3.8L	Other	1996 - 1997	ABS/TCS	●	●	●
Cougar	3.8L	Other	1996 - 1997	HEC	●	●	●
Cougar	3.8L	Other	1996 - 1997	PCM	●	●	●
Cougar	4.6L	2V	1994 - 1997	ABS/TCS	●	●	●
Cougar	4.6L	2V	1994 - 1997	HEC	●	●	●
Cougar	4.6L	2V	1994 - 1997	PCM	●	●	●
Crown Victoria	4.6L	2V	1995 - 1997	DSM	●	●	●
Crown Victoria	4.6L	2V	1995 - 2004	ABS/TCS	●	●	●
Crown Victoria	4.6L	2V	1995 - 2007	EATC	●	●	●
Crown Victoria	4.6L	2V	1995 - 2011	DDM	●	●	●
Crown Victoria	4.6L	2V	1995 - 2011	LCM	●	●	●
Crown Victoria	4.6L	2V	1995 - 2011	PCM	●	●	●
Crown Victoria	4.6L	2V	1996 - 1997	IAB	●	●	●
Crown Victoria	4.6L	2V	1998 - 2000	ECS	●	●	●
Crown Victoria	4.6L	2V	1998 - 2002	PATS	●	●	●
Crown Victoria	4.6L	2V	2000 - 2011	RCM	●	●	●
Crown Victoria	4.6L	2V	2003 - 2006	RASM	●	●	●
Crown Victoria	4.6L	2V	2003 - 2006	VAPS	●	●	●
Crown Victoria	4.6L	2V	2004 - 2010	MC	●	●	●
Crown Victoria	4.6L	2V	2005 - 2011	ABS	●	●	●
Crown Victoria	4.6L	2V	2005 - 2011	FSSM	●	●	●
Crown Victoria	4.6L	2V	2006 - 2011	IC	●	●	●
Crown Victoria	4.6L	2V	2007 - 2011	VDM	●	●	●
Crown Victoria	4.6L	2V	2008 - 2011	HVAC	●	●	●
Crown Victoria	4.6L	2V_NGV	1996 - 1997	DSM	●	●	●
Crown Victoria	4.6L	2V_NGV	1996 - 1997	IAB	●	●	●
Crown Victoria	4.6L	2V_NGV	1996 - 2000	ABS/TCS	●	●	●
Crown Victoria	4.6L	2V_NGV	1996 - 2000	DDM	●	●	●
Crown Victoria	4.6L	2V_NGV	1996 - 2000	FIM	●	●	●
Crown Victoria	4.6L	2V_NGV	1996 - 2000	LCM	●	●	●
Crown Victoria	4.6L	2V_NGV	1996 - 2000	PCM	●	●	●
Crown Victoria	4.6L	2V_NGV	1998 - 2000	EATC	●	●	●
Crown Victoria	4.6L	2V_NGV	1998 - 2000	ECS	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Crown Victoria	4. 6L	2V_NGV	1998 - 2000	PATS	●	●	●
Crown Victoria	4. 6L	2V_NGV	2000	RCM	●	●	●
Crown Victoria	4. 6L	Other	1995	ABS/TCS	●	●	●
Crown Victoria	4. 6L	Other	1995	PCM	●	●	●
DEMIO / FESTIVA MINI WAGON	1. 3L	B3	1996 - 1999	ABS	●	●	●
DEMIO / FESTIVA MINI WAGON	1. 3L	B3	1996 - Other	PCM	●	●	●
DEMIO / FESTIVA MINI WAGON	1. 3L	B3	2000	ABS/TCS	●	●	●
DEMIO / FESTIVA MINI WAGON	1. 5L	B5	1996 - 1999	ABS	●	●	●
E-Series	4. 2L	Other	1997 - 2003	ABS/TCS	●	●	●
E-Series	4. 2L	Other	1997 - 2003	ECS	●	●	●
E-Series	4. 2L	Other	1997 - 2003	PCM	●	●	●
E-Series	4. 6L	2V	2003	ECS	●	●	●
E-Series	4. 6L	2V	2003 - 2007	ABS/TCS	●	●	●
E-Series	4. 6L	2V	2003 - 2014	PCM	●	●	●
E-Series	4. 6L	2V	2004 - 2006	RAP	●	●	●
E-Series	4. 6L	2V	2004 - 2008	IC	●	●	●
E-Series	4. 6L	2V	2004 - 2014	RCM	●	●	●
E-Series	4. 6L	2V	2006 - 2014	ABS	●	●	●
E-Series	4. 6L	2V	2007 - 2008	VSM	●	●	●
E-Series	4. 6L	2V	2007 - 2014	PAM	●	●	●
E-Series	4. 6L	2V	2009 - 2014	ACM	●	●	●
E-Series	4. 6L	2V	2009 - 2014	GEM / SJB	●	●	●
E-Series	4. 6L	2V	2009 - 2014	IPC	●	●	●
E-Series	4. 6L	2V	2009 - 2014	TBC	●	●	●
E-Series	4. 6L	2V	2010 - 2013	SDARS	●	●	●
E-Series	4. 6L	2V	2010 - 2014	APIM	●	●	●
E-Series	4. 6L	2V	2010 - 2014	GPSM	●	●	●
E-Series	4. 6L	Other	1997 - 2002	ABS/TCS	●	●	●
E-Series	4. 6L	Other	1997 - 2002	ECS	●	●	●
E-Series	4. 6L	Other	1997 - 2002	PCM	●	●	●
E-Series	4. 9L	GFP	1996	ABS/TCS	●	●	●
E-Series	4. 9L	GFP	1996	PCM	●	●	●
E-Series	4. 9L	Other	1996	ABS/TCS	●	●	●
E-Series	4. 9L	Other	1996	PCM	●	●	●
E-Series	5. 0L	Other	1996	ABS/TCS	●	●	●
E-Series	5. 0L	Other	1996	PCM	●	●	●
E-Series	5. 4L	2V	2004	AFCM	●	●	●
E-Series	5. 4L	2V	2004 - 2006	RAP	●	●	●
E-Series	5. 4L	2V	2004 - 2007	ABS/TCS	●	●	●
E-Series	5. 4L	2V	2004 - 2008	IC	●	●	●
E-Series	5. 4L	2V	2004 - 2014	PCM	●	●	●
E-Series	5. 4L	2V	2004 - 2014	RCM	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
E-Series	5.4L	2V	2006 - 2014	ABS	●	●	●
E-Series	5.4L	2V	2007 - 2008	VSM	●	●	●
E-Series	5.4L	2V	2007 - 2014	PAM	●	●	●
E-Series	5.4L	2V	2009 - 2014	ACM	●	●	●
E-Series	5.4L	2V	2009 - 2014	GEM / SJB	●	●	●
E-Series	5.4L	2V	2009 - 2014	IPC	●	●	●
E-Series	5.4L	2V	2009 - 2014	TBC	●	●	●
E-Series	5.4L	2V	2010 - 2013	SDARS	●	●	●
E-Series	5.4L	2V	2010 - 2014	APIM	●	●	●
E-Series	5.4L	2V	2010 - 2014	GPSM	●	●	●
E-Series	5.4L	BIF	1999	ABS/TCS	●	●	●
E-Series	5.4L	BIF	1999	AFCM	●	●	●
E-Series	5.4L	BIF	1999	ECS	●	●	●
E-Series	5.4L	BIF	1999	PCM	●	●	●
E-Series	5.4L	NGV	1997 - 2000	ABS/TCS	●	●	●
E-Series	5.4L	NGV	1997 - 2000	ECS	●	●	●
E-Series	5.4L	NGV	1997 - 2000	PCM	●	●	●
E-Series	5.4L	NGV	1998 - 2000	FIM	●	●	●
E-Series	5.4L	Other	1997 - 2003	ABS/TCS	●	●	●
E-Series	5.4L	Other	1997 - 2003	ECS	●	●	●
E-Series	5.4L	Other	1997 - 2003	PCM	●	●	●
E-Series	5.8L	Other	1996	ABS/TCS	●	●	●
E-Series	5.8L	Other	1996	PCM	●	●	●
E-Series	6.0L	Direct Injection - Turbo	2004 - 2006	RAP	●	●	●
E-Series	6.0L	Direct Injection - Turbo	2004 - 2007	ABS/TCS	●	●	●
E-Series	6.0L	Direct Injection - Turbo	2004 - 2008	IC	●	●	●
E-Series	6.0L	Direct Injection - Turbo	2004 - 2010	PCM	●	●	●
E-Series	6.0L	Direct Injection - Turbo	2004 - 2010	RCM	●	●	●
E-Series	6.0L	Direct Injection - Turbo	2004 - 2010	TCM	●	●	●
E-Series	6.0L	Direct Injection - Turbo	2006 - 2010	ABS	●	●	●
E-Series	6.0L	Direct Injection - Turbo	2007 - 2008	VSM	●	●	●
E-Series	6.0L	Direct Injection - Turbo	2007 - 2010	PAM	●	●	●
E-Series	6.0L	Direct Injection - Turbo	2009 - 2010	ACM	●	●	●
E-Series	6.0L	Direct Injection - Turbo	2009 - 2010	GEM / SJB	●	●	●
E-Series	6.0L	Direct Injection - Turbo	2009 - 2010	IPC	●	●	●
E-Series	6.0L	Direct Injection - Turbo	2009 - 2010	TBC	●	●	●
E-Series	6.0L	Direct Injection - Turbo	2010	APIM	●	●	●
E-Series	6.0L	Direct Injection - Turbo	2010	GPSM	●	●	●
E-Series	6.0L	Direct Injection - Turbo	2010	SDARS	●	●	●
E-Series	6.8L	2V	2004 - 2006	RAP	●	●	●
E-Series	6.8L	2V	2004 - 2007	ABS/TCS	●	●	●
E-Series	6.8L	2V	2004 - 2008	IC	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
E-Series	6. 8L	2V	2004 - 2014	PCM	●	●	●
E-Series	6. 8L	2V	2004 - 2014	RCM	●	●	●
E-Series	6. 8L	2V	2006 - 2014	ABS	●	●	●
E-Series	6. 8L	2V	2007 - 2008	VSM	●	●	●
E-Series	6. 8L	2V	2007 - 2014	PAM	●	●	●
E-Series	6. 8L	2V	2009 - 2014	ACM	●	●	●
E-Series	6. 8L	2V	2009 - 2014	GEM / SJB	●	●	●
E-Series	6. 8L	2V	2009 - 2014	IPC	●	●	●
E-Series	6. 8L	2V	2009 - 2014	TBC	●	●	●
E-Series	6. 8L	2V	2010 - 2013	SDARS	●	●	●
E-Series	6. 8L	2V	2010 - 2014	APIM	●	●	●
E-Series	6. 8L	2V	2010 - 2014	GPSM	●	●	●
E-Series	6. 8L	Other	1997 - 2003	ABS/TCS	●	●	●
E-Series	6. 8L	Other	1997 - 2003	ECS	●	●	●
E-Series	6. 8L	Other	1997 - 2003	PCM	●	●	●
E-Series	7. 3L	Direct Injection - Turbo	1995 - 2003	ABS/TCS	●	●	●
E-Series	7. 3L	Direct Injection - Turbo	1995 - 2003	PCM	●	●	●
E-Series	7. 3L	Direct Injection - Turbo	1997 - 2003	ECS	●	●	●
E-Series	7. 5L	Other	1996	ABS/TCS	●	●	●
E-Series	7. 5L	Other	1996	PCM	●	●	●
E-Series	Other	Other	2012	ABS	●	●	●
E-Series	Other	Other	2012	ACM	●	●	●
E-Series	Other	Other	2012	APIM	●	●	●
E-Series	Other	Other	2012	GEM / SJB	●	●	●
E-Series	Other	Other	2012	GPSM	●	●	●
E-Series	Other	Other	2012	IPC	●	●	●
E-Series	Other	Other	2012	PAM	●	●	●
E-Series	Other	Other	2012	PCM	●	●	●
E-Series	Other	Other	2012	RCM	●	●	●
E-Series	Other	Other	2012	SDARS	●	●	●
E-Series	Other	Other	2012	TBC	●	●	●
E-Series Shuttle Bus	6. 8L	H2ICE	2006	ABS/TCS	●	●	●
E-Series Shuttle Bus	6. 8L	H2ICE	2006	AFCM	●	●	●
E-Series Shuttle Bus	6. 8L	H2ICE	2006	EMM	●	●	●
E-Series Shuttle Bus	6. 8L	H2ICE	2006	IC	●	●	●
E-Series Shuttle Bus	6. 8L	H2ICE	2006	PCM	●	●	●
E-Series Shuttle Bus	6. 8L	H2ICE	2006	RCM	●	●	●
EcoSport	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	2013	ABS	●	●	●
EcoSport	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	2013	ACM	●	●	●
EcoSport	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	2013	DDM	●	●	●
EcoSport	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	2013	HVAC	●	●	●
EcoSport	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	2013	PSCM	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
EcoSport	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	RCM	●	●	●
EcoSport	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	APIM	●	●	●
EcoSport	1.0L	Zetec Rocam	2003	ABS/TCS	●	●	●
EcoSport	1.0L	Zetec Rocam	2003	GEM	●	●	●
EcoSport	1.0L	Zetec Rocam	2003	IC	●	●	●
EcoSport	1.0L	Zetec Rocam	2003	PCM	●	●	●
EcoSport	1.0L	Zetec Rocam	2003	RCM	●	●	●
EcoSport	1.0L	Zetec Rocam	2003	RKE	●	●	●
EcoSport	1.4L	Duratorq Turbo Diesel Common Rail Injection	2003	ABS/TCS	●	●	●
EcoSport	1.4L	Duratorq Turbo Diesel Common Rail Injection	2003	GEM	●	●	●
EcoSport	1.4L	Duratorq Turbo Diesel Common Rail Injection	2003	IC	●	●	●
EcoSport	1.4L	Duratorq Turbo Diesel Common Rail Injection	2003	PCM	●	●	●
EcoSport	1.4L	Duratorq Turbo Diesel Common Rail Injection	2003	RCM	●	●	●
EcoSport	1.4L	Duratorq Turbo Diesel Common Rail Injection	2003	RKE	●	●	●
EcoSport	1.5L	DURATEC VCT	2014	APIM	●	●	●
EcoSport	1.5L	Duratorq Turbo Diesel Common Rail Injection	2012	ABS	●	●	●
EcoSport	1.5L	Duratorq Turbo Diesel Common Rail Injection	2012	ACM	●	●	●
EcoSport	1.5L	Duratorq Turbo Diesel Common Rail Injection	2012	APIM	●	●	●
EcoSport	1.5L	Duratorq Turbo Diesel Common Rail Injection	2012	FCDIM	●	●	●
EcoSport	1.5L	Duratorq Turbo Diesel Common Rail Injection	2012	HVAC	●	●	●
EcoSport	1.5L	Duratorq Turbo Diesel Common Rail Injection	2012	PSCM	●	●	●
EcoSport	1.5L	Duratorq Turbo Diesel Common Rail Injection	2012	RCM	●	●	●
EcoSport	1.5L	Duratorq Turbo Diesel Common Rail Injection	2012	TBM	●	●	●
EcoSport	1.5L	Duratorq Turbo Diesel Common Rail Injection StgV	2014	APIM	●	●	●
EcoSport	1.5L	TiVCT	2012	ABS	●	●	●
EcoSport	1.5L	TiVCT	2012	ACM	●	●	●
EcoSport	1.5L	TiVCT	2012	APIM	●	●	●
EcoSport	1.5L	TiVCT	2012	BCM#1	●	●	●
EcoSport	1.5L	TiVCT	2012	DDM	●	●	●
EcoSport	1.5L	TiVCT	2012	FCDIM	●	●	●
EcoSport	1.5L	TiVCT	2012	HVAC	●	●	●
EcoSport	1.5L	TiVCT	2012	IPC	●	●	●
EcoSport	1.5L	TiVCT	2012	PCM	●	●	●
EcoSport	1.5L	TiVCT	2012	PSCM	●	●	●
EcoSport	1.5L	TiVCT	2012	RCM	●	●	●
EcoSport	1.5L	TiVCT	2012	TCM	●	●	●
EcoSport	1.6L	FFV	2003 - 2006	GEM	●	●	●
EcoSport	1.6L	FFV	2003 - 2011	ABS/TCS	●	●	●
EcoSport	1.6L	FFV	2003 - 2011	IC	●	●	●
EcoSport	1.6L	FFV	2003 - 2011	PCM	●	●	●
EcoSport	1.6L	FFV	2003 - 2011	RCM	●	●	●
EcoSport	1.6L	FFV	2003 - 2011	RKE	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
EcoSport	1. 6L	FFV	2011	TBM	●	●	●
EcoSport	1. 6L	Sigma	2012	ABS	●	●	●
EcoSport	1. 6L	Sigma	2012	ACM	●	●	●
EcoSport	1. 6L	Sigma	2012	APIM	●	●	●
EcoSport	1. 6L	Sigma	2012	BCM#1	●	●	●
EcoSport	1. 6L	Sigma	2012	DDM	●	●	●
EcoSport	1. 6L	Sigma	2012	FCDIM	●	●	●
EcoSport	1. 6L	Sigma	2012	HVAC	●	●	●
EcoSport	1. 6L	Sigma	2012	IPC	●	●	●
EcoSport	1. 6L	Sigma	2012	PCM	●	●	●
EcoSport	1. 6L	Sigma	2012	PSCM	●	●	●
EcoSport	1. 6L	Sigma	2012	RCM	●	●	●
EcoSport	1. 6L	Sigma	2012	RFA	●	●	●
EcoSport	1. 6L	Sigma	2012	TBM	●	●	●
EcoSport	1. 6L	Zetec Rocam	2003	GEM	●	●	●
EcoSport	1. 6L	Zetec Rocam	2003 - 2009	ABS/TCS	●	●	●
EcoSport	1. 6L	Zetec Rocam	2003 - 2009	IC	●	●	●
EcoSport	1. 6L	Zetec Rocam	2003 - 2009	PCM	●	●	●
EcoSport	1. 6L	Zetec Rocam	2003 - 2009	RCM	●	●	●
EcoSport	1. 6L	Zetec Rocam	2003 - 2009	RKE	●	●	●
EcoSport	2. 0L	DURATEC	2013	ABS	●	●	●
EcoSport	2. 0L	DURATEC	2013	ACM	●	●	●
EcoSport	2. 0L	DURATEC	2013	APIM	●	●	●
EcoSport	2. 0L	DURATEC	2013	DDM	●	●	●
EcoSport	2. 0L	DURATEC	2013	HVAC	●	●	●
EcoSport	2. 0L	DURATEC	2013	PSCM	●	●	●
EcoSport	2. 0L	DURATEC	2013	RCM	●	●	●
EcoSport	2. 0L	DURATEC	2013	TBM	●	●	●
EcoSport	2. 0L	DURATEC-HE / I4	2003 - 2006	GEM	●	●	●
EcoSport	2. 0L	DURATEC-HE / I4	2003 - 2007	ABS/TCS	●	●	●
EcoSport	2. 0L	DURATEC-HE / I4	2003 - 2007	IC	●	●	●
EcoSport	2. 0L	DURATEC-HE / I4	2003 - 2007	RKE	●	●	●
EcoSport	2. 0L	DURATEC-HE / I4	2003 - 2012	PCM	●	●	●
EcoSport	2. 0L	DURATEC-HE / I4	2003 - 2012	RCM	●	●	●
EcoSport	2. 0L	DURATEC-HE / I4	2012	ABS	●	●	●
EcoSport	2. 0L	DURATEC-HE / I4	2012	ACM	●	●	●
EcoSport	2. 0L	DURATEC-HE / I4	2012	APIM	●	●	●
EcoSport	2. 0L	DURATEC-HE / I4	2012	BCM#1	●	●	●
EcoSport	2. 0L	DURATEC-HE / I4	2012	DDM	●	●	●
EcoSport	2. 0L	DURATEC-HE / I4	2012	FCDIM	●	●	●
EcoSport	2. 0L	DURATEC-HE / I4	2012	HVAC	●	●	●
EcoSport	2. 0L	DURATEC-HE / I4	2012	IPC	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
EcoSport	2.0L	DURATEC-HE / I4	2012	PSCM	●	●	●
EcoSport	2.0L	DURATEC-HE / I4	2012	RFA	●	●	●
EcoSport	2.0L	DURATEC-HE / I4	2012	TBM	●	●	●
EcoSport	2.0L	FFV	2009 - 2011	ABS/TCS	●	●	●
EcoSport	2.0L	FFV	2009 - 2011	IC	●	●	●
EcoSport	2.0L	FFV	2009 - 2011	PCM	●	●	●
EcoSport	2.0L	FFV	2009 - 2011	RCM	●	●	●
EcoSport	2.0L	FFV	2009 - 2011	RKE	●	●	●
EcoSport	2.0L	FFV	2011	TBM	●	●	●
EcoSport	2.0L	Zetec Rocam	2009	ABS/TCS	●	●	●
EcoSport	2.0L	Zetec Rocam	2009	IC	●	●	●
EcoSport	2.0L	Zetec Rocam	2009	PCM	●	●	●
EcoSport	2.0L	Zetec Rocam	2009	RCM	●	●	●
EcoSport	2.0L	Zetec Rocam	2009	RKE	●	●	●
EcoSport	Other	Other	2012	ABS	●	●	●
EcoSport	Other	Other	2012	ACM	●	●	●
EcoSport	Other	Other	2012	APIM	●	●	●
EcoSport	Other	Other	2012	BCM#1	●	●	●
EcoSport	Other	Other	2012	DDM	●	●	●
EcoSport	Other	Other	2012	FCDIM	●	●	●
EcoSport	Other	Other	2012	HVAC	●	●	●
EcoSport	Other	Other	2012	IPC	●	●	●
EcoSport	Other	Other	2012	PSCM	●	●	●
EcoSport	Other	Other	2012	RCM	●	●	●
Econovan	2.0L	OHC	2008	IC	●	●	●
Econovan	2.0L	OHC	2008	PCM	●	●	●
Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2012	TPM	●	●	●
Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2012 - 2013	C-CM	●	●	●
Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2012 - 2013	FCDIM	●	●	●
Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2012 - 2013	HVAC	●	●	●
Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2012 - 2013	OCSM	●	●	●
Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2012 - 2013	PCM	●	●	●
Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2012 - 2013	RCM	●	●	●
Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2012 - 2013	TCM	●	●	●
Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2012 - 2014	ABS	●	●	●
Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2012 - 2014	ACM	●	●	●
Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2012 - 2014	APIM	●	●	●
Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2012 - 2014	BCM#1	●	●	●
Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2012 - 2014	DCSM	●	●	●
Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2012 - 2014	DSM	●	●	●
Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2012 - 2014	DSP	●	●	●
Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2012 - 2014	FCIM	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2012 - 2014	FLM	●	●	●
Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2012 - 2014	GPSM	●	●	●
Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2012 - 2014	HUD	●	●	●
Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2012 - 2014	IPC	●	●	●
Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2012 - 2014	LTM	●	●	●
Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2012 - 2014	PAM	●	●	●
Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2012 - 2014	RFA	●	●	●
Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2012 - 2014	RLCM-A	●	●	●
Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2012 - 2014	SCCM	●	●	●
Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2012 - 2014	SOD-L	●	●	●
Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2012 - 2014	SOD-R	●	●	●
Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2012 - 2014	TBM	●	●	●
Edge	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	RTM	●	●	●
Edge	3.5L	4V	2007	EATC	●	●	●
Edge	3.5L	4V	2007	GEM	●	●	●
Edge	3.5L	4V	2007 - 2010	4X4	●	●	●
Edge	3.5L	4V	2007 - 2010	ABS	●	●	●
Edge	3.5L	4V	2007 - 2010	ACM	●	●	●
Edge	3.5L	4V	2007 - 2010	DSM	●	●	●
Edge	3.5L	4V	2007 - 2010	IC	●	●	●
Edge	3.5L	4V	2007 - 2010	OCSM	●	●	●
Edge	3.5L	4V	2007 - 2010	PAM	●	●	●
Edge	3.5L	4V	2007 - 2010	PCM	●	●	●
Edge	3.5L	4V	2007 - 2010	RCM	●	●	●
Edge	3.5L	4V	2007 - 2010	RETM	●	●	●
Edge	3.5L	4V	2007 - 2010	SASM	●	●	●
Edge	3.5L	4V	2007 - 2010	SDARS	●	●	●
Edge	3.5L	4V	2007 - 2010	TBM	●	●	●
Edge	3.5L	4V	2008 - 2010	APIM	●	●	●
Edge	3.5L	4V	2008 - 2010	GEM / SJB	●	●	●
Edge	3.5L	4V	2008 - 2010	HVAC	●	●	●
Edge	3.5L	4V	2008 - 2010	LTM	●	●	●
Edge	3.5L	4V	2010	GPSM	●	●	●
Edge	3.5L	TiVCT	2011 - 2012	TPM	●	●	●
Edge	3.5L	TiVCT	2011 - 2013	C-CM	●	●	●
Edge	3.5L	TiVCT	2011 - 2013	FCDIM	●	●	●
Edge	3.5L	TiVCT	2011 - 2013	HVAC	●	●	●
Edge	3.5L	TiVCT	2011 - 2013	OCSM	●	●	●
Edge	3.5L	TiVCT	2011 - 2013	PCM	●	●	●
Edge	3.5L	TiVCT	2011 - 2013	RCM	●	●	●
Edge	3.5L	TiVCT	2011 - 2014	ABS	●	●	●
Edge	3.5L	TiVCT	2011 - 2014	ACM	●	●	●



Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Edge	3.5L	TiVCT	2011 - 2014	APIM	●	●	●
Edge	3.5L	TiVCT	2011 - 2014	BCM#1	●	●	●
Edge	3.5L	TiVCT	2011 - 2014	DCSM	●	●	●
Edge	3.5L	TiVCT	2011 - 2014	DSM	●	●	●
Edge	3.5L	TiVCT	2011 - 2014	DSP	●	●	●
Edge	3.5L	TiVCT	2011 - 2014	FCIM	●	●	●
Edge	3.5L	TiVCT	2011 - 2014	FLM	●	●	●
Edge	3.5L	TiVCT	2011 - 2014	GPSM	●	●	●
Edge	3.5L	TiVCT	2011 - 2014	HUD	●	●	●
Edge	3.5L	TiVCT	2011 - 2014	IPC	●	●	●
Edge	3.5L	TiVCT	2011 - 2014	LTM	●	●	●
Edge	3.5L	TiVCT	2011 - 2014	PAM	●	●	●
Edge	3.5L	TiVCT	2011 - 2014	RFA	●	●	●
Edge	3.5L	TiVCT	2011 - 2014	RLCM-A	●	●	●
Edge	3.5L	TiVCT	2011 - 2014	SCCM	●	●	●
Edge	3.5L	TiVCT	2011 - 2014	SOD-L	●	●	●
Edge	3.5L	TiVCT	2011 - 2014	SOD-R	●	●	●
Edge	3.5L	TiVCT	2011 - 2014	TBM	●	●	●
Edge	3.5L	TiVCT	2013 - 2014	RTM	●	●	●
Edge	3.7L	TiVCT	2011 - 2012	TPM	●	●	●
Edge	3.7L	TiVCT	2011 - 2013	C-CM	●	●	●
Edge	3.7L	TiVCT	2011 - 2013	FCDIM	●	●	●
Edge	3.7L	TiVCT	2011 - 2013	HVAC	●	●	●
Edge	3.7L	TiVCT	2011 - 2013	OCSM	●	●	●
Edge	3.7L	TiVCT	2011 - 2013	PCM	●	●	●
Edge	3.7L	TiVCT	2011 - 2013	RCM	●	●	●
Edge	3.7L	TiVCT	2011 - 2014	ABS	●	●	●
Edge	3.7L	TiVCT	2011 - 2014	ACM	●	●	●
Edge	3.7L	TiVCT	2011 - 2014	APIM	●	●	●
Edge	3.7L	TiVCT	2011 - 2014	BCM#1	●	●	●
Edge	3.7L	TiVCT	2011 - 2014	DCSM	●	●	●
Edge	3.7L	TiVCT	2011 - 2014	DSM	●	●	●
Edge	3.7L	TiVCT	2011 - 2014	DSP	●	●	●
Edge	3.7L	TiVCT	2011 - 2014	FCIM	●	●	●
Edge	3.7L	TiVCT	2011 - 2014	FLM	●	●	●
Edge	3.7L	TiVCT	2011 - 2014	GPSM	●	●	●
Edge	3.7L	TiVCT	2011 - 2014	HUD	●	●	●
Edge	3.7L	TiVCT	2011 - 2014	IPC	●	●	●
Edge	3.7L	TiVCT	2011 - 2014	LTM	●	●	●
Edge	3.7L	TiVCT	2011 - 2014	PAM	●	●	●
Edge	3.7L	TiVCT	2011 - 2014	RFA	●	●	●
Edge	3.7L	TiVCT	2011 - 2014	RLCM-A	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Edge	3. 7L	TiVCT	2011 - 2014	SCCM	●	●	●
Edge	3. 7L	TiVCT	2011 - 2014	SOD-L	●	●	●
Edge	3. 7L	TiVCT	2011 - 2014	SOD-R	●	●	●
Edge	3. 7L	TiVCT	2011 - 2014	TBM	●	●	●
Edge	3. 7L	TiVCT	2013 - 2014	RTM	●	●	●
Edge	Other	Other	2014	ABS	●	●	●
Edge	Other	Other	2014	ACM	●	●	●
Edge	Other	Other	2014	APIM	●	●	●
Edge	Other	Other	2014	BCM#1	●	●	●
Edge	Other	Other	2014	DCSM	●	●	●
Edge	Other	Other	2014	DSM	●	●	●
Edge	Other	Other	2014	DSP	●	●	●
Edge	Other	Other	2014	FCIM	●	●	●
Edge	Other	Other	2014	FLM	●	●	●
Edge	Other	Other	2014	GPSM	●	●	●
Edge	Other	Other	2014	HUD	●	●	●
Edge	Other	Other	2014	IPC	●	●	●
Edge	Other	Other	2014	LTM	●	●	●
Edge	Other	Other	2014	PAM	●	●	●
Edge	Other	Other	2014	RFA	●	●	●
Edge	Other	Other	2014	RLCM-A	●	●	●
Edge	Other	Other	2014	RTM	●	●	●
Edge	Other	Other	2014	SCCM	●	●	●
Edge	Other	Other	2014	SOD-L	●	●	●
Edge	Other	Other	2014	SOD-R	●	●	●
Edge	Other	Other	2014	TBM	●	●	●
Escape / Mariner Hybrid	2. 3L	HEV / ATKINSON 4V	2005 - 2007	4X4	●	●	●
Escape / Mariner Hybrid	2. 3L	HEV / ATKINSON 4V	2005 - 2007	ABS	●	●	●
Escape / Mariner Hybrid	2. 3L	HEV / ATKINSON 4V	2005 - 2007	BCM	●	●	●
Escape / Mariner Hybrid	2. 3L	HEV / ATKINSON 4V	2005 - 2007	EPS	●	●	●
Escape / Mariner Hybrid	2. 3L	HEV / ATKINSON 4V	2005 - 2007	GEM	●	●	●
Escape / Mariner Hybrid	2. 3L	HEV / ATKINSON 4V	2005 - 2007	IC	●	●	●
Escape / Mariner Hybrid	2. 3L	HEV / ATKINSON 4V	2005 - 2007	PAM	●	●	●
Escape / Mariner Hybrid	2. 3L	HEV / ATKINSON 4V	2005 - 2007	PCM	●	●	●
Escape / Mariner Hybrid	2. 3L	HEV / ATKINSON 4V	2005 - 2007	RCM	●	●	●
Escape / Mariner Hybrid	2. 3L	HEV / ATKINSON 4V	2005 - 2007	TCM	●	●	●
Escape / Tribute ( 2006/4 - )	2. 3L	L3	2006	ABS	●	●	●
Escape / Tribute ( 2006/4 - )	2. 3L	L3	2006	GEM	●	●	●
Escape / Tribute ( 2006/4 - )	2. 3L	L3	2006	IC	●	●	●
Escape / Tribute ( 2006/4 - )	2. 3L	L3	2006	PCM	●	●	●
Escape / Tribute ( 2006/4 - )	2. 3L	L3	2006	RCM	●	●	●
Escape / Tribute (2006/3)	2. 3L	L3	2003	ABS	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Escape / Tribute (2006/3)	2. 3L	L3	2003	GEM	●	●	●
Escape / Tribute (2006/3)	2. 3L	L3	2003	IC	●	●	●
Escape / Tribute (2006/3)	2. 3L	L3	2003	PCM	●	●	●
Escape / Tribute (2006/3)	2. 3L	L3	2003	RCM	●	●	●
Escape / Tribute / Mariner	2. 3L	DURATEC-HE / I4	2008	4X4	●	●	●
Escape / Tribute / Mariner	2. 3L	DURATEC-HE / I4	2008	ABS	●	●	●
Escape / Tribute / Mariner	2. 3L	DURATEC-HE / I4	2008	ACM	●	●	●
Escape / Tribute / Mariner	2. 3L	DURATEC-HE / I4	2008	FCIM	●	●	●
Escape / Tribute / Mariner	2. 3L	DURATEC-HE / I4	2008	FDIM	●	●	●
Escape / Tribute / Mariner	2. 3L	DURATEC-HE / I4	2008	GEM / SJB	●	●	●
Escape / Tribute / Mariner	2. 3L	DURATEC-HE / I4	2008	HVAC	●	●	●
Escape / Tribute / Mariner	2. 3L	DURATEC-HE / I4	2008	IC	●	●	●
Escape / Tribute / Mariner	2. 3L	DURATEC-HE / I4	2008	OCSM	●	●	●
Escape / Tribute / Mariner	2. 3L	DURATEC-HE / I4	2008	PAM	●	●	●
Escape / Tribute / Mariner	2. 3L	DURATEC-HE / I4	2008	PCM	●	●	●
Escape / Tribute / Mariner	2. 3L	DURATEC-HE / I4	2008	PSCM	●	●	○
Escape / Tribute / Mariner	2. 3L	DURATEC-HE / I4	2008	RCM	●	●	●
Escape / Tribute / Mariner	2. 3L	DURATEC-HE / I4	2008	SDARS	●	●	●
Escape / Tribute / Mariner	2. 3L	HEV / ATKINSON 4V	2008	4X4	●	●	●
Escape / Tribute / Mariner	2. 3L	HEV / ATKINSON 4V	2008	ABS	●	●	●
Escape / Tribute / Mariner	2. 3L	HEV / ATKINSON 4V	2008	ACM	●	●	●
Escape / Tribute / Mariner	2. 3L	HEV / ATKINSON 4V	2008	BCM	●	●	●
Escape / Tribute / Mariner	2. 3L	HEV / ATKINSON 4V	2008	FCIM	●	●	●
Escape / Tribute / Mariner	2. 3L	HEV / ATKINSON 4V	2008	FDIM	●	●	●
Escape / Tribute / Mariner	2. 3L	HEV / ATKINSON 4V	2008	GEM / SJB	●	●	●
Escape / Tribute / Mariner	2. 3L	HEV / ATKINSON 4V	2008	HVAC	●	●	●
Escape / Tribute / Mariner	2. 3L	HEV / ATKINSON 4V	2008	IC	●	●	●
Escape / Tribute / Mariner	2. 3L	HEV / ATKINSON 4V	2008	OCSM	●	●	●
Escape / Tribute / Mariner	2. 3L	HEV / ATKINSON 4V	2008	PAM	●	●	●
Escape / Tribute / Mariner	2. 3L	HEV / ATKINSON 4V	2008	PCM	●	●	●
Escape / Tribute / Mariner	2. 3L	HEV / ATKINSON 4V	2008	PSCM	●	●	○
Escape / Tribute / Mariner	2. 3L	HEV / ATKINSON 4V	2008	RCM	●	●	●
Escape / Tribute / Mariner	2. 3L	HEV / ATKINSON 4V	2008	SDARS	●	●	●
Escape / Tribute / Mariner	2. 3L	HEV / ATKINSON 4V	2008	TCM	●	●	●
Escape / Tribute / Mariner	2. 5L	DURATEC-HE / I4	2009	SDARS	●	●	●
Escape / Tribute / Mariner	2. 5L	DURATEC-HE / I4	2009 - 2012	4X4	●	●	●
Escape / Tribute / Mariner	2. 5L	DURATEC-HE / I4	2009 - 2012	ABS	●	●	●
Escape / Tribute / Mariner	2. 5L	DURATEC-HE / I4	2009 - 2012	ACM	●	●	●
Escape / Tribute / Mariner	2. 5L	DURATEC-HE / I4	2009 - 2012	APIM	●	●	●
Escape / Tribute / Mariner	2. 5L	DURATEC-HE / I4	2009 - 2012	FCIM	●	●	●
Escape / Tribute / Mariner	2. 5L	DURATEC-HE / I4	2009 - 2012	FDIM	●	●	●
Escape / Tribute / Mariner	2. 5L	DURATEC-HE / I4	2009 - 2012	GEM / SJB	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Escape / Tribute / Mariner	2.5L	DURATEC-HE / I4	2009 - 2012	HVAC	●	●	●
Escape / Tribute / Mariner	2.5L	DURATEC-HE / I4	2009 - 2012	IC	●	●	●
Escape / Tribute / Mariner	2.5L	DURATEC-HE / I4	2009 - 2012	OCSM	●	●	●
Escape / Tribute / Mariner	2.5L	DURATEC-HE / I4	2009 - 2012	PAM	●	●	●
Escape / Tribute / Mariner	2.5L	DURATEC-HE / I4	2009 - 2012	PCM	●	●	●
Escape / Tribute / Mariner	2.5L	DURATEC-HE / I4	2009 - 2012	PSCM	●	●	○
Escape / Tribute / Mariner	2.5L	DURATEC-HE / I4	2009 - 2012	RCM	●	●	●
Escape / Tribute / Mariner	2.5L	DURATEC-HE / I4	2010 - 2012	GPSM	●	●	●
Escape / Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2009	SDARS	●	●	●
Escape / Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2009 - 2012	4X4	●	●	●
Escape / Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2009 - 2012	ABS	●	●	●
Escape / Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2009 - 2012	ACM	●	●	●
Escape / Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2009 - 2012	APIM	●	●	●
Escape / Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2009 - 2012	BCM	●	●	●
Escape / Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2009 - 2012	FCIM	●	●	●
Escape / Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2009 - 2012	FDIM	●	●	●
Escape / Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2009 - 2012	GEM / SJB	●	●	●
Escape / Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2009 - 2012	HVAC	●	●	●
Escape / Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2009 - 2012	IC	●	●	●
Escape / Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2009 - 2012	OCSM	●	●	●
Escape / Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2009 - 2012	PAM	●	●	●
Escape / Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2009 - 2012	PCM	●	●	●
Escape / Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2009 - 2012	PSCM	●	●	○
Escape / Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2009 - 2012	RCM	●	●	●
Escape / Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2009 - 2012	TCM	●	●	●
Escape / Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2010 - 2012	ACCM#2	●	●	●
Escape / Tribute / Mariner	2.5L	HEV / ATKINSON 4V	2010 - 2012	GPSM	●	●	●
Escape / Tribute / Mariner	3.0L	4V	2008 - 2009	SDARS	●	●	●
Escape / Tribute / Mariner	3.0L	4V	2008 - 2012	4X4	●	●	●
Escape / Tribute / Mariner	3.0L	4V	2008 - 2012	ABS	●	●	●
Escape / Tribute / Mariner	3.0L	4V	2008 - 2012	ACM	●	●	●
Escape / Tribute / Mariner	3.0L	4V	2008 - 2012	FCIM	●	●	●
Escape / Tribute / Mariner	3.0L	4V	2008 - 2012	FDIM	●	●	●
Escape / Tribute / Mariner	3.0L	4V	2008 - 2012	GEM / SJB	●	●	●
Escape / Tribute / Mariner	3.0L	4V	2008 - 2012	HVAC	●	●	●
Escape / Tribute / Mariner	3.0L	4V	2008 - 2012	IC	●	●	●
Escape / Tribute / Mariner	3.0L	4V	2008 - 2012	OCSM	●	●	●
Escape / Tribute / Mariner	3.0L	4V	2008 - 2012	PAM	●	●	●
Escape / Tribute / Mariner	3.0L	4V	2008 - 2012	PCM	●	●	●
Escape / Tribute / Mariner	3.0L	4V	2008 - 2012	PSCM	●	●	○
Escape / Tribute / Mariner	3.0L	4V	2008 - 2012	RCM	●	●	●
Escape / Tribute / Mariner	3.0L	4V	2009 - 2012	APIM	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Escape / Tribute / Mariner	3.0L	4V	2010 - 2012	GPSM	●	●	●
Escape / Tribute / Mariner	Other	Other	2012	4X4	●	●	●
Escape / Tribute / Mariner	Other	Other	2012	ABS	●	●	●
Escape / Tribute / Mariner	Other	Other	2012	ACM	●	●	●
Escape / Tribute / Mariner	Other	Other	2012	APIM	●	●	●
Escape / Tribute / Mariner	Other	Other	2012	FCIM	●	●	●
Escape / Tribute / Mariner	Other	Other	2012	FDIM	●	●	●
Escape / Tribute / Mariner	Other	Other	2012	GEM / SJB	●	●	●
Escape / Tribute / Mariner	Other	Other	2012	GPSM	●	●	●
Escape / Tribute / Mariner	Other	Other	2012	HVAC	●	●	●
Escape / Tribute / Mariner	Other	Other	2012	IC	●	●	●
Escape / Tribute / Mariner	Other	Other	2012	OCSM	●	●	●
Escape / Tribute / Mariner	Other	Other	2012	PAM	●	●	●
Escape / Tribute / Mariner	Other	Other	2012	PSCM	●	●	○
Escape / Tribute / Mariner	Other	Other	2012	RCM	●	●	●
Escape / Tribute / Maverick	2.0L	Zetec	2001 - 2004	ABS/TCS	●	●	●
Escape / Tribute / Maverick	2.0L	Zetec	2001 - 2004	GEM	●	●	●
Escape / Tribute / Maverick	2.0L	Zetec	2001 - 2004	IC	●	●	●
Escape / Tribute / Maverick	2.0L	Zetec	2001 - 2004	PCM	●	●	●
Escape / Tribute / Maverick	2.0L	Zetec	2001 - 2004	RCM	●	●	●
Escape / Tribute / Maverick	2.0L	Zetec	2003 - 2004	PAM	●	●	●
Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	2006 - 2007	4X4	●	●	●
Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	2006 - 2007	ABS	●	●	●
Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	2006 - 2007	GEM	●	●	●
Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	2006 - 2007	IC	●	●	●
Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	2006 - 2007	PAM	●	●	●
Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	2006 - 2007	PCM	●	●	●
Escape / Tribute / Maverick	2.3L	DURATEC-HE / I4	2006 - 2007	RCM	●	●	●
Escape / Tribute / Maverick	3.0L	4V	2001 - 2004	ABS/TCS	●	●	●
Escape / Tribute / Maverick	3.0L	4V	2001 - 2007	GEM	●	●	●
Escape / Tribute / Maverick	3.0L	4V	2001 - 2007	IC	●	●	●
Escape / Tribute / Maverick	3.0L	4V	2001 - 2007	PCM	●	●	●
Escape / Tribute / Maverick	3.0L	4V	2001 - 2007	RCM	●	●	●
Escape / Tribute / Maverick	3.0L	4V	2003 - 2007	PAM	●	●	●
Escape / Tribute / Maverick	3.0L	4V	2006 - 2007	4X4	●	●	●
Escape / Tribute / Maverick	3.0L	4V	2006 - 2007	ABS	●	●	●
Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	ABS	●	●	●
Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	ACM	●	●	●
Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	BCM#1	●	●	●
Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	DSM	●	●	●
Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	FCDIM	●	●	●
Escape/Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	IPC	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Escape/Kuga	1. 6L	EcoBoost - Gas Turbocharged Direct Injection	2013	IPM-B	●	●	●
Escape/Kuga	1. 6L	EcoBoost - Gas Turbocharged Direct Injection	2013	OCSM	●	●	●
Escape/Kuga	1. 6L	EcoBoost - Gas Turbocharged Direct Injection	2013	PCM	●	●	●
Escape/Kuga	1. 6L	EcoBoost - Gas Turbocharged Direct Injection	2013	RGTM	●	●	●
Escape/Kuga	1. 6L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	APIM	●	●	●
Escape/Kuga	1. 6L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	DDM	●	●	●
Escape/Kuga	1. 6L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	DSP	●	●	●
Escape/Kuga	1. 6L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	FCIM	●	●	●
Escape/Kuga	1. 6L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	GPSM	●	●	●
Escape/Kuga	1. 6L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	HCM	●	●	●
Escape/Kuga	1. 6L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	HVAC	●	●	●
Escape/Kuga	1. 6L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	PAM	●	●	○
Escape/Kuga	1. 6L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	PDM	●	●	●
Escape/Kuga	1. 6L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	PSCM	●	●	●
Escape/Kuga	1. 6L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	RCM	●	●	●
Escape/Kuga	1. 6L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	RFA	●	●	●
Escape/Kuga	1. 6L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	SASM	●	●	●
Escape/Kuga	1. 6L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	SOD-L	●	●	●
Escape/Kuga	1. 6L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	SOD-R	●	●	●
Escape/Kuga	1. 6L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	TRM	●	●	●
Escape/Kuga	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	2013	ABS	●	●	●
Escape/Kuga	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	2013	ACM	●	●	●
Escape/Kuga	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	2013	BCM#1	●	●	●
Escape/Kuga	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	2013	DSM	●	●	●
Escape/Kuga	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	2013	FCDIM	●	●	●
Escape/Kuga	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	2013	IPC	●	●	●
Escape/Kuga	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	2013	IPM-B	●	●	●
Escape/Kuga	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	2013	OCSM	●	●	●
Escape/Kuga	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	2013	PCM	●	●	●
Escape/Kuga	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	2013	RGTM	●	●	●
Escape/Kuga	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	APIM	●	●	●
Escape/Kuga	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	DDM	●	●	●
Escape/Kuga	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	DSP	●	●	●
Escape/Kuga	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	FCIM	●	●	●
Escape/Kuga	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	GPSM	●	●	●
Escape/Kuga	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	HCM	●	●	●
Escape/Kuga	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	HVAC	●	●	●
Escape/Kuga	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	PAM	●	●	○
Escape/Kuga	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	PDM	●	●	●
Escape/Kuga	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	PSCM	●	●	●
Escape/Kuga	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	RCM	●	●	●
Escape/Kuga	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	RFA	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Escape/Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	SASM	●	●	●
Escape/Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	SOD-L	●	●	●
Escape/Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	SOD-R	●	●	●
Escape/Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	TRM	●	●	●
Escape/Kuga	2.5L	IVCT	2013	ABS	●	●	●
Escape/Kuga	2.5L	IVCT	2013	ACM	●	●	●
Escape/Kuga	2.5L	IVCT	2013	BCM#1	●	●	●
Escape/Kuga	2.5L	IVCT	2013	DSM	●	●	●
Escape/Kuga	2.5L	IVCT	2013	FCDIM	●	●	●
Escape/Kuga	2.5L	IVCT	2013	IPC	●	●	●
Escape/Kuga	2.5L	IVCT	2013	IPM-B	●	●	●
Escape/Kuga	2.5L	IVCT	2013	OCSM	●	●	●
Escape/Kuga	2.5L	IVCT	2013	PCM	●	●	●
Escape/Kuga	2.5L	IVCT	2013	RGTM	●	●	●
Escape/Kuga	2.5L	IVCT	2013 - 2014	APIM	●	●	●
Escape/Kuga	2.5L	IVCT	2013 - 2014	DDM	●	●	●
Escape/Kuga	2.5L	IVCT	2013 - 2014	DSP	●	●	●
Escape/Kuga	2.5L	IVCT	2013 - 2014	FCIM	●	●	●
Escape/Kuga	2.5L	IVCT	2013 - 2014	GPSM	●	●	●
Escape/Kuga	2.5L	IVCT	2013 - 2014	HCM	●	●	●
Escape/Kuga	2.5L	IVCT	2013 - 2014	HVAC	●	●	●
Escape/Kuga	2.5L	IVCT	2013 - 2014	PAM	●	●	○
Escape/Kuga	2.5L	IVCT	2013 - 2014	PDM	●	●	●
Escape/Kuga	2.5L	IVCT	2013 - 2014	PSCM	●	●	●
Escape/Kuga	2.5L	IVCT	2013 - 2014	RCM	●	●	●
Escape/Kuga	2.5L	IVCT	2013 - 2014	RFA	●	●	●
Escape/Kuga	2.5L	IVCT	2013 - 2014	SASM	●	●	●
Escape/Kuga	2.5L	IVCT	2013 - 2014	SOD-L	●	●	●
Escape/Kuga	2.5L	IVCT	2013 - 2014	SOD-R	●	●	●
Escape/Kuga	2.5L	IVCT	2013 - 2014	TRM	●	●	●
Escort	1.3L	Endura-E	1995 - 1998	ABS	●	●	●
Escort	1.3L	Endura-E	1995 - 1998	ABS/TCS	●	●	●
Escort	1.3L	Endura-E	1995 - 1998	CSM	●	●	●
Escort	1.3L	Endura-E	1995 - 1998	HEC	●	●	●
Escort	1.3L	Endura-E	1995 - 1998	PATS	●	●	●
Escort	1.3L	Endura-E	1995 - 1998	PCM	●	●	●
Escort	1.4L	1.4 PT-E SFI	1994 - 1998	ABS/TCS	●	●	●
Escort	1.4L	1.4 PT-E SFI	1994 - 1998	CSM	●	●	●
Escort	1.4L	1.4 PT-E SFI	1994 - 1998	HEC	●	●	●
Escort	1.4L	1.4 PT-E SFI	1994 - 1998	PATS	●	●	●
Escort	1.4L	1.4 PT-E SFI	1994 - 1998	PCM	●	●	●
Escort	1.4L	1.4 PT-E SFI	1995 - 1998	ABS	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Escort	1. 6L	PT-E	Other	ABS/TCS	●	●	●
Escort	1. 6L	PT-E	Other	CSM	●	●	●
Escort	1. 6L	PT-E	Other	HEC	●	●	●
Escort	1. 6L	PT-E	Other	PATS	●	●	●
Escort	1. 6L	PT-E	Other	PCM	●	●	●
Escort	1. 6L	Zetec	1993 - 1997	PCM	●	●	●
Escort	1. 6L	Zetec	1993 - 1998	ABS/TCS	●	●	●
Escort	1. 6L	Zetec	1993 - 1998	CSM	●	●	●
Escort	1. 6L	Zetec	1993 - 1998	HEC	●	●	●
Escort	1. 6L	Zetec	1993 - 1998	PATS	●	●	●
Escort	1. 6L	Zetec	1995 - 1998	ABS	●	●	●
Escort	1. 6L	Zetec Rocam	2000	ABS/TCS	●	●	●
Escort	1. 6L	Zetec Rocam	2000	CSM	●	●	●
Escort	1. 6L	Zetec Rocam	2000	HEC	●	●	●
Escort	1. 6L	Zetec Rocam	2000	PATS	●	●	●
Escort	1. 6L	Zetec Rocam	2000	PCM	●	●	●
Escort	1. 8L	Endura-DE	1996 - Other	ABS/TCS	●	●	●
Escort	1. 8L	Endura-DE	1996 - Other	CSM	●	●	●
Escort	1. 8L	Endura-DE	1996 - Other	HEC	●	●	●
Escort	1. 8L	Endura-DE	1996 - Other	PATS	●	●	●
Escort	1. 8L	Endura-DE	1996 - Other	PCM	●	●	●
Escort	1. 8L	Endura-DE	1997	ABS	●	●	●
Escort	1. 8L	Other	1996	ABS/TCS	●	●	●
Escort	1. 8L	Other	1996	CSM	●	●	●
Escort	1. 8L	Other	1996	HEC	●	●	●
Escort	1. 8L	Other	1996	PATS	●	●	●
Escort	1. 8L	Other	1996	PCM	●	●	●
Escort	1. 8L	Zetec	1992 - 1996	PCM	●	●	●
Escort	1. 8L	Zetec	1992 - 1998	ABS/TCS	●	●	●
Escort	1. 8L	Zetec	1992 - 1998	CSM	●	●	●
Escort	1. 8L	Zetec	1992 - 1998	HEC	●	●	●
Escort	1. 8L	Zetec	1992 - 1998	PATS	●	●	●
Escort	1. 8L	Zetec	1995 - 1998	ABS	●	●	●
Escort	1. 9L	Other	1996	ABS/TCS	●	●	●
Escort	1. 9L	Other	1996	PATS	●	●	●
Escort	1. 9L	Other	1996	PCM	●	●	●
Escort	2. 0L	DOHC Cosworth	1994 - 1995	ABS/TCS	●	●	●
Escort	2. 0L	DOHC Cosworth	1994 - 1995	PATS	●	●	●
Escort	2. 0L	DOHC Cosworth	1994 - 1995	PCM	●	●	●
Escort	2. 0L	DOHC Cosworth	1995	ABS	●	●	●
Escort	2. 0L	SPI	1997 - 2002	ABS/TCS	●	●	●
Escort	2. 0L	SPI	1997 - 2002	PATS	●	●	●



Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Escort	2.0L	SPI	1997 - 2002	PCM	●	●	●
Escort	2.0L	SPI	1997 - 2002	RAP	●	●	●
Escort	2.0L	SPI	1998 - 1999	ABS	●	●	●
Escort	2.0L	SPI	1998 - 2002	ECS	●	●	●
Escort	2.0L	Zetec	1998 - 1999	ABS	●	●	●
Escort	2.0L	Zetec	1998 - 2003	ABS/TCS	●	●	●
Escort	2.0L	Zetec	1998 - 2003	ECS	●	●	●
Escort	2.0L	Zetec	1998 - 2003	PATS	●	●	●
Escort	2.0L	Zetec	1998 - 2003	PCM	●	●	●
Escort	2.0L	Zetec	1998 - 2003	RAP	●	●	●
Everest / Endeavour	2.5L	WL-CD	2007	ABS/TCS	●	●	●
Everest / Endeavour	2.5L	WL-CD	2007	PCM	●	●	●
Everest / Endeavour	2.5L	WL-CD	2007	RCM	●	●	●
Everest / Endeavour	2.5L	WL-CD	2007	TCM	●	●	●
Everest / Endeavour	2.6L	G6	2007	ABS/TCS	●	●	●
Everest / Endeavour	2.6L	G6	2007	PCM	●	●	●
Everest / Endeavour	2.6L	G6	2007	RCM	●	●	●
Everest / Endeavour	3.0L	WE-CD	2007	ABS/TCS	●	●	●
Everest / Endeavour	3.0L	WE-CD	2007	PCM	●	●	●
Everest / Endeavour	3.0L	WE-CD	2007	RCM	●	●	●
Everest / Endeavour	3.0L	WE-CD	2007	TCM	●	●	●
Excursion	5.4L	2V	2004	ECS	●	●	●
Excursion	5.4L	2V	2004 - 2005	ABS/TCS	●	●	●
Excursion	5.4L	2V	2004 - 2005	DSM	●	●	●
Excursion	5.4L	2V	2004 - 2005	EATC	●	●	●
Excursion	5.4L	2V	2004 - 2005	GEM	●	●	●
Excursion	5.4L	2V	2004 - 2005	HEC	●	●	●
Excursion	5.4L	2V	2004 - 2005	OTC	●	●	●
Excursion	5.4L	2V	2004 - 2005	PAM	●	●	●
Excursion	5.4L	2V	2004 - 2005	PATS	●	●	●
Excursion	5.4L	2V	2004 - 2005	PCM	●	●	●
Excursion	5.4L	2V	2004 - 2005	VSM	●	●	●
Excursion	5.4L	2V	2005	RCM	●	●	●
Excursion	5.4L	Other	2000	MC	●	●	●
Excursion	5.4L	Other	2000 - 2003	ABS/TCS	●	●	●
Excursion	5.4L	Other	2000 - 2003	ECS	●	●	●
Excursion	5.4L	Other	2000 - 2003	GEM	●	●	●
Excursion	5.4L	Other	2000 - 2003	PAM	●	●	●
Excursion	5.4L	Other	2000 - 2003	PATS	●	●	●
Excursion	5.4L	Other	2000 - 2003	PCM	●	●	●
Excursion	5.4L	Other	2002	CSM	●	●	●
Excursion	5.4L	Other	2002 - 2003	DSM	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Excursion	5.4L	Other	2002 - 2003	EATC	●	●	●
Excursion	5.4L	Other	2002 - 2003	HEC	●	●	●
Excursion	5.4L	Other	2002 - 2003	OTC	●	●	●
Excursion	5.4L	Other	2003	FOH	●	●	●
Excursion	5.4L	Other	2003	VSM	●	●	●
Excursion	6.0L	Direct Injection - Turbo	2003	FOH	●	●	●
Excursion	6.0L	Direct Injection - Turbo	2003 - 2004	ECS	●	●	●
Excursion	6.0L	Direct Injection - Turbo	2003 - 2005	ABS/TCS	●	●	●
Excursion	6.0L	Direct Injection - Turbo	2003 - 2005	DSM	●	●	●
Excursion	6.0L	Direct Injection - Turbo	2003 - 2005	EATC	●	●	●
Excursion	6.0L	Direct Injection - Turbo	2003 - 2005	GEM	●	●	●
Excursion	6.0L	Direct Injection - Turbo	2003 - 2005	HEC	●	●	●
Excursion	6.0L	Direct Injection - Turbo	2003 - 2005	OTC	●	●	●
Excursion	6.0L	Direct Injection - Turbo	2003 - 2005	PAM	●	●	●
Excursion	6.0L	Direct Injection - Turbo	2003 - 2005	PATS	●	●	●
Excursion	6.0L	Direct Injection - Turbo	2003 - 2005	PCM	●	●	●
Excursion	6.0L	Direct Injection - Turbo	2003 - 2005	TCM	●	●	●
Excursion	6.0L	Direct Injection - Turbo	2003 - 2005	VSM	●	●	●
Excursion	6.0L	Direct Injection - Turbo	2005	RCM	●	●	●
Excursion	6.8L	2V	2004	ECS	●	●	●
Excursion	6.8L	2V	2004 - 2005	ABS/TCS	●	●	●
Excursion	6.8L	2V	2004 - 2005	DSM	●	●	●
Excursion	6.8L	2V	2004 - 2005	EATC	●	●	●
Excursion	6.8L	2V	2004 - 2005	GEM	●	●	●
Excursion	6.8L	2V	2004 - 2005	HEC	●	●	●
Excursion	6.8L	2V	2004 - 2005	OTC	●	●	●
Excursion	6.8L	2V	2004 - 2005	PAM	●	●	●
Excursion	6.8L	2V	2004 - 2005	PATS	●	●	●
Excursion	6.8L	2V	2004 - 2005	PCM	●	●	●
Excursion	6.8L	2V	2004 - 2005	VSM	●	●	●
Excursion	6.8L	2V	2005	RCM	●	●	●
Excursion	6.8L	Other	2000	MC	●	●	●
Excursion	6.8L	Other	2000 - 2003	ABS/TCS	●	●	●
Excursion	6.8L	Other	2000 - 2003	ECS	●	●	●
Excursion	6.8L	Other	2000 - 2003	GEM	●	●	●
Excursion	6.8L	Other	2000 - 2003	PAM	●	●	●
Excursion	6.8L	Other	2000 - 2003	PATS	●	●	●
Excursion	6.8L	Other	2000 - 2003	PCM	●	●	●
Excursion	6.8L	Other	2002	CSM	●	●	●
Excursion	6.8L	Other	2002 - 2003	DSM	●	●	●
Excursion	6.8L	Other	2002 - 2003	EATC	●	●	●
Excursion	6.8L	Other	2002 - 2003	HEC	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Excursion	6.8L	Other	2002 - 2003	OTC	●	●	●
Excursion	6.8L	Other	2003	FOH	●	●	●
Excursion	6.8L	Other	2003	VSM	●	●	●
Excursion	7.3L	Direct Injection - Turbo	2000	MC	●	●	●
Excursion	7.3L	Direct Injection - Turbo	2000 - 2003	ABS/TCS	●	●	●
Excursion	7.3L	Direct Injection - Turbo	2000 - 2003	ECS	●	●	●
Excursion	7.3L	Direct Injection - Turbo	2000 - 2003	GEM	●	●	●
Excursion	7.3L	Direct Injection - Turbo	2000 - 2003	PAM	●	●	●
Excursion	7.3L	Direct Injection - Turbo	2000 - 2003	PATS	●	●	●
Excursion	7.3L	Direct Injection - Turbo	2000 - 2003	PCM	●	●	●
Excursion	7.3L	Direct Injection - Turbo	2002	CSM	●	●	●
Excursion	7.3L	Direct Injection - Turbo	2002 - 2003	DSM	●	●	●
Excursion	7.3L	Direct Injection - Turbo	2002 - 2003	EATC	●	●	●
Excursion	7.3L	Direct Injection - Turbo	2002 - 2003	HEC	●	●	●
Excursion	7.3L	Direct Injection - Turbo	2002 - 2003	OTC	●	●	●
Excursion	7.3L	Direct Injection - Turbo	2003	FOH	●	●	●
Excursion	7.3L	Direct Injection - Turbo	2003	VSM	●	●	●
Expedition	4.6L	2V	2003 - 2004	4X4	●	●	●
Expedition	4.6L	2V	2003 - 2004	ABS/TCS	●	●	●
Expedition	4.6L	2V	2003 - 2004	DCSM	●	●	●
Expedition	4.6L	2V	2003 - 2004	DSM	●	●	●
Expedition	4.6L	2V	2003 - 2004	EATC	●	●	●
Expedition	4.6L	2V	2003 - 2004	HEC	●	●	●
Expedition	4.6L	2V	2003 - 2004	PAM	●	●	●
Expedition	4.6L	2V	2003 - 2004	PCM	●	●	●
Expedition	4.6L	2V	2003 - 2004	PCSM	●	●	●
Expedition	4.6L	2V	2003 - 2004	RCM	●	●	●
Expedition	4.6L	2V	2003 - 2004	TPM	●	●	●
Expedition	4.6L	2V	2003 - 2004	VDM	●	●	●
Expedition	4.6L	2V	2003 - 2004	VSM	●	●	●
Expedition	4.6L	Other	1997 - 1998	IAB	●	●	●
Expedition	4.6L	Other	1997 - 1998	PATS	●	●	●
Expedition	4.6L	Other	1997 - 2000	4WAS	●	●	●
Expedition	4.6L	Other	1997 - 2000	ABS/TCS	●	●	●
Expedition	4.6L	Other	1997 - 2000	GEM	●	●	●
Expedition	4.6L	Other	1997 - 2000	PCM	●	●	●
Expedition	4.6L	Other	1997 - 2000	RAP	●	●	●
Expedition	4.6L	Other	1998	RCC	●	●	●
Expedition	4.6L	Other	1999 - 2000	EATC	●	●	●
Expedition	4.6L	Other	1999 - 2000	HEC	●	●	●
Expedition	4.6L	Other	1999 - 2000	RCM	●	●	●
Expedition	4.6L	Other	2000	DSM	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Expedition	4. 6L	Other	2000	PAM	●	●	●
Expedition	5. 4L	2V	2003 - 2004	4X4	●	●	●
Expedition	5. 4L	2V	2003 - 2004	ABS/TCS	●	●	●
Expedition	5. 4L	2V	2003 - 2004	DCSM	●	●	●
Expedition	5. 4L	2V	2003 - 2004	DSM	●	●	●
Expedition	5. 4L	2V	2003 - 2004	EATC	●	●	●
Expedition	5. 4L	2V	2003 - 2004	HEC	●	●	●
Expedition	5. 4L	2V	2003 - 2004	PAM	●	●	●
Expedition	5. 4L	2V	2003 - 2004	PCM	●	●	●
Expedition	5. 4L	2V	2003 - 2004	PCSM	●	●	●
Expedition	5. 4L	2V	2003 - 2004	RCM	●	●	●
Expedition	5. 4L	2V	2003 - 2004	TPM	●	●	●
Expedition	5. 4L	2V	2003 - 2004	VDM	●	●	●
Expedition	5. 4L	2V	2003 - 2004	VSM	●	●	●
Expedition	5. 4L	3V	2005 - 2006	VSM	●	●	●
Expedition	5. 4L	3V	2005 - 2007	EATC	●	●	●
Expedition	5. 4L	3V	2005 - 2010	4X4	●	●	●
Expedition	5. 4L	3V	2005 - 2012	PAM	●	●	●
Expedition	5. 4L	3V	2005 - 2014	ABS	●	●	●
Expedition	5. 4L	3V	2005 - 2014	DCSM	●	●	●
Expedition	5. 4L	3V	2005 - 2014	DSM	●	●	●
Expedition	5. 4L	3V	2005 - 2014	IC	●	●	●
Expedition	5. 4L	3V	2005 - 2014	PCM	●	●	●
Expedition	5. 4L	3V	2005 - 2014	RCM	●	●	●
Expedition	5. 4L	3V	2005 - 2014	VDM	●	●	●
Expedition	5. 4L	3V	2007	GEM	●	●	●
Expedition	5. 4L	3V	2007 - 2011	TCM	●	●	●
Expedition	5. 4L	3V	2007 - 2012	RETM	●	●	●
Expedition	5. 4L	3V	2007 - 2014	ACM	●	●	●
Expedition	5. 4L	3V	2007 - 2014	DSP	●	●	●
Expedition	5. 4L	3V	2007 - 2014	LTM	●	●	●
Expedition	5. 4L	3V	2007 - 2014	RCU	●	●	●
Expedition	5. 4L	3V	2007 - 2014	SDARS	●	●	●
Expedition	5. 4L	3V	2008 - 2014	GEM / SJB	●	●	●
Expedition	5. 4L	3V	2008 - 2014	HVAC	●	●	●
Expedition	5. 4L	3V	2008 - 2014	PRB	●	●	●
Expedition	5. 4L	3V	2009 - 2014	APIM	●	●	●
Expedition	5. 4L	3V	2010 - 2012	GPSM	●	●	●
Expedition	5. 4L	3V	2010 - 2014	TCCM	●	●	●
Expedition	5. 4L	3V	2013 - 2014	TBC	●	●	●
Expedition	5. 4L	Other	1997 - 1998	IAB	●	●	●
Expedition	5. 4L	Other	1997 - 1998	PATS	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Expedition	5.4L	Other	1997 - 2000	4WAS	●	●	●
Expedition	5.4L	Other	1997 - 2000	ABS/TCS	●	●	●
Expedition	5.4L	Other	1997 - 2000	GEM	●	●	●
Expedition	5.4L	Other	1997 - 2000	PCM	●	●	●
Expedition	5.4L	Other	1997 - 2000	RAP	●	●	●
Expedition	5.4L	Other	1998	RCC	●	●	●
Expedition	5.4L	Other	1999 - 2000	EATC	●	●	●
Expedition	5.4L	Other	1999 - 2000	HEC	●	●	●
Expedition	5.4L	Other	1999 - 2000	RCM	●	●	●
Expedition	5.4L	Other	2000	DSM	●	●	●
Expedition	5.4L	Other	2000	PAM	●	●	●
Expedition	Other	Other	2013	ABS	●	●	●
Expedition	Other	Other	2013	ACM	●	●	●
Expedition	Other	Other	2013	APIM	●	●	●
Expedition	Other	Other	2013	DCSM	●	●	●
Expedition	Other	Other	2013	DSM	●	●	●
Expedition	Other	Other	2013	DSP	●	●	●
Expedition	Other	Other	2013	GEM / SJB	●	●	●
Expedition	Other	Other	2013	HVAC	●	●	●
Expedition	Other	Other	2013	IC	●	●	●
Expedition	Other	Other	2013	LTM	●	●	●
Expedition	Other	Other	2013	PCM	●	●	●
Expedition	Other	Other	2013	PRB	●	●	●
Expedition	Other	Other	2013	RCM	●	●	●
Expedition	Other	Other	2013	RCU	●	●	●
Expedition	Other	Other	2013	SDARS	●	●	●
Expedition	Other	Other	2013	TBC	●	●	●
Expedition	Other	Other	2013	TCCM	●	●	●
Expedition	Other	Other	2013	VDM	●	●	●
Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2012	TPM	●	●	●
Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	ABS	●	●	●
Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	ACM	●	●	●
Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	BCM#1	●	●	●
Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	C-CM	●	●	●
Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	FCDIM	●	●	●
Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	HVAC	●	●	●
Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	IPC	●	●	●
Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	OCSM	●	●	●
Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	PCM	●	●	●
Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	SCCM	●	●	●
Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	TCM	●	●	●
Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2014	APIM	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2014	ATCM	●	●	●
Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2014	CLM#1	●	●	●
Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2014	DCSM	●	●	●
Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2014	DSM	●	●	●
Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2014	DSP	●	●	●
Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2014	FCIM	●	●	●
Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2014	FLM	●	●	●
Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2014	GPSM	●	●	●
Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2014	HSWM	●	●	●
Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2014	HUD	●	●	●
Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2014	LTM	●	●	●
Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2014	PAM	●	●	●
Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2014	PSCM	●	●	●
Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2014	RCM	●	●	●
Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2014	RFA	●	●	●
Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2014	RLCM-A	●	●	●
Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2014	SOD-L	●	●	●
Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2014	SOD-R	●	●	●
Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	IPM-A	●	●	●
Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	GFM	●	●	●
Explorer	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	RTM	●	●	●
Explorer	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	ABS	●	●	●
Explorer	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	ACM	●	●	●
Explorer	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	BCM#1	●	●	●
Explorer	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	C-CM	●	●	●
Explorer	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	FCDIM	●	●	●
Explorer	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	HVAC	●	●	●
Explorer	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	IPC	●	●	●
Explorer	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	IPM-A	●	●	●
Explorer	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	OCSM	●	●	●
Explorer	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	PCM	●	●	●
Explorer	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	SCCM	●	●	●
Explorer	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	APIM	●	●	●
Explorer	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	ATCM	●	●	●
Explorer	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	CLM#1	●	●	●
Explorer	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	DCSM	●	●	●
Explorer	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	DSM	●	●	●
Explorer	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	DSP	●	●	●
Explorer	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	FCIM	●	●	●
Explorer	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	FLM	●	●	●
Explorer	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	GFM	●	●	●
Explorer	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	GPSM	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Explorer	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	HSWM	●	●	●
Explorer	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	HUD	●	●	●
Explorer	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	LTM	●	●	●
Explorer	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	PAM	●	●	●
Explorer	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	PSCM	●	●	●
Explorer	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	RCM	●	●	●
Explorer	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	RFA	●	●	●
Explorer	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	RLCM-A	●	●	●
Explorer	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	RTM	●	●	●
Explorer	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	SOD-L	●	●	●
Explorer	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	SOD-R	●	●	●
Explorer	3.5L	TiVCT	2011 - 2012	TPM	●	●	●
Explorer	3.5L	TiVCT	2011 - 2013	ABS	●	●	●
Explorer	3.5L	TiVCT	2011 - 2013	ACM	●	●	●
Explorer	3.5L	TiVCT	2011 - 2013	BCM#1	●	●	●
Explorer	3.5L	TiVCT	2011 - 2013	C-CM	●	●	●
Explorer	3.5L	TiVCT	2011 - 2013	FCDIM	●	●	●
Explorer	3.5L	TiVCT	2011 - 2013	HVAC	●	●	●
Explorer	3.5L	TiVCT	2011 - 2013	IPC	●	●	●
Explorer	3.5L	TiVCT	2011 - 2013	OCSM	●	●	●
Explorer	3.5L	TiVCT	2011 - 2013	PCM	●	●	●
Explorer	3.5L	TiVCT	2011 - 2013	SCCM	●	●	●
Explorer	3.5L	TiVCT	2011 - 2014	APIM	●	●	●
Explorer	3.5L	TiVCT	2011 - 2014	ATCM	●	●	●
Explorer	3.5L	TiVCT	2011 - 2014	CLM#1	●	●	●
Explorer	3.5L	TiVCT	2011 - 2014	DCSM	●	●	●
Explorer	3.5L	TiVCT	2011 - 2014	DSM	●	●	●
Explorer	3.5L	TiVCT	2011 - 2014	DSP	●	●	●
Explorer	3.5L	TiVCT	2011 - 2014	FCIM	●	●	●
Explorer	3.5L	TiVCT	2011 - 2014	FLM	●	●	●
Explorer	3.5L	TiVCT	2011 - 2014	GPSM	●	●	●
Explorer	3.5L	TiVCT	2011 - 2014	HSWM	●	●	●
Explorer	3.5L	TiVCT	2011 - 2014	HUD	●	●	●
Explorer	3.5L	TiVCT	2011 - 2014	LTM	●	●	●
Explorer	3.5L	TiVCT	2011 - 2014	PAM	●	●	●
Explorer	3.5L	TiVCT	2011 - 2014	PSCM	●	●	●
Explorer	3.5L	TiVCT	2011 - 2014	RCM	●	●	●
Explorer	3.5L	TiVCT	2011 - 2014	RFA	●	●	●
Explorer	3.5L	TiVCT	2011 - 2014	RLCM-A	●	●	●
Explorer	3.5L	TiVCT	2011 - 2014	SOD-L	●	●	●
Explorer	3.5L	TiVCT	2011 - 2014	SOD-R	●	●	●
Explorer	3.5L	TiVCT	2013	IPM-A	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Explorer	3.5L	TiVCT	2013 - 2014	GFM	●	●	●
Explorer	3.5L	TiVCT	2013 - 2014	RTM	●	●	●
Explorer	3.7L	TiVCT	2013	ABS	●	●	●
Explorer	3.7L	TiVCT	2013	ACM	●	●	●
Explorer	3.7L	TiVCT	2013	BCM#1	●	●	●
Explorer	3.7L	TiVCT	2013	C-CM	●	●	●
Explorer	3.7L	TiVCT	2013	FCDIM	●	●	●
Explorer	3.7L	TiVCT	2013	HVAC	●	●	●
Explorer	3.7L	TiVCT	2013	IPC	●	●	●
Explorer	3.7L	TiVCT	2013	IPM-A	●	●	●
Explorer	3.7L	TiVCT	2013	OCSM	●	●	●
Explorer	3.7L	TiVCT	2013	PCM	●	●	●
Explorer	3.7L	TiVCT	2013	SCCM	●	●	●
Explorer	3.7L	TiVCT	2013 - 2014	APIM	●	●	●
Explorer	3.7L	TiVCT	2013 - 2014	ATCM	●	●	●
Explorer	3.7L	TiVCT	2013 - 2014	CLM#1	●	●	●
Explorer	3.7L	TiVCT	2013 - 2014	DCSM	●	●	●
Explorer	3.7L	TiVCT	2013 - 2014	DSM	●	●	●
Explorer	3.7L	TiVCT	2013 - 2014	DSP	●	●	●
Explorer	3.7L	TiVCT	2013 - 2014	FCIM	●	●	●
Explorer	3.7L	TiVCT	2013 - 2014	FLM	●	●	●
Explorer	3.7L	TiVCT	2013 - 2014	GFM	●	●	●
Explorer	3.7L	TiVCT	2013 - 2014	GPSM	●	●	●
Explorer	3.7L	TiVCT	2013 - 2014	HSWM	●	●	●
Explorer	3.7L	TiVCT	2013 - 2014	HUD	●	●	●
Explorer	3.7L	TiVCT	2013 - 2014	LTM	●	●	●
Explorer	3.7L	TiVCT	2013 - 2014	PAM	●	●	●
Explorer	3.7L	TiVCT	2013 - 2014	PSCM	●	●	●
Explorer	3.7L	TiVCT	2013 - 2014	RCM	●	●	●
Explorer	3.7L	TiVCT	2013 - 2014	RFA	●	●	●
Explorer	3.7L	TiVCT	2013 - 2014	RLCM-A	●	●	●
Explorer	3.7L	TiVCT	2013 - 2014	RTM	●	●	●
Explorer	3.7L	TiVCT	2013 - 2014	SOD-L	●	●	●
Explorer	3.7L	TiVCT	2013 - 2014	SOD-R	●	●	●
Explorer	4.0L	2V	2006 - 2007	EATC	●	●	●
Explorer	4.0L	2V	2006 - 2007	GEM	●	●	●
Explorer	4.0L	2V	2006 - 2010	4X4	●	●	●
Explorer	4.0L	2V	2006 - 2010	ABS	●	●	●
Explorer	4.0L	2V	2006 - 2010	ACM	●	●	●
Explorer	4.0L	2V	2006 - 2010	DSM	●	●	●
Explorer	4.0L	2V	2006 - 2010	IC	●	●	●
Explorer	4.0L	2V	2006 - 2010	OCSM	●	●	●



Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Explorer	4.0L	2V	2006 - 2010	PAM	●	●	●
Explorer	4.0L	2V	2006 - 2010	PCM	●	●	●
Explorer	4.0L	2V	2006 - 2010	PRB	●	●	●
Explorer	4.0L	2V	2006 - 2010	RCM	●	●	●
Explorer	4.0L	2V	2006 - 2010	RETM	●	●	●
Explorer	4.0L	2V	2006 - 2010	SDARS	●	●	●
Explorer	4.0L	2V	2008 - 2010	APIM	●	●	●
Explorer	4.0L	2V	2008 - 2010	GEM / SJB	●	●	●
Explorer	4.0L	2V	2008 - 2010	HVAC	●	●	●
Explorer	4.0L	2V	2010	GPSM	●	●	●
Explorer	4.0L	Other	1996 - 1998	IAB	●	●	●
Explorer	4.0L	Other	1996 - 2000	ABS/TCS	●	●	●
Explorer	4.0L	Other	1996 - 2000	ARC	●	●	●
Explorer	4.0L	Other	1996 - 2000	EATC	●	●	●
Explorer	4.0L	Other	1996 - 2000	GEM	●	●	●
Explorer	4.0L	Other	1996 - 2000	PCM	●	●	●
Explorer	4.0L	Other	1996 - 2000	RAP	●	●	●
Explorer	4.0L	Other	1998 - 2000	DSM	●	●	●
Explorer	4.0L	Other	1998 - 2000	PAM	●	●	●
Explorer	4.0L	Other	1998 - 2000	PATS	●	●	●
Explorer	4.0L	Other	1999 - 2000	RCM	●	●	●
Explorer	4.0L	V6 OHV	1996 - 1998	IAB	●	●	●
Explorer	4.0L	V6 OHV	1996 - 1999	ABS/TCS	●	●	●
Explorer	4.0L	V6 OHV	1996 - 1999	ARC	●	●	●
Explorer	4.0L	V6 OHV	1996 - 1999	EATC	●	●	●
Explorer	4.0L	V6 OHV	1996 - 1999	GEM	●	●	●
Explorer	4.0L	V6 OHV	1996 - 1999	PCM	●	●	●
Explorer	4.0L	V6 OHV	1996 - 1999	RAP	●	●	●
Explorer	4.0L	V6 OHV	1998 - 1999	DSM	●	●	●
Explorer	4.0L	V6 OHV	1998 - 1999	PAM	●	●	●
Explorer	4.0L	V6 OHV	1998 - 1999	PATS	●	●	●
Explorer	4.0L	V6 OHV	1999	RCM	●	●	●
Explorer	4.0L	V6 SOHC	1997 - 1998	IAB	●	●	●
Explorer	4.0L	V6 SOHC	1997 - 2000	ARC	●	●	●
Explorer	4.0L	V6 SOHC	1997 - 2000	RAP	●	●	●
Explorer	4.0L	V6 SOHC	1997 - 2002	GEM	●	●	●
Explorer	4.0L	V6 SOHC	1997 - 2003	ABS/TCS	●	●	●
Explorer	4.0L	V6 SOHC	1997 - 2005	EATC	●	●	●
Explorer	4.0L	V6 SOHC	1997 - 2005	PCM	●	●	●
Explorer	4.0L	V6 SOHC	1998 - 2000	PATS	●	●	●
Explorer	4.0L	V6 SOHC	1998 - 2005	DSM	●	●	●
Explorer	4.0L	V6 SOHC	1998 - 2005	PAM	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Explorer	4.0L	V6 SOHC	1999	MC	●	●	●
Explorer	4.0L	V6 SOHC	1999 - 2005	RCM	●	●	●
Explorer	4.0L	V6 SOHC	2002	CSM	●	●	●
Explorer	4.0L	V6 SOHC	2002 - 2003	HEC	●	●	●
Explorer	4.0L	V6 SOHC	2002 - 2005	4X4	●	●	●
Explorer	4.0L	V6 SOHC	2002 - 2005	IC	●	●	●
Explorer	4.0L	V6 SOHC	2002 - 2005	TPM	●	●	●
Explorer	4.0L	V6 SOHC	2003 - 2005	VSM	●	●	●
Explorer	4.0L	V6 SOHC	2004 - 2005	ABS	●	●	●
Explorer	4.6L	2V	2002	CSM	●	●	●
Explorer	4.6L	2V	2002	GEM	●	●	●
Explorer	4.6L	2V	2002 - 2003	ABS/TCS	●	●	●
Explorer	4.6L	2V	2002 - 2003	HEC	●	●	●
Explorer	4.6L	2V	2002 - 2005	4X4	●	●	●
Explorer	4.6L	2V	2002 - 2005	DSM	●	●	●
Explorer	4.6L	2V	2002 - 2005	EATC	●	●	●
Explorer	4.6L	2V	2002 - 2005	IC	●	●	●
Explorer	4.6L	2V	2002 - 2005	PAM	●	●	●
Explorer	4.6L	2V	2002 - 2005	PCM	●	●	●
Explorer	4.6L	2V	2002 - 2005	RCM	●	●	●
Explorer	4.6L	2V	2002 - 2005	TPM	●	●	●
Explorer	4.6L	2V	2003 - 2005	VSM	●	●	●
Explorer	4.6L	2V	2004 - 2005	ABS	●	●	●
Explorer	4.6L	3V	2006 - 2007	EATC	●	●	●
Explorer	4.6L	3V	2006 - 2007	GEM	●	●	●
Explorer	4.6L	3V	2006 - 2010	4X4	●	●	●
Explorer	4.6L	3V	2006 - 2010	ABS	●	●	●
Explorer	4.6L	3V	2006 - 2010	ACM	●	●	●
Explorer	4.6L	3V	2006 - 2010	DSM	●	●	●
Explorer	4.6L	3V	2006 - 2010	IC	●	●	●
Explorer	4.6L	3V	2006 - 2010	OCSM	●	●	●
Explorer	4.6L	3V	2006 - 2010	PAM	●	●	●
Explorer	4.6L	3V	2006 - 2010	PCM	●	●	●
Explorer	4.6L	3V	2006 - 2010	PRB	●	●	●
Explorer	4.6L	3V	2006 - 2010	RCM	●	●	●
Explorer	4.6L	3V	2006 - 2010	RETM	●	●	●
Explorer	4.6L	3V	2006 - 2010	SDARS	●	●	●
Explorer	4.6L	3V	2006 - 2010	TCM	●	●	●
Explorer	4.6L	3V	2008 - 2010	APIM	●	●	●
Explorer	4.6L	3V	2008 - 2010	GEM / SJB	●	●	●
Explorer	4.6L	3V	2008 - 2010	HVAC	●	●	●
Explorer	4.6L	3V	2010	GPSM	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Explorer	5.0L	Other	1996 - 1998	IAB	●	●	●
Explorer	5.0L	Other	1996 - 2000	ABS/TCS	●	●	●
Explorer	5.0L	Other	1996 - 2000	EATC	●	●	●
Explorer	5.0L	Other	1996 - 2000	GEM	●	●	●
Explorer	5.0L	Other	1996 - 2000	PCM	●	●	●
Explorer	5.0L	Other	1996 - 2000	RAP	●	●	●
Explorer	5.0L	Other	1997 - 2000	ARC	●	●	●
Explorer	5.0L	Other	1998 - 2000	DSM	●	●	●
Explorer	5.0L	Other	1998 - 2000	PAM	●	●	●
Explorer	5.0L	Other	1998 - 2000	PATS	●	●	●
Explorer	5.0L	Other	1999 - 2000	RCM	●	●	●
Explorer	Other	Other	2014	APIM	●	●	●
Explorer	Other	Other	2014	ATCM	●	●	●
Explorer	Other	Other	2014	CLM#1	●	●	●
Explorer	Other	Other	2014	DCSM	●	●	●
Explorer	Other	Other	2014	DSM	●	●	●
Explorer	Other	Other	2014	DSP	●	●	●
Explorer	Other	Other	2014	FCIM	●	●	●
Explorer	Other	Other	2014	FLM	●	●	●
Explorer	Other	Other	2014	GFM	●	●	●
Explorer	Other	Other	2014	GPSM	●	●	●
Explorer	Other	Other	2014	HSWM	●	●	●
Explorer	Other	Other	2014	HUD	●	●	●
Explorer	Other	Other	2014	LTM	●	●	●
Explorer	Other	Other	2014	PAM	●	●	●
Explorer	Other	Other	2014	PSCM	●	●	●
Explorer	Other	Other	2014	RCM	●	●	●
Explorer	Other	Other	2014	RFA	●	●	●
Explorer	Other	Other	2014	RLCM-A	●	●	●
Explorer	Other	Other	2014	RTM	●	●	●
Explorer	Other	Other	2014	SOD-L	●	●	●
Explorer	Other	Other	2014	SOD-R	●	●	●
Explorer Sport	4.0L	V6 SOHC	2000	PATS	●	●	●
Explorer Sport	4.0L	V6 SOHC	2000 - 2003	4X4	●	●	●
Explorer Sport	4.0L	V6 SOHC	2000 - 2003	ABS/TCS	●	●	●
Explorer Sport	4.0L	V6 SOHC	2000 - 2003	GEM	●	●	●
Explorer Sport	4.0L	V6 SOHC	2000 - 2003	PCM	●	●	●
Explorer Sport	4.0L	V6 SOHC	2000 - 2003	RAP	●	●	●
Explorer Sport	4.0L	V6 SOHC	2000 - 2003	RCM	●	●	●
Explorer SportTrac	4.0L	2V	2007	EATC	●	●	●
Explorer SportTrac	4.0L	2V	2007	GEM	●	●	●
Explorer SportTrac	4.0L	2V	2007 - 2010	4X4	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Explorer SportTrac	4.0L	2V	2007 - 2010	ABS	●	●	●
Explorer SportTrac	4.0L	2V	2007 - 2010	ACM	●	●	●
Explorer SportTrac	4.0L	2V	2007 - 2010	IC	●	●	●
Explorer SportTrac	4.0L	2V	2007 - 2010	OCSM	●	●	●
Explorer SportTrac	4.0L	2V	2007 - 2010	PAM	●	●	●
Explorer SportTrac	4.0L	2V	2007 - 2010	PCM	●	●	●
Explorer SportTrac	4.0L	2V	2007 - 2010	RCM	●	●	●
Explorer SportTrac	4.0L	2V	2007 - 2010	RETM	●	●	●
Explorer SportTrac	4.0L	2V	2007 - 2010	SDARS	●	●	●
Explorer SportTrac	4.0L	2V	2008 - 2010	APIM	●	●	●
Explorer SportTrac	4.0L	2V	2008 - 2010	GEM / SJB	●	●	●
Explorer SportTrac	4.0L	2V	2008 - 2010	HVAC	●	●	●
Explorer SportTrac	4.0L	2V	2010	GPSM	●	●	●
Explorer SportTrac	4.0L	V6 SOHC	2000 - 2003	GEM	●	●	●
Explorer SportTrac	4.0L	V6 SOHC	2000 - 2005	4X4	●	●	●
Explorer SportTrac	4.0L	V6 SOHC	2000 - 2005	ABS/TCS	●	●	●
Explorer SportTrac	4.0L	V6 SOHC	2000 - 2005	PCM	●	●	●
Explorer SportTrac	4.0L	V6 SOHC	2000 - 2005	RAP	●	●	●
Explorer SportTrac	4.0L	V6 SOHC	2000 - 2005	RCM	●	●	●
Explorer SportTrac	4.0L	V6 SOHC	2004 - 2005	HEC	●	●	●
Explorer SportTrac	4.6L	3V	2007	EATC	●	●	●
Explorer SportTrac	4.6L	3V	2007	GEM	●	●	●
Explorer SportTrac	4.6L	3V	2007 - 2010	4X4	●	●	●
Explorer SportTrac	4.6L	3V	2007 - 2010	ABS	●	●	●
Explorer SportTrac	4.6L	3V	2007 - 2010	ACM	●	●	●
Explorer SportTrac	4.6L	3V	2007 - 2010	IC	●	●	●
Explorer SportTrac	4.6L	3V	2007 - 2010	OCSM	●	●	●
Explorer SportTrac	4.6L	3V	2007 - 2010	PAM	●	●	●
Explorer SportTrac	4.6L	3V	2007 - 2010	PCM	●	●	●
Explorer SportTrac	4.6L	3V	2007 - 2010	RCM	●	●	●
Explorer SportTrac	4.6L	3V	2007 - 2010	RETM	●	●	●
Explorer SportTrac	4.6L	3V	2007 - 2010	SDARS	●	●	●
Explorer SportTrac	4.6L	3V	2007 - 2010	TCM	●	●	●
Explorer SportTrac	4.6L	3V	2008 - 2010	APIM	●	●	●
Explorer SportTrac	4.6L	3V	2008 - 2010	GEM / SJB	●	●	●
Explorer SportTrac	4.6L	3V	2008 - 2010	HVAC	●	●	●
Explorer SportTrac	4.6L	3V	2010	GPSM	●	●	●
F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2012	ABS	●	●	●
F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2012	ACM	●	●	●
F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2012	DSP	●	●	●
F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2012	FCIM	●	●	●
F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2012	GPSM	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2012	HVAC	●	●	●
F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2012	ILCM	●	●	●
F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2012	OCSM	●	●	●
F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2012	PCM	●	●	●
F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2012	SCCM	●	●	●
F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2012	TPM	●	●	●
F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2014	APIM	●	●	●
F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2014	BCM#1	●	●	●
F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2014	DCSM	●	●	●
F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2014	DSM	●	●	●
F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2014	FDIM	●	●	●
F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2014	IPC	●	●	●
F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2014	PAM	●	●	●
F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2014	PRB	●	●	●
F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2014	PSCM	●	●	●
F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2014	RCM	●	●	●
F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2014	TBC	●	●	●
F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2014	TCCM	●	●	●
F-150	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	RTM	●	●	●
F-150	3.7L	TiVCT	2011 - 2012	ABS	●	●	●
F-150	3.7L	TiVCT	2011 - 2012	ACM	●	●	●
F-150	3.7L	TiVCT	2011 - 2012	DSP	●	●	●
F-150	3.7L	TiVCT	2011 - 2012	FCIM	●	●	●
F-150	3.7L	TiVCT	2011 - 2012	GPSM	●	●	●
F-150	3.7L	TiVCT	2011 - 2012	HVAC	●	●	●
F-150	3.7L	TiVCT	2011 - 2012	ILCM	●	●	●
F-150	3.7L	TiVCT	2011 - 2012	OCSM	●	●	●
F-150	3.7L	TiVCT	2011 - 2012	PCM	●	●	●
F-150	3.7L	TiVCT	2011 - 2012	SCCM	●	●	●
F-150	3.7L	TiVCT	2011 - 2012	TPM	●	●	●
F-150	3.7L	TiVCT	2011 - 2014	APIM	●	●	●
F-150	3.7L	TiVCT	2011 - 2014	BCM#1	●	●	●
F-150	3.7L	TiVCT	2011 - 2014	DCSM	●	●	●
F-150	3.7L	TiVCT	2011 - 2014	DSM	●	●	●
F-150	3.7L	TiVCT	2011 - 2014	FDIM	●	●	●
F-150	3.7L	TiVCT	2011 - 2014	IPC	●	●	●
F-150	3.7L	TiVCT	2011 - 2014	PAM	●	●	●
F-150	3.7L	TiVCT	2011 - 2014	PRB	●	●	●
F-150	3.7L	TiVCT	2011 - 2014	PSCM	●	●	●
F-150	3.7L	TiVCT	2011 - 2014	RCM	●	●	●
F-150	3.7L	TiVCT	2011 - 2014	TBC	●	●	●
F-150	3.7L	TiVCT	2011 - 2014	TCCM	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
F-150	3. 7L	TiVCT	2013 - 2014	RTM	●	●	●
F-150	4. 2L	2V	2005 - 2007	EATC	●	●	●
F-150	4. 2L	2V	2005 - 2008	4X4	●	●	●
F-150	4. 2L	2V	2005 - 2008	ABS	●	●	●
F-150	4. 2L	2V	2005 - 2008	DSM	●	●	●
F-150	4. 2L	2V	2005 - 2008	IC	●	●	●
F-150	4. 2L	2V	2005 - 2008	PAM	●	●	●
F-150	4. 2L	2V	2005 - 2008	PCM	●	●	●
F-150	4. 2L	2V	2005 - 2008	RCM	●	●	●
F-150	4. 2L	2V	2005 - 2008	VSM	●	●	●
F-150	4. 2L	2V	2008	HVAC	●	●	●
F-150	4. 2L	2V	2008	RETM	●	●	●
F-150	4. 2L	Other	1997 - 2000	IAB	●	●	●
F-150	4. 2L	Other	1997 - 2006	ABS/TCS	●	●	●
F-150	4. 2L	Other	1997 - 2006	GEM	●	●	●
F-150	4. 2L	Other	1997 - 2006	PCM	●	●	●
F-150	4. 2L	Other	1997 - 2006	RAP	●	●	●
F-150	4. 2L	Other	1999 - 2006	IC	●	●	●
F-150	4. 2L	Other	2002 - 2006	RCM	●	●	●
F-150	4. 6L	2V	2003 - 2005	ABS/TCS	●	●	●
F-150	4. 6L	2V	2003 - 2005	GEM	●	●	●
F-150	4. 6L	2V	2003 - 2005	RAP	●	●	●
F-150	4. 6L	2V	2003 - 2010	IC	●	●	●
F-150	4. 6L	2V	2003 - 2010	PCM	●	●	●
F-150	4. 6L	2V	2003 - 2010	RCM	●	●	●
F-150	4. 6L	2V	2004 - 2007	EATC	●	●	●
F-150	4. 6L	2V	2004 - 2008	4X4	●	●	●
F-150	4. 6L	2V	2004 - 2008	VSM	●	●	●
F-150	4. 6L	2V	2004 - 2010	ABS	●	●	●
F-150	4. 6L	2V	2004 - 2010	DSM	●	●	●
F-150	4. 6L	2V	2004 - 2010	PAM	●	●	●
F-150	4. 6L	2V	2008	RETM	●	●	●
F-150	4. 6L	2V	2008 - 2010	HVAC	●	●	●
F-150	4. 6L	2V	2009 - 2010	ACM	●	●	●
F-150	4. 6L	2V	2009 - 2010	APIM	●	●	●
F-150	4. 6L	2V	2009 - 2010	DCSM	●	●	●
F-150	4. 6L	2V	2009 - 2010	DSP	●	●	●
F-150	4. 6L	2V	2009 - 2010	FCIM	●	●	●
F-150	4. 6L	2V	2009 - 2010	FDIM	●	●	●
F-150	4. 6L	2V	2009 - 2010	GEM / SJB	●	●	●
F-150	4. 6L	2V	2009 - 2010	OCSM	●	●	●
F-150	4. 6L	2V	2009 - 2010	PRB	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
F-150	4.6L	2V	2009 - 2010	TBC	●	●	●
F-150	4.6L	2V	2009 - 2010	TCCM	●	●	●
F-150	4.6L	2V	2010	GPSM	●	●	●
F-150	4.6L	2V	2010	ILCM	●	●	●
F-150	4.6L	3V	2009 - 2010	ABS	●	●	●
F-150	4.6L	3V	2009 - 2010	ACM	●	●	●
F-150	4.6L	3V	2009 - 2010	APIM	●	●	●
F-150	4.6L	3V	2009 - 2010	DCSM	●	●	●
F-150	4.6L	3V	2009 - 2010	DSM	●	●	●
F-150	4.6L	3V	2009 - 2010	DSP	●	●	●
F-150	4.6L	3V	2009 - 2010	FCIM	●	●	●
F-150	4.6L	3V	2009 - 2010	FDIM	●	●	●
F-150	4.6L	3V	2009 - 2010	GEM / SJB	●	●	●
F-150	4.6L	3V	2009 - 2010	HVAC	●	●	●
F-150	4.6L	3V	2009 - 2010	IC	●	●	●
F-150	4.6L	3V	2009 - 2010	OCSM	●	●	●
F-150	4.6L	3V	2009 - 2010	PAM	●	●	●
F-150	4.6L	3V	2009 - 2010	PCM	●	●	●
F-150	4.6L	3V	2009 - 2010	PRB	●	●	●
F-150	4.6L	3V	2009 - 2010	RCM	●	●	●
F-150	4.6L	3V	2009 - 2010	TBC	●	●	●
F-150	4.6L	3V	2009 - 2010	TCCM	●	●	●
F-150	4.6L	3V	2009 - 2010	TCM	●	●	●
F-150	4.6L	3V	2010	GPSM	●	●	●
F-150	4.6L	3V	2010	ILCM	●	●	●
F-150	4.6L	Other	1997 - 2000	IAB	●	●	●
F-150	4.6L	Other	1997 - 2002	ABS/TCS	●	●	●
F-150	4.6L	Other	1997 - 2002	GEM	●	●	●
F-150	4.6L	Other	1997 - 2002	PCM	●	●	●
F-150	4.6L	Other	1997 - 2002	RAP	●	●	●
F-150	4.6L	Other	1999 - 2002	IC	●	●	●
F-150	4.6L	Other	2002	RCM	●	●	●
F-150	5.0L	TiVCT	2011 - 2012	ABS	●	●	●
F-150	5.0L	TiVCT	2011 - 2012	ACM	●	●	●
F-150	5.0L	TiVCT	2011 - 2012	DSP	●	●	●
F-150	5.0L	TiVCT	2011 - 2012	FCIM	●	●	●
F-150	5.0L	TiVCT	2011 - 2012	GPSM	●	●	●
F-150	5.0L	TiVCT	2011 - 2012	HVAC	●	●	●
F-150	5.0L	TiVCT	2011 - 2012	ILCM	●	●	●
F-150	5.0L	TiVCT	2011 - 2012	OCSM	●	●	●
F-150	5.0L	TiVCT	2011 - 2012	PCM	●	●	●
F-150	5.0L	TiVCT	2011 - 2012	SCCM	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
F-150	5.0L	TiVCT	2011 - 2012	TPM	●	●	●
F-150	5.0L	TiVCT	2011 - 2014	APIM	●	●	●
F-150	5.0L	TiVCT	2011 - 2014	BCM#1	●	●	●
F-150	5.0L	TiVCT	2011 - 2014	DCSM	●	●	●
F-150	5.0L	TiVCT	2011 - 2014	DSM	●	●	●
F-150	5.0L	TiVCT	2011 - 2014	FDIM	●	●	●
F-150	5.0L	TiVCT	2011 - 2014	IPC	●	●	●
F-150	5.0L	TiVCT	2011 - 2014	PAM	●	●	●
F-150	5.0L	TiVCT	2011 - 2014	PRB	●	●	●
F-150	5.0L	TiVCT	2011 - 2014	PSCM	●	●	●
F-150	5.0L	TiVCT	2011 - 2014	RCM	●	●	●
F-150	5.0L	TiVCT	2011 - 2014	TBC	●	●	●
F-150	5.0L	TiVCT	2011 - 2014	TCCM	●	●	●
F-150	5.0L	TiVCT	2013 - 2014	RTM	●	●	●
F-150	5.4L	2V	2004	ABS/TCS	●	●	●
F-150	5.4L	2V	2004	GEM	●	●	●
F-150	5.4L	2V	2004	IC	●	●	●
F-150	5.4L	2V	2004	PCM	●	●	●
F-150	5.4L	2V	2004	RAP	●	●	●
F-150	5.4L	2V	2004	RCM	●	●	●
F-150	5.4L	3V	2004 - 2007	EATC	●	●	●
F-150	5.4L	3V	2004 - 2008	4X4	●	●	●
F-150	5.4L	3V	2004 - 2008	VSM	●	●	●
F-150	5.4L	3V	2004 - 2010	ABS	●	●	●
F-150	5.4L	3V	2004 - 2010	DSM	●	●	●
F-150	5.4L	3V	2004 - 2010	IC	●	●	●
F-150	5.4L	3V	2004 - 2010	PAM	●	●	●
F-150	5.4L	3V	2004 - 2010	PCM	●	●	●
F-150	5.4L	3V	2004 - 2010	RCM	●	●	●
F-150	5.4L	3V	2008	RETM	●	●	●
F-150	5.4L	3V	2008 - 2010	HVAC	●	●	●
F-150	5.4L	3V	2009 - 2010	ACM	●	●	●
F-150	5.4L	3V	2009 - 2010	APIM	●	●	●
F-150	5.4L	3V	2009 - 2010	DCSM	●	●	●
F-150	5.4L	3V	2009 - 2010	DSP	●	●	●
F-150	5.4L	3V	2009 - 2010	FCIM	●	●	●
F-150	5.4L	3V	2009 - 2010	FDIM	●	●	●
F-150	5.4L	3V	2009 - 2010	GEM / SJB	●	●	●
F-150	5.4L	3V	2009 - 2010	OCSM	●	●	●
F-150	5.4L	3V	2009 - 2010	PRB	●	●	●
F-150	5.4L	3V	2009 - 2010	TBC	●	●	●
F-150	5.4L	3V	2009 - 2010	TCCM	●	●	●



Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
F-150	5. 4L	3V	2009 - 2010	TCM	●	●	●
F-150	5. 4L	3V	2010	GPSM	●	●	●
F-150	5. 4L	3V	2010	ILCM	●	●	●
F-150	5. 4L	BIF	1998 - 2000	ABS/TCS	●	●	●
F-150	5. 4L	BIF	1998 - 2000	AFCM	●	●	●
F-150	5. 4L	BIF	1998 - 2000	GEM	●	●	●
F-150	5. 4L	BIF	1998 - 2000	IAB	●	●	●
F-150	5. 4L	BIF	1998 - 2000	PCM	●	●	●
F-150	5. 4L	BIF	1998 - 2000	RAP	●	●	●
F-150	5. 4L	BIF	1999 - 2000	IC	●	●	●
F-150	5. 4L	NGV	2000	ABS/TCS	●	●	●
F-150	5. 4L	NGV	2000	FIM	●	●	●
F-150	5. 4L	NGV	2000	GEM	●	●	●
F-150	5. 4L	NGV	2000	IAB	●	●	●
F-150	5. 4L	NGV	2000	IC	●	●	●
F-150	5. 4L	NGV	2000	PCM	●	●	●
F-150	5. 4L	NGV	2000	RAP	●	●	●
F-150	5. 4L	Other	1997 - 2000	IAB	●	●	●
F-150	5. 4L	Other	1997 - 2003	ABS/TCS	●	●	●
F-150	5. 4L	Other	1997 - 2003	GEM	●	●	●
F-150	5. 4L	Other	1997 - 2003	PCM	●	●	●
F-150	5. 4L	Other	1997 - 2003	RAP	●	●	●
F-150	5. 4L	Other	1999 - 2003	IC	●	●	●
F-150	5. 4L	Other	2002 - 2003	RCM	●	●	●
F-150	6. 2L	2V	2010	GEM / SJB	●	●	●
F-150	6. 2L	2V	2010	IC	●	●	●
F-150	6. 2L	2V	2010 - 2012	ABS	●	●	●
F-150	6. 2L	2V	2010 - 2012	ACM	●	●	●
F-150	6. 2L	2V	2010 - 2012	DSP	●	●	●
F-150	6. 2L	2V	2010 - 2012	FCIM	●	●	●
F-150	6. 2L	2V	2010 - 2012	GPSM	●	●	●
F-150	6. 2L	2V	2010 - 2012	HVAC	●	●	●
F-150	6. 2L	2V	2010 - 2012	ILCM	●	●	●
F-150	6. 2L	2V	2010 - 2012	OCSM	●	●	●
F-150	6. 2L	2V	2010 - 2012	PCM	●	●	●
F-150	6. 2L	2V	2010 - 2014	APIM	●	●	●
F-150	6. 2L	2V	2010 - 2014	DCSM	●	●	●
F-150	6. 2L	2V	2010 - 2014	DSM	●	●	●
F-150	6. 2L	2V	2010 - 2014	FDIM	●	●	●
F-150	6. 2L	2V	2010 - 2014	PAM	●	●	●
F-150	6. 2L	2V	2010 - 2014	PRB	●	●	●
F-150	6. 2L	2V	2010 - 2014	RCM	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
F-150	6.2L	2V	2010 - 2014	TBC	●	●	●
F-150	6.2L	2V	2010 - 2014	TCCM	●	●	●
F-150	6.2L	2V	2011 - 2012	SCCM	●	●	●
F-150	6.2L	2V	2011 - 2012	TPM	●	●	●
F-150	6.2L	2V	2011 - 2014	BCM#1	●	●	●
F-150	6.2L	2V	2011 - 2014	IPC	●	●	●
F-150	6.2L	2V	2011 - 2014	PSCM	●	●	●
F-150	6.2L	2V	2013 - 2014	RTM	●	●	●
F-150	Other	Other	2004	4X4	●	●	●
F-150	Other	Other	2004	EATC	●	●	●
F-150	Other	Other	2004	IC	●	●	●
F-150	Other	Other	2004	PCM	●	●	●
F-150	Other	Other	2004	VSM	●	●	●
F-150	Other	Other	2004 - 2012	ABS	●	●	●
F-150	Other	Other	2004 - 2012	DSM	●	●	●
F-150	Other	Other	2004 - 2012	PAM	●	●	●
F-150	Other	Other	2004 - 2012	RCM	●	●	●
F-150	Other	Other	2012	ACM	●	●	●
F-150	Other	Other	2012	BCM#1	●	●	●
F-150	Other	Other	2012	DCSM	●	●	●
F-150	Other	Other	2012	DSP	●	●	●
F-150	Other	Other	2012	FCIM	●	●	●
F-150	Other	Other	2012	FDIM	●	●	●
F-150	Other	Other	2012	HVAC	●	●	●
F-150	Other	Other	2012	IHCM	●	●	●
F-150	Other	Other	2012	IPC	●	●	●
F-150	Other	Other	2012	OCSM	●	●	●
F-150	Other	Other	2012	PRB	●	●	●
F-150	Other	Other	2012	PSCM	●	●	●
F-150	Other	Other	2012	SCCM	●	●	●
F-150	Other	Other	2012	TBC	●	●	●
F-150	Other	Other	2012	TCCM	●	●	●
F-150	Other	Other	2012	TPM	●	●	●
F-150 SuperCrew (4 full size doors)	4.6L	2V	2003	ABS/TCS	●	●	●
F-150 SuperCrew (4 full size doors)	4.6L	2V	2003	EATC	●	●	●
F-150 SuperCrew (4 full size doors)	4.6L	2V	2003	GEM	●	●	●
F-150 SuperCrew (4 full size doors)	4.6L	2V	2003	HEC	●	●	●
F-150 SuperCrew (4 full size doors)	4.6L	2V	2003	PCM	●	●	●
F-150 SuperCrew (4 full size doors)	4.6L	2V	2003	RAP	●	●	●
F-150 SuperCrew (4 full size doors)	4.6L	2V	2003	RCM	●	●	●
F-150 SuperCrew (4 full size doors)	4.6L	Other	2001 - 2002	ABS/TCS	●	●	●
F-150 SuperCrew (4 full size doors)	4.6L	Other	2001 - 2002	GEM	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
F-150 SuperCrew (4 full size doors)	4.6L	Other	2001 - 2002	HEC	●	●	●
F-150 SuperCrew (4 full size doors)	4.6L	Other	2001 - 2002	PCM	●	●	●
F-150 SuperCrew (4 full size doors)	4.6L	Other	2001 - 2002	RAP	●	●	●
F-150 SuperCrew (4 full size doors)	4.6L	Other	2001 - 2002	RCM	●	●	●
F-150 SuperCrew (4 full size doors)	4.6L	Other	2002	EATC	●	●	●
F-150 SuperCrew (4 full size doors)	5.4L	2V	2003	ABS/TCS	●	●	●
F-150 SuperCrew (4 full size doors)	5.4L	2V	2003	EATC	●	●	●
F-150 SuperCrew (4 full size doors)	5.4L	2V	2003	GEM	●	●	●
F-150 SuperCrew (4 full size doors)	5.4L	2V	2003	HEC	●	●	●
F-150 SuperCrew (4 full size doors)	5.4L	2V	2003	PCM	●	●	●
F-150 SuperCrew (4 full size doors)	5.4L	2V	2003	RAP	●	●	●
F-150 SuperCrew (4 full size doors)	5.4L	2V	2003	RCM	●	●	●
F-150 SuperCrew (4 full size doors)	5.4L	Other	2001 - 2002	ABS/TCS	●	●	●
F-150 SuperCrew (4 full size doors)	5.4L	Other	2001 - 2002	GEM	●	●	●
F-150 SuperCrew (4 full size doors)	5.4L	Other	2001 - 2002	HEC	●	●	●
F-150 SuperCrew (4 full size doors)	5.4L	Other	2001 - 2002	PCM	●	●	●
F-150 SuperCrew (4 full size doors)	5.4L	Other	2001 - 2002	RAP	●	●	●
F-150 SuperCrew (4 full size doors)	5.4L	Other	2001 - 2002	RCM	●	●	●
F-150 SuperCrew (4 full size doors)	5.4L	Other	2002	EATC	●	●	●
F-250	3.9L	Cummins Diesel	2006	4X4	●	●	●
F-250	3.9L	Cummins Diesel	2006	ABS/TCS	●	●	●
F-250	3.9L	Cummins Diesel	2006	GEM	●	●	●
F-250	3.9L	Cummins Diesel	2006	HEC	●	●	●
F-250	3.9L	Cummins Diesel	2006	OTC	●	●	●
F-250	3.9L	Cummins Diesel	2006	PAM	●	●	●
F-250	3.9L	Cummins Diesel	2006	RCM	●	●	●
F-250	3.9L	Cummins Diesel	2006	TBM	●	●	●
F-250 Light Duty	4.2L	Other	1999	ABS/TCS	●	●	●
F-250 Light Duty	4.2L	Other	1999	GEM	●	●	●
F-250 Light Duty	4.2L	Other	1999	IC	●	●	●
F-250 Light Duty	4.2L	Other	1999	PCM	●	●	●
F-250 Light Duty	4.2L	Other	1999	RAP	●	●	●
F-250 Light Duty	4.2L	Other	1999	RCM	●	●	●
F-250 Light Duty	4.6L	Other	1997 - 1998	IAB	●	●	●
F-250 Light Duty	4.6L	Other	1997 - 2000	ABS/TCS	●	●	●
F-250 Light Duty	4.6L	Other	1997 - 2000	GEM	●	●	●
F-250 Light Duty	4.6L	Other	1997 - 2000	PCM	●	●	●
F-250 Light Duty	4.6L	Other	1997 - 2000	RAP	●	●	●
F-250 Light Duty	4.6L	Other	1999 - 2000	IC	●	●	●
F-250 Light Duty	4.6L	Other	1999 - 2000	RCM	●	●	●
F-250 Light Duty	5.4L	BIF	1998	IAB	●	●	●
F-250 Light Duty	5.4L	BIF	1998 - 1999	ABS/TCS	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
F-250 Light Duty	5.4L	BIF	1998 - 1999	AFCM	●	●	●
F-250 Light Duty	5.4L	BIF	1998 - 1999	GEM	●	●	●
F-250 Light Duty	5.4L	BIF	1998 - 1999	PCM	●	●	●
F-250 Light Duty	5.4L	BIF	1998 - 1999	RAP	●	●	●
F-250 Light Duty	5.4L	BIF	1999	IC	●	●	●
F-250 Light Duty	5.4L	BIF	1999	RCM	●	●	●
F-250 Light Duty	5.4L	NGV	1997 - 1998	IAB	●	●	●
F-250 Light Duty	5.4L	NGV	1997 - 2000	ABS/TCS	●	●	●
F-250 Light Duty	5.4L	NGV	1997 - 2000	FIM	●	●	●
F-250 Light Duty	5.4L	NGV	1997 - 2000	GEM	●	●	●
F-250 Light Duty	5.4L	NGV	1997 - 2000	PCM	●	●	●
F-250 Light Duty	5.4L	NGV	1997 - 2000	RAP	●	●	●
F-250 Light Duty	5.4L	NGV	1999 - 2000	IC	●	●	●
F-250 Light Duty	5.4L	NGV	1999 - 2000	RCM	●	●	●
F-250 Light Duty	5.4L	Other	1997 - 1998	IAB	●	●	●
F-250 Light Duty	5.4L	Other	1997 - 2000	ABS/TCS	●	●	●
F-250 Light Duty	5.4L	Other	1997 - 2000	GEM	●	●	●
F-250 Light Duty	5.4L	Other	1997 - 2000	PCM	●	●	●
F-250 Light Duty	5.4L	Other	1997 - 2000	RAP	●	●	●
F-250 Light Duty	5.4L	Other	1999 - 2000	IC	●	●	●
F-250 Light Duty	5.4L	Other	1999 - 2000	RCM	●	●	●
F-650 / F-750	5.9L	Cummins Diesel	2000 - 2007	ABS/TCS	●	●	●
F-650 / F-750	5.9L	Cummins Diesel	2000 - 2007	GEM	●	●	●
F-650 / F-750	6.0L	Direct Injection - Turbo	2004 - 2007	GEM	●	●	●
F-650 / F-750	6.0L	Direct Injection - Turbo	2005 - 2007	ABS/TCS	●	●	●
F-650 / F-750	6.7L	Cummins Diesel	2008 - 2012	GEM / SJB	●	●	●
F-650 / F-750	6.7L	Cummins Diesel	2011 - 2013	ACM	●	●	●
F-650 / F-750	6.7L	Cummins Diesel	2011 - 2013	HVAC	●	●	●
F-650 / F-750	6.7L	Cummins Diesel	2011 - 2013	IPC	●	●	●
F-650 / F-750	6.7L	Cummins Diesel	2012 - 2013	APIM	●	●	●
F-650 / F-750	6.8L	3V	2012	GEM / SJB	●	●	●
F-650 / F-750	6.8L	3V	2012	PCM	●	●	●
F-650 / F-750	6.8L	3V	2012 - 2013	ACM	●	●	●
F-650 / F-750	6.8L	3V	2012 - 2013	IPC	●	●	●
F-650 / F-750	6.8L	3V	2012 - 2014	APIM	●	●	●
F-650 / F-750	6.8L	3V	2012 - 2014	HVAC	●	●	●
F-650 / F-750	7.2L	Caterpillar Diesel	2000 - 2007	ABS/TCS	●	●	●
F-650 / F-750	7.2L	Caterpillar Diesel	2000 - 2007	GEM	●	●	●
F-650 / F-750	7.2L	Caterpillar Diesel	2008 - 2010	GEM / SJB	●	●	●
F-650 / F-750	7.3L	Direct Injection - Turbo	2000 - 2003	ABS/TCS	●	●	●
F-650 / F-750	7.3L	Direct Injection - Turbo	2000 - 2003	GEM	●	●	●
F-650 / F-750	7.3L	Direct Injection - Turbo	2000 - 2003	PCM	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
F-650 / F-750	Other	Other	2005 - 2006	ABS/TCS	●	●	●
F-650 / F-750	Other	Other	2005 - 2006	GEM	●	●	●
F-650 / F-750	Other	Other	2013	ACM	●	●	●
F-650 / F-750	Other	Other	2013	APIM	●	●	●
F-650 / F-750	Other	Other	2013	HVAC	●	●	●
F-650 / F-750	Other	Other	2013	IPC	●	●	●
F-Series	4.9L	GFP	1996	PCM	●	●	●
F-Series	4.9L	Other	1996	PCM	●	●	●
F-Series	5.0L	Other	1996	PCM	●	●	●
F-Series	5.8L	Other	1996 - 1997	PCM	●	●	●
F-Series	7.3L	Direct Injection - Turbo	1994 - 1997	PCM	●	●	●
F-Series	7.5L	Other	1996 - 1997	PCM	●	●	●
F-Series Super Duty	4.2L	Direct Injection - Turbo	2003	ABS/TCS	●	●	●
F-Series Super Duty	4.2L	Direct Injection - Turbo	2003	FOH	●	●	●
F-Series Super Duty	4.2L	Direct Injection - Turbo	2003	GEM	●	●	●
F-Series Super Duty	4.2L	Direct Injection - Turbo	2003	HEC	●	●	●
F-Series Super Duty	4.2L	Direct Injection - Turbo	2003	OTC	●	●	●
F-Series Super Duty	4.2L	Direct Injection - Turbo	2003	PAM	●	●	●
F-Series Super Duty	4.2L	Direct Injection - Turbo	2003	PATS	●	●	●
F-Series Super Duty	4.2L	Direct Injection - Turbo	2003	PCM	●	●	●
F-Series Super Duty	4.2L	Direct Injection - Turbo	2003	RCM	●	●	●
F-Series Super Duty	4.2L	Direct Injection - Turbo	2003	VSM	●	●	●
F-Series Super Duty	4.2L	Other	2001	ABS/TCS	●	●	●
F-Series Super Duty	4.2L	Other	2001	ECS	●	●	●
F-Series Super Duty	4.2L	Other	2001	GEM	●	●	●
F-Series Super Duty	4.2L	Other	2001	OTC	●	●	●
F-Series Super Duty	4.2L	Other	2001	PAM	●	●	●
F-Series Super Duty	4.2L	Other	2001	PCM	●	●	●
F-Series Super Duty	4.2L	Other	2001	RCM	●	●	●
F-Series Super Duty	5.4L	2V	2004	ABS/TCS	●	●	●
F-Series Super Duty	5.4L	2V	2004	HEC	●	●	●
F-Series Super Duty	5.4L	2V	2004	OTC	●	●	●
F-Series Super Duty	5.4L	2V	2004	PATS	●	●	●
F-Series Super Duty	5.4L	2V	2004 - 2006	GEM	●	●	●
F-Series Super Duty	5.4L	2V	2004 - 2006	VSM	●	●	●
F-Series Super Duty	5.4L	2V	2004 - 2008	PAM	●	●	●
F-Series Super Duty	5.4L	2V	2004 - 2008	PCM	●	●	●
F-Series Super Duty	5.4L	2V	2004 - 2008	RCM	●	●	●
F-Series Super Duty	5.4L	2V	2005 - 2006	EATC	●	●	●
F-Series Super Duty	5.4L	2V	2005 - 2008	ABS	●	●	●
F-Series Super Duty	5.4L	2V	2005 - 2008	IC	●	●	●
F-Series Super Duty	5.4L	2V	2005 - 2008	TBC	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
F-Series Super Duty	5.4L	2V	2008	4X4	●	●	●
F-Series Super Duty	5.4L	2V	2008	ACM	●	●	●
F-Series Super Duty	5.4L	2V	2008	DSM	●	●	●
F-Series Super Duty	5.4L	2V	2008	GEM / SJB	●	●	●
F-Series Super Duty	5.4L	2V	2008	HVAC	●	●	●
F-Series Super Duty	5.4L	2V	2008	RETM	●	●	●
F-Series Super Duty	5.4L	2V	2008	SDARS	●	●	●
F-Series Super Duty	5.4L	3V	2005 - 2007	EATC	●	●	●
F-Series Super Duty	5.4L	3V	2005 - 2007	GEM	●	●	●
F-Series Super Duty	5.4L	3V	2005 - 2007	VSM	●	●	●
F-Series Super Duty	5.4L	3V	2005 - 2010	ABS	●	●	●
F-Series Super Duty	5.4L	3V	2005 - 2010	IC	●	●	●
F-Series Super Duty	5.4L	3V	2005 - 2010	PAM	●	●	●
F-Series Super Duty	5.4L	3V	2005 - 2010	PCM	●	●	●
F-Series Super Duty	5.4L	3V	2005 - 2010	RCM	●	●	●
F-Series Super Duty	5.4L	3V	2005 - 2010	TBC	●	●	●
F-Series Super Duty	5.4L	3V	2008 - 2010	4X4	●	●	●
F-Series Super Duty	5.4L	3V	2008 - 2010	ACM	●	●	●
F-Series Super Duty	5.4L	3V	2008 - 2010	DSM	●	●	●
F-Series Super Duty	5.4L	3V	2008 - 2010	GEM / SJB	●	●	●
F-Series Super Duty	5.4L	3V	2008 - 2010	HVAC	●	●	●
F-Series Super Duty	5.4L	3V	2008 - 2010	RETM	●	●	●
F-Series Super Duty	5.4L	3V	2008 - 2010	SDARS	●	●	●
F-Series Super Duty	5.4L	3V	2009 - 2010	APIM	●	●	●
F-Series Super Duty	5.4L	3V	2010	GPSM	●	●	●
F-Series Super Duty	5.4L	BIF	1999	ABS/TCS	●	●	●
F-Series Super Duty	5.4L	BIF	1999	AFCM	●	●	●
F-Series Super Duty	5.4L	BIF	1999	ECS	●	●	●
F-Series Super Duty	5.4L	BIF	1999	GEM	●	●	●
F-Series Super Duty	5.4L	BIF	1999	OTC	●	●	●
F-Series Super Duty	5.4L	BIF	1999	PCM	●	●	●
F-Series Super Duty	5.4L	Other	1999 - 2001	ECS	●	●	●
F-Series Super Duty	5.4L	Other	1999 - 2003	ABS/TCS	●	●	●
F-Series Super Duty	5.4L	Other	1999 - 2003	GEM	●	●	●
F-Series Super Duty	5.4L	Other	1999 - 2003	OTC	●	●	●
F-Series Super Duty	5.4L	Other	1999 - 2003	PCM	●	●	●
F-Series Super Duty	5.4L	Other	2000 - 2003	PATS	●	●	●
F-Series Super Duty	5.4L	Other	2001 - 2003	PAM	●	●	●
F-Series Super Duty	5.4L	Other	2001 - 2003	RCM	●	●	●
F-Series Super Duty	5.4L	Other	2002	CSM	●	●	●
F-Series Super Duty	5.4L	Other	2002 - 2003	HEC	●	●	●
F-Series Super Duty	5.4L	Other	2003	FOH	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
F-Series Super Duty	5.4L	Other	2003	VSM	●	●	●
F-Series Super Duty	6.0L	Direct Injection - Turbo	2003 - 2004	ABS/TCS	●	●	●
F-Series Super Duty	6.0L	Direct Injection - Turbo	2003 - 2004	FOH	●	●	●
F-Series Super Duty	6.0L	Direct Injection - Turbo	2003 - 2004	HEC	●	●	●
F-Series Super Duty	6.0L	Direct Injection - Turbo	2003 - 2004	OTC	●	●	●
F-Series Super Duty	6.0L	Direct Injection - Turbo	2003 - 2004	PATS	●	●	●
F-Series Super Duty	6.0L	Direct Injection - Turbo	2003 - 2007	GEM	●	●	●
F-Series Super Duty	6.0L	Direct Injection - Turbo	2003 - 2007	PAM	●	●	●
F-Series Super Duty	6.0L	Direct Injection - Turbo	2003 - 2007	PCM	●	●	●
F-Series Super Duty	6.0L	Direct Injection - Turbo	2003 - 2007	RCM	●	●	●
F-Series Super Duty	6.0L	Direct Injection - Turbo	2003 - 2007	TCM	●	●	●
F-Series Super Duty	6.0L	Direct Injection - Turbo	2003 - 2007	VSM	●	●	●
F-Series Super Duty	6.0L	Direct Injection - Turbo	2005 - 2007	ABS	●	●	●
F-Series Super Duty	6.0L	Direct Injection - Turbo	2005 - 2007	EATC	●	●	●
F-Series Super Duty	6.0L	Direct Injection - Turbo	2005 - 2007	IC	●	●	●
F-Series Super Duty	6.0L	Direct Injection - Turbo	2005 - 2007	TBC	●	●	●
F-Series Super Duty	6.2L	2V	2011 - 2012	ABS	●	●	●
F-Series Super Duty	6.2L	2V	2011 - 2012	ACM	●	●	●
F-Series Super Duty	6.2L	2V	2011 - 2012	HVAC	●	●	●
F-Series Super Duty	6.2L	2V	2011 - 2012	IPC	●	●	●
F-Series Super Duty	6.2L	2V	2011 - 2012	PAM	●	●	●
F-Series Super Duty	6.2L	2V	2011 - 2012	PCM	●	●	●
F-Series Super Duty	6.2L	2V	2011 - 2012	SDARS	●	●	●
F-Series Super Duty	6.2L	2V	2011 - 2012	TPM	●	●	●
F-Series Super Duty	6.2L	2V	2011 - 2014	APIM	●	●	●
F-Series Super Duty	6.2L	2V	2011 - 2014	BCM#1	●	●	●
F-Series Super Duty	6.2L	2V	2011 - 2014	DCSM	●	●	●
F-Series Super Duty	6.2L	2V	2011 - 2014	DSM	●	●	●
F-Series Super Duty	6.2L	2V	2011 - 2014	GPSM	●	●	●
F-Series Super Duty	6.2L	2V	2011 - 2014	RCM	●	●	●
F-Series Super Duty	6.2L	2V	2011 - 2014	SCCM	●	●	●
F-Series Super Duty	6.2L	2V	2011 - 2014	TBC	●	●	●
F-Series Super Duty	6.2L	2V	2011 - 2014	TCCM	●	●	●
F-Series Super Duty	6.2L	2V	2013 - 2014	FCIM	●	●	●
F-Series Super Duty	6.2L	2V	2013 - 2014	RTM	●	●	●
F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	2008 - 2010	4X4	●	●	●
F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	2008 - 2010	ABS	●	●	●
F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	2008 - 2010	ACM	●	●	●
F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	2008 - 2010	AHCM	●	●	●
F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	2008 - 2010	CDIM	●	●	●
F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	2008 - 2010	DSM	●	●	●
F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	2008 - 2010	GEM / SJB	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	2008 - 2010	HVAC	●	●	●
F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	2008 - 2010	IC	●	●	●
F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	2008 - 2010	PAM	●	●	●
F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	2008 - 2010	PCM	●	●	●
F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	2008 - 2010	RCM	●	●	●
F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	2008 - 2010	RETM	●	●	●
F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	2008 - 2010	SDARS	●	●	●
F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	2008 - 2010	TBC	●	●	●
F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	2008 - 2010	TCM	●	●	●
F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	2009 - 2010	APIM	●	●	●
F-Series Super Duty	6.4L	Power Stroke - Direct Injection Turbo Diesel	2010	GPSM	●	●	●
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2011	GPCM	●	●	●
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2011	NOx#1	●	●	●
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2011 - 2012	ABS	●	●	●
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2011 - 2012	ACM	●	●	●
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2011 - 2012	HVAC	●	●	●
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2011 - 2012	IPC	●	●	●
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2011 - 2012	PAM	●	●	●
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2011 - 2012	SDARS	●	●	●
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2011 - 2012	TPM	●	●	●
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2011 - 2013	PCM	●	●	●
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2011 - 2013	TCM	●	●	●
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2011 - 2014	AHCM	●	●	●
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2011 - 2014	APIM	●	●	●
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2011 - 2014	BCM#1	●	●	●
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2011 - 2014	CDIM	●	●	●
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2011 - 2014	DCSM	●	●	●
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2011 - 2014	DSM	●	●	●
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2011 - 2014	GPSM	●	●	●
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2011 - 2014	RCM	●	●	●
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2011 - 2014	SCCM	●	●	●
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2011 - 2014	TBC	●	●	●
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2011 - 2014	TCCM	●	●	●
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2014	FCIM	●	●	●
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2014	RTM	●	●	●
F-Series Super Duty	6.8L	2V	2004	ABS/TCS	●	●	●
F-Series Super Duty	6.8L	2V	2004	HEC	●	●	●
F-Series Super Duty	6.8L	2V	2004	OTC	●	●	●
F-Series Super Duty	6.8L	2V	2004	PATS	●	●	●
F-Series Super Duty	6.8L	2V	2004 - 2007	GEM	●	●	●
F-Series Super Duty	6.8L	2V	2004 - 2007	VSM	●	●	●
F-Series Super Duty	6.8L	2V	2004 - 2008	PAM	●	●	●



Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
F-Series Super Duty	6.8L	2V	2004 - 2008	PCM	●	●	●
F-Series Super Duty	6.8L	2V	2004 - 2008	RCM	●	●	●
F-Series Super Duty	6.8L	2V	2005 - 2007	EATC	●	●	●
F-Series Super Duty	6.8L	2V	2005 - 2008	ABS	●	●	●
F-Series Super Duty	6.8L	2V	2005 - 2008	IC	●	●	●
F-Series Super Duty	6.8L	2V	2005 - 2008	TBC	●	●	●
F-Series Super Duty	6.8L	2V	2008	4X4	●	●	●
F-Series Super Duty	6.8L	2V	2008	ACM	●	●	●
F-Series Super Duty	6.8L	2V	2008	DSM	●	●	●
F-Series Super Duty	6.8L	2V	2008	GEM / SJB	●	●	●
F-Series Super Duty	6.8L	2V	2008	HVAC	●	●	●
F-Series Super Duty	6.8L	2V	2008	RETM	●	●	●
F-Series Super Duty	6.8L	2V	2008	SDARS	●	●	●
F-Series Super Duty	6.8L	3V	2005 - 2007	EATC	●	●	●
F-Series Super Duty	6.8L	3V	2005 - 2007	GEM	●	●	●
F-Series Super Duty	6.8L	3V	2005 - 2007	VSM	●	●	●
F-Series Super Duty	6.8L	3V	2005 - 2010	IC	●	●	●
F-Series Super Duty	6.8L	3V	2005 - 2012	ABS	●	●	●
F-Series Super Duty	6.8L	3V	2005 - 2012	PAM	●	●	●
F-Series Super Duty	6.8L	3V	2005 - 2012	PCM	●	●	●
F-Series Super Duty	6.8L	3V	2005 - 2014	RCM	●	●	●
F-Series Super Duty	6.8L	3V	2005 - 2014	TBC	●	●	●
F-Series Super Duty	6.8L	3V	2008 - 2010	4X4	●	●	●
F-Series Super Duty	6.8L	3V	2008 - 2010	GEM / SJB	●	●	●
F-Series Super Duty	6.8L	3V	2008 - 2010	RETM	●	●	●
F-Series Super Duty	6.8L	3V	2008 - 2011	SDARS	●	●	●
F-Series Super Duty	6.8L	3V	2008 - 2012	ACM	●	●	●
F-Series Super Duty	6.8L	3V	2008 - 2012	HVAC	●	●	●
F-Series Super Duty	6.8L	3V	2008 - 2014	DSM	●	●	●
F-Series Super Duty	6.8L	3V	2009 - 2014	APIM	●	●	●
F-Series Super Duty	6.8L	3V	2010 - 2014	GPSM	●	●	●
F-Series Super Duty	6.8L	3V	2011 - 2012	IPC	●	●	●
F-Series Super Duty	6.8L	3V	2011 - 2012	TPM	●	●	●
F-Series Super Duty	6.8L	3V	2011 - 2014	BCM#1	●	●	●
F-Series Super Duty	6.8L	3V	2011 - 2014	DCSM	●	●	●
F-Series Super Duty	6.8L	3V	2011 - 2014	SCCM	●	●	●
F-Series Super Duty	6.8L	3V	2011 - 2014	TCCM	●	●	●
F-Series Super Duty	6.8L	3V	2013 - 2014	FCIM	●	●	●
F-Series Super Duty	6.8L	3V	2013 - 2014	RTM	●	●	●
F-Series Super Duty	6.8L	Other	1999 - 2001	ECS	●	●	●
F-Series Super Duty	6.8L	Other	1999 - 2003	ABS/TCS	●	●	●
F-Series Super Duty	6.8L	Other	1999 - 2003	GEM	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
F-Series Super Duty	6.8L	Other	1999 - 2003	OTC	●	●	●
F-Series Super Duty	6.8L	Other	1999 - 2003	PCM	●	●	●
F-Series Super Duty	6.8L	Other	2000 - 2001	AFCM	●	●	●
F-Series Super Duty	6.8L	Other	2000 - 2003	PATS	●	●	●
F-Series Super Duty	6.8L	Other	2001 - 2003	PAM	●	●	●
F-Series Super Duty	6.8L	Other	2001 - 2003	RCM	●	●	●
F-Series Super Duty	6.8L	Other	2002	CSM	●	●	●
F-Series Super Duty	6.8L	Other	2002 - 2003	HEC	●	●	●
F-Series Super Duty	6.8L	Other	2003	FOH	●	●	●
F-Series Super Duty	6.8L	Other	2003	VSM	●	●	●
F-Series Super Duty	7.3L	Direct Injection - Turbo	1999 - 2001	ECS	●	●	●
F-Series Super Duty	7.3L	Direct Injection - Turbo	1999 - 2003	ABS/TCS	●	●	●
F-Series Super Duty	7.3L	Direct Injection - Turbo	1999 - 2003	GEM	●	●	●
F-Series Super Duty	7.3L	Direct Injection - Turbo	1999 - 2003	OTC	●	●	●
F-Series Super Duty	7.3L	Direct Injection - Turbo	1999 - 2003	PCM	●	●	●
F-Series Super Duty	7.3L	Direct Injection - Turbo	2000 - 2003	PATS	●	●	●
F-Series Super Duty	7.3L	Direct Injection - Turbo	2001 - 2003	PAM	●	●	●
F-Series Super Duty	7.3L	Direct Injection - Turbo	2001 - 2003	RCM	●	●	●
F-Series Super Duty	7.3L	Direct Injection - Turbo	2002	CSM	●	●	●
F-Series Super Duty	7.3L	Direct Injection - Turbo	2002 - 2003	HEC	●	●	●
F-Series Super Duty	7.3L	Direct Injection - Turbo	2003	FOH	●	●	●
F-Series Super Duty	7.3L	Direct Injection - Turbo	2003	VSM	●	●	●
F350/4000	3.9L	Cummins Diesel	2009	4X4	●	●	●
F350/4000	3.9L	Cummins Diesel	2009	GEM	●	●	●
F350/4000	3.9L	Cummins Diesel	2009	TBM	●	●	●
FAMILIA / LASER	1.3L	B3	1998	ABS	●	●	●
FAMILIA / LASER	1.3L	B3	1998	PCM	●	●	●
FAMILIA / LASER	1.5L	ZL	1998 - 2000	ABS	●	●	●
FAMILIA / LASER	1.5L	ZL	1998 - 2002	PCM	●	●	●
FAMILIA / LASER	1.5L	ZL	2000 - 2002	ABS/TCS	●	●	●
FAMILIA / LASER	1.8L	FP	1998	ABS	●	●	●
FAMILIA / LASER	1.8L	FP	1998	PCM	●	●	●
FAMILIA / LASER	2.0L	FS	1999 - 2000	ABS	●	●	●
FAMILIA / LASER	2.0L	FS	1999 - 2002	PCM	●	●	●
FAMILIA / LASER	2.0L	FS	2002	ABS/TCS	●	●	●
FAMILIA / LASER	2.0L	RF	1998	ABS	●	●	●
FAMILIA / LASER	2.0L	RF	1998	PCM	●	●	●
FIGO	1.4 DV4	Duratorq Turbo Diesel Common Rail Injection	2010	ABS/TCS	●	●	●
FIGO	1.4 DV4	Duratorq Turbo Diesel Common Rail Injection	2010	IC	●	●	●
FIGO	1.4 DV4	Duratorq Turbo Diesel Common Rail Injection	2010	PCM	●	●	●
FIGO	1.4 DV4	Duratorq Turbo Diesel Common Rail Injection	2010	RCM	●	●	●
FIGO	1.4L	DURATEC 16V	2010 - 2011	ABS/TCS	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
FIGO	1. 4L	DURATEC 16V	2010 - 2011	IC	●	●	●
FIGO	1. 4L	DURATEC 16V	2010 - 2011	PCM	●	●	●
FIGO	1. 4L	DURATEC 16V	2010 - 2011	RCM	●	●	●
FIGO	1. 4L	DURATEC 16V	2011	GEM	●	●	●
FIGO	1. 6L	DURATEC 16V	2011	ABS/TCS	●	●	●
FIGO	1. 6L	DURATEC 16V	2011	GEM	●	●	●
FIGO	1. 6L	DURATEC 16V	2011	IC	●	●	●
FIGO	1. 6L	DURATEC 16V	2011	PCM	●	●	●
FIGO	1. 6L	DURATEC 16V	2011	RCM	●	●	●
FIGO	1_19L	DURATEC 16V	2010	ABS/TCS	●	●	●
FIGO	1_19L	DURATEC 16V	2010	IC	●	●	●
FIGO	1_19L	DURATEC 16V	2010	PCM	●	●	●
FIGO	1_19L	DURATEC 16V	2010	RCM	●	●	●
FIGO	Other	DURATEC 16V	2011	ABS/TCS	●	●	●
FIGO	Other	DURATEC 16V	2011	GEM	●	●	●
FIGO	Other	DURATEC 16V	2011	IC	●	●	●
FIGO	Other	DURATEC 16V	2011	RCM	●	●	●
FORD GT	5. 4L	4V	2005 - 2006	ABS/TCS	●	●	●
FORD GT	5. 4L	4V	2005 - 2006	AFCM	●	●	●
FORD GT	5. 4L	4V	2005 - 2006	GEM	●	●	●
FORD GT	5. 4L	4V	2005 - 2006	IC	●	●	●
FORD GT	5. 4L	4V	2005 - 2006	PATS	●	●	●
FORD GT	5. 4L	4V	2005 - 2006	PCM	●	●	●
FORD GT	5. 4L	4V	2005 - 2006	RCM	●	●	●
FRIENDEE / FREDA / BONGO FRIENDEE	2. 0L	FE	1997 - 2002	PCM	●	●	●
FRIENDEE / FREDA / BONGO FRIENDEE	2. 0L	FE	2002	TCM	●	●	●
FRIENDEE / FREDA / BONGO FRIENDEE	2. 5L	WL_T	1999	PCM	●	●	●
Fairlane / LTD	4. 0L	DOHC VCT	2003 - 2006	ABS/TCS	●	●	●
Fairlane / LTD	4. 0L	DOHC VCT	2003 - 2006	ACM	●	●	●
Fairlane / LTD	4. 0L	DOHC VCT	2003 - 2006	BEM	●	●	●
Fairlane / LTD	4. 0L	DOHC VCT	2003 - 2006	HIM	●	●	●
Fairlane / LTD	4. 0L	DOHC VCT	2003 - 2006	IC	●	●	●
Fairlane / LTD	4. 0L	DOHC VCT	2003 - 2006	PAM	●	●	●
Fairlane / LTD	4. 0L	DOHC VCT	2003 - 2006	PCM	●	●	●
Fairlane / LTD	4. 0L	DOHC VCT	2003 - 2006	RCM	●	●	●
Fairlane / LTD	4. 0L	DOHC VCT	2006	ABS	●	●	●
Fairlane / LTD	4. 0L	DOHC VCT	2006	TCM	●	●	●
Fairlane / LTD	4. 0L	Other	Other	ABS	●	●	●
Fairlane / LTD	5. 0L	Other	Other	ABS	●	●	●
Fairlane / LTD	5. 4L	3V	2003 - 2006	ABS/TCS	●	●	●
Fairlane / LTD	5. 4L	3V	2003 - 2006	ACM	●	●	●
Fairlane / LTD	5. 4L	3V	2003 - 2006	BEM	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Fairlane / LTD	5. 4L	3V	2003 - 2006	HIM	●	●	●
Fairlane / LTD	5. 4L	3V	2003 - 2006	IC	●	●	●
Fairlane / LTD	5. 4L	3V	2003 - 2006	PAM	●	●	●
Fairlane / LTD	5. 4L	3V	2003 - 2006	PCM	●	●	●
Fairlane / LTD	5. 4L	3V	2003 - 2006	RCM	●	●	●
Fairlane / LTD	5. 4L	3V	2006	ABS	●	●	●
Fairlane / LTD	5. 4L	3V	2006	TCM	●	●	●
Fairmont	4. 0L	DOHC VCT	2003 - 2006	ABS/TCS	●	●	●
Fairmont	4. 0L	DOHC VCT	2003 - 2006	ACM	●	●	●
Fairmont	4. 0L	DOHC VCT	2003 - 2006	BEM	●	●	●
Fairmont	4. 0L	DOHC VCT	2003 - 2006	HIM	●	●	●
Fairmont	4. 0L	DOHC VCT	2003 - 2006	IC	●	●	●
Fairmont	4. 0L	DOHC VCT	2003 - 2006	PAM	●	●	●
Fairmont	4. 0L	DOHC VCT	2003 - 2006	PCM	●	●	●
Fairmont	4. 0L	DOHC VCT	2003 - 2006	RCM	●	●	●
Fairmont	4. 0L	DOHC VCT	2006	ABS	●	●	●
Fairmont	4. 0L	DOHC VCT	2006	TCM	●	●	●
Fairmont	4. 0L	Other	Other	ABS	●	●	●
Fairmont	5. 0L	Other	Other	ABS	●	●	●
Fairmont	5. 4L	3V	2003 - 2006	ABS/TCS	●	●	●
Fairmont	5. 4L	3V	2003 - 2006	ACM	●	●	●
Fairmont	5. 4L	3V	2003 - 2006	BEM	●	●	●
Fairmont	5. 4L	3V	2003 - 2006	HIM	●	●	●
Fairmont	5. 4L	3V	2003 - 2006	IC	●	●	●
Fairmont	5. 4L	3V	2003 - 2006	PAM	●	●	●
Fairmont	5. 4L	3V	2003 - 2006	PCM	●	●	●
Fairmont	5. 4L	3V	2003 - 2006	RCM	●	●	●
Fairmont	5. 4L	3V	2006	ABS	●	●	●
Fairmont	5. 4L	3V	2006	TCM	●	●	●
Festiva	1. 5L	Other	Other	PCM	●	●	●
Festiva Sedan	1. 5L	Other	Other	PCM	●	●	●
Fiesta	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	APIM	●	●	●
Fiesta	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	2014	DDM	●	●	●
Fiesta	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	2014	FCIM	●	●	●
Fiesta	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	2014	GPSM	●	●	●
Fiesta	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	2014	HVAC	●	●	●
Fiesta	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	2014	RCM	●	●	●
Fiesta	1. 0L	EcoBoost - Gas Turbocharged Direct Injection	2014	RFA	●	●	●
Fiesta	1. 0L	GTDI FGEC	2013	APIM	●	●	●
Fiesta	1. 0L	GTDI FGEC	2013	PCM	●	●	●
Fiesta	1. 0L	GTDI FGEC	2013	TCM	●	●	●
Fiesta	1. 0L	Gasoline_Direct_injection	2013	APIM	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Fiesta	1. 25L	DURATEC 16V	2002 - 2006	ABS/TCS	●	●	●
Fiesta	1. 25L	DURATEC 16V	2002 - 2006	GEM	●	●	●
Fiesta	1. 25L	DURATEC 16V	2002 - 2006	IC	●	●	●
Fiesta	1. 25L	DURATEC 16V	2002 - 2008	RCM	●	●	●
Fiesta	1. 25L	DURATEC 16V	2002 - 2013	PCM	●	●	●
Fiesta	1. 25L	DURATEC 16V	2006	EATC	●	●	●
Fiesta	1. 25L	DURATEC 16V	2006 - 2008	ACM	●	●	●
Fiesta	1. 25L	DURATEC 16V	2006 - 2008	SRM	●	●	●
Fiesta	1. 25L	DURATEC 16V	2008	ABS	●	●	●
Fiesta	1. 25L	DURATEC 16V	2008	BCMii	●	●	●
Fiesta	1. 25L	DURATEC 16V	2008	FCDIM	●	●	●
Fiesta	1. 25L	DURATEC 16V	2008	HVAC	●	●	●
Fiesta	1. 25L	DURATEC 16V	2008	IPC	●	●	●
Fiesta	1. 25L	DURATEC 16V	2008	PSCM	●	●	●
Fiesta	1. 25L	DURATEC 16V	2008	RFA	●	●	●
Fiesta	1. 25L	DURATEC 16V	2013	APIM	●	●	●
Fiesta	1. 3L	BZ	2008	ABS	●	●	●
Fiesta	1. 3L	BZ	2008	ACM	●	●	●
Fiesta	1. 3L	BZ	2008	BCMii	●	●	●
Fiesta	1. 3L	BZ	2008	FCDIM	●	●	●
Fiesta	1. 3L	BZ	2008	HVAC	●	●	●
Fiesta	1. 3L	BZ	2008	IPC	●	●	●
Fiesta	1. 3L	BZ	2008	PCM	●	●	●
Fiesta	1. 3L	BZ	2008	PSCM	●	●	●
Fiesta	1. 3L	BZ	2008	RCM	●	●	●
Fiesta	1. 3L	BZ	2008	RFA	●	●	●
Fiesta	1. 3L	BZ	2008	SRM	●	●	●
Fiesta	1. 3L	DURATEC 8V	2002 - 2006	ABS/TCS	●	●	●
Fiesta	1. 3L	DURATEC 8V	2002 - 2006	GEM	●	●	●
Fiesta	1. 3L	DURATEC 8V	2002 - 2006	IC	●	●	●
Fiesta	1. 3L	DURATEC 8V	2002 - 2006	PCM	●	●	●
Fiesta	1. 3L	DURATEC 8V	2002 - 2006	RCM	●	●	●
Fiesta	1. 3L	DURATEC 8V	2006	ACM	●	●	●
Fiesta	1. 3L	DURATEC 8V	2006	EATC	●	●	●
Fiesta	1. 3L	DURATEC 8V	2006	SRM	●	●	●
Fiesta	1. 4L	DURATEC 16V	2002 - 2006	ABS/TCS	●	●	●
Fiesta	1. 4L	DURATEC 16V	2002 - 2006	GEM	●	●	●
Fiesta	1. 4L	DURATEC 16V	2002 - 2006	IC	●	●	●
Fiesta	1. 4L	DURATEC 16V	2002 - 2006	TCM	●	●	●
Fiesta	1. 4L	DURATEC 16V	2002 - 2008	RCM	●	●	●
Fiesta	1. 4L	DURATEC 16V	2002 - 2013	PCM	●	●	●
Fiesta	1. 4L	DURATEC 16V	2006	EATC	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Fiesta	1.4L	DURATEC 16V	2006 - 2008	ACM	●	●	●
Fiesta	1.4L	DURATEC 16V	2006 - 2008	SRM	●	●	●
Fiesta	1.4L	DURATEC 16V	2008	ABS	●	●	●
Fiesta	1.4L	DURATEC 16V	2008	BCMii	●	●	●
Fiesta	1.4L	DURATEC 16V	2008	FCDIM	●	●	●
Fiesta	1.4L	DURATEC 16V	2008	HVAC	●	●	●
Fiesta	1.4L	DURATEC 16V	2008	IPC	●	●	●
Fiesta	1.4L	DURATEC 16V	2008	PSCM	●	●	●
Fiesta	1.4L	DURATEC 16V	2008	RFA	●	●	●
Fiesta	1.4L	DURATEC 16V	2013	APIM	●	●	●
Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2006	ABS/TCS	●	●	●
Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2006	GEM	●	●	●
Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2006	IC	●	●	●
Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2006	TCM	●	●	●
Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	PCM	●	●	●
Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	RCM	●	●	●
Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	2006	EATC	●	●	●
Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	2006 - 2008	ACM	●	●	●
Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	2006 - 2008	SRM	●	●	●
Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	2008	ABS	●	●	●
Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	2008	BCMii	●	●	●
Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	2008	FCDIM	●	●	●
Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	2008	HVAC	●	●	●
Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	2008	IPC	●	●	●
Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	2008	PSCM	●	●	●
Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection	2008	RFA	●	●	●
Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	ABS	●	●	●
Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	ACM	●	●	●
Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	BCMii	●	●	●
Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	FCDIM	●	●	●
Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	HVAC	●	●	●
Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	IPC	●	●	●
Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	PCM	●	●	●
Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	PSCM	●	●	●
Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	RCM	●	●	●
Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	RFA	●	●	●
Fiesta	1.4L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	SRM	●	●	●
Fiesta	1.5L	BZ	2008	ABS	●	●	●
Fiesta	1.5L	BZ	2008	ACM	●	●	●
Fiesta	1.5L	BZ	2008	BCMii	●	●	●
Fiesta	1.5L	BZ	2008	FCDIM	●	●	●
Fiesta	1.5L	BZ	2008	HVAC	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Fiesta	1.5L	BZ	2008	IPC	●	●	●
Fiesta	1.5L	BZ	2008	PCM	●	●	●
Fiesta	1.5L	BZ	2008	PSCM	●	●	●
Fiesta	1.5L	BZ	2008	RCM	●	●	●
Fiesta	1.5L	BZ	2008	RFA	●	●	●
Fiesta	1.5L	BZ	2008	SRM	●	●	●
Fiesta	1.5L	DURATEC 16V	2013	APIM	●	●	●
Fiesta	1.5L	DURATEC 16V	2013	PCM	●	●	●
Fiesta	1.5L	Duratorq Turbo Diesel Common Rail Injection	2008	ABS	●	●	●
Fiesta	1.5L	Duratorq Turbo Diesel Common Rail Injection	2008	ACM	●	●	●
Fiesta	1.5L	Duratorq Turbo Diesel Common Rail Injection	2008	BCMii	●	●	●
Fiesta	1.5L	Duratorq Turbo Diesel Common Rail Injection	2008	FCDIM	●	●	●
Fiesta	1.5L	Duratorq Turbo Diesel Common Rail Injection	2008	HVAC	●	●	●
Fiesta	1.5L	Duratorq Turbo Diesel Common Rail Injection	2008	IPC	●	●	●
Fiesta	1.5L	Duratorq Turbo Diesel Common Rail Injection	2008	PCM	●	●	●
Fiesta	1.5L	Duratorq Turbo Diesel Common Rail Injection	2008	PSCM	●	●	●
Fiesta	1.5L	Duratorq Turbo Diesel Common Rail Injection	2008	RCM	●	●	●
Fiesta	1.5L	Duratorq Turbo Diesel Common Rail Injection	2008	RFA	●	●	●
Fiesta	1.5L	Duratorq Turbo Diesel Common Rail Injection	2008	SRM	●	●	●
Fiesta	1.5L	Duratorq Turbo Diesel Common Rail Injection StgV	2013	APIM	●	●	●
Fiesta	1.5L	TiVCT	2008	ABS	●	●	●
Fiesta	1.5L	TiVCT	2008	ACM	●	●	●
Fiesta	1.5L	TiVCT	2008	BCMii	●	●	●
Fiesta	1.5L	TiVCT	2008	FCDIM	●	●	●
Fiesta	1.5L	TiVCT	2008	HVAC	●	●	●
Fiesta	1.5L	TiVCT	2008	IPC	●	●	●
Fiesta	1.5L	TiVCT	2008	PSCM	●	●	●
Fiesta	1.5L	TiVCT	2008	RCM	●	●	●
Fiesta	1.5L	TiVCT	2008	RFA	●	●	●
Fiesta	1.5L	TiVCT	2008	SRM	●	●	●
Fiesta	1.5L	TiVCT	2008 - 2013	PCM	●	●	●
Fiesta	1.5L	TiVCT	2013	APIM	●	●	●
Fiesta	1.5L	TiVCT	2013	TCM	●	●	●
Fiesta	1.5L	Zetec-SE	2013	APIM	●	●	●
Fiesta	1.6L	DURATEC 16V	2002	TCM	●	●	●
Fiesta	1.6L	DURATEC 16V	2002 - 2006	ABS/TCS	●	●	●
Fiesta	1.6L	DURATEC 16V	2002 - 2006	GEM	●	●	●
Fiesta	1.6L	DURATEC 16V	2002 - 2006	IC	●	●	●
Fiesta	1.6L	DURATEC 16V	2002 - 2006	PCM	●	●	●
Fiesta	1.6L	DURATEC 16V	2002 - 2006	RCM	●	●	●
Fiesta	1.6L	DURATEC 16V	2006	ACM	●	●	●
Fiesta	1.6L	DURATEC 16V	2006	EATC	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Fiesta	1.6L	DURATEC 16V	2006	SRM	●	●	●
Fiesta	1.6L	DURATEC VCT	2008	ABS	●	●	●
Fiesta	1.6L	DURATEC VCT	2008	ACM	●	●	●
Fiesta	1.6L	DURATEC VCT	2008	BCMii	●	●	●
Fiesta	1.6L	DURATEC VCT	2008	FCDIM	●	●	●
Fiesta	1.6L	DURATEC VCT	2008	HVAC	●	●	●
Fiesta	1.6L	DURATEC VCT	2008	IPC	●	●	●
Fiesta	1.6L	DURATEC VCT	2008	PSCM	●	●	●
Fiesta	1.6L	DURATEC VCT	2008	RCM	●	●	●
Fiesta	1.6L	DURATEC VCT	2008	RFA	●	●	●
Fiesta	1.6L	DURATEC VCT	2008	SRM	●	●	●
Fiesta	1.6L	DURATEC VCT	2008 - 2013	PCM	●	●	●
Fiesta	1.6L	DURATEC VCT	2013	APIM	●	●	●
Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2006	ABS/TCS	●	●	●
Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2006	EPS	●	●	●
Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2006	GEM	●	●	●
Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2006	IC	●	●	●
Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	PCM	●	●	●
Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	RCM	●	●	●
Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	2006	EATC	●	●	●
Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	2006 - 2008	ACM	●	●	●
Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	2006 - 2008	SRM	●	●	●
Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	2008	ABS	●	●	●
Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	2008	BCMii	●	●	●
Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	2008	FCDIM	●	●	●
Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	2008	HVAC	●	●	●
Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	2008	IPC	●	●	●
Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	2008	PSCM	●	●	●
Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	2008	RFA	●	●	●
Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	ABS	●	●	●
Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	ACM	●	●	●
Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	BCMii	●	●	●
Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	FCDIM	●	●	●
Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	HVAC	●	●	●
Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	IPC	●	●	●
Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	PCM	●	●	●
Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	PSCM	●	●	●
Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	RCM	●	●	●
Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	RFA	●	●	●
Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	SRM	●	●	●
Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	2013	APIM	●	●	●
Fiesta	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	APIM	●	●	●



Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Fiesta	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2014	DDM	●	●	●
Fiesta	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2014	FCIM	●	●	●
Fiesta	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2014	GPSM	●	●	●
Fiesta	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2014	HVAC	●	●	●
Fiesta	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2014	RCM	●	●	●
Fiesta	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2014	RFA	●	●	●
Fiesta	1.6L	Sigma	2011 - 2012	ABS	●	●	●
Fiesta	1.6L	Sigma	2011 - 2012	ACM	●	●	●
Fiesta	1.6L	Sigma	2011 - 2012	APIM	●	●	●
Fiesta	1.6L	Sigma	2011 - 2012	BCM#1	●	●	●
Fiesta	1.6L	Sigma	2011 - 2012	FCDIM	●	●	●
Fiesta	1.6L	Sigma	2011 - 2012	GPSM	●	●	●
Fiesta	1.6L	Sigma	2011 - 2012	IPC	●	●	●
Fiesta	1.6L	Sigma	2011 - 2012	OCSM	●	●	●
Fiesta	1.6L	Sigma	2011 - 2012	PCM	●	●	●
Fiesta	1.6L	Sigma	2011 - 2012	PSCM	●	●	●
Fiesta	1.6L	Sigma	2011 - 2012	RCM	●	●	●
Fiesta	1.6L	Sigma	2011 - 2012	RFA	●	●	●
Fiesta	1.6L	Sigma	2011 - 2012	TBM	●	●	●
Fiesta	1.6L	Sigma	2011 - 2012	TCM	●	●	●
Fiesta	1.6L	Sigma	2011 - 2012	VSM	●	●	●
Fiesta	1.6L	TDCi ECO II	2008	ABS	●	●	●
Fiesta	1.6L	TDCi ECO II	2008	ACM	●	●	●
Fiesta	1.6L	TDCi ECO II	2008	BCM i	●	●	●
Fiesta	1.6L	TDCi ECO II	2008	FCDIM	●	●	●
Fiesta	1.6L	TDCi ECO II	2008	HVAC	●	●	●
Fiesta	1.6L	TDCi ECO II	2008	IPC	●	●	●
Fiesta	1.6L	TDCi ECO II	2008	PCM	●	●	●
Fiesta	1.6L	TDCi ECO II	2008	PSCM	●	●	●
Fiesta	1.6L	TDCi ECO II	2008	RCM	●	●	●
Fiesta	1.6L	TDCi ECO II	2008	RFA	●	●	●
Fiesta	1.6L	TDCi ECO II	2008	SRM	●	●	●
Fiesta	1.6L	TDCi ECO II	2013	APIM	●	●	●
Fiesta	1.6L	TiVCT	2008	BCM i	●	●	●
Fiesta	1.6L	TiVCT	2008	SRM	●	●	●
Fiesta	1.6L	TiVCT	2008 - 2013	ABS	●	●	●
Fiesta	1.6L	TiVCT	2008 - 2013	ACM	●	●	●
Fiesta	1.6L	TiVCT	2008 - 2013	FCDIM	●	●	●
Fiesta	1.6L	TiVCT	2008 - 2013	IPC	●	●	●
Fiesta	1.6L	TiVCT	2008 - 2013	PCM	●	●	●
Fiesta	1.6L	TiVCT	2008 - 2013	PSCM	●	●	●
Fiesta	1.6L	TiVCT	2008 - 2013	TCM	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Fiesta	1. 6L	TiVCT	2008 - 2014	HVAC	●	●	●
Fiesta	1. 6L	TiVCT	2008 - 2014	RCM	●	●	●
Fiesta	1. 6L	TiVCT	2008 - 2014	RFA	●	●	●
Fiesta	1. 6L	TiVCT	2011 - 2013	BCM#1	●	●	●
Fiesta	1. 6L	TiVCT	2011 - 2013	OCSM	●	●	●
Fiesta	1. 6L	TiVCT	2011 - 2013	VSM	●	●	●
Fiesta	1. 6L	TiVCT	2011 - 2014	APIM	●	●	●
Fiesta	1. 6L	TiVCT	2011 - 2014	GPSM	●	●	●
Fiesta	1. 6L	TiVCT	2014	DDM	●	●	●
Fiesta	1. 6L	TiVCT	2014	FCIM	●	●	●
Fiesta / Ikon	1 4 DV4	Duratorq Turbo Diesel Common Rail Injection	2006	ABS/TCS	●	●	●
Fiesta / Ikon	1 4 DV4	Duratorq Turbo Diesel Common Rail Injection	2006	GEM	●	●	●
Fiesta / Ikon	1 4 DV4	Duratorq Turbo Diesel Common Rail Injection	2006	IC	●	●	●
Fiesta / Ikon	1 4 DV4	Duratorq Turbo Diesel Common Rail Injection	2006	PCM	●	●	●
Fiesta / Ikon	1 4 DV4	Duratorq Turbo Diesel Common Rail Injection	2006	RCM	●	●	●
Fiesta / Ikon	1. 4L	DURATEC 16V	2006	ABS/TCS	●	●	●
Fiesta / Ikon	1. 4L	DURATEC 16V	2006	GEM	●	●	●
Fiesta / Ikon	1. 4L	DURATEC 16V	2006	IC	●	●	●
Fiesta / Ikon	1. 4L	DURATEC 16V	2006	PCM	●	●	●
Fiesta / Ikon	1. 4L	DURATEC 16V	2006	RCM	●	●	●
Fiesta / Ikon	1. 6L	DURATEC 16V	2006	ABS/TCS	●	●	●
Fiesta / Ikon	1. 6L	DURATEC 16V	2006	GEM	●	●	●
Fiesta / Ikon	1. 6L	DURATEC 16V	2006	IC	●	●	●
Fiesta / Ikon	1. 6L	DURATEC 16V	2006	PCM	●	●	●
Fiesta / Ikon	1. 6L	DURATEC 16V	2006	RCM	●	●	●
Fiesta / Mazda 121 / Bantam	1. 0L	HCS	1996 - 1999	ABS/TCS	●	●	●
Fiesta / Mazda 121 / Bantam	1. 0L	HCS	1996 - 1999	CSM	●	●	●
Fiesta / Mazda 121 / Bantam	1. 0L	HCS	1996 - 1999	HEC	●	●	●
Fiesta / Mazda 121 / Bantam	1. 0L	HCS	1996 - 1999	PCM	●	●	●
Fiesta / Mazda 121 / Bantam	1. 0L	HCS	1999	ECS	●	●	●
Fiesta / Mazda 121 / Bantam	1. 0L	Zetec Rocam	1999	ABS/TCS	●	●	●
Fiesta / Mazda 121 / Bantam	1. 0L	Zetec Rocam	1999	CSM	●	●	●
Fiesta / Mazda 121 / Bantam	1. 0L	Zetec Rocam	1999	ECS	●	●	●
Fiesta / Mazda 121 / Bantam	1. 0L	Zetec Rocam	1999	GEM	●	●	●
Fiesta / Mazda 121 / Bantam	1. 0L	Zetec Rocam	1999	HEC	●	●	●
Fiesta / Mazda 121 / Bantam	1. 0L	Zetec Rocam	1999	PCM	●	●	●
Fiesta / Mazda 121 / Bantam	1. 25L	Zetec-SE	1996 - 2000	ABS/TCS	●	●	●
Fiesta / Mazda 121 / Bantam	1. 25L	Zetec-SE	1996 - 2000	CSM	●	●	●
Fiesta / Mazda 121 / Bantam	1. 25L	Zetec-SE	1996 - 2000	HEC	●	●	●
Fiesta / Mazda 121 / Bantam	1. 25L	Zetec-SE	1996 - 2000	PCM	●	●	●
Fiesta / Mazda 121 / Bantam	1. 25L	Zetec-SE	1999 - 2000	ECS	●	●	●
Fiesta / Mazda 121 / Bantam	1. 25L	Zetec-SE	1999 - 2000	GEM	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Fiesta / Mazda 121 / Bantam	1. 25L	Zetec-SE	2000	PATS	●	●	●
Fiesta / Mazda 121 / Bantam	1. 3L	Endura-E	1996 - 1999	ABS/TCS	●	●	●
Fiesta / Mazda 121 / Bantam	1. 3L	Endura-E	1996 - 1999	CSM	●	●	●
Fiesta / Mazda 121 / Bantam	1. 3L	Endura-E	1996 - 1999	HEC	●	●	●
Fiesta / Mazda 121 / Bantam	1. 3L	Endura-E	1996 - 1999	PCM	●	●	●
Fiesta / Mazda 121 / Bantam	1. 3L	Endura-E	1999	ECS	●	●	●
Fiesta / Mazda 121 / Bantam	1. 3L	Endura-E	1999	GEM	●	●	●
Fiesta / Mazda 121 / Bantam	1. 4L	1. 4 PT-E SFI	1994 - 1996	ABS/TCS	●	●	●
Fiesta / Mazda 121 / Bantam	1. 4L	1. 4 PT-E SFI	1994 - 1996	CSM	●	●	●
Fiesta / Mazda 121 / Bantam	1. 4L	1. 4 PT-E SFI	1994 - 1996	HEC	●	●	●
Fiesta / Mazda 121 / Bantam	1. 4L	PT-E	2000	ABS/TCS	●	●	●
Fiesta / Mazda 121 / Bantam	1. 4L	PT-E	2000	CSM	●	●	●
Fiesta / Mazda 121 / Bantam	1. 4L	PT-E	2000	ECS	●	●	●
Fiesta / Mazda 121 / Bantam	1. 4L	PT-E	2000	HEC	●	●	●
Fiesta / Mazda 121 / Bantam	1. 4L	PT-E	2000	PCM	●	●	●
Fiesta / Mazda 121 / Bantam	1. 4L	Zetec-SE	1996 - 1999	ABS/TCS	●	●	●
Fiesta / Mazda 121 / Bantam	1. 4L	Zetec-SE	1996 - 1999	CSM	●	●	●
Fiesta / Mazda 121 / Bantam	1. 4L	Zetec-SE	1996 - 1999	HEC	●	●	●
Fiesta / Mazda 121 / Bantam	1. 4L	Zetec-SE	1996 - 1999	PCM	●	●	●
Fiesta / Mazda 121 / Bantam	1. 4L	Zetec-SE	1999	ECS	●	●	●
Fiesta / Mazda 121 / Bantam	1. 4L	Zetec-SE	1999	GEM	●	●	●
Fiesta / Mazda 121 / Bantam	1. 6L	Other	2001	ABS/TCS	●	●	●
Fiesta / Mazda 121 / Bantam	1. 6L	Other	2001	CSM	●	●	●
Fiesta / Mazda 121 / Bantam	1. 6L	Other	2001	GEM	●	●	●
Fiesta / Mazda 121 / Bantam	1. 6L	Other	2001	HEC	●	●	●
Fiesta / Mazda 121 / Bantam	1. 6L	Other	2001	PATS	●	●	●
Fiesta / Mazda 121 / Bantam	1. 6L	Other	2001	PCM	●	●	●
Fiesta / Mazda 121 / Bantam	1. 6L	Zetec Rocam	1999	ABS/TCS	●	●	●
Fiesta / Mazda 121 / Bantam	1. 6L	Zetec Rocam	1999	CSM	●	●	●
Fiesta / Mazda 121 / Bantam	1. 6L	Zetec Rocam	1999	ECS	●	●	●
Fiesta / Mazda 121 / Bantam	1. 6L	Zetec Rocam	1999	GEM	●	●	●
Fiesta / Mazda 121 / Bantam	1. 6L	Zetec Rocam	1999	HEC	●	●	●
Fiesta / Mazda 121 / Bantam	1. 6L	Zetec Rocam	1999	PCM	●	●	●
Fiesta / Mazda 121 / Bantam	1. 6L	Zetec-SE	2000	ABS/TCS	●	●	●
Fiesta / Mazda 121 / Bantam	1. 6L	Zetec-SE	2000	CSM	●	●	●
Fiesta / Mazda 121 / Bantam	1. 6L	Zetec-SE	2000	ECS	●	●	●
Fiesta / Mazda 121 / Bantam	1. 6L	Zetec-SE	2000	GEM	●	●	●
Fiesta / Mazda 121 / Bantam	1. 6L	Zetec-SE	2000	HEC	●	●	●
Fiesta / Mazda 121 / Bantam	1. 6L	Zetec-SE	2000	PCM	●	●	●
Fiesta / Mazda 121 / Bantam	1. 8L	Endura DI	2000	ABS/TCS	●	●	●
Fiesta / Mazda 121 / Bantam	1. 8L	Endura DI	2000	CSM	●	●	●
Fiesta / Mazda 121 / Bantam	1. 8L	Endura DI	2000	ECS	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Fiesta / Mazda 121 / Bantam	1. 8L	Endura DI	2000	FIP	●	●	●
Fiesta / Mazda 121 / Bantam	1. 8L	Endura DI	2000	GEM	●	●	●
Fiesta / Mazda 121 / Bantam	1. 8L	Endura DI	2000	HEC	●	●	●
Fiesta / Mazda 121 / Bantam	1. 8L	Endura DI	2000	PATS	●	●	●
Fiesta / Mazda 121 / Bantam	1. 8L	Endura DI	2000	PCM	●	●	●
Fiesta / Mazda 121 / Bantam	1. 8L	Endura-DE	1996 - Other	ABS/TCS	●	●	●
Fiesta / Mazda 121 / Bantam	1. 8L	Endura-DE	1996 - Other	CSM	●	●	●
Fiesta / Mazda 121 / Bantam	1. 8L	Endura-DE	1996 - Other	ECS	●	●	●
Fiesta / Mazda 121 / Bantam	1. 8L	Endura-DE	1996 - Other	HEC	●	●	●
Fiesta / Mazda 121 / Bantam	1. 8L	Endura-DE	1996 - Other	PATS	●	●	●
Fiesta / Mazda 121 / Bantam	1. 8L	Endura-DE	1996 - Other	PCM	○	○	●
Fiesta / Mazda 121 / Bantam	1. 8L	Zetec	1992 - 1994	ABS/TCS	●	●	●
Fiesta / Mazda 121 / Bantam	1. 8L	Zetec	1992 - 1994	CSM	●	●	●
Fiesta / Mazda 121 / Bantam	1. 8L	Zetec	1992 - 1994	HEC	●	●	●
Fiesta 3-Door	1. 25L	DURATEC 16V	2002 - 2006	ABS/TCS	●	●	●
Fiesta 3-Door	1. 25L	DURATEC 16V	2002 - 2006	GEM	●	●	●
Fiesta 3-Door	1. 25L	DURATEC 16V	2002 - 2006	IC	●	●	●
Fiesta 3-Door	1. 25L	DURATEC 16V	2002 - 2006	PCM	●	●	●
Fiesta 3-Door	1. 25L	DURATEC 16V	2002 - 2006	RCM	●	●	●
Fiesta 3-Door	1. 25L	DURATEC 16V	2006	ACM	●	●	●
Fiesta 3-Door	1. 25L	DURATEC 16V	2006	EATC	●	●	●
Fiesta 3-Door	1. 25L	DURATEC 16V	2006	SRM	●	●	●
Fiesta 3-Door	1. 3L	DURATEC 8V	2002 - 2006	ABS/TCS	●	●	●
Fiesta 3-Door	1. 3L	DURATEC 8V	2002 - 2006	GEM	●	●	●
Fiesta 3-Door	1. 3L	DURATEC 8V	2002 - 2006	IC	●	●	●
Fiesta 3-Door	1. 3L	DURATEC 8V	2002 - 2006	PCM	●	●	●
Fiesta 3-Door	1. 3L	DURATEC 8V	2002 - 2006	RCM	●	●	●
Fiesta 3-Door	1. 3L	DURATEC 8V	2006	ACM	●	●	●
Fiesta 3-Door	1. 3L	DURATEC 8V	2006	EATC	●	●	●
Fiesta 3-Door	1. 3L	DURATEC 8V	2006	SRM	●	●	●
Fiesta 3-Door	1. 4L	DURATEC 16V	2002 - 2006	ABS/TCS	●	●	●
Fiesta 3-Door	1. 4L	DURATEC 16V	2002 - 2006	GEM	●	●	●
Fiesta 3-Door	1. 4L	DURATEC 16V	2002 - 2006	IC	●	●	●
Fiesta 3-Door	1. 4L	DURATEC 16V	2002 - 2006	PCM	●	●	●
Fiesta 3-Door	1. 4L	DURATEC 16V	2002 - 2006	RCM	●	●	●
Fiesta 3-Door	1. 4L	DURATEC 16V	2002 - 2006	TCM	●	●	●
Fiesta 3-Door	1. 4L	DURATEC 16V	2006	ACM	●	●	●
Fiesta 3-Door	1. 4L	DURATEC 16V	2006	EATC	●	●	●
Fiesta 3-Door	1. 4L	DURATEC 16V	2006	SRM	●	●	●
Fiesta 3-Door	1. 4L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2006	ABS/TCS	●	●	●
Fiesta 3-Door	1. 4L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2006	GEM	●	●	●
Fiesta 3-Door	1. 4L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2006	IC	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Fiesta 3-Door	1.4L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2006	PCM	●	●	●
Fiesta 3-Door	1.4L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2006	RCM	●	●	●
Fiesta 3-Door	1.4L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2006	TCM	●	●	●
Fiesta 3-Door	1.4L	Duratorq Turbo Diesel Common Rail Injection	2006	ACM	●	●	●
Fiesta 3-Door	1.4L	Duratorq Turbo Diesel Common Rail Injection	2006	EATC	●	●	●
Fiesta 3-Door	1.4L	Duratorq Turbo Diesel Common Rail Injection	2006	SRM	●	●	●
Fiesta 3-Door	1.6L	DURATEC 16V	2002	TCM	●	●	●
Fiesta 3-Door	1.6L	DURATEC 16V	2002 - 2006	ABS/TCS	●	●	●
Fiesta 3-Door	1.6L	DURATEC 16V	2002 - 2006	GEM	●	●	●
Fiesta 3-Door	1.6L	DURATEC 16V	2002 - 2006	IC	●	●	●
Fiesta 3-Door	1.6L	DURATEC 16V	2002 - 2006	PCM	●	●	●
Fiesta 3-Door	1.6L	DURATEC 16V	2002 - 2006	RCM	●	●	●
Fiesta 3-Door	1.6L	DURATEC 16V	2006	ACM	●	●	●
Fiesta 3-Door	1.6L	DURATEC 16V	2006	EATC	●	●	●
Fiesta 3-Door	1.6L	DURATEC 16V	2006	SRM	●	●	●
Fiesta 3-Door	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2006	ABS/TCS	●	●	●
Fiesta 3-Door	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2006	EPS	●	●	●
Fiesta 3-Door	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2006	GEM	●	●	●
Fiesta 3-Door	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2006	IC	●	●	●
Fiesta 3-Door	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2006	PCM	●	●	●
Fiesta 3-Door	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2006	RCM	●	●	●
Fiesta 3-Door	1.6L	Duratorq Turbo Diesel Common Rail Injection	2006	ACM	●	●	●
Fiesta 3-Door	1.6L	Duratorq Turbo Diesel Common Rail Injection	2006	EATC	●	●	●
Fiesta 3-Door	1.6L	Duratorq Turbo Diesel Common Rail Injection	2006	SRM	●	●	●
Fiesta 3-Door	2.0L	DURATEC-HE / I4	2002 - 2006	ABS/TCS	●	●	●
Fiesta 3-Door	2.0L	DURATEC-HE / I4	2002 - 2006	GEM	●	●	●
Fiesta 3-Door	2.0L	DURATEC-HE / I4	2002 - 2006	IC	●	●	●
Fiesta 3-Door	2.0L	DURATEC-HE / I4	2002 - 2006	PCM	●	●	●
Fiesta 3-Door	2.0L	DURATEC-HE / I4	2002 - 2006	RCM	●	●	●
Fiesta 3-Door	2.0L	DURATEC-HE / I4	2006	ACM	●	●	●
Fiesta 3-Door	2.0L	DURATEC-HE / I4	2006	EATC	●	●	●
Fiesta 3-Door	2.0L	DURATEC-HE / I4	2006	SRM	●	●	●
Five Hundred	3.0L	4V	2006 - 2007	4X4	●	●	●
Five Hundred	3.0L	4V	2006 - 2007	ABS	●	●	●
Five Hundred	3.0L	4V	2006 - 2007	ACM	●	●	●
Five Hundred	3.0L	4V	2006 - 2007	DSM	●	●	●
Five Hundred	3.0L	4V	2006 - 2007	EATC	●	●	●
Five Hundred	3.0L	4V	2006 - 2007	GEM	●	●	●
Five Hundred	3.0L	4V	2006 - 2007	IC	●	●	●
Five Hundred	3.0L	4V	2006 - 2007	PAM	●	●	●
Five Hundred	3.0L	4V	2006 - 2007	PCM	●	●	●
Five Hundred	3.0L	4V	2006 - 2007	RCM	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Five Hundred	3.0L	4V	2006 - 2007	RETM	●	●	●
Five Hundred	3.0L	4V	2006 - 2007	TCM	●	●	●
Five Hundred	3.0L	4V	2007	SDARS	●	●	●
Five Hundred (MY05) / Montego (MY05)	3.0L	4V	2005	4X4	●	●	●
Five Hundred (MY05) / Montego (MY05)	3.0L	4V	2005	ABS	●	●	●
Five Hundred (MY05) / Montego (MY05)	3.0L	4V	2005	ACM	●	●	●
Five Hundred (MY05) / Montego (MY05)	3.0L	4V	2005	DSM	●	●	●
Five Hundred (MY05) / Montego (MY05)	3.0L	4V	2005	EATC	●	●	●
Five Hundred (MY05) / Montego (MY05)	3.0L	4V	2005	GEM	●	●	●
Five Hundred (MY05) / Montego (MY05)	3.0L	4V	2005	IC	●	●	●
Five Hundred (MY05) / Montego (MY05)	3.0L	4V	2005	PAM	●	●	●
Five Hundred (MY05) / Montego (MY05)	3.0L	4V	2005	PCM	●	●	●
Five Hundred (MY05) / Montego (MY05)	3.0L	4V	2005	RCM	●	●	●
Five Hundred (MY05) / Montego (MY05)	3.0L	4V	2005	RETM	●	●	●
Five Hundred (MY05) / Montego (MY05)	3.0L	4V	2005	TCM	●	●	●
Flex	3.5L	4V	2009	SECM	●	●	○
Flex	3.5L	4V	2009 - 2012	4X4	●	●	●
Flex	3.5L	4V	2009 - 2012	ABS	●	●	●
Flex	3.5L	4V	2009 - 2012	ACM	●	●	●
Flex	3.5L	4V	2009 - 2012	APIM	●	●	●
Flex	3.5L	4V	2009 - 2012	DCSM	●	●	●
Flex	3.5L	4V	2009 - 2012	DSM	●	●	●
Flex	3.5L	4V	2009 - 2012	DSP	●	●	●
Flex	3.5L	4V	2009 - 2012	FCIM	●	●	●
Flex	3.5L	4V	2009 - 2012	GEM / SJB	●	●	●
Flex	3.5L	4V	2009 - 2012	HVAC	●	●	●
Flex	3.5L	4V	2009 - 2012	IC	●	●	●
Flex	3.5L	4V	2009 - 2012	LTM	●	●	●
Flex	3.5L	4V	2009 - 2012	OCSM	●	●	●
Flex	3.5L	4V	2009 - 2012	PAM	●	●	●
Flex	3.5L	4V	2009 - 2012	PCM	●	●	●
Flex	3.5L	4V	2009 - 2012	RCM	●	●	●
Flex	3.5L	4V	2009 - 2012	RETM	●	●	●
Flex	3.5L	4V	2010 - 2011	C-CM	●	●	●
Flex	3.5L	4V	2010 - 2011	HUD	●	●	●
Flex	3.5L	4V	2010 - 2012	DDM	●	●	●
Flex	3.5L	4V	2010 - 2012	GPSM	●	●	●
Flex	3.5L	4V	2010 - 2012	HCM	●	●	●
Flex	3.5L	4V	2010 - 2012	HCM-2	●	●	●
Flex	3.5L	4V	2010 - 2012	IHCM	●	●	●
Flex	3.5L	4V	2010 - 2012	PSCM	●	●	●
Flex	3.5L	4V	2010 - 2012	SASM	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2012	4X4	●	●	●
Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2012	GEM / SJB	●	●	●
Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2012	HCM-2	●	●	●
Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2012	IC	●	●	●
Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2012	IHCM	●	●	●
Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2012	RETM	●	●	●
Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2012	SASM	●	●	●
Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2013	C-CM	●	●	●
Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2013	DCSM	●	●	●
Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2013	LTM	●	●	●
Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2013	OCSM	●	●	●
Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2013	PCM	●	●	●
Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2014	ABS	●	●	●
Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2014	ACM	●	●	●
Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2014	APIM	●	●	●
Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2014	DDM	●	●	●
Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2014	DSM	●	●	●
Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2014	DSP	●	●	●
Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2014	FCIM	●	●	●
Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2014	GPSM	●	●	●
Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2014	HCM	●	●	●
Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2014	HUD	●	●	●
Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2014	HVAC	●	●	●
Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2014	PAM	●	●	●
Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2014	PSCM	●	●	●
Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2014	RCM	●	●	●
Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	BCM#1	●	●	●
Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	FCDIM	●	●	●
Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	IPC	●	●	●
Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	RACM	●	●	●
Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	RFA	●	●	●
Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	RTM	●	●	●
Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	SCCM	●	●	●
Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	SOD-L	●	●	●
Flex	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	SOD-R	●	●	●
Flex	3.5L	TiVCT	2013	BCM#1	●	●	●
Flex	3.5L	TiVCT	2013	C-CM	●	●	●
Flex	3.5L	TiVCT	2013	DCSM	●	●	●
Flex	3.5L	TiVCT	2013	FCDIM	●	●	●
Flex	3.5L	TiVCT	2013	IPC	●	●	●
Flex	3.5L	TiVCT	2013	LTM	●	●	●
Flex	3.5L	TiVCT	2013	OCSM	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Flex	3.5L	TiVCT	2013	PCM	●	●	●
Flex	3.5L	TiVCT	2013 - 2014	ABS	●	●	●
Flex	3.5L	TiVCT	2013 - 2014	ACM	●	●	●
Flex	3.5L	TiVCT	2013 - 2014	APIM	●	●	●
Flex	3.5L	TiVCT	2013 - 2014	DDM	●	●	●
Flex	3.5L	TiVCT	2013 - 2014	DSM	●	●	●
Flex	3.5L	TiVCT	2013 - 2014	DSP	●	●	●
Flex	3.5L	TiVCT	2013 - 2014	FCIM	●	●	●
Flex	3.5L	TiVCT	2013 - 2014	GPSM	●	●	●
Flex	3.5L	TiVCT	2013 - 2014	HCM	●	●	●
Flex	3.5L	TiVCT	2013 - 2014	HUD	●	●	●
Flex	3.5L	TiVCT	2013 - 2014	HVAC	●	●	●
Flex	3.5L	TiVCT	2013 - 2014	PAM	●	●	●
Flex	3.5L	TiVCT	2013 - 2014	PSCM	●	●	●
Flex	3.5L	TiVCT	2013 - 2014	RACM	●	●	●
Flex	3.5L	TiVCT	2013 - 2014	RCM	●	●	●
Flex	3.5L	TiVCT	2013 - 2014	RFA	●	●	●
Flex	3.5L	TiVCT	2013 - 2014	RTM	●	●	●
Flex	3.5L	TiVCT	2013 - 2014	SCCM	●	●	●
Flex	3.5L	TiVCT	2013 - 2014	SOD-L	●	●	●
Flex	3.5L	TiVCT	2013 - 2014	SOD-R	●	●	●
Flex	Other	Other	2012	4X4	●	●	●
Flex	Other	Other	2012	DCSM	●	●	●
Flex	Other	Other	2012	GEM / SJB	●	●	●
Flex	Other	Other	2012	HCM-2	●	●	●
Flex	Other	Other	2012	IC	●	●	●
Flex	Other	Other	2012	IHCM	●	●	●
Flex	Other	Other	2012	LTM	●	●	●
Flex	Other	Other	2012	OCSM	●	●	●
Flex	Other	Other	2012	RETM	●	●	●
Flex	Other	Other	2012	SASM	●	●	●
Flex	Other	Other	2012 - 2014	ABS	●	●	●
Flex	Other	Other	2012 - 2014	ACM	●	●	●
Flex	Other	Other	2012 - 2014	APIM	●	●	●
Flex	Other	Other	2012 - 2014	DDM	●	●	●
Flex	Other	Other	2012 - 2014	DSM	●	●	●
Flex	Other	Other	2012 - 2014	DSP	●	●	●
Flex	Other	Other	2012 - 2014	FCIM	●	●	●
Flex	Other	Other	2012 - 2014	GPSM	●	●	●
Flex	Other	Other	2012 - 2014	HCM	●	●	●
Flex	Other	Other	2012 - 2014	HVAC	●	●	●
Flex	Other	Other	2012 - 2014	PAM	●	●	●



Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Flex	Other	Other	2012 - 2014	PSCM	●	●	●
Flex	Other	Other	2012 - 2014	RCM	●	●	●
Flex	Other	Other	2014	HUD	●	●	●
Flex	Other	Other	2014	RACM	●	●	●
Flex	Other	Other	2014	RFA	●	●	●
Flex	Other	Other	2014	RTM	●	●	●
Flex	Other	Other	2014	SCCM	●	●	●
Flex	Other	Other	2014	SOD-L	●	●	●
Flex	Other	Other	2014	SOD-R	●	●	●
Focus	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	ABS	●	●	●
Focus	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	ACM	●	●	●
Focus	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	AHCM	●	●	●
Focus	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	APIM	●	●	●
Focus	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	BCMii	●	●	●
Focus	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	CCMii	●	●	●
Focus	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	DDM	●	●	●
Focus	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	DSP	●	●	●
Focus	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	FCDIM	●	●	●
Focus	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	FCIM	●	●	●
Focus	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	FDSM	●	●	●
Focus	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	HCM	●	●	●
Focus	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	HVAC	●	●	●
Focus	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	IPC	●	●	●
Focus	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	IPM-A	●	●	●
Focus	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	IPM-B	●	●	●
Focus	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	PAM	●	●	●
Focus	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	PCM	●	●	●
Focus	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	PDM	●	●	●
Focus	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	PSCM	●	●	●
Focus	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	RCM	●	●	●
Focus	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	RFA	●	●	●
Focus	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	SASM	●	●	●
Focus	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	SOD-L	●	●	●
Focus	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	SOD-R	●	●	●
Focus	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	SRM	●	●	●
Focus	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	TRM	●	●	●
Focus	1.4L	DURATEC 16V	2003	RL_DCU	●	●	●
Focus	1.4L	DURATEC 16V	2003	RR_DCU	●	●	●
Focus	1.4L	DURATEC 16V	2003 - 2007	GDM	●	●	●
Focus	1.4L	DURATEC 16V	2003 - 2007	NAV	●	●	●
Focus	1.4L	DURATEC 16V	2003 - 2008	ABS	●	●	●
Focus	1.4L	DURATEC 16V	2003 - 2008	ACM	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Focus	1. 4L	DURATEC 16V	2003 - 2008	CDP	●	●	●
Focus	1. 4L	DURATEC 16V	2003 - 2008	D_DCU	●	●	●
Focus	1. 4L	DURATEC 16V	2003 - 2008	EATC	●	●	●
Focus	1. 4L	DURATEC 16V	2003 - 2008	FFH	●	●	●
Focus	1. 4L	DURATEC 16V	2003 - 2008	GEM	●	●	●
Focus	1. 4L	DURATEC 16V	2003 - 2008	HCM	●	●	●
Focus	1. 4L	DURATEC 16V	2003 - 2008	IC	●	●	●
Focus	1. 4L	DURATEC 16V	2003 - 2008	PAM	●	●	●
Focus	1. 4L	DURATEC 16V	2003 - 2008	PCM	●	●	●
Focus	1. 4L	DURATEC 16V	2003 - 2008	P_DCU	●	●	●
Focus	1. 4L	DURATEC 16V	2003 - 2008	RCM	●	●	●
Focus	1. 4L	DURATEC 16V	2003 - 2008	RETM	●	●	●
Focus	1. 4L	DURATEC 16V	2003 - 2008	RKE	●	●	●
Focus	1. 4L	DURATEC 16V	2003 - 2008	SRM	●	●	●
Focus	1. 4L	DURATEC 16V	2008	CMR	●	●	●
Focus	1. 4L	DURATEC 16V	2008	EPS	●	●	●
Focus	1. 4L	Zetec-SE	1999	CSM	●	●	●
Focus	1. 4L	Zetec-SE	1999	CTM	●	●	●
Focus	1. 4L	Zetec-SE	1999 - 2002	ABS/TCS	●	●	●
Focus	1. 4L	Zetec-SE	1999 - 2002	ECS	●	●	●
Focus	1. 4L	Zetec-SE	1999 - 2002	HEC	●	●	●
Focus	1. 4L	Zetec-SE	1999 - 2002	MC	●	●	●
Focus	1. 4L	Zetec-SE	1999 - 2002	PATS	●	●	●
Focus	1. 4L	Zetec-SE	1999 - 2002	PCM	●	●	●
Focus	1. 4L	Zetec-SE	2002	EATC	●	●	●
Focus	1. 4L	Zetec-SE	2002	GEM	●	●	●
Focus	1. 4L	Zetec-SE	2002	HCM	●	●	●
Focus	1. 4L	Zetec-SE	2002	RCM	●	●	●
Focus	1. 6L	BZ	2005	ABS	●	●	●
Focus	1. 6L	BZ	2005	D_DCU	●	●	●
Focus	1. 6L	BZ	2005	EATC	●	●	●
Focus	1. 6L	BZ	2005	GEM	●	●	●
Focus	1. 6L	BZ	2005	HCM	●	●	●
Focus	1. 6L	BZ	2005	IC	●	●	●
Focus	1. 6L	BZ	2005	PAM	●	●	●
Focus	1. 6L	BZ	2005	PCM	●	●	●
Focus	1. 6L	BZ	2005	P_DCU	●	●	●
Focus	1. 6L	BZ	2005	RCM	●	●	●
Focus	1. 6L	BZ	2005	RL_DCU	●	●	●
Focus	1. 6L	BZ	2005	RR_DCU	●	●	●
Focus	1. 6L	DURATEC 16V	2003	RL_DCU	●	●	●
Focus	1. 6L	DURATEC 16V	2003	RR_DCU	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Focus	1. 6L	DURATEC 16V	2003 - 2007	GDM	●	●	●
Focus	1. 6L	DURATEC 16V	2003 - 2007	NAV	●	●	●
Focus	1. 6L	DURATEC 16V	2003 - 2007	RETM	●	●	●
Focus	1. 6L	DURATEC 16V	2003 - 2008	ABS	●	●	●
Focus	1. 6L	DURATEC 16V	2003 - 2008	ACM	●	●	●
Focus	1. 6L	DURATEC 16V	2003 - 2008	CDP	●	●	●
Focus	1. 6L	DURATEC 16V	2003 - 2008	D_DCU	●	●	●
Focus	1. 6L	DURATEC 16V	2003 - 2008	EATC	●	●	●
Focus	1. 6L	DURATEC 16V	2003 - 2008	FFH	●	●	●
Focus	1. 6L	DURATEC 16V	2003 - 2008	GEM	●	●	●
Focus	1. 6L	DURATEC 16V	2003 - 2008	HCM	●	●	●
Focus	1. 6L	DURATEC 16V	2003 - 2008	IC	●	●	●
Focus	1. 6L	DURATEC 16V	2003 - 2008	PAM	●	●	●
Focus	1. 6L	DURATEC 16V	2003 - 2008	PCM	●	●	●
Focus	1. 6L	DURATEC 16V	2003 - 2008	P_DCU	●	●	●
Focus	1. 6L	DURATEC 16V	2003 - 2008	RCM	●	●	●
Focus	1. 6L	DURATEC 16V	2003 - 2008	RKE	●	●	●
Focus	1. 6L	DURATEC 16V	2003 - 2008	SRM	●	●	●
Focus	1. 6L	DURATEC 16V	2006 - 2008	FTCM	●	●	●
Focus	1. 6L	DURATEC 16V	2007	TCM	●	●	●
Focus	1. 6L	DURATEC 16V	2008	EPS	●	●	●
Focus	1. 6L	DURATEC VCT	2003	RL_DCU	●	●	●
Focus	1. 6L	DURATEC VCT	2003	RR_DCU	●	●	●
Focus	1. 6L	DURATEC VCT	2003 - 2007	GDM	●	●	●
Focus	1. 6L	DURATEC VCT	2003 - 2007	NAV	●	●	●
Focus	1. 6L	DURATEC VCT	2003 - 2008	CDP	●	●	●
Focus	1. 6L	DURATEC VCT	2003 - 2008	D_DCU	●	●	●
Focus	1. 6L	DURATEC VCT	2003 - 2008	EATC	●	●	●
Focus	1. 6L	DURATEC VCT	2003 - 2008	FFH	●	●	●
Focus	1. 6L	DURATEC VCT	2003 - 2008	GEM	●	●	●
Focus	1. 6L	DURATEC VCT	2003 - 2008	IC	●	●	●
Focus	1. 6L	DURATEC VCT	2003 - 2008	P_DCU	●	●	●
Focus	1. 6L	DURATEC VCT	2003 - 2008	RETM	●	●	●
Focus	1. 6L	DURATEC VCT	2003 - 2008	RKE	●	●	●
Focus	1. 6L	DURATEC VCT	2003 - 2011	ABS	●	●	●
Focus	1. 6L	DURATEC VCT	2003 - 2011	ACM	●	●	●
Focus	1. 6L	DURATEC VCT	2003 - 2011	HCM	●	●	●
Focus	1. 6L	DURATEC VCT	2003 - 2011	PAM	●	●	●
Focus	1. 6L	DURATEC VCT	2003 - 2011	PCM	●	●	●
Focus	1. 6L	DURATEC VCT	2003 - 2011	RCM	●	●	●
Focus	1. 6L	DURATEC VCT	2003 - 2011	SRM	●	●	●
Focus	1. 6L	DURATEC VCT	2008	CMR	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Focus	1.6L	DURATEC VCT	2008	EPS	●	●	●
Focus	1.6L	DURATEC VCT	2011	AHCM	●	●	●
Focus	1.6L	DURATEC VCT	2011	APIM	●	●	●
Focus	1.6L	DURATEC VCT	2011	BCMii	●	●	●
Focus	1.6L	DURATEC VCT	2011	CCMii	●	●	●
Focus	1.6L	DURATEC VCT	2011	DDM	●	●	●
Focus	1.6L	DURATEC VCT	2011	DSP	●	●	●
Focus	1.6L	DURATEC VCT	2011	FCDIM	●	●	●
Focus	1.6L	DURATEC VCT	2011	FCIM	●	●	●
Focus	1.6L	DURATEC VCT	2011	FDSM	●	●	●
Focus	1.6L	DURATEC VCT	2011	HVAC	●	●	●
Focus	1.6L	DURATEC VCT	2011	IPC	●	●	●
Focus	1.6L	DURATEC VCT	2011	IPM-A	●	●	●
Focus	1.6L	DURATEC VCT	2011	IPM-B	●	●	●
Focus	1.6L	DURATEC VCT	2011	PDM	●	●	●
Focus	1.6L	DURATEC VCT	2011	PSCM	●	●	●
Focus	1.6L	DURATEC VCT	2011	RFA	●	●	●
Focus	1.6L	DURATEC VCT	2011	SASM	●	●	●
Focus	1.6L	DURATEC VCT	2011	SOD-L	●	●	●
Focus	1.6L	DURATEC VCT	2011	SOD-R	●	●	●
Focus	1.6L	DURATEC VCT	2011	TCM	●	●	●
Focus	1.6L	DURATEC VCT	2011	TRM	●	●	●
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2003	RL_DCU	●	●	●
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2003	RR_DCU	●	●	●
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2007	GDM	●	●	●
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2007	NAV	●	●	●
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2008	CDP	●	●	●
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2008	D_DCU	●	●	●
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2008	EATC	●	●	●
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2008	EPS	●	●	●
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2008	FACM	●	●	●
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2008	FFH	●	●	●
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2008	GEM	●	●	●
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2008	IC	●	●	●
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2008	P_DCU	●	●	●
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2008	RETM	●	●	●
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2008	RKE	●	●	●
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2011	ABS	●	●	●
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2011	ACM	●	●	●
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2011	HCM	●	●	●
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2011	PAM	●	●	●
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2011	PCM	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2011	RCM	●	●	●
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2011	SRM	●	●	●
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2008	CMR	●	●	●
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	AHCM	●	●	●
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	APIM	●	●	●
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	BCMii	●	●	●
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	CCMii	●	●	●
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	DDM	●	●	●
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	DSP	●	●	●
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	FCDIM	●	●	●
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	FCIM	●	●	●
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	FDSM	●	●	●
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	HVAC	●	●	●
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	IPC	●	●	●
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	IPM-A	●	●	●
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	IPM-B	●	●	●
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	PDM	●	●	●
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	PSCM	●	●	●
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	RFA	●	●	●
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	SASM	●	●	●
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	SOD-L	●	●	●
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	SOD-R	●	●	●
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	TRM	●	●	●
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	ABS	●	●	●
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	ACM	●	●	●
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	CDP	●	●	●
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	CMR	●	●	●
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	D_DCU	●	●	●
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	EATC	●	●	●
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	EPS	●	●	●
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	FFH	●	●	●
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	GEM	●	●	●
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	HCM	●	●	●
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	IC	●	●	●
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	PAM	●	●	●
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	PCM	●	●	●
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	P_DCU	●	●	●
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	RCM	●	●	●
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	RETM	●	●	●
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	RKE	●	●	●
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	SRM	●	●	●
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	TCM	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Focus	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	ABS	●	●	●
Focus	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	ACM	●	●	●
Focus	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	AHCM	●	●	●
Focus	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	APIM	●	●	●
Focus	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	BCMii	●	●	●
Focus	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	CCMii	●	●	●
Focus	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	DDM	●	●	●
Focus	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	DSP	●	●	●
Focus	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	FCDIM	●	●	●
Focus	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	FCIM	●	●	●
Focus	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	FDSM	●	●	●
Focus	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	HCM	●	●	●
Focus	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	HVAC	●	●	●
Focus	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	IPC	●	●	●
Focus	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	IPM-A	●	●	●
Focus	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	IPM-B	●	●	●
Focus	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	PAM	●	●	●
Focus	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	PCM	●	●	●
Focus	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	PDM	●	●	●
Focus	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	PSCM	●	●	●
Focus	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	RCM	●	●	●
Focus	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	RFA	●	●	●
Focus	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	SASM	●	●	●
Focus	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	SOD-L	●	●	●
Focus	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	SOD-R	●	●	●
Focus	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	SRM	●	●	●
Focus	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	TRM	●	●	●
Focus	1.6L	FFV	2007 - 2009	ABS/TCS	●	●	●
Focus	1.6L	FFV	2007 - 2010	GEM	●	●	●
Focus	1.6L	FFV	2007 - 2010	IC	●	●	●
Focus	1.6L	FFV	2007 - 2010	PCM	●	●	●
Focus	1.6L	FFV	2007 - 2010	RCM	●	●	●
Focus	1.6L	FFV	2009	MC	●	●	●
Focus	1.6L	FFV	2009 - 2010	EATC	●	●	●
Focus	1.6L	FFV	2009 - 2010	HCM	●	●	●
Focus	1.6L	FFV	2010	ABS	●	●	●
Focus	1.6L	FFV	2010	ACM	●	●	●
Focus	1.6L	FFV	2010	D_DCU	●	●	●
Focus	1.6L	FFV	2010	EPS	●	●	●
Focus	1.6L	FFV	2010	PAM	●	●	●
Focus	1.6L	FFV	2010	P_DCU	●	●	●
Focus	1.6L	FFV	2010	RKE	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Focus	1.6L	FFV	2010	SRM	●	●	●
Focus	1.6L	FFV	2010	TBM	●	●	●
Focus	1.6L	FFV	2010	TCM	●	●	●
Focus	1.6L	OHC	2009	ABS/TCS	●	●	●
Focus	1.6L	OHC	2009	EATC	●	●	●
Focus	1.6L	OHC	2009	GEM	●	●	●
Focus	1.6L	OHC	2009	HCM	●	●	●
Focus	1.6L	OHC	2009	IC	●	●	●
Focus	1.6L	OHC	2009	MC	●	●	●
Focus	1.6L	OHC	2009	PCM	●	●	●
Focus	1.6L	OHC	2009	RCM	●	●	●
Focus	1.6L	Sigma	2010	ABS	●	●	●
Focus	1.6L	Sigma	2010	ACM	●	●	●
Focus	1.6L	Sigma	2010	D_DCU	●	●	●
Focus	1.6L	Sigma	2010	EATC	●	●	●
Focus	1.6L	Sigma	2010	EPS	●	●	●
Focus	1.6L	Sigma	2010	GEM	●	●	●
Focus	1.6L	Sigma	2010	HCM	●	●	●
Focus	1.6L	Sigma	2010	IC	●	●	●
Focus	1.6L	Sigma	2010	PAM	●	●	●
Focus	1.6L	Sigma	2010	PCM	●	●	●
Focus	1.6L	Sigma	2010	P_DCU	●	●	●
Focus	1.6L	Sigma	2010	RCM	●	●	●
Focus	1.6L	Sigma	2010	RKE	●	●	●
Focus	1.6L	Sigma	2010	SRM	●	●	●
Focus	1.6L	Sigma	2010	TBM	●	●	●
Focus	1.6L	Sigma	2010	TCM	●	●	●
Focus	1.6L	TDCi ECO III	2011	ABS	●	●	●
Focus	1.6L	TDCi ECO III	2011	ACM	●	●	●
Focus	1.6L	TDCi ECO III	2011	AHCM	●	●	●
Focus	1.6L	TDCi ECO III	2011	APIM	●	●	●
Focus	1.6L	TDCi ECO III	2011	BCM i	●	●	●
Focus	1.6L	TDCi ECO III	2011	CCM i	●	●	●
Focus	1.6L	TDCi ECO III	2011	DDM	●	●	●
Focus	1.6L	TDCi ECO III	2011	DSP	●	●	●
Focus	1.6L	TDCi ECO III	2011	FCDIM	●	●	●
Focus	1.6L	TDCi ECO III	2011	FCIM	●	●	●
Focus	1.6L	TDCi ECO III	2011	FDSM	●	●	●
Focus	1.6L	TDCi ECO III	2011	HCM	●	●	●
Focus	1.6L	TDCi ECO III	2011	HVAC	●	●	●
Focus	1.6L	TDCi ECO III	2011	IPC	●	●	●
Focus	1.6L	TDCi ECO III	2011	IPM-A	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Focus	1.6L	TDCi ECO III	2011	IPM-B	●	●	●
Focus	1.6L	TDCi ECO III	2011	PAM	●	●	●
Focus	1.6L	TDCi ECO III	2011	PCM	●	●	●
Focus	1.6L	TDCi ECO III	2011	PDM	●	●	●
Focus	1.6L	TDCi ECO III	2011	PSCM	●	●	●
Focus	1.6L	TDCi ECO III	2011	RCM	●	●	●
Focus	1.6L	TDCi ECO III	2011	RFA	●	●	●
Focus	1.6L	TDCi ECO III	2011	SASM	●	●	●
Focus	1.6L	TDCi ECO III	2011	SOD-L	●	●	●
Focus	1.6L	TDCi ECO III	2011	SOD-R	●	●	●
Focus	1.6L	TDCi ECO III	2011	SRM	●	●	●
Focus	1.6L	TDCi ECO III	2011	TRM	●	●	●
Focus	1.6L	Zetec	1999	CSM	●	●	●
Focus	1.6L	Zetec	1999	CTM	●	●	●
Focus	1.6L	Zetec	1999	PATS	●	●	●
Focus	1.6L	Zetec	1999 - 2002	ABS/TCS	●	●	●
Focus	1.6L	Zetec	1999 - 2002	ECS	●	●	●
Focus	1.6L	Zetec	1999 - 2002	HEC	●	●	●
Focus	1.6L	Zetec	1999 - 2002	PCM	●	●	●
Focus	1.6L	Zetec	2002	EATC	●	●	●
Focus	1.6L	Zetec	2002	GEM	●	●	●
Focus	1.6L	Zetec	2002	HCM	●	●	●
Focus	1.6L	Zetec	2002	MC	●	●	●
Focus	1.6L	Zetec	2002	RCM	●	●	●
Focus	1.6L	Zetec Rocam	2002	ABS/TCS	●	●	●
Focus	1.6L	Zetec Rocam	2002	EATC	●	●	●
Focus	1.6L	Zetec Rocam	2002	ECS	●	●	●
Focus	1.6L	Zetec Rocam	2002	GEM	●	●	●
Focus	1.6L	Zetec Rocam	2002	HCM	●	●	●
Focus	1.6L	Zetec Rocam	2002	HEC	●	●	●
Focus	1.6L	Zetec Rocam	2002	MC	●	●	●
Focus	1.6L	Zetec Rocam	2002	PCM	●	●	●
Focus	1.6L	Zetec Rocam	2002	RCM	●	●	●
Focus	1.6L	Zetec-SE	1999	CSM	●	●	●
Focus	1.6L	Zetec-SE	1999	CTM	●	●	●
Focus	1.6L	Zetec-SE	1999 - 2002	ABS/TCS	●	●	●
Focus	1.6L	Zetec-SE	1999 - 2002	ECS	●	●	●
Focus	1.6L	Zetec-SE	1999 - 2002	HEC	●	●	●
Focus	1.6L	Zetec-SE	1999 - 2002	MC	●	●	●
Focus	1.6L	Zetec-SE	1999 - 2002	PATS	●	●	●
Focus	1.6L	Zetec-SE	1999 - 2002	PCM	●	●	●
Focus	1.6L	Zetec-SE	2002	EATC	●	●	●



Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Focus	1. 6L	Zetec-SE	2002	GEM	●	●	●
Focus	1. 6L	Zetec-SE	2002	HCM	●	●	●
Focus	1. 6L	Zetec-SE	2002	RCM	●	●	●
Focus	1. 8L	DURATEC-HE / I4	2003 - 2005	RL_DCU	●	●	●
Focus	1. 8L	DURATEC-HE / I4	2003 - 2005	RR_DCU	●	●	●
Focus	1. 8L	DURATEC-HE / I4	2003 - 2007	GDM	●	●	●
Focus	1. 8L	DURATEC-HE / I4	2003 - 2007	NAV	●	●	●
Focus	1. 8L	DURATEC-HE / I4	2003 - 2007	TCM	●	●	●
Focus	1. 8L	DURATEC-HE / I4	2003 - 2008	ABS	●	●	●
Focus	1. 8L	DURATEC-HE / I4	2003 - 2008	ACM	●	●	●
Focus	1. 8L	DURATEC-HE / I4	2003 - 2008	CDP	●	●	●
Focus	1. 8L	DURATEC-HE / I4	2003 - 2008	D_DCU	●	●	●
Focus	1. 8L	DURATEC-HE / I4	2003 - 2008	EATC	●	●	●
Focus	1. 8L	DURATEC-HE / I4	2003 - 2008	EPS	●	●	●
Focus	1. 8L	DURATEC-HE / I4	2003 - 2008	FFH	●	●	●
Focus	1. 8L	DURATEC-HE / I4	2003 - 2008	GEM	●	●	●
Focus	1. 8L	DURATEC-HE / I4	2003 - 2008	HCM	●	●	●
Focus	1. 8L	DURATEC-HE / I4	2003 - 2008	IC	●	●	●
Focus	1. 8L	DURATEC-HE / I4	2003 - 2008	PAM	●	●	●
Focus	1. 8L	DURATEC-HE / I4	2003 - 2008	PCM	●	●	●
Focus	1. 8L	DURATEC-HE / I4	2003 - 2008	P_DCU	●	●	●
Focus	1. 8L	DURATEC-HE / I4	2003 - 2008	RCM	●	●	●
Focus	1. 8L	DURATEC-HE / I4	2003 - 2008	RETM	●	●	●
Focus	1. 8L	DURATEC-HE / I4	2003 - 2008	RKE	●	●	●
Focus	1. 8L	DURATEC-HE / I4	2003 - 2008	SRM	●	●	●
Focus	1. 8L	DURATEC-HE / I4	2008	CMR	●	●	●
Focus	1. 8L	Duratorq Turbo Diesel Common Rail Injection	2001	CSM	●	●	●
Focus	1. 8L	Duratorq Turbo Diesel Common Rail Injection	2001	CTM	●	●	●
Focus	1. 8L	Duratorq Turbo Diesel Common Rail Injection	2001 - 2002	ABS/TCS	●	●	●
Focus	1. 8L	Duratorq Turbo Diesel Common Rail Injection	2001 - 2002	ECS	●	●	●
Focus	1. 8L	Duratorq Turbo Diesel Common Rail Injection	2001 - 2002	HEC	●	●	●
Focus	1. 8L	Duratorq Turbo Diesel Common Rail Injection	2001 - 2002	ICU	○	○	●
Focus	1. 8L	Duratorq Turbo Diesel Common Rail Injection	2001 - 2002	MC	●	●	●
Focus	1. 8L	Duratorq Turbo Diesel Common Rail Injection	2001 - 2008	FFH	●	●	●
Focus	1. 8L	Duratorq Turbo Diesel Common Rail Injection	2001 - 2008	PCM	●	●	●
Focus	1. 8L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	EATC	●	●	●
Focus	1. 8L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	GEM	●	●	●
Focus	1. 8L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	HCM	●	●	●
Focus	1. 8L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	RCM	●	●	●
Focus	1. 8L	Duratorq Turbo Diesel Common Rail Injection	2003	RL_DCU	●	●	●
Focus	1. 8L	Duratorq Turbo Diesel Common Rail Injection	2003	RR_DCU	●	●	●
Focus	1. 8L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2007	GDM	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2007	NAV	●	●	●
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2008	ABS	●	●	●
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2008	ACM	●	●	●
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2008	CDP	●	●	●
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2008	D_DCUI	●	●	●
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2008	EPS	●	●	●
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2008	IC	●	●	●
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2008	PAM	●	●	●
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2008	P_DCUI	●	●	●
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2008	RETM	●	●	●
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2008	RKE	●	●	●
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2008	SRM	●	●	●
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2008	CMR	●	●	●
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2008	FACM	●	●	●
Focus	1.8L	Endura DI	1999	CSM	●	●	●
Focus	1.8L	Endura DI	1999	CTM	●	●	●
Focus	1.8L	Endura DI	1999 - 2002	ABS/TCS	●	●	●
Focus	1.8L	Endura DI	1999 - 2002	ECS	●	●	●
Focus	1.8L	Endura DI	1999 - 2002	FFH	●	●	●
Focus	1.8L	Endura DI	1999 - 2002	FIP	●	●	●
Focus	1.8L	Endura DI	1999 - 2002	HEC	●	●	●
Focus	1.8L	Endura DI	1999 - 2002	MC	●	●	●
Focus	1.8L	Endura DI	1999 - 2002	PATS	●	●	●
Focus	1.8L	Endura DI	1999 - 2002	PCM	●	●	●
Focus	1.8L	Endura DI	2002	EATC	●	●	●
Focus	1.8L	Endura DI	2002	GEM	●	●	●
Focus	1.8L	Endura DI	2002	HCM	●	●	●
Focus	1.8L	Endura DI	2002	RCM	●	●	●
Focus	1.8L	Zetec	1999	CSM	●	●	●
Focus	1.8L	Zetec	1999	CTM	●	●	●
Focus	1.8L	Zetec	1999	PATS	●	●	●
Focus	1.8L	Zetec	1999 - 2002	ABS/TCS	●	●	●
Focus	1.8L	Zetec	1999 - 2002	ECS	●	●	●
Focus	1.8L	Zetec	1999 - 2002	HEC	●	●	●
Focus	1.8L	Zetec	1999 - 2002	MC	●	●	●
Focus	1.8L	Zetec	1999 - 2002	PCM	●	●	●
Focus	1.8L	Zetec	2002	AFCM	●	●	●
Focus	1.8L	Zetec	2002	EATC	●	●	●
Focus	1.8L	Zetec	2002	GEM	●	●	●
Focus	1.8L	Zetec	2002	HCM	●	●	●
Focus	1.8L	Zetec	2002	RCM	●	●	●
Focus	2.0L	DURATEC 16V	2005	ABS/TCS	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Focus	2.0L	DURATEC 16V	2005	EATC	●	●	●
Focus	2.0L	DURATEC 16V	2005	GEM	●	●	●
Focus	2.0L	DURATEC 16V	2005	HCM	●	●	●
Focus	2.0L	DURATEC 16V	2005	IC	●	●	●
Focus	2.0L	DURATEC 16V	2005	MC	●	●	●
Focus	2.0L	DURATEC 16V	2005	PCM	●	●	●
Focus	2.0L	DURATEC 16V	2005	RCM	●	●	●
Focus	2.0L	DURATEC-HE / I4	2003	RL_DCU	●	●	●
Focus	2.0L	DURATEC-HE / I4	2003	RR_DCU	●	●	●
Focus	2.0L	DURATEC-HE / I4	2003 - 2007	GDM	●	●	●
Focus	2.0L	DURATEC-HE / I4	2003 - 2007	NAV	●	●	●
Focus	2.0L	DURATEC-HE / I4	2003 - 2007	RETM	●	●	●
Focus	2.0L	DURATEC-HE / I4	2003 - 2008	CDP	●	●	●
Focus	2.0L	DURATEC-HE / I4	2003 - 2008	D_DCU	●	●	●
Focus	2.0L	DURATEC-HE / I4	2003 - 2008	EATC	●	●	●
Focus	2.0L	DURATEC-HE / I4	2003 - 2008	EPS	●	●	●
Focus	2.0L	DURATEC-HE / I4	2003 - 2008	FFH	●	●	●
Focus	2.0L	DURATEC-HE / I4	2003 - 2008	GEM	●	●	●
Focus	2.0L	DURATEC-HE / I4	2003 - 2008	HCM	●	●	●
Focus	2.0L	DURATEC-HE / I4	2003 - 2008	PAM	●	●	●
Focus	2.0L	DURATEC-HE / I4	2003 - 2008	P_DCU	●	●	●
Focus	2.0L	DURATEC-HE / I4	2003 - 2008	RKE	●	●	●
Focus	2.0L	DURATEC-HE / I4	2003 - 2008	SRM	●	●	●
Focus	2.0L	DURATEC-HE / I4	2003 - 2011	ABS	●	●	●
Focus	2.0L	DURATEC-HE / I4	2003 - 2011	ACM	●	●	●
Focus	2.0L	DURATEC-HE / I4	2003 - 2011	IC	●	●	●
Focus	2.0L	DURATEC-HE / I4	2003 - 2011	PCM	●	●	●
Focus	2.0L	DURATEC-HE / I4	2003 - 2011	RCM	●	●	●
Focus	2.0L	DURATEC-HE / I4	2006 - 2008	FTCM	●	●	●
Focus	2.0L	DURATEC-HE / I4	2008	SDARS	●	●	●
Focus	2.0L	DURATEC-HE / I4	2008 - 2011	APIM	●	●	●
Focus	2.0L	DURATEC-HE / I4	2008 - 2011	FCIM	●	●	●
Focus	2.0L	DURATEC-HE / I4	2008 - 2011	FDIM	●	●	●
Focus	2.0L	DURATEC-HE / I4	2008 - 2011	GEM / SJB	●	●	●
Focus	2.0L	DURATEC-HE / I4	2008 - 2011	HVAC	●	●	●
Focus	2.0L	DURATEC-HE / I4	2008 - 2011	OCSM	●	●	●
Focus	2.0L	DURATEC-HE / I4	2010 - 2011	GPSM	●	●	●
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2005	RL_DCU	●	●	●
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2005	RR_DCU	●	●	●
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2007	GDM	●	●	●
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2007	NAV	●	●	●
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2007	RETM	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2008	CDP	●	●	●
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2008	D_DCUI	●	●	●
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2008	EATC	●	●	●
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2008	EPS	●	●	●
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2008	FACM	●	●	●
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2008	FFH	●	●	●
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2008	GEM	●	●	●
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2008	IC	●	●	●
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2008	P_DCUI	●	●	●
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2008	RKE	●	●	●
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2011	ABS	●	●	●
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2011	ACM	●	●	●
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2011	HCM	●	●	●
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2011	PAM	●	●	●
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2011	PCM	●	●	●
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2011	RCM	●	●	●
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2003 - 2011	SRM	●	●	●
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2006 - 2008	FTCM	●	●	●
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	AHCM	●	●	●
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	APIM	●	●	●
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	BCMii	●	●	●
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	CCMii	●	●	●
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	DDM	●	●	●
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	DSP	●	●	●
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	FCDIM	●	●	●
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	FCIM	●	●	●
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	FDSM	●	●	●
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	HVAC	●	●	●
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	IPC	●	●	●
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	IPM-A	●	●	●
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	IPM-B	●	●	●
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	PDM	●	●	●
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	PSCM	●	●	●
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	RFA	●	●	●
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	SASM	●	●	●
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	SOD-L	●	●	●
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	SOD-R	●	●	●
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	TCM	●	●	●
Focus	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	TRM	●	●	●
Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	AHCM	●	●	●
Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	BCMii	●	●	●
Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	CCMii	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	FDSM	●	●	●
Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	IPM-A	●	●	●
Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	SOD-L	●	●	●
Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	SOD-R	●	●	●
Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	SRM	●	●	●
Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	TRM	●	●	●
Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	ACM	●	●	●
Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	FCDIM	●	●	●
Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	IPC	●	●	●
Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	IPM-B	●	●	●
Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	PCM	●	●	●
Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	PSCM	●	●	●
Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2014	ABS	●	●	●
Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2014	APIM	●	●	●
Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2014	DDM	●	●	●
Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2014	DSP	●	●	●
Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2014	FCIM	●	●	●
Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2014	HCM	●	●	●
Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2014	HVAC	●	●	●
Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2014	ICM#1	●	●	●
Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2014	PAM	●	●	○
Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2014	PDM	●	●	●
Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2014	RCM	●	●	●
Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2014	RFA	●	●	●
Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2014	SASM	●	●	●
Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	BCM#1	●	●	●
Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	OCSM	●	●	●
Focus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	GPSM	●	●	●
Focus	2.0L	FFV	2010	ABS	●	●	●
Focus	2.0L	FFV	2010	ACM	●	●	●
Focus	2.0L	FFV	2010	D_DCU	●	●	●
Focus	2.0L	FFV	2010	EATC	●	●	●
Focus	2.0L	FFV	2010	EPS	●	●	●
Focus	2.0L	FFV	2010	GEM	●	●	●
Focus	2.0L	FFV	2010	HCM	●	●	●
Focus	2.0L	FFV	2010	IC	●	●	●
Focus	2.0L	FFV	2010	PAM	●	●	●
Focus	2.0L	FFV	2010	PCM	●	●	●
Focus	2.0L	FFV	2010	P_DCU	●	●	●
Focus	2.0L	FFV	2010	RCM	●	●	●
Focus	2.0L	FFV	2010	RKE	●	●	●
Focus	2.0L	FFV	2010	SRM	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Focus	2.0L	FFV	2010	TBM	●	●	●
Focus	2.0L	FFV	2010	TCM	●	●	●
Focus	2.0L	Gasoline Direct injection	2011	ABS	●	●	●
Focus	2.0L	Gasoline Direct injection	2011	AHCM	●	●	●
Focus	2.0L	Gasoline Direct injection	2011	APIM	●	●	●
Focus	2.0L	Gasoline Direct injection	2011	CCMi i	●	●	●
Focus	2.0L	Gasoline Direct injection	2011	DDM	●	●	●
Focus	2.0L	Gasoline Direct injection	2011	DSP	●	●	●
Focus	2.0L	Gasoline Direct injection	2011	FCDIM	●	●	●
Focus	2.0L	Gasoline Direct injection	2011	FCIM	●	●	●
Focus	2.0L	Gasoline Direct injection	2011	FDSM	●	●	●
Focus	2.0L	Gasoline Direct injection	2011	HCM	●	●	●
Focus	2.0L	Gasoline Direct injection	2011	HVAC	●	●	●
Focus	2.0L	Gasoline Direct injection	2011	IPM-A	●	●	●
Focus	2.0L	Gasoline Direct injection	2011	IPM-B	●	●	●
Focus	2.0L	Gasoline Direct injection	2011	PAM	●	●	●
Focus	2.0L	Gasoline Direct injection	2011	PCM	●	●	●
Focus	2.0L	Gasoline Direct injection	2011	PDM	●	●	●
Focus	2.0L	Gasoline Direct injection	2011	PSCM	●	●	●
Focus	2.0L	Gasoline Direct injection	2011	RCM	●	●	●
Focus	2.0L	Gasoline Direct injection	2011	RFA	●	●	●
Focus	2.0L	Gasoline Direct injection	2011	SASM	●	●	●
Focus	2.0L	Gasoline Direct injection	2011	SOD-L	●	●	●
Focus	2.0L	Gasoline Direct injection	2011	SOD-R	●	●	●
Focus	2.0L	Gasoline Direct injection	2011	SRM	●	●	●
Focus	2.0L	Gasoline Direct injection	2011	TCM	●	●	●
Focus	2.0L	Gasoline Direct injection	2011	TRM	●	●	●
Focus	2.0L	Gasoline Direct injection	2011	ACM	●	●	●
Focus	2.0L	Gasoline Direct injection	2011	AHCM	●	●	●
Focus	2.0L	Gasoline Direct injection	2011	BCM i i	●	●	●
Focus	2.0L	Gasoline Direct injection	2011	CCMi i	●	●	●
Focus	2.0L	Gasoline Direct injection	2011	FCDIM	●	●	●
Focus	2.0L	Gasoline Direct injection	2011	FDSM	●	●	●
Focus	2.0L	Gasoline Direct injection	2011	HCM	●	●	●
Focus	2.0L	Gasoline Direct injection	2011	IPM-A	●	●	●
Focus	2.0L	Gasoline Direct injection	2011	PCM	●	●	●
Focus	2.0L	Gasoline Direct injection	2011	SOD-L	●	●	●
Focus	2.0L	Gasoline Direct injection	2011	SOD-R	●	●	●
Focus	2.0L	Gasoline Direct injection	2011	SRM	●	●	●
Focus	2.0L	Gasoline Direct injection	2011	TRM	●	●	●
Focus	2.0L	Gasoline Direct injection	2011 - 2012	IPC	●	●	●
Focus	2.0L	Gasoline Direct injection	2011 - 2012	IPM-B	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Focus	2.0L	Gasoline_Direct_injection	2011 - 2012	PSCM	●	●	●
Focus	2.0L	Gasoline_Direct_injection	2011 - 2012	TCM	●	●	●
Focus	2.0L	Gasoline_Direct_injection	2011 - 2014	ABS	●	●	●
Focus	2.0L	Gasoline_Direct_injection	2011 - 2014	APIM	●	●	●
Focus	2.0L	Gasoline_Direct_injection	2011 - 2014	DDM	●	●	●
Focus	2.0L	Gasoline_Direct_injection	2011 - 2014	DSP	●	●	●
Focus	2.0L	Gasoline_Direct_injection	2011 - 2014	FCIM	●	●	●
Focus	2.0L	Gasoline_Direct_injection	2011 - 2014	HVAC	●	●	●
Focus	2.0L	Gasoline_Direct_injection	2011 - 2014	PAM	●	●	●
Focus	2.0L	Gasoline_Direct_injection	2011 - 2014	PDM	●	●	●
Focus	2.0L	Gasoline_Direct_injection	2011 - 2014	RCM	●	●	●
Focus	2.0L	Gasoline_Direct_injection	2011 - 2014	RFA	●	●	●
Focus	2.0L	Gasoline_Direct_injection	2011 - 2014	SASM	●	●	●
Focus	2.0L	Gasoline_Direct_injection	2012 - 2014	GPSM	●	●	●
Focus	2.0L	SPI	2000	CSM	●	●	●
Focus	2.0L	SPI	2000	CTM	●	●	●
Focus	2.0L	SPI	2000 - 2002	ECS	●	●	●
Focus	2.0L	SPI	2000 - 2004	ABS/TCS	●	●	●
Focus	2.0L	SPI	2000 - 2004	HEC	●	●	●
Focus	2.0L	SPI	2000 - 2004	PCM	●	●	●
Focus	2.0L	SPI	2002	EATC	●	●	●
Focus	2.0L	SPI	2002	HCM	●	●	●
Focus	2.0L	SPI	2002	MC	●	●	●
Focus	2.0L	SPI	2002 - 2004	GEM	●	●	●
Focus	2.0L	SPI	2002 - 2004	RCM	●	●	●
Focus	2.0L	ZETEC ST	2002	EATC	●	●	●
Focus	2.0L	ZETEC ST	2002	ECS	●	●	●
Focus	2.0L	ZETEC ST	2002	HCM	●	●	●
Focus	2.0L	ZETEC ST	2002	MC	●	●	●
Focus	2.0L	ZETEC ST	2002 - 2004	ABS/TCS	●	●	●
Focus	2.0L	ZETEC ST	2002 - 2004	GEM	●	●	●
Focus	2.0L	ZETEC ST	2002 - 2004	HEC	●	●	●
Focus	2.0L	ZETEC ST	2002 - 2004	PCM	●	●	●
Focus	2.0L	ZETEC ST	2002 - 2004	RCM	●	●	●
Focus	2.0L	Zetec	1999	PATS	●	●	●
Focus	2.0L	Zetec	1999 - 2000	CSM	●	●	●
Focus	2.0L	Zetec	1999 - 2000	CTM	●	●	●
Focus	2.0L	Zetec	1999 - 2002	ECS	●	●	●
Focus	2.0L	Zetec	1999 - 2002	MC	●	●	●
Focus	2.0L	Zetec	1999 - 2004	ABS/TCS	●	●	●
Focus	2.0L	Zetec	1999 - 2004	HEC	●	●	●
Focus	2.0L	Zetec	1999 - 2004	PCM	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Focus	2.0L	Zetec	2002	EATC	●	●	●
Focus	2.0L	Zetec	2002	HCM	●	●	●
Focus	2.0L	Zetec	2002 - 2004	GEM	●	●	●
Focus	2.0L	Zetec	2002 - 2004	RCM	●	●	●
Focus	2.3L	DURATEC-HE / I4	2003 - 2004	ABS/TCS	●	●	●
Focus	2.3L	DURATEC-HE / I4	2003 - 2007	GEM	●	●	●
Focus	2.3L	DURATEC-HE / I4	2003 - 2007	IC	●	●	●
Focus	2.3L	DURATEC-HE / I4	2003 - 2007	PCM	●	●	●
Focus	2.3L	DURATEC-HE / I4	2003 - 2007	RCM	●	●	●
Focus	2.3L	DURATEC-HE / I4	2004	HEC	●	●	●
Focus	2.3L	DURATEC-HE / I4	2005 - 2007	ABS	●	●	●
Focus	2.5L	Duratec RS	2008	ABS	●	●	●
Focus	2.5L	Duratec RS	2008	ACM	●	●	●
Focus	2.5L	Duratec RS	2008	CDP	●	●	●
Focus	2.5L	Duratec RS	2008	CMR	●	●	●
Focus	2.5L	Duratec RS	2008	D_DCU	●	●	●
Focus	2.5L	Duratec RS	2008	EATC	●	●	●
Focus	2.5L	Duratec RS	2008	EPS	●	●	●
Focus	2.5L	Duratec RS	2008	FFH	●	●	●
Focus	2.5L	Duratec RS	2008	GEM	●	●	●
Focus	2.5L	Duratec RS	2008	HCM	●	●	●
Focus	2.5L	Duratec RS	2008	IC	●	●	●
Focus	2.5L	Duratec RS	2008	MC	●	●	●
Focus	2.5L	Duratec RS	2008	PAM	●	●	●
Focus	2.5L	Duratec RS	2008	PCM	●	●	●
Focus	2.5L	Duratec RS	2008	P_DCU	●	●	●
Focus	2.5L	Duratec RS	2008	RCM	●	●	●
Focus	2.5L	Duratec RS	2008	RETM	●	●	●
Focus	2.5L	Duratec RS	2008	RKE	●	●	●
Focus	2.5L	Duratec RS	2008	SRM	●	●	●
Focus	2.5L	I5	2003	RL_DCU	●	●	●
Focus	2.5L	I5	2003	RR_DCU	●	●	●
Focus	2.5L	I5	2003 - 2007	GDM	●	●	●
Focus	2.5L	I5	2003 - 2007	NAV	●	●	●
Focus	2.5L	I5	2003 - 2008	ABS	●	●	●
Focus	2.5L	I5	2003 - 2008	ACM	●	●	●
Focus	2.5L	I5	2003 - 2008	CDP	●	●	●
Focus	2.5L	I5	2003 - 2008	D_DCU	●	●	●
Focus	2.5L	I5	2003 - 2008	EATC	●	●	●
Focus	2.5L	I5	2003 - 2008	EPS	●	●	●
Focus	2.5L	I5	2003 - 2008	FFH	●	●	●
Focus	2.5L	I5	2003 - 2008	GEM	●	●	●



Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Focus	2.5L	I5	2003 - 2008	HCM	●	●	●
Focus	2.5L	I5	2003 - 2008	IC	●	●	●
Focus	2.5L	I5	2003 - 2008	MC	●	●	●
Focus	2.5L	I5	2003 - 2008	PAM	●	●	●
Focus	2.5L	I5	2003 - 2008	PCM	●	●	●
Focus	2.5L	I5	2003 - 2008	P_DCU	●	●	●
Focus	2.5L	I5	2003 - 2008	RCM	●	●	●
Focus	2.5L	I5	2003 - 2008	RETM	●	●	●
Focus	2.5L	I5	2003 - 2008	RKE	●	●	●
Focus	2.5L	I5	2003 - 2008	SRM	●	●	●
Focus	2.5L	I5	2008	CMR	●	●	●
Focus	23kWh	Battery_Electric_Vehicle	2012	ACCM#2	●	●	●
Focus	23kWh	Battery_Electric_Vehicle	2012	BCCM	●	●	●
Focus	23kWh	Battery_Electric_Vehicle	2012	BCM#1	●	●	●
Focus	23kWh	Battery_Electric_Vehicle	2012	IPM-B	●	●	●
Focus	23kWh	Battery_Electric_Vehicle	2012	OCSM	●	●	●
Focus	23kWh	Battery_Electric_Vehicle	2012	PCM	●	●	●
Focus	23kWh	Battery_Electric_Vehicle	2012	PSCM	●	●	●
Focus	23kWh	Battery_Electric_Vehicle	2012 - 2013	ACM	●	●	●
Focus	23kWh	Battery_Electric_Vehicle	2012 - 2013	FCDIM	●	●	●
Focus	23kWh	Battery_Electric_Vehicle	2012 - 2013	IPC	●	●	●
Focus	23kWh	Battery_Electric_Vehicle	2012 - 2013	TCM	●	●	●
Focus	23kWh	Battery_Electric_Vehicle	2012 - 2014	ABS	●	●	●
Focus	23kWh	Battery_Electric_Vehicle	2012 - 2014	APIM	●	●	●
Focus	23kWh	Battery_Electric_Vehicle	2012 - 2014	BECM	●	●	●
Focus	23kWh	Battery_Electric_Vehicle	2012 - 2014	DCDC	●	●	●
Focus	23kWh	Battery_Electric_Vehicle	2012 - 2014	DDM	●	●	●
Focus	23kWh	Battery_Electric_Vehicle	2012 - 2014	DSP	●	●	●
Focus	23kWh	Battery_Electric_Vehicle	2012 - 2014	FCIM	●	●	●
Focus	23kWh	Battery_Electric_Vehicle	2012 - 2014	GFM	●	●	●
Focus	23kWh	Battery_Electric_Vehicle	2012 - 2014	GPSM	●	●	●
Focus	23kWh	Battery_Electric_Vehicle	2012 - 2014	GWM	●	●	●
Focus	23kWh	Battery_Electric_Vehicle	2012 - 2014	HVAC	●	●	●
Focus	23kWh	Battery_Electric_Vehicle	2012 - 2014	PAM	●	●	○
Focus	23kWh	Battery_Electric_Vehicle	2012 - 2014	PDM	●	●	●
Focus	23kWh	Battery_Electric_Vehicle	2012 - 2014	RCM	●	●	●
Focus	23kWh	Battery_Electric_Vehicle	2012 - 2014	RFA	●	●	●
Focus	23kWh	Battery_Electric_Vehicle	2012 - 2014	SASM	●	●	●
Focus	23kWh	Battery_Electric_Vehicle	2012 - 2014	TCU#1	●	●	●
Focus	23kWh	Battery_Electric_Vehicle	2013	BCMii	●	●	●
Focus	23kWh	Battery_Electric_Vehicle	2013 - 2014	SOBDM	●	●	●
Focus	23kWh	Battery_Electric_Vehicle	2014	HCM	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Focus	Other	Other	2013	ABS	●	●	●
Focus	Other	Other	2013	ACM	●	●	●
Focus	Other	Other	2013	APIM	●	●	●
Focus	Other	Other	2013	BCM#1	●	●	●
Focus	Other	Other	2013	DDM	●	●	●
Focus	Other	Other	2013	DSP	●	●	●
Focus	Other	Other	2013	FCDIM	●	●	●
Focus	Other	Other	2013	FCIM	●	●	●
Focus	Other	Other	2013	GPSM	●	●	●
Focus	Other	Other	2013	HVAC	●	●	●
Focus	Other	Other	2013	IPC	●	●	●
Focus	Other	Other	2013	IPM-B	●	●	●
Focus	Other	Other	2013	OCSM	●	●	●
Focus	Other	Other	2013	PAM	●	●	○
Focus	Other	Other	2013	PDM	●	●	●
Focus	Other	Other	2013	PSCM	●	●	●
Focus	Other	Other	2013	RCM	●	●	●
Focus	Other	Other	2013	RFA	●	●	●
Focus	Other	Other	2013	SASM	●	●	●
Focus C-MAX	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	ABS	●	●	●
Focus C-MAX	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	AHCM	●	●	●
Focus C-MAX	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	DDM	●	●	●
Focus C-MAX	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	FCDIM	●	●	●
Focus C-MAX	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	FDSM	●	●	●
Focus C-MAX	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	HCM	●	●	●
Focus C-MAX	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	HVAC	●	●	●
Focus C-MAX	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	IPC	●	●	●
Focus C-MAX	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	IPM-A	●	●	●
Focus C-MAX	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	IPM-B	●	●	●
Focus C-MAX	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	PAM	●	●	●
Focus C-MAX	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	PCM	●	●	●
Focus C-MAX	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	PDM	●	●	●
Focus C-MAX	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	PSCM	●	●	●
Focus C-MAX	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	RCM	●	●	●
Focus C-MAX	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	RFA	●	●	●
Focus C-MAX	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	SASM	●	●	●
Focus C-MAX	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	SOD-L	●	●	●
Focus C-MAX	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	SOD-R	●	●	●
Focus C-MAX	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	SRM	●	●	●
Focus C-MAX	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	TRM	●	●	●
Focus C-MAX	1.4L	DURATEC 16V	2002	RL_DCU	●	●	●
Focus C-MAX	1.4L	DURATEC 16V	2002	RR_DCU	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Focus C-MAX	1.4L	DURATEC 16V	2002 - 2007	ABS	●	●	●
Focus C-MAX	1.4L	DURATEC 16V	2002 - 2007	ACM	●	●	●
Focus C-MAX	1.4L	DURATEC 16V	2002 - 2007	CDP	●	●	●
Focus C-MAX	1.4L	DURATEC 16V	2002 - 2007	D_DCU	●	●	●
Focus C-MAX	1.4L	DURATEC 16V	2002 - 2007	EATC	●	●	●
Focus C-MAX	1.4L	DURATEC 16V	2002 - 2007	EPB	●	●	●
Focus C-MAX	1.4L	DURATEC 16V	2002 - 2007	FFH	●	●	●
Focus C-MAX	1.4L	DURATEC 16V	2002 - 2007	GDM	●	●	●
Focus C-MAX	1.4L	DURATEC 16V	2002 - 2007	GEM	●	●	●
Focus C-MAX	1.4L	DURATEC 16V	2002 - 2007	HCM	●	●	●
Focus C-MAX	1.4L	DURATEC 16V	2002 - 2007	IC	●	●	●
Focus C-MAX	1.4L	DURATEC 16V	2002 - 2007	NAV	●	●	●
Focus C-MAX	1.4L	DURATEC 16V	2002 - 2007	PAM	●	●	●
Focus C-MAX	1.4L	DURATEC 16V	2002 - 2007	PCM	●	●	●
Focus C-MAX	1.4L	DURATEC 16V	2002 - 2007	P_DCU	●	●	●
Focus C-MAX	1.4L	DURATEC 16V	2002 - 2007	RCM	●	●	●
Focus C-MAX	1.4L	DURATEC 16V	2002 - 2007	RETM	●	●	●
Focus C-MAX	1.4L	DURATEC 16V	2002 - 2007	RKE	●	●	●
Focus C-MAX	1.4L	DURATEC 16V	2002 - 2007	SRM	●	●	●
Focus C-MAX	1.6L	DURATEC 16V	2002	RL_DCU	●	●	●
Focus C-MAX	1.6L	DURATEC 16V	2002	RR_DCU	●	●	●
Focus C-MAX	1.6L	DURATEC 16V	2002 - 2007	EPB	●	●	●
Focus C-MAX	1.6L	DURATEC 16V	2002 - 2007	GDM	●	●	●
Focus C-MAX	1.6L	DURATEC 16V	2002 - 2007	NAV	●	●	●
Focus C-MAX	1.6L	DURATEC 16V	2002 - 2008	ABS	●	●	●
Focus C-MAX	1.6L	DURATEC 16V	2002 - 2008	ACM	●	●	●
Focus C-MAX	1.6L	DURATEC 16V	2002 - 2008	CDP	●	●	●
Focus C-MAX	1.6L	DURATEC 16V	2002 - 2008	D_DCU	●	●	●
Focus C-MAX	1.6L	DURATEC 16V	2002 - 2008	EATC	●	●	●
Focus C-MAX	1.6L	DURATEC 16V	2002 - 2008	FFH	●	●	●
Focus C-MAX	1.6L	DURATEC 16V	2002 - 2008	GEM	●	●	●
Focus C-MAX	1.6L	DURATEC 16V	2002 - 2008	HCM	●	●	●
Focus C-MAX	1.6L	DURATEC 16V	2002 - 2008	IC	●	●	●
Focus C-MAX	1.6L	DURATEC 16V	2002 - 2008	PAM	●	●	●
Focus C-MAX	1.6L	DURATEC 16V	2002 - 2008	PCM	●	●	●
Focus C-MAX	1.6L	DURATEC 16V	2002 - 2008	P_DCU	●	●	●
Focus C-MAX	1.6L	DURATEC 16V	2002 - 2008	RCM	●	●	●
Focus C-MAX	1.6L	DURATEC 16V	2002 - 2008	RETM	●	●	●
Focus C-MAX	1.6L	DURATEC 16V	2002 - 2008	RKE	●	●	●
Focus C-MAX	1.6L	DURATEC 16V	2002 - 2008	SRM	●	●	●
Focus C-MAX	1.6L	DURATEC 16V	2008	CMR	●	●	●
Focus C-MAX	1.6L	DURATEC 16V	2008	EPS	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Focus C-MAX	1.6L	DURATEC VCT	2002	RL_DCU	●	●	●
Focus C-MAX	1.6L	DURATEC VCT	2002	RR_DCU	●	●	●
Focus C-MAX	1.6L	DURATEC VCT	2002 - 2007	EPB	●	●	●
Focus C-MAX	1.6L	DURATEC VCT	2002 - 2007	GDM	●	●	●
Focus C-MAX	1.6L	DURATEC VCT	2002 - 2007	NAV	●	●	●
Focus C-MAX	1.6L	DURATEC VCT	2002 - 2008	CDP	●	●	●
Focus C-MAX	1.6L	DURATEC VCT	2002 - 2008	D_DCU	●	●	●
Focus C-MAX	1.6L	DURATEC VCT	2002 - 2008	EATC	●	●	●
Focus C-MAX	1.6L	DURATEC VCT	2002 - 2008	FFH	●	●	●
Focus C-MAX	1.6L	DURATEC VCT	2002 - 2008	GEM	●	●	●
Focus C-MAX	1.6L	DURATEC VCT	2002 - 2008	IC	●	●	●
Focus C-MAX	1.6L	DURATEC VCT	2002 - 2008	P_DCU	●	●	●
Focus C-MAX	1.6L	DURATEC VCT	2002 - 2008	RETM	●	●	●
Focus C-MAX	1.6L	DURATEC VCT	2002 - 2008	RKE	●	●	●
Focus C-MAX	1.6L	DURATEC VCT	2002 - 2011	ABS	●	●	●
Focus C-MAX	1.6L	DURATEC VCT	2002 - 2011	ACM	●	●	●
Focus C-MAX	1.6L	DURATEC VCT	2002 - 2011	HCM	●	●	●
Focus C-MAX	1.6L	DURATEC VCT	2002 - 2011	PAM	●	●	●
Focus C-MAX	1.6L	DURATEC VCT	2002 - 2011	PCM	●	●	●
Focus C-MAX	1.6L	DURATEC VCT	2002 - 2011	RCM	●	●	●
Focus C-MAX	1.6L	DURATEC VCT	2002 - 2011	SRM	●	●	●
Focus C-MAX	1.6L	DURATEC VCT	2008	CMR	●	●	●
Focus C-MAX	1.6L	DURATEC VCT	2008	EPS	●	●	●
Focus C-MAX	1.6L	DURATEC VCT	2011	AHCM	●	●	●
Focus C-MAX	1.6L	DURATEC VCT	2011	BCM i	●	●	●
Focus C-MAX	1.6L	DURATEC VCT	2011	DDM	●	●	●
Focus C-MAX	1.6L	DURATEC VCT	2011	FCDIM	●	●	●
Focus C-MAX	1.6L	DURATEC VCT	2011	HVAC	●	●	●
Focus C-MAX	1.6L	DURATEC VCT	2011	IPC	●	●	●
Focus C-MAX	1.6L	DURATEC VCT	2011	IPM-A	●	●	●
Focus C-MAX	1.6L	DURATEC VCT	2011	IPM-B	●	●	●
Focus C-MAX	1.6L	DURATEC VCT	2011	PDM	●	●	●
Focus C-MAX	1.6L	DURATEC VCT	2011	PSCM	●	●	●
Focus C-MAX	1.6L	DURATEC VCT	2011	RFA	●	●	●
Focus C-MAX	1.6L	DURATEC VCT	2011	RGTM	●	●	●
Focus C-MAX	1.6L	DURATEC VCT	2011	SASM	●	●	●
Focus C-MAX	1.6L	DURATEC VCT	2011	SOD-L	●	●	●
Focus C-MAX	1.6L	DURATEC VCT	2011	SOD-R	●	●	●
Focus C-MAX	1.6L	DURATEC VCT	2011	TRM	●	●	●
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002	RL_DCU	●	●	●
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002	RR_DCU	●	●	●
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2007	EPB	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2007	GDM	●	●	●
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2007	NAV	●	●	●
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2007	TCM	●	●	●
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	CDP	●	●	●
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	D_DCUC	●	●	●
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	EATC	●	●	●
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	EPS	●	●	●
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	FACM	●	●	●
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	FFH	●	●	●
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	GEM	●	●	●
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	IC	●	●	●
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	P_DCUC	●	●	●
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	RETM	●	●	●
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	RKE	●	●	●
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2011	ABS	●	●	●
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2011	ACM	●	●	●
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2011	HCM	●	●	●
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2011	PAM	●	●	●
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2011	PCM	●	●	●
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2011	RCM	●	●	●
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2011	SRM	●	●	●
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2008	CMR	●	●	●
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	AHCM	●	●	●
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	BCMii	●	●	●
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	DDM	●	●	●
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	FCDIM	●	●	●
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	HVAC	●	●	●
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	IPC	●	●	●
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	IPM-A	●	●	●
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	IPM-B	●	●	●
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	PDM	●	●	●
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	PSCM	●	●	●
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	RFA	●	●	●
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	RGTM	●	●	●
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	SASM	●	●	●
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	SOD-L	●	●	●
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	SOD-R	●	●	●
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	TRM	●	●	●
Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	ABS	●	●	●
Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	ACM	●	●	●
Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	AHCM	●	●	●
Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	BCMii	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	DDM	●	●	●
Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	FCDIM	●	●	●
Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	HCM	●	●	●
Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	HVAC	●	●	●
Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	IPC	●	●	●
Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	IPM-A	●	●	●
Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	IPM-B	●	●	●
Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	PAM	●	●	●
Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	PCM	●	●	●
Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	PDM	●	●	●
Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	PSCM	●	●	●
Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	RCM	●	●	●
Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	RFA	●	●	●
Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	RGTM	●	●	●
Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	SASM	●	●	●
Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	SOD-L	●	●	●
Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	SOD-R	●	●	●
Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	SRM	●	●	●
Focus C-MAX	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	TRM	●	●	●
Focus C-MAX	1.8L	DURATEC-HE / I4	2002	RL_DCU	●	●	●
Focus C-MAX	1.8L	DURATEC-HE / I4	2002	RR_DCU	●	●	●
Focus C-MAX	1.8L	DURATEC-HE / I4	2002 - 2007	EPB	●	●	●
Focus C-MAX	1.8L	DURATEC-HE / I4	2002 - 2007	GDM	●	●	●
Focus C-MAX	1.8L	DURATEC-HE / I4	2002 - 2007	NAV	●	●	●
Focus C-MAX	1.8L	DURATEC-HE / I4	2002 - 2007	TCM	●	●	●
Focus C-MAX	1.8L	DURATEC-HE / I4	2002 - 2008	ABS	●	●	●
Focus C-MAX	1.8L	DURATEC-HE / I4	2002 - 2008	ACM	●	●	●
Focus C-MAX	1.8L	DURATEC-HE / I4	2002 - 2008	CDP	●	●	●
Focus C-MAX	1.8L	DURATEC-HE / I4	2002 - 2008	D_DCU	●	●	●
Focus C-MAX	1.8L	DURATEC-HE / I4	2002 - 2008	EATC	●	●	●
Focus C-MAX	1.8L	DURATEC-HE / I4	2002 - 2008	EPS	●	●	●
Focus C-MAX	1.8L	DURATEC-HE / I4	2002 - 2008	FFH	●	●	●
Focus C-MAX	1.8L	DURATEC-HE / I4	2002 - 2008	GEM	●	●	●
Focus C-MAX	1.8L	DURATEC-HE / I4	2002 - 2008	HCM	●	●	●
Focus C-MAX	1.8L	DURATEC-HE / I4	2002 - 2008	IC	●	●	●
Focus C-MAX	1.8L	DURATEC-HE / I4	2002 - 2008	PAM	●	●	●
Focus C-MAX	1.8L	DURATEC-HE / I4	2002 - 2008	PCM	●	●	●
Focus C-MAX	1.8L	DURATEC-HE / I4	2002 - 2008	P_DCU	●	●	●
Focus C-MAX	1.8L	DURATEC-HE / I4	2002 - 2008	RCM	●	●	●
Focus C-MAX	1.8L	DURATEC-HE / I4	2002 - 2008	RETM	●	●	●
Focus C-MAX	1.8L	DURATEC-HE / I4	2002 - 2008	RKE	●	●	●
Focus C-MAX	1.8L	DURATEC-HE / I4	2002 - 2008	SRM	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Focus C-MAX	1.8L	DURATEC-HE / I4	2008	CMR	●	●	●
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002	RL_DCU	●	●	●
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002	RR_DCU	●	●	●
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2007	EPB	●	●	●
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2007	GDM	●	●	●
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2007	NAV	●	●	●
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	ABS	●	●	●
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	ACM	●	●	●
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	CDP	●	●	●
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	D_DCU	●	●	●
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	EATC	●	●	●
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	EPS	●	●	●
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	FFH	●	●	●
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	GEM	●	●	●
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	HCM	●	●	●
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	IC	●	●	●
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	PAM	●	●	●
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	PCM	●	●	●
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	P_DCU	●	●	●
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	RCM	●	●	●
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	RETM	●	●	●
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	RKE	●	●	●
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	SRM	●	●	●
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	2008	CMR	●	●	●
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	2008	FACM	●	●	●
Focus C-MAX	2.0L	DURATEC-HE / I4	2002	RL_DCU	●	●	●
Focus C-MAX	2.0L	DURATEC-HE / I4	2002	RR_DCU	●	●	●
Focus C-MAX	2.0L	DURATEC-HE / I4	2002 - 2007	EPB	●	●	●
Focus C-MAX	2.0L	DURATEC-HE / I4	2002 - 2007	GDM	●	●	●
Focus C-MAX	2.0L	DURATEC-HE / I4	2002 - 2007	NAV	●	●	●
Focus C-MAX	2.0L	DURATEC-HE / I4	2002 - 2008	ABS	●	●	●
Focus C-MAX	2.0L	DURATEC-HE / I4	2002 - 2008	ACM	●	●	●
Focus C-MAX	2.0L	DURATEC-HE / I4	2002 - 2008	CDP	●	●	●
Focus C-MAX	2.0L	DURATEC-HE / I4	2002 - 2008	D_DCU	●	●	●
Focus C-MAX	2.0L	DURATEC-HE / I4	2002 - 2008	EATC	●	●	●
Focus C-MAX	2.0L	DURATEC-HE / I4	2002 - 2008	EPS	●	●	●
Focus C-MAX	2.0L	DURATEC-HE / I4	2002 - 2008	FFH	●	●	●
Focus C-MAX	2.0L	DURATEC-HE / I4	2002 - 2008	GEM	●	●	●
Focus C-MAX	2.0L	DURATEC-HE / I4	2002 - 2008	HCM	●	●	●
Focus C-MAX	2.0L	DURATEC-HE / I4	2002 - 2008	IC	●	●	●
Focus C-MAX	2.0L	DURATEC-HE / I4	2002 - 2008	PAM	●	●	●
Focus C-MAX	2.0L	DURATEC-HE / I4	2002 - 2008	PCM	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Focus C-MAX	2.0L	DURATEC-HE / I4	2002 - 2008	P_DCU	●	●	●
Focus C-MAX	2.0L	DURATEC-HE / I4	2002 - 2008	RCM	●	●	●
Focus C-MAX	2.0L	DURATEC-HE / I4	2002 - 2008	RETM	●	●	●
Focus C-MAX	2.0L	DURATEC-HE / I4	2002 - 2008	RKE	●	●	●
Focus C-MAX	2.0L	DURATEC-HE / I4	2002 - 2008	SRM	●	●	●
Focus C-MAX	2.0L	DURATEC-HE / I4	2008	CMR	●	●	●
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2002	RL_DCU	●	●	●
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2002	RR_DCU	●	●	●
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2007	EPB	●	●	●
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2007	GDM	●	●	●
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2007	NAV	●	●	●
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	CDP	●	●	●
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	D_DCU	●	●	●
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	EATC	●	●	●
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	EPS	●	●	●
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	FACM	●	●	●
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	FFH	●	●	●
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	GEM	●	●	●
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	IC	●	●	●
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	P_DCU	●	●	●
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	RETM	●	●	●
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2008	RKE	●	●	●
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2011	ABS	●	●	●
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2011	ACM	●	●	●
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2011	HCM	●	●	●
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2011	PAM	●	●	●
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2011	PCM	●	●	●
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2011	RCM	●	●	●
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2011	SRM	●	●	●
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2008	CMR	●	●	●
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2008 - 2011	TCM	●	●	●
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	AHCM	●	●	●
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	BCMii	●	●	●
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	DDM	●	●	●
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	FCDIM	●	●	●
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	HVAC	●	●	●
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	IPC	●	●	●
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	IPM-A	●	●	●
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	IPM-B	●	●	●
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	PDM	●	●	●
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	PSCM	●	●	●
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	RFA	●	●	●



Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	RGTM	●	●	●
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	SASM	●	●	●
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	SOD-L	●	●	●
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	SOD-R	●	●	●
Focus C-MAX	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	TRM	●	●	●
Freestar / Monterey	3.9L	V6 OHV	2004 - 2005	ABS/TCS	●	●	●
Freestar / Monterey	3.9L	V6 OHV	2004 - 2007	DCSM	●	●	●
Freestar / Monterey	3.9L	V6 OHV	2004 - 2007	DSM	●	●	●
Freestar / Monterey	3.9L	V6 OHV	2004 - 2007	EATC	●	●	●
Freestar / Monterey	3.9L	V6 OHV	2004 - 2007	GEM	●	●	●
Freestar / Monterey	3.9L	V6 OHV	2004 - 2007	IC	●	●	●
Freestar / Monterey	3.9L	V6 OHV	2004 - 2007	LPSDM	●	●	●
Freestar / Monterey	3.9L	V6 OHV	2004 - 2007	LTM	●	●	●
Freestar / Monterey	3.9L	V6 OHV	2004 - 2007	NGSC	●	●	●
Freestar / Monterey	3.9L	V6 OHV	2004 - 2007	PAM	●	●	●
Freestar / Monterey	3.9L	V6 OHV	2004 - 2007	PCM	●	●	●
Freestar / Monterey	3.9L	V6 OHV	2004 - 2007	PCSM	●	●	●
Freestar / Monterey	3.9L	V6 OHV	2004 - 2007	RCM	●	●	●
Freestar / Monterey	3.9L	V6 OHV	2004 - 2007	RPSDM	●	●	●
Freestar / Monterey	3.9L	V6 OHV	2005	TPM	●	●	●
Freestar / Monterey	3.9L	V6 OHV	2006 - 2007	ABS	●	●	●
Freestar / Monterey	4.2L	V6 OHV	2004 - 2005	ABS/TCS	●	●	●
Freestar / Monterey	4.2L	V6 OHV	2004 - 2007	DCSM	●	●	●
Freestar / Monterey	4.2L	V6 OHV	2004 - 2007	DSM	●	●	●
Freestar / Monterey	4.2L	V6 OHV	2004 - 2007	EATC	●	●	●
Freestar / Monterey	4.2L	V6 OHV	2004 - 2007	GEM	●	●	●
Freestar / Monterey	4.2L	V6 OHV	2004 - 2007	IC	●	●	●
Freestar / Monterey	4.2L	V6 OHV	2004 - 2007	LPSDM	●	●	●
Freestar / Monterey	4.2L	V6 OHV	2004 - 2007	LTM	●	●	●
Freestar / Monterey	4.2L	V6 OHV	2004 - 2007	NGSC	●	●	●
Freestar / Monterey	4.2L	V6 OHV	2004 - 2007	PAM	●	●	●
Freestar / Monterey	4.2L	V6 OHV	2004 - 2007	PCM	●	●	●
Freestar / Monterey	4.2L	V6 OHV	2004 - 2007	PCSM	●	●	●
Freestar / Monterey	4.2L	V6 OHV	2004 - 2007	RCM	●	●	●
Freestar / Monterey	4.2L	V6 OHV	2004 - 2007	RPSDM	●	●	●
Freestar / Monterey	4.2L	V6 OHV	2005	TPM	●	●	●
Freestar / Monterey	4.2L	V6 OHV	2006 - 2007	ABS	●	●	●
Freestyle	3.0L	4V	2005 - 2007	4X4	●	●	●
Freestyle	3.0L	4V	2005 - 2007	ABS	●	●	●
Freestyle	3.0L	4V	2005 - 2007	ACM	●	●	●
Freestyle	3.0L	4V	2005 - 2007	DSM	●	●	●
Freestyle	3.0L	4V	2005 - 2007	EATC	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Freestyle	3.0L	4V	2005 - 2007	GEM	●	●	●
Freestyle	3.0L	4V	2005 - 2007	IC	●	●	●
Freestyle	3.0L	4V	2005 - 2007	PAM	●	●	●
Freestyle	3.0L	4V	2005 - 2007	PCM	●	●	●
Freestyle	3.0L	4V	2005 - 2007	RCM	●	●	●
Freestyle	3.0L	4V	2005 - 2007	RETM	●	●	●
Freestyle	3.0L	4V	2005 - 2007	TCM	●	●	●
Freestyle	3.0L	4V	2007	SDARS	●	●	●
Fusion	1.25L	DURATEC 16V	2002 - 2006	ABS/TCS	●	●	●
Fusion	1.25L	DURATEC 16V	2002 - 2006	GEM	●	●	●
Fusion	1.25L	DURATEC 16V	2002 - 2006	IC	●	●	●
Fusion	1.25L	DURATEC 16V	2002 - 2006	PCM	●	●	●
Fusion	1.25L	DURATEC 16V	2002 - 2006	RCM	●	●	○
Fusion	1.25L	DURATEC 16V	2006	ACM	●	●	●
Fusion	1.25L	DURATEC 16V	2006	EATC	●	●	●
Fusion	1.25L	DURATEC 16V	2006	SRM	●	●	●
Fusion	1.4L	DURATEC 16V	2002 - 2006	ABS/TCS	●	●	●
Fusion	1.4L	DURATEC 16V	2002 - 2006	GEM	●	●	●
Fusion	1.4L	DURATEC 16V	2002 - 2006	IC	●	●	●
Fusion	1.4L	DURATEC 16V	2002 - 2006	PCM	●	●	●
Fusion	1.4L	DURATEC 16V	2002 - 2006	RCM	●	●	○
Fusion	1.4L	DURATEC 16V	2002 - 2006	TCM	●	●	●
Fusion	1.4L	DURATEC 16V	2006	ACM	●	●	●
Fusion	1.4L	DURATEC 16V	2006	EATC	●	●	●
Fusion	1.4L	DURATEC 16V	2006	SRM	●	●	●
Fusion	1.4L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2006	ABS/TCS	●	●	●
Fusion	1.4L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2006	GEM	●	●	●
Fusion	1.4L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2006	IC	●	●	●
Fusion	1.4L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2006	PCM	●	●	●
Fusion	1.4L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2006	RCM	●	●	○
Fusion	1.4L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2006	TCM	●	●	●
Fusion	1.4L	Duratorq Turbo Diesel Common Rail Injection	2006	ACM	●	●	●
Fusion	1.4L	Duratorq Turbo Diesel Common Rail Injection	2006	EATC	●	●	●
Fusion	1.4L	Duratorq Turbo Diesel Common Rail Injection	2006	SRM	●	●	●
Fusion	1.5L	EcoBoost - Gas Turbocharged Direct Injection	2014	APIM	●	●	●
Fusion	1.5L	EcoBoost - Gas Turbocharged Direct Injection	2014	DACM-C	●	●	●
Fusion	1.5L	EcoBoost - Gas Turbocharged Direct Injection	2014	DSM	●	●	●
Fusion	1.5L	EcoBoost - Gas Turbocharged Direct Injection	2014	DSP	●	●	●
Fusion	1.5L	EcoBoost - Gas Turbocharged Direct Injection	2014	FCDIM	●	●	●
Fusion	1.5L	EcoBoost - Gas Turbocharged Direct Injection	2014	FCIM	●	●	●
Fusion	1.5L	EcoBoost - Gas Turbocharged Direct Injection	2014	HUD	●	●	●
Fusion	1.5L	EcoBoost - Gas Turbocharged Direct Injection	2014	PCM	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Fusion	1.5L	EcoBoost - Gas Turbocharged Direct Injection	2014	RACM	●	●	○
Fusion	1.5L	EcoBoost - Gas Turbocharged Direct Injection	2014	RCM	●	●	○
Fusion	1.5L	EcoBoost - Gas Turbocharged Direct Injection	2014	RTM	●	●	○
Fusion	1.5L	EcoBoost - Gas Turbocharged Direct Injection	2014	SCCM	●	●	○
Fusion	1.5L	EcoBoost - Gas Turbocharged Direct Injection	2014	SCM-E	●	●	○
Fusion	1.5L	EcoBoost - Gas Turbocharged Direct Injection	2014	SOD-L	●	●	○
Fusion	1.5L	EcoBoost - Gas Turbocharged Direct Injection	2014	SOD-R	●	●	○
Fusion	1.6L	DURATEC 16V	2002	TCM	●	●	●
Fusion	1.6L	DURATEC 16V	2002 - 2006	ABS/TCS	●	●	●
Fusion	1.6L	DURATEC 16V	2002 - 2006	GEM	●	●	●
Fusion	1.6L	DURATEC 16V	2002 - 2006	IC	●	●	●
Fusion	1.6L	DURATEC 16V	2002 - 2006	PCM	●	●	●
Fusion	1.6L	DURATEC 16V	2002 - 2006	RCM	●	●	○
Fusion	1.6L	DURATEC 16V	2006	ACM	●	●	●
Fusion	1.6L	DURATEC 16V	2006	EATC	●	●	●
Fusion	1.6L	DURATEC 16V	2006	SRM	●	●	●
Fusion	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2006	ABS/TCS	●	●	●
Fusion	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2006	EPS	●	●	●
Fusion	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2006	GEM	●	●	●
Fusion	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2006	IC	●	●	●
Fusion	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2006	PCM	●	●	●
Fusion	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2006	RCM	●	●	○
Fusion	1.6L	Duratorq Turbo Diesel Common Rail Injection	2006	ACM	●	●	●
Fusion	1.6L	Duratorq Turbo Diesel Common Rail Injection	2006	EATC	●	●	●
Fusion	1.6L	Duratorq Turbo Diesel Common Rail Injection	2006	SRM	●	●	●
Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	ABS	●	●	●
Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	ACM	●	●	●
Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	BCM#1	●	●	●
Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	C-CM	●	●	●
Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	DDM	●	●	●
Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	GFM	●	●	●
Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	GPSM	●	●	●
Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	GWM	●	●	●
Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	HCM	●	●	●
Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	HSWM	●	●	●
Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	IPC	●	●	●
Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	IPM-A	●	●	●
Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	OCSM	●	●	●
Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	PAM	●	●	○
Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	PCM	●	●	●
Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	PDM	●	●	○
Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	PSCM	●	●	○

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	RGTM	●	●	○
Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	SCM-G	●	●	○
Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	SCM-H	●	●	○
Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	VDM	●	●	○
Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	APIM	●	●	●
Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	DACM-C	●	●	●
Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	DSM	●	●	●
Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	DSP	●	●	●
Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	FCDIM	●	●	●
Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	FCIM	●	●	●
Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	HUD	●	●	●
Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	RACM	●	●	○
Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	RCM	●	●	○
Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	RTM	●	●	○
Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	SCCM	●	●	○
Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	SCM-E	●	●	○
Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	SOD-L	●	●	○
Fusion	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	SOD-R	●	●	○
Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	ABS	●	●	●
Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	ACM	●	●	●
Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	BCM#1	●	●	●
Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	C-CM	●	●	●
Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	DDM	●	●	●
Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	GFM	●	●	●
Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	GPSM	●	●	●
Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	GWM	●	●	●
Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	HCM	●	●	●
Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	HSWM	●	●	●
Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	IPC	●	●	●
Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	IPM-A	●	●	●
Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	OCSM	●	●	●
Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	PAM	●	●	○
Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	PDM	●	●	○
Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	PSCM	●	●	○
Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	RGTM	●	●	○
Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	SCM-G	●	●	○
Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	SCM-H	●	●	○
Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	VDM	●	●	○
Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	APIM	●	●	●
Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	DACM-C	●	●	●
Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	DSM	●	●	●
Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	DSP	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	FCDIM	●	●	●
Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	FCIM	●	●	●
Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	HUD	●	●	●
Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	PCM	●	●	●
Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	RACM	●	●	○
Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	RCM	●	●	○
Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	RTM	●	●	○
Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	SCCM	●	●	○
Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	SCM-E	●	●	○
Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	SOD-L	●	●	○
Fusion	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	SOD-R	●	●	○
Fusion	2.0L	Full Hybrid Electric Vehicle	2013	C-CM	●	●	●
Fusion	2.0L	Full Hybrid Electric Vehicle	2013	GWM	●	●	●
Fusion	2.0L	Full Hybrid Electric Vehicle	2013 - 2014	ACCM#2	●	●	●
Fusion	2.0L	Full Hybrid Electric Vehicle	2013 - 2014	APIM	●	●	●
Fusion	2.0L	Full Hybrid Electric Vehicle	2013 - 2014	DACM-C	●	●	●
Fusion	2.0L	Full Hybrid Electric Vehicle	2013 - 2014	DSM	●	●	●
Fusion	2.0L	Full Hybrid Electric Vehicle	2013 - 2014	DSP	●	●	●
Fusion	2.0L	Full Hybrid Electric Vehicle	2013 - 2014	FCDIM	●	●	●
Fusion	2.0L	Full Hybrid Electric Vehicle	2013 - 2014	HUD	●	●	●
Fusion	2.0L	Full Hybrid Electric Vehicle	2013 - 2014	RACM	●	●	○
Fusion	2.0L	Full Hybrid Electric Vehicle	2013 - 2014	RCM	●	●	○
Fusion	2.0L	Full Hybrid Electric Vehicle	2013 - 2014	SCCM	●	●	○
Fusion	2.0L	Full Hybrid Electric Vehicle	2013 - 2014	SCM-E	●	●	○
Fusion	2.0L	Full Hybrid Electric Vehicle	2013 - 2014	SOD-L	●	●	○
Fusion	2.0L	Full Hybrid Electric Vehicle	2013 - 2014	SOD-R	●	●	○
Fusion	2.0L	Full Hybrid Electric Vehicle	2014	FCIM	●	●	●
Fusion	2.0L	Full Hybrid Electric Vehicle	2014	RTM	●	●	○
Fusion	2.0L	HEV / ATKINSON 4V	2013	ABS	●	●	●
Fusion	2.0L	HEV / ATKINSON 4V	2013	ACCM#2	●	●	●
Fusion	2.0L	HEV / ATKINSON 4V	2013	ACM	●	●	●
Fusion	2.0L	HEV / ATKINSON 4V	2013	APIM	●	●	●
Fusion	2.0L	HEV / ATKINSON 4V	2013	BCM#1	●	●	●
Fusion	2.0L	HEV / ATKINSON 4V	2013	BECM	●	●	●
Fusion	2.0L	HEV / ATKINSON 4V	2013	C-CM	●	●	●
Fusion	2.0L	HEV / ATKINSON 4V	2013	DACM-C	●	●	●
Fusion	2.0L	HEV / ATKINSON 4V	2013	DCDC	●	●	●
Fusion	2.0L	HEV / ATKINSON 4V	2013	DDM	●	●	●
Fusion	2.0L	HEV / ATKINSON 4V	2013	DSM	●	●	●
Fusion	2.0L	HEV / ATKINSON 4V	2013	DSP	●	●	●
Fusion	2.0L	HEV / ATKINSON 4V	2013	FCDIM	●	●	●
Fusion	2.0L	HEV / ATKINSON 4V	2013	FCIM	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Fusion	2.0L	HEV / ATKINSON 4V	2013	GFM	●	●	●
Fusion	2.0L	HEV / ATKINSON 4V	2013	GPSM	●	●	●
Fusion	2.0L	HEV / ATKINSON 4V	2013	GWM	●	●	●
Fusion	2.0L	HEV / ATKINSON 4V	2013	HCM	●	●	●
Fusion	2.0L	HEV / ATKINSON 4V	2013	HSWM	●	●	●
Fusion	2.0L	HEV / ATKINSON 4V	2013	HUD	●	●	●
Fusion	2.0L	HEV / ATKINSON 4V	2013	IPC	●	●	●
Fusion	2.0L	HEV / ATKINSON 4V	2013	IPM-A	●	●	●
Fusion	2.0L	HEV / ATKINSON 4V	2013	OCSM	●	●	●
Fusion	2.0L	HEV / ATKINSON 4V	2013	PAM	●	●	○
Fusion	2.0L	HEV / ATKINSON 4V	2013	PCM	●	●	●
Fusion	2.0L	HEV / ATKINSON 4V	2013	PDM	●	●	○
Fusion	2.0L	HEV / ATKINSON 4V	2013	PSCM	●	●	○
Fusion	2.0L	HEV / ATKINSON 4V	2013	RACM	●	●	○
Fusion	2.0L	HEV / ATKINSON 4V	2013	RCM	●	●	○
Fusion	2.0L	HEV / ATKINSON 4V	2013	RGTM	●	●	○
Fusion	2.0L	HEV / ATKINSON 4V	2013	RTM	●	●	○
Fusion	2.0L	HEV / ATKINSON 4V	2013	SCCM	●	●	○
Fusion	2.0L	HEV / ATKINSON 4V	2013	SCM-E	●	●	○
Fusion	2.0L	HEV / ATKINSON 4V	2013	SCM-G	●	●	○
Fusion	2.0L	HEV / ATKINSON 4V	2013	SCM-H	●	●	○
Fusion	2.0L	HEV / ATKINSON 4V	2013	SOBDM-C	●	●	●
Fusion	2.0L	HEV / ATKINSON 4V	2013	SOD-L	●	●	○
Fusion	2.0L	HEV / ATKINSON 4V	2013	SOD-R	●	●	○
Fusion	2.0L	HEV / ATKINSON 4V	2013	VDM	●	●	○
Fusion	2.0L	PHEV	2013	ABS	●	●	●
Fusion	2.0L	PHEV	2013	ACM	●	●	●
Fusion	2.0L	PHEV	2013	BCM#1	●	●	●
Fusion	2.0L	PHEV	2013	C-CM	●	●	●
Fusion	2.0L	PHEV	2013	DDM	●	●	●
Fusion	2.0L	PHEV	2013	GPSM	●	●	●
Fusion	2.0L	PHEV	2013	GWM	●	●	●
Fusion	2.0L	PHEV	2013	HCM	●	●	●
Fusion	2.0L	PHEV	2013	HSWM	●	●	●
Fusion	2.0L	PHEV	2013	IPC	●	●	●
Fusion	2.0L	PHEV	2013	IPM-A	●	●	●
Fusion	2.0L	PHEV	2013	OCSM	●	●	●
Fusion	2.0L	PHEV	2013	PAM	●	●	○
Fusion	2.0L	PHEV	2013	PCM	●	●	●
Fusion	2.0L	PHEV	2013	PDM	●	●	○
Fusion	2.0L	PHEV	2013	PSCM	●	●	○
Fusion	2.0L	PHEV	2013	RGTM	●	●	○

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Fusion	2.0L	PHEV	2013	SCM-G	●	●	○
Fusion	2.0L	PHEV	2013	SCM-H	●	●	○
Fusion	2.0L	PHEV	2013	SOBDM-C	●	●	○
Fusion	2.0L	PHEV	2013	VDM	●	●	○
Fusion	2.0L	PHEV	2013 - 2014	APIM	●	●	●
Fusion	2.0L	PHEV	2013 - 2014	DACM-C	●	●	●
Fusion	2.0L	PHEV	2013 - 2014	DSM	●	●	●
Fusion	2.0L	PHEV	2013 - 2014	DSP	●	●	●
Fusion	2.0L	PHEV	2013 - 2014	FCDIM	●	●	●
Fusion	2.0L	PHEV	2013 - 2014	FCIM	●	●	●
Fusion	2.0L	PHEV	2013 - 2014	GFM	●	●	●
Fusion	2.0L	PHEV	2013 - 2014	HUD	●	●	●
Fusion	2.0L	PHEV	2013 - 2014	RACM	●	●	○
Fusion	2.0L	PHEV	2013 - 2014	RCM	●	●	○
Fusion	2.0L	PHEV	2013 - 2014	RTM	●	●	○
Fusion	2.0L	PHEV	2013 - 2014	SCCM	●	●	○
Fusion	2.0L	PHEV	2013 - 2014	SCM-E	●	●	○
Fusion	2.0L	PHEV	2013 - 2014	SOD-L	●	●	○
Fusion	2.0L	PHEV	2013 - 2014	SOD-R	●	●	○
Fusion	2.0L	PHEV	2014	ACCM#2	●	●	●
Fusion	2.0L	PHEV	2014	BECM	●	●	●
Fusion	2.0L	PHEV	2014	SOBDM	●	●	●
Fusion	2.3L	DURATEC-HE / I4	2006 - 2007	EATC	●	●	●
Fusion	2.3L	DURATEC-HE / I4	2006 - 2007	GEM	●	●	●
Fusion	2.3L	DURATEC-HE / I4	2006 - 2009	ABS	●	●	●
Fusion	2.3L	DURATEC-HE / I4	2006 - 2009	ACM	●	●	●
Fusion	2.3L	DURATEC-HE / I4	2006 - 2009	IC	●	●	●
Fusion	2.3L	DURATEC-HE / I4	2006 - 2009	OCSM	●	●	●
Fusion	2.3L	DURATEC-HE / I4	2006 - 2009	PCM	●	●	●
Fusion	2.3L	DURATEC-HE / I4	2006 - 2009	RCM	●	●	●
Fusion	2.3L	DURATEC-HE / I4	2006 - 2009	TBM	●	●	●
Fusion	2.3L	DURATEC-HE / I4	2006 - 2009	TCM	●	●	●
Fusion	2.3L	DURATEC-HE / I4	2007 - 2009	4X4	●	●	●
Fusion	2.3L	DURATEC-HE / I4	2007 - 2009	SDARS	●	●	●
Fusion	2.3L	DURATEC-HE / I4	2008 - 2009	APIM	●	●	●
Fusion	2.3L	DURATEC-HE / I4	2008 - 2009	GEM / SJB	●	●	●
Fusion	2.3L	DURATEC-HE / I4	2008 - 2009	HVAC	●	●	●
Fusion	2.3L	DURATEC-HE / I4	2008 - 2009	PAM	●	●	●
Fusion	2.5L	DURATEC-HE / I4	2010 - 2012	4X4	●	●	●
Fusion	2.5L	DURATEC-HE / I4	2010 - 2012	ABS	●	●	●
Fusion	2.5L	DURATEC-HE / I4	2010 - 2012	ACM	●	●	●
Fusion	2.5L	DURATEC-HE / I4	2010 - 2012	APIM	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Fusion	2.5L	DURATEC-HE / I4	2010 - 2012	DSP	●	●	●
Fusion	2.5L	DURATEC-HE / I4	2010 - 2012	FCIM	●	●	●
Fusion	2.5L	DURATEC-HE / I4	2010 - 2012	FDIM	●	●	●
Fusion	2.5L	DURATEC-HE / I4	2010 - 2012	GEM / SJB	●	●	●
Fusion	2.5L	DURATEC-HE / I4	2010 - 2012	GPSM	●	●	●
Fusion	2.5L	DURATEC-HE / I4	2010 - 2012	HVAC	●	●	●
Fusion	2.5L	DURATEC-HE / I4	2010 - 2012	IPC	●	●	●
Fusion	2.5L	DURATEC-HE / I4	2010 - 2012	OCSM	●	●	●
Fusion	2.5L	DURATEC-HE / I4	2010 - 2012	PAM	●	●	●
Fusion	2.5L	DURATEC-HE / I4	2010 - 2012	PCM	●	●	●
Fusion	2.5L	DURATEC-HE / I4	2010 - 2012	PSCM	●	●	●
Fusion	2.5L	DURATEC-HE / I4	2010 - 2012	RCM	●	●	●
Fusion	2.5L	DURATEC-HE / I4	2010 - 2012	SOD-L	●	●	●
Fusion	2.5L	DURATEC-HE / I4	2010 - 2012	SOD-R	●	●	●
Fusion	2.5L	DURATEC-HE / I4	2010 - 2012	TBM	●	●	●
Fusion	2.5L	HEV / ATKINSON 4V	2010 - 2012	4X4	●	●	●
Fusion	2.5L	HEV / ATKINSON 4V	2010 - 2012	ABS	●	●	●
Fusion	2.5L	HEV / ATKINSON 4V	2010 - 2012	ACCM#2	●	●	●
Fusion	2.5L	HEV / ATKINSON 4V	2010 - 2012	ACM	●	●	●
Fusion	2.5L	HEV / ATKINSON 4V	2010 - 2012	APIM	●	●	●
Fusion	2.5L	HEV / ATKINSON 4V	2010 - 2012	BECM	●	●	●
Fusion	2.5L	HEV / ATKINSON 4V	2010 - 2012	DCDC	●	●	●
Fusion	2.5L	HEV / ATKINSON 4V	2010 - 2012	DSP	●	●	●
Fusion	2.5L	HEV / ATKINSON 4V	2010 - 2012	FCIM	●	●	●
Fusion	2.5L	HEV / ATKINSON 4V	2010 - 2012	FDIM	●	●	●
Fusion	2.5L	HEV / ATKINSON 4V	2010 - 2012	GEM / SJB	●	●	●
Fusion	2.5L	HEV / ATKINSON 4V	2010 - 2012	GPSM	●	●	●
Fusion	2.5L	HEV / ATKINSON 4V	2010 - 2012	HVAC	●	●	●
Fusion	2.5L	HEV / ATKINSON 4V	2010 - 2012	IPC	●	●	●
Fusion	2.5L	HEV / ATKINSON 4V	2010 - 2012	OCSM	●	●	●
Fusion	2.5L	HEV / ATKINSON 4V	2010 - 2012	PAM	●	●	●
Fusion	2.5L	HEV / ATKINSON 4V	2010 - 2012	PCM	●	●	●
Fusion	2.5L	HEV / ATKINSON 4V	2010 - 2012	PSCM	●	●	●
Fusion	2.5L	HEV / ATKINSON 4V	2010 - 2012	RCM	●	●	●
Fusion	2.5L	HEV / ATKINSON 4V	2010 - 2012	SOD-L	●	●	●
Fusion	2.5L	HEV / ATKINSON 4V	2010 - 2012	SOD-R	●	●	●
Fusion	2.5L	HEV / ATKINSON 4V	2010 - 2012	TBM	●	●	●
Fusion	2.5L	HEV / ATKINSON 4V	2010 - 2012	TCM	●	●	●
Fusion	2.5L	IVCT	2013	ABS	●	●	●
Fusion	2.5L	IVCT	2013	ACM	●	●	●
Fusion	2.5L	IVCT	2013	BCM#1	●	●	●
Fusion	2.5L	IVCT	2013	C-CM	●	●	●



Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Fusion	2.5L	IVCT	2013	DDM	●	●	●
Fusion	2.5L	IVCT	2013	GFM	●	●	●
Fusion	2.5L	IVCT	2013	GPSM	●	●	●
Fusion	2.5L	IVCT	2013	GWM	●	●	●
Fusion	2.5L	IVCT	2013	HCM	●	●	●
Fusion	2.5L	IVCT	2013	HSWM	●	●	●
Fusion	2.5L	IVCT	2013	IPC	●	●	●
Fusion	2.5L	IVCT	2013	IPM-A	●	●	●
Fusion	2.5L	IVCT	2013	OCSM	●	●	●
Fusion	2.5L	IVCT	2013	PAM	●	●	○
Fusion	2.5L	IVCT	2013	PDM	●	●	○
Fusion	2.5L	IVCT	2013	PSCM	●	●	○
Fusion	2.5L	IVCT	2013	RGTM	●	●	○
Fusion	2.5L	IVCT	2013	SCM-G	●	●	○
Fusion	2.5L	IVCT	2013	SCM-H	●	●	○
Fusion	2.5L	IVCT	2013	VDM	●	●	○
Fusion	2.5L	IVCT	2013 - 2014	APIM	●	●	●
Fusion	2.5L	IVCT	2013 - 2014	DACM-C	●	●	●
Fusion	2.5L	IVCT	2013 - 2014	DSM	●	●	●
Fusion	2.5L	IVCT	2013 - 2014	DSP	●	●	●
Fusion	2.5L	IVCT	2013 - 2014	FCDIM	●	●	●
Fusion	2.5L	IVCT	2013 - 2014	FCIM	●	●	●
Fusion	2.5L	IVCT	2013 - 2014	HUD	●	●	●
Fusion	2.5L	IVCT	2013 - 2014	PCM	●	●	●
Fusion	2.5L	IVCT	2013 - 2014	RACM	●	●	○
Fusion	2.5L	IVCT	2013 - 2014	RCM	●	●	○
Fusion	2.5L	IVCT	2013 - 2014	RTM	●	●	○
Fusion	2.5L	IVCT	2013 - 2014	SCCM	●	●	○
Fusion	2.5L	IVCT	2013 - 2014	SCM-E	●	●	○
Fusion	2.5L	IVCT	2013 - 2014	SOD-L	●	●	○
Fusion	2.5L	IVCT	2013 - 2014	SOD-R	●	●	○
Fusion	3.0L	4V	2006 - 2007	EATC	●	●	●
Fusion	3.0L	4V	2006 - 2007	GEM	●	●	●
Fusion	3.0L	4V	2006 - 2009	IC	●	●	●
Fusion	3.0L	4V	2006 - 2009	TCM	●	●	●
Fusion	3.0L	4V	2006 - 2012	ABS	●	●	●
Fusion	3.0L	4V	2006 - 2012	ACM	●	●	●
Fusion	3.0L	4V	2006 - 2012	OCSM	●	●	●
Fusion	3.0L	4V	2006 - 2012	PCM	●	●	●
Fusion	3.0L	4V	2006 - 2012	RCM	●	●	●
Fusion	3.0L	4V	2006 - 2012	TBM	●	●	●
Fusion	3.0L	4V	2007 - 2009	SDARS	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Fusion	3.0L	4V	2007 - 2012	4X4	●	●	●
Fusion	3.0L	4V	2008 - 2012	APIM	●	●	●
Fusion	3.0L	4V	2008 - 2012	GEM / SJB	●	●	●
Fusion	3.0L	4V	2008 - 2012	HVAC	●	●	●
Fusion	3.0L	4V	2008 - 2012	PAM	●	●	●
Fusion	3.0L	4V	2010 - 2012	DSP	●	●	●
Fusion	3.0L	4V	2010 - 2012	FCIM	●	●	●
Fusion	3.0L	4V	2010 - 2012	FDIM	●	●	●
Fusion	3.0L	4V	2010 - 2012	GPSM	●	●	●
Fusion	3.0L	4V	2010 - 2012	IPC	●	●	●
Fusion	3.0L	4V	2010 - 2012	PSCM	●	●	●
Fusion	3.0L	4V	2010 - 2012	SOD-L	●	●	●
Fusion	3.0L	4V	2010 - 2012	SOD-R	●	●	●
Fusion	3.5L	4V	2010 - 2012	4X4	●	●	●
Fusion	3.5L	4V	2010 - 2012	ABS	●	●	●
Fusion	3.5L	4V	2010 - 2012	ACM	●	●	●
Fusion	3.5L	4V	2010 - 2012	APIM	●	●	●
Fusion	3.5L	4V	2010 - 2012	DSP	●	●	●
Fusion	3.5L	4V	2010 - 2012	FCIM	●	●	●
Fusion	3.5L	4V	2010 - 2012	FDIM	●	●	●
Fusion	3.5L	4V	2010 - 2012	GEM / SJB	●	●	●
Fusion	3.5L	4V	2010 - 2012	GPSM	●	●	●
Fusion	3.5L	4V	2010 - 2012	HVAC	●	●	●
Fusion	3.5L	4V	2010 - 2012	IPC	●	●	●
Fusion	3.5L	4V	2010 - 2012	OCSM	●	●	●
Fusion	3.5L	4V	2010 - 2012	PAM	●	●	●
Fusion	3.5L	4V	2010 - 2012	PCM	●	●	●
Fusion	3.5L	4V	2010 - 2012	PSCM	●	●	●
Fusion	3.5L	4V	2010 - 2012	RCM	●	●	●
Fusion	3.5L	4V	2010 - 2012	SOD-L	●	●	●
Fusion	3.5L	4V	2010 - 2012	SOD-R	●	●	●
Fusion	3.5L	4V	2010 - 2012	TBM	●	●	●
Fusion	3.5L	4V	2010 - 2012	TCM	●	●	●
Fusion	Other	Other	2012	4X4	●	●	●
Fusion	Other	Other	2012	ABS	●	●	●
Fusion	Other	Other	2012	ACM	●	●	●
Fusion	Other	Other	2012	APIM	●	●	●
Fusion	Other	Other	2012	DSP	●	●	●
Fusion	Other	Other	2012	FCIM	●	●	●
Fusion	Other	Other	2012	FDIM	●	●	●
Fusion	Other	Other	2012	GEM / SJB	●	●	●
Fusion	Other	Other	2012	GPSM	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Fusion	Other	Other	2012	HVAC	●	●	●
Fusion	Other	Other	2012	IPC	●	●	●
Fusion	Other	Other	2012	OCSM	●	●	●
Fusion	Other	Other	2012	PAM	●	●	●
Fusion	Other	Other	2012	PSCM	●	●	●
Fusion	Other	Other	2012	RCM	●	●	●
Fusion	Other	Other	2012	SOD-L	●	●	●
Fusion	Other	Other	2012	SOD-R	●	●	●
Fusion	Other	Other	2012	TBM	●	●	●
GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2010	ABS	●	●	●
GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2010	ACM	●	●	●
GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2010	AHCM	●	●	●
GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2010	BCMii	●	●	●
GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2010	CCMii	●	●	●
GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2010	CDP	●	●	●
GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2010	CMR	●	●	●
GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2010	DDM	●	●	●
GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2010	DSM	●	●	●
GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2010	HCM	●	●	●
GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2010	HVAC	●	●	●
GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2010	IPC	●	●	●
GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2010	IPM-A	●	●	●
GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2010	NAV	●	●	●
GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2010	PAM	●	●	●
GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2010	PBM	●	●	●
GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2010	PCM	●	●	●
GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2010	PDM	●	●	●
GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2010	PSCM	●	●	●
GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2010	RCM	●	●	●
GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2010	RFA	●	●	●
GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2010	RGTM	●	●	●
GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2010	RHVAC	●	●	●
GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2010	SASM	●	●	●
GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2010	SOD-L	●	●	●
GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2010	SOD-R	●	●	●
GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2010	SRM	●	●	●
GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2010	TRM	●	●	●
GALAXY\S-Max	1.6L	Duratorq Turbo Diesel Common Rail Injection	2010	VDM	●	●	●
GALAXY\S-Max	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2010	ABS	●	●	●
GALAXY\S-Max	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2010	ACM	●	●	●
GALAXY\S-Max	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2010	AHCM	●	●	●
GALAXY\S-Max	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2010	BCMii	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
GALAXY\S-Max	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2010	CCMii	●	●	●
GALAXY\S-Max	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2010	CDP	●	●	●
GALAXY\S-Max	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2010	CMR	●	●	●
GALAXY\S-Max	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2010	DDM	●	●	●
GALAXY\S-Max	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2010	DSM	●	●	●
GALAXY\S-Max	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2010	HCM	●	●	●
GALAXY\S-Max	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2010	HVAC	●	●	●
GALAXY\S-Max	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2010	IPC	●	●	●
GALAXY\S-Max	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2010	IPM-A	●	●	●
GALAXY\S-Max	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2010	NAV	●	●	●
GALAXY\S-Max	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2010	PAM	●	●	●
GALAXY\S-Max	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2010	PBM	●	●	●
GALAXY\S-Max	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2010	PCM	●	●	●
GALAXY\S-Max	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2010	PDM	●	●	●
GALAXY\S-Max	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2010	PSCM	●	●	●
GALAXY\S-Max	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2010	RCM	●	●	●
GALAXY\S-Max	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2010	RFA	●	●	●
GALAXY\S-Max	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2010	RGTM	●	●	●
GALAXY\S-Max	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2010	RHVAC	●	●	●
GALAXY\S-Max	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2010	SASM	●	●	●
GALAXY\S-Max	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2010	SOD-L	●	●	●
GALAXY\S-Max	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2010	SOD-R	●	●	●
GALAXY\S-Max	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2010	SRM	●	●	●
GALAXY\S-Max	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2010	TRM	●	●	●
GALAXY\S-Max	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2010	VDM	●	●	●
GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	2006	ABS	●	●	●
GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	2006	ACM	●	●	●
GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	2006	AHCM	●	●	●
GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	2006	BCMii	●	●	●
GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	2006	CCMii	●	●	●
GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	2006	CDP	●	●	●
GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	2006	DDM	●	●	●
GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	2006	GDM	●	●	●
GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	2006	HCM	●	●	●
GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	2006	HVAC	●	●	●
GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	2006	IPC	●	●	●
GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	2006	NAV	●	●	●
GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	2006	PAM	●	●	●
GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	2006	PBM	●	●	●
GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	2006	PCM	●	●	●
GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	2006	PDM	●	●	●
GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	2006	PSCM	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	2006	RCM	●	●	●
GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	2006	RFA	●	●	●
GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	2006	RGTM	●	●	●
GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	2006	RHVAC	●	●	●
GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	2006	SASM	●	●	●
GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	2006	SRM	●	●	●
GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	2006	TRM	●	●	●
GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	2006	VDM	●	●	●
GALAXY\S-Max	2.0L	DURATEC-HE / I4	2006	GDM	●	●	●
GALAXY\S-Max	2.0L	DURATEC-HE / I4	2006 - 2010	ABS	●	●	●
GALAXY\S-Max	2.0L	DURATEC-HE / I4	2006 - 2010	ACM	●	●	●
GALAXY\S-Max	2.0L	DURATEC-HE / I4	2006 - 2010	AHCM	●	●	●
GALAXY\S-Max	2.0L	DURATEC-HE / I4	2006 - 2010	BCMii	●	●	●
GALAXY\S-Max	2.0L	DURATEC-HE / I4	2006 - 2010	CCMii	●	●	●
GALAXY\S-Max	2.0L	DURATEC-HE / I4	2006 - 2010	CDP	●	●	●
GALAXY\S-Max	2.0L	DURATEC-HE / I4	2006 - 2010	DDM	●	●	●
GALAXY\S-Max	2.0L	DURATEC-HE / I4	2006 - 2010	HCM	●	●	●
GALAXY\S-Max	2.0L	DURATEC-HE / I4	2006 - 2010	HVAC	●	●	●
GALAXY\S-Max	2.0L	DURATEC-HE / I4	2006 - 2010	IPC	●	●	●
GALAXY\S-Max	2.0L	DURATEC-HE / I4	2006 - 2010	NAV	●	●	●
GALAXY\S-Max	2.0L	DURATEC-HE / I4	2006 - 2010	PAM	●	●	●
GALAXY\S-Max	2.0L	DURATEC-HE / I4	2006 - 2010	PBM	●	●	●
GALAXY\S-Max	2.0L	DURATEC-HE / I4	2006 - 2010	PCM	●	●	●
GALAXY\S-Max	2.0L	DURATEC-HE / I4	2006 - 2010	PDM	●	●	●
GALAXY\S-Max	2.0L	DURATEC-HE / I4	2006 - 2010	PSCM	●	●	●
GALAXY\S-Max	2.0L	DURATEC-HE / I4	2006 - 2010	RCM	●	●	●
GALAXY\S-Max	2.0L	DURATEC-HE / I4	2006 - 2010	RFA	●	●	●
GALAXY\S-Max	2.0L	DURATEC-HE / I4	2006 - 2010	RGTM	●	●	●
GALAXY\S-Max	2.0L	DURATEC-HE / I4	2006 - 2010	RHVAC	●	●	●
GALAXY\S-Max	2.0L	DURATEC-HE / I4	2006 - 2010	SASM	●	●	●
GALAXY\S-Max	2.0L	DURATEC-HE / I4	2006 - 2010	SRM	●	●	●
GALAXY\S-Max	2.0L	DURATEC-HE / I4	2006 - 2010	TRM	●	●	●
GALAXY\S-Max	2.0L	DURATEC-HE / I4	2006 - 2010	VDM	●	●	●
GALAXY\S-Max	2.0L	DURATEC-HE / I4	2010	CMR	●	●	●
GALAXY\S-Max	2.0L	DURATEC-HE / I4	2010	DSM	●	●	●
GALAXY\S-Max	2.0L	DURATEC-HE / I4	2010	IPM-A	●	●	●
GALAXY\S-Max	2.0L	DURATEC-HE / I4	2010	SOD-L	●	●	●
GALAXY\S-Max	2.0L	DURATEC-HE / I4	2010	SOD-R	●	●	●
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	2006	GDM	●	●	●
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	2006 - 2010	ABS	●	●	●
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	2006 - 2010	ACM	●	●	●
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	2006 - 2010	AHCM	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	2006 - 2010	BCMii	●	●	●
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	2006 - 2010	CCMii	●	●	●
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	2006 - 2010	CDP	●	●	●
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	2006 - 2010	DDM	●	●	●
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	2006 - 2010	HCM	●	●	●
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	2006 - 2010	HVAC	●	●	●
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	2006 - 2010	IPC	●	●	●
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	2006 - 2010	NAV	●	●	●
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	2006 - 2010	PAM	●	●	●
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	2006 - 2010	PBM	●	●	●
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	2006 - 2010	PCM	●	●	●
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	2006 - 2010	PDM	●	●	●
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	2006 - 2010	PSCM	●	●	●
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	2006 - 2010	RCM	●	●	●
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	2006 - 2010	RFA	●	●	●
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	2006 - 2010	RGTM	●	●	●
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	2006 - 2010	RHVAC	●	●	●
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	2006 - 2010	SASM	●	●	●
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	2006 - 2010	SRM	●	●	●
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	2006 - 2010	TCM	●	●	●
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	2006 - 2010	TRM	●	●	●
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	2006 - 2010	VDM	●	●	●
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	2010	CMR	●	●	●
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	2010	DABM	●	●	●
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	2010	DSM	●	●	●
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	2010	IPM-A	●	●	●
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	2010	SOD-L	●	●	●
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection	2010	SOD-R	●	●	●
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	ABS	●	●	●
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	ACM	●	●	●
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	AHCM	●	●	●
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	BCMii	●	●	●
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	CCMii	●	●	●
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	CDP	●	●	●
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	CMR	●	●	●
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	DDM	●	●	●
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	DSM	●	●	●
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	HCM	●	●	●
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	HVAC	●	●	●
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	IPC	●	●	●
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	IPM-A	●	●	●
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	NAV	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	PAM	●	●	●
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	PBM	●	●	●
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	PCM	●	●	●
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	PDM	●	●	●
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	PSCM	●	●	●
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	RCM	●	●	●
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	RFA	●	●	●
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	RGTM	●	●	●
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	RHVAC	●	●	●
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	SASM	●	●	●
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	SOD-L	●	●	●
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	SOD-R	●	●	●
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	SRM	●	●	●
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	TCM	●	●	●
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	TRM	●	●	●
GALAXY\S-Max	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	VDM	●	●	●
GALAXY\S-Max	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2010	ABS	●	●	●
GALAXY\S-Max	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2010	ACM	●	●	●
GALAXY\S-Max	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2010	AHCM	●	●	●
GALAXY\S-Max	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2010	BCM i	●	●	●
GALAXY\S-Max	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2010	CCM i	●	●	●
GALAXY\S-Max	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2010	CDP	●	●	●
GALAXY\S-Max	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2010	CMR	●	●	●
GALAXY\S-Max	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2010	DABM	●	●	●
GALAXY\S-Max	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2010	DDM	●	●	●
GALAXY\S-Max	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2010	DSM	●	●	●
GALAXY\S-Max	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2010	HCM	●	●	●
GALAXY\S-Max	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2010	HVAC	●	●	●
GALAXY\S-Max	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2010	IPC	●	●	●
GALAXY\S-Max	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2010	IPM-A	●	●	●
GALAXY\S-Max	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2010	NAV	●	●	●
GALAXY\S-Max	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2010	PBM	●	●	●
GALAXY\S-Max	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2010	PCM	●	●	●
GALAXY\S-Max	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2010	PDM	●	●	●
GALAXY\S-Max	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2010	PSCM	●	●	●
GALAXY\S-Max	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2010	RCM	●	●	●
GALAXY\S-Max	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2010	RGTM	●	●	●
GALAXY\S-Max	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2010	RHVAC	●	●	●
GALAXY\S-Max	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2010	SASM	●	●	●
GALAXY\S-Max	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2010	SOD-L	●	●	●
GALAXY\S-Max	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2010	SOD-R	●	●	●
GALAXY\S-Max	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2010	SRM	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
GALAXY\S-Max	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2010	TCM	●	●	●
GALAXY\S-Max	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2010	TRM	●	●	●
GALAXY\S-Max	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2010	VDM	●	●	●
GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	2006	GDM	●	●	●
GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	2006	PAM	●	●	●
GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	2006	RFA	●	●	●
GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	2006 - 2010	ABS	●	●	●
GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	2006 - 2010	ACM	●	●	●
GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	2006 - 2010	AHCM	●	●	●
GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	2006 - 2010	BCMii	●	●	●
GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	2006 - 2010	CCMii	●	●	●
GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	2006 - 2010	CDP	●	●	●
GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	2006 - 2010	DDM	●	●	●
GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	2006 - 2010	HCM	●	●	●
GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	2006 - 2010	HVAC	●	●	●
GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	2006 - 2010	IPC	●	●	●
GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	2006 - 2010	NAV	●	●	●
GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	2006 - 2010	PBM	●	●	●
GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	2006 - 2010	PCM	●	●	●
GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	2006 - 2010	PDM	●	●	●
GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	2006 - 2010	PSCM	●	●	●
GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	2006 - 2010	RCM	●	●	●
GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	2006 - 2010	RGTM	●	●	●
GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	2006 - 2010	RHVAC	●	●	●
GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	2006 - 2010	SASM	●	●	●
GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	2006 - 2010	SRM	●	●	●
GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	2006 - 2010	TRM	●	●	●
GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	2006 - 2010	VDM	●	●	●
GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	2010	CMR	●	●	●
GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	2010	DABM	●	●	●
GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	2010	DSM	●	●	●
GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	2010	IPM-A	●	●	●
GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	2010	SOD-L	●	●	●
GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection	2010	SOD-R	●	●	●
GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	ABS	●	●	●
GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	ACM	●	●	●
GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	AHCM	●	●	●
GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	BCMii	●	●	●
GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	CCMii	●	●	●
GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	CDP	●	●	●
GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	CMR	●	●	●
GALAXY\S-Max	2.2L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	DABM	●	●	●



Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	DDM	●	●	●
GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	DSM	●	●	●
GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	HCM	●	●	●
GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	HVAC	●	●	●
GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	IPC	●	●	●
GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	IPM-A	●	●	●
GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	NAV	●	●	●
GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	PBM	●	●	●
GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	PCM	●	●	●
GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	PDM	●	●	●
GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	PSCM	●	●	●
GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	RCM	●	●	●
GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	RGTM	●	●	●
GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	RHVAC	●	●	●
GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	SASM	●	●	●
GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	SOD-L	●	●	●
GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	SOD-R	●	●	●
GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	SRM	●	●	●
GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	TCM	●	●	●
GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	TRM	●	●	●
GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	2010	VDM	●	●	●
GALAXY\S-Max	2. 3L	DURATEC-HE / I4	2006	GDM	●	●	●
GALAXY\S-Max	2. 3L	DURATEC-HE / I4	2006 - 2010	ABS	●	●	●
GALAXY\S-Max	2. 3L	DURATEC-HE / I4	2006 - 2010	ACM	●	●	●
GALAXY\S-Max	2. 3L	DURATEC-HE / I4	2006 - 2010	AHCM	●	●	●
GALAXY\S-Max	2. 3L	DURATEC-HE / I4	2006 - 2010	BCMii	●	●	●
GALAXY\S-Max	2. 3L	DURATEC-HE / I4	2006 - 2010	CCMii	●	●	●
GALAXY\S-Max	2. 3L	DURATEC-HE / I4	2006 - 2010	CDP	●	●	●
GALAXY\S-Max	2. 3L	DURATEC-HE / I4	2006 - 2010	DDM	●	●	●
GALAXY\S-Max	2. 3L	DURATEC-HE / I4	2006 - 2010	HCM	●	●	●
GALAXY\S-Max	2. 3L	DURATEC-HE / I4	2006 - 2010	HVAC	●	●	●
GALAXY\S-Max	2. 3L	DURATEC-HE / I4	2006 - 2010	IPC	●	●	●
GALAXY\S-Max	2. 3L	DURATEC-HE / I4	2006 - 2010	NAV	●	●	●
GALAXY\S-Max	2. 3L	DURATEC-HE / I4	2006 - 2010	PAM	●	●	●
GALAXY\S-Max	2. 3L	DURATEC-HE / I4	2006 - 2010	PBM	●	●	●
GALAXY\S-Max	2. 3L	DURATEC-HE / I4	2006 - 2010	PCM	●	●	●
GALAXY\S-Max	2. 3L	DURATEC-HE / I4	2006 - 2010	PDM	●	●	●
GALAXY\S-Max	2. 3L	DURATEC-HE / I4	2006 - 2010	PSCM	●	●	●
GALAXY\S-Max	2. 3L	DURATEC-HE / I4	2006 - 2010	RCM	●	●	●
GALAXY\S-Max	2. 3L	DURATEC-HE / I4	2006 - 2010	RFA	●	●	●
GALAXY\S-Max	2. 3L	DURATEC-HE / I4	2006 - 2010	RGTM	●	●	●
GALAXY\S-Max	2. 3L	DURATEC-HE / I4	2006 - 2010	RHVAC	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
GALAXY\S-Max	2. 3L	DURATEC-HE / I4	2006 - 2010	SASM	●	●	●
GALAXY\S-Max	2. 3L	DURATEC-HE / I4	2006 - 2010	SRM	●	●	●
GALAXY\S-Max	2. 3L	DURATEC-HE / I4	2006 - 2010	TCM	●	●	●
GALAXY\S-Max	2. 3L	DURATEC-HE / I4	2006 - 2010	TRM	●	●	●
GALAXY\S-Max	2. 3L	DURATEC-HE / I4	2006 - 2010	VDM	●	●	●
GALAXY\S-Max	2. 3L	DURATEC-HE / I4	2010	CMR	●	●	●
GALAXY\S-Max	2. 3L	DURATEC-HE / I4	2010	DABM	●	●	●
GALAXY\S-Max	2. 3L	DURATEC-HE / I4	2010	DSM	●	●	●
GALAXY\S-Max	2. 3L	DURATEC-HE / I4	2010	IPM-A	●	●	●
GALAXY\S-Max	2. 3L	DURATEC-HE / I4	2010	SOD-L	●	●	●
GALAXY\S-Max	2. 3L	DURATEC-HE / I4	2010	SOD-R	●	●	●
GALAXY\S-Max	2. 5L	I5	2006	ABS	●	●	●
GALAXY\S-Max	2. 5L	I5	2006	ACM	●	●	●
GALAXY\S-Max	2. 5L	I5	2006	AHCM	●	●	●
GALAXY\S-Max	2. 5L	I5	2006	BCM i i	●	●	●
GALAXY\S-Max	2. 5L	I5	2006	CCM i i	●	●	●
GALAXY\S-Max	2. 5L	I5	2006	CDP	●	●	●
GALAXY\S-Max	2. 5L	I5	2006	DDM	●	●	●
GALAXY\S-Max	2. 5L	I5	2006	GDM	●	●	●
GALAXY\S-Max	2. 5L	I5	2006	HCM	●	●	●
GALAXY\S-Max	2. 5L	I5	2006	HVAC	●	●	●
GALAXY\S-Max	2. 5L	I5	2006	IPC	●	●	●
GALAXY\S-Max	2. 5L	I5	2006	NAV	●	●	●
GALAXY\S-Max	2. 5L	I5	2006	PAM	●	●	●
GALAXY\S-Max	2. 5L	I5	2006	PBM	●	●	●
GALAXY\S-Max	2. 5L	I5	2006	PCM	●	●	●
GALAXY\S-Max	2. 5L	I5	2006	PDM	●	●	●
GALAXY\S-Max	2. 5L	I5	2006	PSCM	●	●	●
GALAXY\S-Max	2. 5L	I5	2006	RCM	●	●	●
GALAXY\S-Max	2. 5L	I5	2006	RFA	●	●	●
GALAXY\S-Max	2. 5L	I5	2006	RGTM	●	●	●
GALAXY\S-Max	2. 5L	I5	2006	RHVAC	●	●	●
GALAXY\S-Max	2. 5L	I5	2006	SASM	●	●	●
GALAXY\S-Max	2. 5L	I5	2006	SRM	●	●	●
GALAXY\S-Max	2. 5L	I5	2006	TRM	●	●	●
GALAXY\S-Max	2. 5L	I5	2006	VDM	●	●	●
Galaxy	1. 9L	EDC 1.9	2001	FFH	●	●	●
Galaxy	1. 9L	EDC 1.9	2001	LHID	●	●	●
Galaxy	1. 9L	EDC 1.9	2001	MFSW	●	●	●
Galaxy	1. 9L	EDC 1.9	2001	PAM	●	●	●
Galaxy	1. 9L	EDC 1.9	2001	RADIO	●	●	●
Galaxy	1. 9L	EDC 1.9	2001	RCC	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Galaxy	1.9L	EDC 1.9	2001	RHID	●	●	●
Galaxy	1.9L	EDC 1.9	2001	RNS	●	●	●
Galaxy	1.9L	EDC 1.9	2001 - Other	ABS	●	●	●
Galaxy	1.9L	EDC 1.9	2001 - Other	CCM	●	●	●
Galaxy	1.9L	EDC 1.9	2001 - Other	CJB	●	●	●
Galaxy	1.9L	EDC 1.9	2001 - Other	IC	●	●	●
Galaxy	1.9L	EDC 1.9	2001 - Other	PATS	●	●	●
Galaxy	1.9L	EDC 1.9	2001 - Other	PCM	●	●	●
Galaxy	1.9L	EDC 1.9	2001 - Other	RCM	●	●	●
Galaxy	1.9L	EDC 1.9	2001 - Other	TCM	●	●	●
Galaxy	2.0L	2.0 DOHC SFI (8V)	1995 - 2000	ABS	●	●	●
Galaxy	2.0L	2.0 DOHC SFI (8V)	1995 - 2000	CCM	●	●	●
Galaxy	2.0L	2.0 DOHC SFI (8V)	1995 - 2000	CJB	●	●	●
Galaxy	2.0L	2.0 DOHC SFI (8V)	1995 - 2000	IC	●	●	●
Galaxy	2.0L	2.0 DOHC SFI (8V)	1995 - 2000	PATS	●	●	●
Galaxy	2.0L	2.0 DOHC SFI (8V)	1995 - 2000	PCM	●	●	●
Galaxy	2.0L	2.0 DOHC SFI (8V)	1995 - 2000	RCM	●	●	●
Galaxy	2.0L	2.0 DOHC SFI (8V)	1995 - 2000	TCM	●	●	●
Galaxy	2.0L	2.0 DOHC SFI (8V)	2000	LHID	●	●	●
Galaxy	2.0L	2.0 DOHC SFI (8V)	2000	MFSW	●	●	●
Galaxy	2.0L	2.0 DOHC SFI (8V)	2000	PAM	●	●	●
Galaxy	2.0L	2.0 DOHC SFI (8V)	2000	RADIO	●	●	●
Galaxy	2.0L	2.0 DOHC SFI (8V)	2000	RCC	●	●	●
Galaxy	2.0L	2.0 DOHC SFI (8V)	2000	RHID	●	●	●
Galaxy	2.0L	2.0 DOHC SFI (8V)	2000	RNS	●	●	●
Galaxy	2.3L	DOHC SFI (16V)	1997 - 2000	ABS	●	●	●
Galaxy	2.3L	DOHC SFI (16V)	1997 - 2000	CCM	●	●	●
Galaxy	2.3L	DOHC SFI (16V)	1997 - 2000	CJB	●	●	●
Galaxy	2.3L	DOHC SFI (16V)	1997 - 2000	IC	●	●	●
Galaxy	2.3L	DOHC SFI (16V)	1997 - 2000	PATS	●	●	●
Galaxy	2.3L	DOHC SFI (16V)	1997 - 2000	PCM	●	●	●
Galaxy	2.3L	DOHC SFI (16V)	1997 - 2000	RCM	●	●	●
Galaxy	2.3L	DOHC SFI (16V)	1997 - 2000	TCM	●	●	●
Galaxy	2.3L	DOHC SFI (16V)	2000	LHID	●	●	●
Galaxy	2.3L	DOHC SFI (16V)	2000	MFSW	●	●	●
Galaxy	2.3L	DOHC SFI (16V)	2000	PAM	●	●	●
Galaxy	2.3L	DOHC SFI (16V)	2000	RADIO	●	●	●
Galaxy	2.3L	DOHC SFI (16V)	2000	RCC	●	●	●
Galaxy	2.3L	DOHC SFI (16V)	2000	RHID	●	●	●
Galaxy	2.3L	DOHC SFI (16V)	2000	RNS	●	●	●
Galaxy	2.8L	2.8 CD-V6	2001	LHID	●	●	●
Galaxy	2.8L	2.8 CD-V6	2001	MFSW	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Galaxy	2.8L	2.8 CD-V6	2001	PAM	●	●	●
Galaxy	2.8L	2.8 CD-V6	2001	RADIO	●	●	●
Galaxy	2.8L	2.8 CD-V6	2001	RCC	●	●	●
Galaxy	2.8L	2.8 CD-V6	2001	RHID	●	●	●
Galaxy	2.8L	2.8 CD-V6	2001	RNS	●	●	●
Galaxy	2.8L	2.8 CD-V6	2001 - Other	ABS	●	●	●
Galaxy	2.8L	2.8 CD-V6	2001 - Other	CCM	●	●	●
Galaxy	2.8L	2.8 CD-V6	2001 - Other	CJB	●	●	●
Galaxy	2.8L	2.8 CD-V6	2001 - Other	IC	●	●	●
Galaxy	2.8L	2.8 CD-V6	2001 - Other	PATS	●	●	●
Galaxy	2.8L	2.8 CD-V6	2001 - Other	PCM	●	●	●
Galaxy	2.8L	2.8 CD-V6	2001 - Other	RCM	●	●	●
Galaxy	2.8L	2.8 CD-V6	2001 - Other	TCM	●	●	●
Granada / Scorpio	2.0L	2.0 DOHC SFI (8V)	1995 - 1997	ABS/TCS	●	●	●
Granada / Scorpio	2.0L	2.0 DOHC SFI (8V)	1995 - 1997	GEM	●	●	●
Granada / Scorpio	2.0L	2.0 DOHC SFI (8V)	1995 - 1997	PATS	○	○	●
Granada / Scorpio	2.0L	2.0 DOHC SFI (8V)	1995 - 1997	PCM	●	●	●
Granada / Scorpio	2.0L	2.0 DOHC SFI (8V)	1995 - 1997	RCM	●	●	●
Granada / Scorpio	2.0L	DOHC SFI (16V)	1995	ABS/TCS	●	●	●
Granada / Scorpio	2.0L	DOHC SFI (16V)	1995	GEM	●	●	●
Granada / Scorpio	2.0L	DOHC SFI (16V)	1995	PATS	○	○	●
Granada / Scorpio	2.0L	DOHC SFI (16V)	1995	PCM	●	●	●
Granada / Scorpio	2.0L	DOHC SFI (16V)	1995	RCM	●	●	●
Granada / Scorpio	2.0L	Other	1995	ABS/TCS	●	●	●
Granada / Scorpio	2.0L	Other	1995	GEM	●	●	●
Granada / Scorpio	2.0L	Other	1995	PATS	●	●	●
Granada / Scorpio	2.0L	Other	1995	PCM	●	●	●
Granada / Scorpio	2.0L	Other	1995	RCM	●	●	●
Granada / Scorpio	2.3L	DOHC SFI (16V)	1996 - 1998	ABS/TCS	●	●	●
Granada / Scorpio	2.3L	DOHC SFI (16V)	1996 - 1998	GEM	●	●	●
Granada / Scorpio	2.3L	DOHC SFI (16V)	1996 - 1998	PATS	○	○	●
Granada / Scorpio	2.3L	DOHC SFI (16V)	1996 - 1998	PCM	●	●	●
Granada / Scorpio	2.3L	DOHC SFI (16V)	1996 - 1998	RCM	●	●	●
Granada / Scorpio	2.5L	Other	Other	ABS/TCS	●	●	●
Granada / Scorpio	2.5L	Other	Other	GEM	●	●	●
Granada / Scorpio	2.5L	Other	Other	PATS	●	●	●
Granada / Scorpio	2.5L	Other	Other	PCM	●	●	●
Granada / Scorpio	2.5L	Other	Other	RCM	●	●	●
Granada / Scorpio	2.9L	2.9 V6 24V	1991 - 1998	ABS/TCS	●	●	●
Granada / Scorpio	2.9L	2.9 V6 24V	1991 - 1998	GEM	●	●	●
Granada / Scorpio	2.9L	2.9 V6 24V	1991 - 1998	PATS	●	●	●
Granada / Scorpio	2.9L	2.9 V6 24V	1991 - 1998	PCM	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Granada / Scorpio	2. 9L	2.9 V6 24V	1991 - 1998	RCM	●	●	●
Grand Marquis	4. 6L	2V	1995 - 1997	DSM	●	●	●
Grand Marquis	4. 6L	2V	1995 - 2004	ABS/TCS	●	●	●
Grand Marquis	4. 6L	2V	1995 - 2007	EATC	●	●	●
Grand Marquis	4. 6L	2V	1995 - 2011	DDM	●	●	●
Grand Marquis	4. 6L	2V	1995 - 2011	LCM	●	●	●
Grand Marquis	4. 6L	2V	1995 - 2011	PCM	●	●	●
Grand Marquis	4. 6L	2V	1996 - 1998	IAB	●	●	●
Grand Marquis	4. 6L	2V	1998 - 2000	ECS	●	●	●
Grand Marquis	4. 6L	2V	1998 - 2002	PATS	●	●	●
Grand Marquis	4. 6L	2V	2000 - 2011	RCM	●	●	●
Grand Marquis	4. 6L	2V	2003 - 2006	RASM	●	●	●
Grand Marquis	4. 6L	2V	2003 - 2006	VAPS	●	●	●
Grand Marquis	4. 6L	2V	2004 - 2010	MC	●	●	●
Grand Marquis	4. 6L	2V	2005 - 2011	ABS	●	●	●
Grand Marquis	4. 6L	2V	2006 - 2011	IC	●	●	●
Grand Marquis	4. 6L	2V	2007 - 2011	VDM	●	●	●
Grand Marquis	4. 6L	2V	2008 - 2011	HVAC	●	●	●
Grand Marquis	4. 6L	2V_NGV	1996	ABS/TCS	●	●	●
Grand Marquis	4. 6L	2V_NGV	1996	DDM	●	●	●
Grand Marquis	4. 6L	2V_NGV	1996	DSM	●	●	●
Grand Marquis	4. 6L	2V_NGV	1996	FIM	●	●	●
Grand Marquis	4. 6L	2V_NGV	1996	IAB	●	●	●
Grand Marquis	4. 6L	2V_NGV	1996	LCM	●	●	●
Grand Marquis	4. 6L	2V_NGV	1996	PCM	●	●	●
Ikon	1. 3L	HCS	2000	PCM	●	●	●
Ikon	1. 3L	Zetec Rocam	2003	ABS/TCS	●	●	●
Ikon	1. 3L	Zetec Rocam	2003	CSM	●	●	●
Ikon	1. 3L	Zetec Rocam	2003	ECS	●	●	●
Ikon	1. 3L	Zetec Rocam	2003	GEM	●	●	●
Ikon	1. 3L	Zetec Rocam	2003	PCM	●	●	●
Ikon	1. 4L	Duratorq Turbo Diesel Common Rail Injection	2009	IC	●	●	●
Ikon	1. 4L	Duratorq Turbo Diesel Common Rail Injection	2009	PCM	●	●	●
Ikon	1. 6L	Other	2001	ECS	●	●	●
Ikon	1. 6L	Other	2001	HEC	●	●	●
Ikon	1. 6L	Other	2001	PCM	●	●	●
Ikon	1. 6L	Zetec Rocam	1999 - 2003	ECS	●	●	●
Ikon	1. 6L	Zetec Rocam	1999 - 2003	HEC	●	●	●
Ikon	1. 6L	Zetec Rocam	1999 - 2003	PCM	●	●	●
Ikon	1. 6L	Zetec Rocam	2003	ABS/TCS	●	●	●
Ikon	1. 6L	Zetec Rocam	2003	CSM	●	●	●
Ikon	1. 6L	Zetec Rocam	2003	GEM	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Ikon	1. 6L	Zetec Rocam	2003	TCM	●	●	●
KA	1. 0L	HCS	1997	PATS	●	●	●
KA	1. 0L	HCS	1997 - 1999	ABS/TCS	●	●	●
KA	1. 0L	HCS	1997 - 1999	CSM	●	●	●
KA	1. 0L	HCS	1997 - 1999	PCM	●	●	●
KA	1. 0L	HCS	1999	ECS	●	●	●
KA	1. 0L	Zetec Rocam	1999	ABS/TCS	●	●	●
KA	1. 0L	Zetec Rocam	1999	CSM	●	●	●
KA	1. 0L	Zetec Rocam	1999	PCM	●	●	●
KA	1. 2L	DURATEC 8V	2009	ABS	●	●	●
KA	1. 2L	DURATEC 8V	2009	BCMii	●	●	●
KA	1. 2L	DURATEC 8V	2009	EATC	●	●	●
KA	1. 2L	DURATEC 8V	2009	EPS	●	●	●
KA	1. 2L	DURATEC 8V	2009	IPC	●	●	●
KA	1. 2L	DURATEC 8V	2009	PAM	●	●	●
KA	1. 2L	DURATEC 8V	2009	PCM	●	●	●
KA	1. 2L	DURATEC 8V	2009	RCM	●	●	●
KA	1. 3L	DURATEC 8V	2000	ABS/TCS	●	●	●
KA	1. 3L	DURATEC 8V	2000	CSM	●	●	●
KA	1. 3L	DURATEC 8V	2000	ECS	●	●	●
KA	1. 3L	DURATEC 8V	2000	GEM	●	●	●
KA	1. 3L	DURATEC 8V	2000	PCM	●	●	●
KA	1. 3L	Duratorq-Turbo Diesel Common Rail Injection	2009	ABS	●	●	●
KA	1. 3L	Duratorq-Turbo Diesel Common Rail Injection	2009	BCMii	●	●	●
KA	1. 3L	Duratorq-Turbo Diesel Common Rail Injection	2009	EATC	●	●	●
KA	1. 3L	Duratorq-Turbo Diesel Common Rail Injection	2009	EPS	●	●	●
KA	1. 3L	Duratorq-Turbo Diesel Common Rail Injection	2009	IPC	●	●	●
KA	1. 3L	Duratorq-Turbo Diesel Common Rail Injection	2009	PAM	●	●	●
KA	1. 3L	Duratorq-Turbo Diesel Common Rail Injection	2009	PCM	●	●	●
KA	1. 3L	Duratorq-Turbo Diesel Common Rail Injection	2009	RCM	●	●	●
KA	1. 3L	Endura-E	1997 - 1998	PATS	●	●	●
KA	1. 3L	Endura-E	1997 - 2000	ABS/TCS	●	●	●
KA	1. 3L	Endura-E	1997 - 2000	CSM	●	●	●
KA	1. 3L	Endura-E	1997 - 2000	PCM	●	●	●
KA	1. 3L	Endura-E	1999 - 2000	ECS	●	●	●
KA	1. 3L	Endura-E	2000	GEM	●	●	●
KA	1. 6L	DURATEC 8V	2000	ABS/TCS	●	●	●
KA	1. 6L	DURATEC 8V	2000	CSM	●	●	●
KA	1. 6L	DURATEC 8V	2000	ECS	●	●	●
KA	1. 6L	DURATEC 8V	2000	GEM	●	●	●
KA	1. 6L	DURATEC 8V	2000	PCM	●	●	●
KA	1. 6L	Zetec Rocam	2001	ABS/TCS	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
KA	1.6L	Zetec Rocam	2001	CSM	●	●	●
KA	1.6L	Zetec Rocam	2001	ECS	●	●	●
KA	1.6L	Zetec Rocam	2001	PCM	●	●	●
KA	Other	Other	2009	ABS	●	●	●
KA	Other	Other	2009	BCMii	●	●	●
KA	Other	Other	2009	EATC	●	●	●
KA	Other	Other	2009	EPS	●	●	●
KA	Other	Other	2009	IPC	●	●	●
KA	Other	Other	2009	PAM	●	●	●
KA	Other	Other	2009	PCM	●	●	●
KA	Other	Other	2009	RCM	●	●	●
Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	ABS	●	●	●
Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	AHCM	●	●	●
Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	APIM	●	●	●
Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	HCM	●	●	●
Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	PCM	●	●	●
Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	PDM	●	●	●
Kuga	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2013	SOD-L	●	●	●
Kuga	1.6L	GTDI FGEC	2013	ABS	●	●	●
Kuga	1.6L	GTDI FGEC	2013	AHCM	●	●	●
Kuga	1.6L	GTDI FGEC	2013	APIM	●	●	●
Kuga	1.6L	GTDI FGEC	2013	HCM	●	●	●
Kuga	1.6L	GTDI FGEC	2013	PDM	●	●	●
Kuga	1.6L	GTDI FGEC	2013	SOD-L	●	●	●
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection	2008	ABS	●	●	●
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection	2008	ACM	●	●	●
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection	2008	AWD	●	●	●
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection	2008	CMR	●	●	●
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection	2008	D_DCU	●	●	●
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection	2008	EATC	●	●	●
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection	2008	EPS	●	●	●
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection	2008	FFH	●	●	●
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection	2008	GEM	●	●	●
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection	2008	HCM	●	●	●
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection	2008	IC	●	●	●
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection	2008	PAM	●	●	●
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection	2008	PCM	●	●	●
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection	2008	P_DCU	●	●	●
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection	2008	RCM	●	●	●
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection	2008	RETM	●	●	●
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection	2008	RKE	●	●	●
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection	2008	SRM	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	ACM	●	●	●
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	AWD	●	●	●
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	CMR	●	●	●
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	D_DCU	●	●	●
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	EATC	●	●	●
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	EPS	●	●	●
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	FFH	●	●	●
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	GEM	●	●	●
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	IC	●	●	●
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	PAM	●	●	●
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	PCM	●	●	●
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	P_DCU	●	●	●
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	RCM	●	●	●
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	RETM	●	●	●
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	RKE	●	●	●
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	SRM	●	●	●
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2008	TCM	●	●	●
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2008 - 2013	ABS	●	●	●
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2008 - 2013	HCM	●	●	●
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2013	AHCM	●	●	●
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2013	APIM	●	●	●
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2013	PDM	●	●	●
Kuga	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2013	SOD-L	●	●	●
Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	ABS	●	●	●
Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	AHCM	●	●	●
Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	APIM	●	●	●
Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	HCM	●	●	●
Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	PCM	●	●	●
Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	PDM	●	●	●
Kuga	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	SOD-L	●	●	●
Kuga	2.5L	I5	2008	ABS	●	●	●
Kuga	2.5L	I5	2008	ACM	●	●	●
Kuga	2.5L	I5	2008	AWD	●	●	●
Kuga	2.5L	I5	2008	CMR	●	●	●
Kuga	2.5L	I5	2008	D_DCU	●	●	●
Kuga	2.5L	I5	2008	EATC	●	●	●
Kuga	2.5L	I5	2008	EPS	●	●	●
Kuga	2.5L	I5	2008	FFH	●	●	●
Kuga	2.5L	I5	2008	GEM	●	●	●
Kuga	2.5L	I5	2008	HCM	●	●	●
Kuga	2.5L	I5	2008	IC	●	●	●
Kuga	2.5L	I5	2008	PAM	●	●	●



Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Kuga	2.5L	I5	2008	PCM	●	●	●
Kuga	2.5L	I5	2008	P_DCU	●	●	●
Kuga	2.5L	I5	2008	RCM	●	●	●
Kuga	2.5L	I5	2008	RETM	●	●	●
Kuga	2.5L	I5	2008	RKE	●	●	●
Kuga	2.5L	I5	2008	SRM	●	●	●
Kuga	2.5L	I5	2008	TCM	●	●	●
LASER / 323 / TIERRA	1.3L	B3	1996 - Other	ABS	●	●	●
LASER / 323 / TIERRA	1.3L	B3	1996 - Other	PCM	●	●	●
LASER / 323 / TIERRA	1.3L	B3	2000	ABS/TCS	●	●	●
LASER / 323 / TIERRA	1.3L	Other	Other	PCM	●	●	●
LASER / 323 / TIERRA	1.5L	Other	Other	PCM	●	●	●
LASER / 323 / TIERRA	1.5L	Z5	1996 - Other	ABS	●	●	●
LASER / 323 / TIERRA	1.5L	Z5	1996 - Other	PCM	●	●	●
LASER / 323 / TIERRA	1.5L	ZL	1998 - Other	ABS	●	●	●
LASER / 323 / TIERRA	1.5L	ZL	1998 - Other	PCM	●	●	●
LASER / 323 / TIERRA	1.6L	B6	1996 - Other	ABS	●	●	●
LASER / 323 / TIERRA	1.6L	B6	1996 - Other	PCM	●	●	●
LASER / 323 / TIERRA	1.6L	Other	Other	PCM	●	●	●
LASER / 323 / TIERRA	1.6L	ZM	1998 - Other	ABS	●	●	●
LASER / 323 / TIERRA	1.6L	ZM	1998 - Other	PCM	●	●	●
LASER / 323 / TIERRA	1.6L	ZM	2000	ABS/TCS	●	●	●
LASER / 323 / TIERRA	1.8L	BP	1996 - Other	ABS	●	●	●
LASER / 323 / TIERRA	1.8L	BP	1996 - Other	PCM	●	●	●
LASER / 323 / TIERRA	1.8L	FP	1998 - Other	ABS	●	●	●
LASER / 323 / TIERRA	1.8L	FP	1998 - Other	PCM	●	●	●
LASER / 323 / TIERRA	1.8L	Other	Other	PCM	●	●	●
LASER / 323 / TIERRA	2.0L	FS	2000	ABS/TCS	●	●	●
LASER / 323 / TIERRA	2.0L	FS	2000 - 2001	ABS	●	●	●
LASER / 323 / TIERRA	2.0L	FS	2000 - 2001	PCM	●	●	●
LASER / 323 / TIERRA	2.0L	RF	1998	PCM	●	●	●
LASER / 323 / TIERRA	2.0L	RF	1998 - Other	ABS	●	●	●
LASER / 323 / TIERRA	2.0L	RF-T	1998 - 2000	PCM	●	●	●
LASER / 323 / TIERRA	2.0L	RF-T	2000	ABS	●	●	●
LS	3.0L	Other	2000 - 2002	CPM	●	●	●
LS	3.0L	Other	2000 - 2002	RESCU	●	●	●
LS	3.0L	Other	2000 - 2005	ABS/TCS	●	●	●
LS	3.0L	Other	2000 - 2005	ACM	●	●	●
LS	3.0L	Other	2000 - 2005	DDM	●	●	●
LS	3.0L	Other	2000 - 2005	DSM	●	●	●
LS	3.0L	Other	2000 - 2005	EATC	●	●	●
LS	3.0L	Other	2000 - 2005	GEM	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
LS	3.0L	Other	2000 - 2005	HEC	●	●	●
LS	3.0L	Other	2000 - 2005	MC	●	●	●
LS	3.0L	Other	2000 - 2005	PCM	●	●	●
LS	3.0L	Other	2000 - 2005	RCM	●	●	●
LS	3.0L	Other	2000 - 2005	REM	●	●	●
LS	3.0L	Other	2003	VEMS	●	●	●
LS	3.0L	Other	2003 - 2005	DCSM	●	●	●
LS	3.0L	Other	2003 - 2005	EPB	●	●	●
LS	3.0L	Other	2003 - 2005	NAV	●	●	●
LS	3.0L	Other	2003 - 2005	PAM	●	●	●
LS	3.0L	Other	2003 - 2005	PCSM	●	●	●
LS	3.0L	Other	2003 - 2005	SCLM	●	●	●
LS	3.9L	4V	2003	VEMS	●	●	●
LS	3.9L	4V	2003 - 2006	ABS/TCS	●	●	●
LS	3.9L	4V	2003 - 2006	ACM	●	●	●
LS	3.9L	4V	2003 - 2006	DCSM	●	●	●
LS	3.9L	4V	2003 - 2006	DDM	●	●	●
LS	3.9L	4V	2003 - 2006	DSM	●	●	●
LS	3.9L	4V	2003 - 2006	EATC	●	●	●
LS	3.9L	4V	2003 - 2006	EPB	●	●	●
LS	3.9L	4V	2003 - 2006	GEM	●	●	●
LS	3.9L	4V	2003 - 2006	HEC	●	●	●
LS	3.9L	4V	2003 - 2006	MC	●	●	●
LS	3.9L	4V	2003 - 2006	NAV	●	●	●
LS	3.9L	4V	2003 - 2006	PAM	●	●	●
LS	3.9L	4V	2003 - 2006	PCM	●	●	●
LS	3.9L	4V	2003 - 2006	PCSM	●	●	●
LS	3.9L	4V	2003 - 2006	RCM	●	●	●
LS	3.9L	4V	2003 - 2006	REM	●	●	●
LS	3.9L	4V	2003 - 2006	SCLM	●	●	●
LS	3.9L	Other	2000 - 2002	ABS/TCS	●	●	●
LS	3.9L	Other	2000 - 2002	ACM	●	●	●
LS	3.9L	Other	2000 - 2002	CPM	●	●	●
LS	3.9L	Other	2000 - 2002	DDM	●	●	●
LS	3.9L	Other	2000 - 2002	DSM	●	●	●
LS	3.9L	Other	2000 - 2002	EATC	●	●	●
LS	3.9L	Other	2000 - 2002	GEM	●	●	●
LS	3.9L	Other	2000 - 2002	HEC	●	●	●
LS	3.9L	Other	2000 - 2002	MC	●	●	●
LS	3.9L	Other	2000 - 2002	PCM	●	●	●
LS	3.9L	Other	2000 - 2002	RCM	●	●	●
LS	3.9L	Other	2000 - 2002	REM	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
LS	3.9L	Other	2000 - 2002	RESCU	●	●	●
Liata	1.6L	Other	Other	PCM	●	●	●
Liata	1.8L	Other	Other	PCM	●	●	●
MAZDA5 (EURO STG3/4/5 and General Specs.) /	1.8L	L8	2005	GEM	●	●	●
MAZDA5 (EURO STG3/4/5 and General Specs.) /	1.8L	L8	2005 - 2007	ABS	●	●	●
MAZDA5 (EURO STG3/4/5 and General Specs.) /	1.8L	L8	2005 - 2007	EATC	●	●	●
MAZDA5 (EURO STG3/4/5 and General Specs.) /	1.8L	L8	2005 - 2007	EPS	●	●	●
MAZDA5 (EURO STG3/4/5 and General Specs.) /	1.8L	L8	2005 - 2007	IC	●	●	●
MAZDA5 (EURO STG3/4/5 and General Specs.) /	1.8L	L8	2005 - 2007	LPSDM	●	●	●
MAZDA5 (EURO STG3/4/5 and General Specs.) /	1.8L	L8	2005 - 2007	PCM	●	●	●
MAZDA5 (EURO STG3/4/5 and General Specs.) /	1.8L	L8	2005 - 2007	RCM	●	●	●
MAZDA5 (EURO STG3/4/5 and General Specs.) /	1.8L	L8	2005 - 2007	RKE	●	●	●
MAZDA5 (EURO STG3/4/5 and General Specs.) /	1.8L	L8	2005 - 2007	RPSDM	●	●	●
MAZDA5 (EURO STG3/4/5 and General Specs.) /	1.8L	L8	2007	TCM	●	●	●
MAZDA5 (EURO STG3/4/5 and General Specs.) /	2.0L	LF	2005 - 2007	ABS	●	●	●
MAZDA5 (EURO STG3/4/5 and General Specs.) /	2.0L	LF	2005 - 2007	EATC	●	●	●
MAZDA5 (EURO STG3/4/5 and General Specs.) /	2.0L	LF	2005 - 2007	EPS	●	●	●
MAZDA5 (EURO STG3/4/5 and General Specs.) /	2.0L	LF	2005 - 2007	GEM	●	●	●
MAZDA5 (EURO STG3/4/5 and General Specs.) /	2.0L	LF	2005 - 2007	IC	●	●	●
MAZDA5 (EURO STG3/4/5 and General Specs.) /	2.0L	LF	2005 - 2007	PCM	●	●	●
MAZDA5 (EURO STG3/4/5 and General Specs.) /	2.0L	LF	2005 - 2007	RCM	●	●	●
MAZDA5 (EURO STG3/4/5 and General Specs.) /	2.0L	LF	2005 - 2007	RKE	●	●	●
MAZDA5 (EURO STG3/4/5 and General Specs.) /	2.0L	LF	2007	LPSDM	●	●	●
MAZDA5 (EURO STG3/4/5 and General Specs.) /	2.0L	LF	2007	RPSDM	●	●	●
MAZDA5 (EURO STG3/4/5 and General Specs.) /	2.0L	LF	2007	TCM	●	●	●
MAZDA5 (EURO STG3/4/5 and General Specs.) /	2.0L	RF-T	2005 - 2007	ABS	●	●	●
MAZDA5 (EURO STG3/4/5 and General Specs.) /	2.0L	RF-T	2005 - 2007	EATC	●	●	●
MAZDA5 (EURO STG3/4/5 and General Specs.) /	2.0L	RF-T	2005 - 2007	FFH	●	●	●
MAZDA5 (EURO STG3/4/5 and General Specs.) /	2.0L	RF-T	2005 - 2007	GEM	●	●	●
MAZDA5 (EURO STG3/4/5 and General Specs.) /	2.0L	RF-T	2005 - 2007	IC	●	●	●
MAZDA5 (EURO STG3/4/5 and General Specs.) /	2.0L	RF-T	2005 - 2007	PCM	●	●	●
MAZDA5 (EURO STG3/4/5 and General Specs.) /	2.0L	RF-T	2005 - 2007	RCM	●	●	●
MAZDA5 (EURO STG3/4/5 and General Specs.) /	2.0L	RF-T	2005 - 2007	RKE	●	●	●
MAZDA5 (EURO STG3/4/5 and General Specs.) /	2.0L	RF-T	2007	LPSDM	●	●	●
MAZDA5 (EURO STG3/4/5 and General Specs.) /	2.0L	RF-T	2007	RPSDM	●	●	●
MAZDA5 (EURO STG3/4/5 and General Specs.) /	2.0L	RF-T	2007	TCM	●	●	●
MILLENNIA / EUNOS 800	2.0L	KF	1998 - 2000	ABS	●	●	●
MILLENNIA / EUNOS 800	2.3L	KJ	1998 - 2000	ABS	●	●	●
MILLENNIA / EUNOS 800	2.5L	KL	1998 - 2000	ABS	●	●	●
MILLENNIA / EUNOS 800	2.5L	KL	2002	ABS/TCS	●	●	●
MILLENNIA / EUNOS 800	2.5L	KL	2002	PCM	●	●	●
MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010	RETM	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2012	4X4	●	●	●
MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2012	FDIM	●	●	●
MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2012	GEM / SJB	●	●	●
MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2012	HD_LVL	●	●	●
MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2012	IHCM	●	●	●
MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2012	SASM	●	●	●
MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2013	ACM	●	●	●
MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2013	C-CM	●	●	●
MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2013	HCM-2	●	●	●
MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2013	IPC	●	●	●
MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2013	OCSM	●	●	●
MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2013	PCM	●	●	●
MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2014	ABS	●	●	●
MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2014	APIM	●	●	●
MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2014	DCSM	●	●	●
MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2014	DDM	●	●	●
MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2014	DSM	●	●	●
MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2014	DSP	●	●	●
MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2014	FCIM	●	●	●
MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2014	GPSM	●	●	●
MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2014	HCM	●	●	●
MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2014	HUD	●	●	●
MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2014	HVAC	●	●	●
MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2014	PAM	●	●	●
MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2014	PSCM	●	●	●
MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2014	RCM	●	●	●
MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2014	RFA	●	●	●
MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2014	SOD-L	●	●	●
MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2014	SOD-R	●	●	●
MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	BCM#1	●	●	●
MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	FCDIM	●	●	●
MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	DACM-C	●	●	●
MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	HSWM	●	●	●
MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	IPM-A	●	●	●
MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	RACM	●	●	●
MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	RTM	●	●	●
MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	SCCM	●	●	●
MKS	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	VDM	●	●	●
MKS	3.7L	4V	2009	SECM	●	●	○
MKS	3.7L	4V	2009 - 2012	4X4	●	●	●
MKS	3.7L	4V	2009 - 2012	ABS	●	●	●
MKS	3.7L	4V	2009 - 2012	ACM	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
MKS	3. 7L	4V	2009 - 2012	APIM	●	●	●
MKS	3. 7L	4V	2009 - 2012	C-CM	●	●	●
MKS	3. 7L	4V	2009 - 2012	DCSM	●	●	●
MKS	3. 7L	4V	2009 - 2012	DDM	●	●	●
MKS	3. 7L	4V	2009 - 2012	DSM	●	●	●
MKS	3. 7L	4V	2009 - 2012	DSP	●	●	●
MKS	3. 7L	4V	2009 - 2012	FCIM	●	●	●
MKS	3. 7L	4V	2009 - 2012	FDIM	●	●	●
MKS	3. 7L	4V	2009 - 2012	GEM / SJB	●	●	●
MKS	3. 7L	4V	2009 - 2012	HCM	●	●	●
MKS	3. 7L	4V	2009 - 2012	HCM-2	●	●	●
MKS	3. 7L	4V	2009 - 2012	HD_LVL	●	●	●
MKS	3. 7L	4V	2009 - 2012	HVAC	●	●	●
MKS	3. 7L	4V	2009 - 2012	IPC	●	●	●
MKS	3. 7L	4V	2009 - 2012	OCSM	●	●	●
MKS	3. 7L	4V	2009 - 2012	PAM	●	●	●
MKS	3. 7L	4V	2009 - 2012	PCM	●	●	●
MKS	3. 7L	4V	2009 - 2012	RCM	●	●	●
MKS	3. 7L	4V	2009 - 2012	RFA	●	●	●
MKS	3. 7L	4V	2010	RETM	●	●	●
MKS	3. 7L	4V	2010 - 2012	GPSM	●	●	●
MKS	3. 7L	4V	2010 - 2012	HUD	●	●	●
MKS	3. 7L	4V	2010 - 2012	ILCM	●	●	●
MKS	3. 7L	4V	2010 - 2012	PSCM	●	●	●
MKS	3. 7L	4V	2010 - 2012	SASM	●	●	●
MKS	3. 7L	4V	2010 - 2012	SOD-L	●	●	●
MKS	3. 7L	4V	2010 - 2012	SOD-R	●	●	●
MKS	3. 7L	TiVCT	2013	ACM	●	●	●
MKS	3. 7L	TiVCT	2013	BCM#1	●	●	●
MKS	3. 7L	TiVCT	2013	C-CM	●	●	●
MKS	3. 7L	TiVCT	2013	FCDIM	●	●	●
MKS	3. 7L	TiVCT	2013	HCM-2	●	●	●
MKS	3. 7L	TiVCT	2013	IPC	●	●	●
MKS	3. 7L	TiVCT	2013	OCSM	●	●	●
MKS	3. 7L	TiVCT	2013	PCM	●	●	●
MKS	3. 7L	TiVCT	2013 - 2014	ABS	●	●	●
MKS	3. 7L	TiVCT	2013 - 2014	APIM	●	●	●
MKS	3. 7L	TiVCT	2013 - 2014	DACM-C	●	●	●
MKS	3. 7L	TiVCT	2013 - 2014	DCSM	●	●	●
MKS	3. 7L	TiVCT	2013 - 2014	DDM	●	●	●
MKS	3. 7L	TiVCT	2013 - 2014	DSM	●	●	●
MKS	3. 7L	TiVCT	2013 - 2014	DSP	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
MKS	3.7L	TiVCT	2013 - 2014	FCIM	●	●	●
MKS	3.7L	TiVCT	2013 - 2014	GPSM	●	●	●
MKS	3.7L	TiVCT	2013 - 2014	HCM	●	●	●
MKS	3.7L	TiVCT	2013 - 2014	HSWM	●	●	●
MKS	3.7L	TiVCT	2013 - 2014	HUD	●	●	●
MKS	3.7L	TiVCT	2013 - 2014	HVAC	●	●	●
MKS	3.7L	TiVCT	2013 - 2014	IPM-A	●	●	●
MKS	3.7L	TiVCT	2013 - 2014	PAM	●	●	●
MKS	3.7L	TiVCT	2013 - 2014	PSCM	●	●	●
MKS	3.7L	TiVCT	2013 - 2014	RACM	●	●	●
MKS	3.7L	TiVCT	2013 - 2014	RCM	●	●	●
MKS	3.7L	TiVCT	2013 - 2014	RFA	●	●	●
MKS	3.7L	TiVCT	2013 - 2014	RTM	●	●	●
MKS	3.7L	TiVCT	2013 - 2014	SCCM	●	●	●
MKS	3.7L	TiVCT	2013 - 2014	SOD-L	●	●	●
MKS	3.7L	TiVCT	2013 - 2014	SOD-R	●	●	●
MKS	3.7L	TiVCT	2013 - 2014	VDM	●	●	●
MKS	Other	Other	2012	4X4	●	●	●
MKS	Other	Other	2012	ABS	●	●	●
MKS	Other	Other	2012	ACM	●	●	●
MKS	Other	Other	2012	APIM	●	●	●
MKS	Other	Other	2012	C-CM	●	●	●
MKS	Other	Other	2012	DCSM	●	●	●
MKS	Other	Other	2012	DDM	●	●	●
MKS	Other	Other	2012	DSM	●	●	●
MKS	Other	Other	2012	DSP	●	●	●
MKS	Other	Other	2012	FCIM	●	●	●
MKS	Other	Other	2012	FDIM	●	●	●
MKS	Other	Other	2012	GEM / SJB	●	●	●
MKS	Other	Other	2012	GPSM	●	●	●
MKS	Other	Other	2012	HCM	●	●	●
MKS	Other	Other	2012	HCM-2	●	●	●
MKS	Other	Other	2012	HD_LVL	●	●	●
MKS	Other	Other	2012	HUD	●	●	●
MKS	Other	Other	2012	HVAC	●	●	●
MKS	Other	Other	2012	IHCM	●	●	●
MKS	Other	Other	2012	IPC	●	●	●
MKS	Other	Other	2012	OCSM	●	●	●
MKS	Other	Other	2012	PAM	●	●	●
MKS	Other	Other	2012	PSCM	●	●	●
MKS	Other	Other	2012	RCM	●	●	●
MKS	Other	Other	2012	RFA	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
MKS	Other	Other	2012	SASM	●	●	●
MKS	Other	Other	2012	SOD-L	●	●	●
MKS	Other	Other	2012	SOD-R	●	●	●
MKT	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	BCM#1	●	●	●
MKT	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	C-CM	●	●	●
MKT	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	DCSM	●	●	●
MKT	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	IPC	●	●	●
MKT	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	IPM-A	●	●	●
MKT	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	OCSM	●	●	●
MKT	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	PCM	●	●	●
MKT	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	ABS	●	●	●
MKT	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	ACM	●	●	●
MKT	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	APIM	●	●	●
MKT	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	DDM	●	●	●
MKT	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	DSM	●	●	●
MKT	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	DSP	●	●	●
MKT	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	FCIM	●	●	●
MKT	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	GPSM	●	●	●
MKT	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	HCM	●	●	●
MKT	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	HSWM	●	●	●
MKT	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	HUD	●	●	●
MKT	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	HVAC	●	●	●
MKT	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	LTM	●	●	●
MKT	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	PAM	●	●	●
MKT	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	PCSM-2	●	●	●
MKT	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	PSCM	●	●	●
MKT	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	RACM	●	●	●
MKT	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	RCM	●	●	●
MKT	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	RFA	●	●	●
MKT	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	RHVAC	●	●	●
MKT	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	RTM	●	●	●
MKT	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	SCCM	●	●	●
MKT	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	SOD-L	●	●	●
MKT	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	SOD-R	●	●	●
MKT	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	VDM	●	●	●
MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2012	4X4	●	●	●
MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2012	GEM / SJB	●	●	●
MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2012	HCM-2	●	●	●
MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2012	ILCM	●	●	●
MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2012	RETM	●	●	●
MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2012	SASM	●	●	●
MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2013	C-CM	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2013	DCSM	●	●	●
MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2013	IPC	●	●	●
MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2013	OCSM	●	●	●
MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2013	PCM	●	●	●
MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2014	ABS	●	●	●
MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2014	ACM	●	●	●
MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2014	APIM	●	●	●
MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2014	DDM	●	●	●
MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2014	DSM	●	●	●
MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2014	DSP	●	●	●
MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2014	FCIM	●	●	●
MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2014	HCM	●	●	●
MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2014	HUD	●	●	●
MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2014	HVAC	●	●	●
MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2014	LTM	●	●	●
MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2014	PAM	●	●	●
MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2014	PCSM-2	●	●	●
MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2014	PSCM	●	●	●
MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2014	RCM	●	●	●
MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2014	RFA	●	●	●
MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2014	RHVAC	●	●	●
MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2014	SOD-L	●	●	●
MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2014	SOD-R	●	●	●
MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2014	GPSM	●	●	●
MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	BCM#1	●	●	●
MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	IPM-A	●	●	●
MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	HSWM	●	●	●
MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	RACM	●	●	●
MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	RTM	●	●	●
MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	SCCM	●	●	●
MKT	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	VDM	●	●	●
MKT	3.7L	4V	2010 - 2012	4X4	●	●	●
MKT	3.7L	4V	2010 - 2012	ABS	●	●	●
MKT	3.7L	4V	2010 - 2012	ACM	●	●	●
MKT	3.7L	4V	2010 - 2012	APIM	●	●	●
MKT	3.7L	4V	2010 - 2012	C-CM	●	●	●
MKT	3.7L	4V	2010 - 2012	DCSM	●	●	●
MKT	3.7L	4V	2010 - 2012	DDM	●	●	●
MKT	3.7L	4V	2010 - 2012	DSM	●	●	●
MKT	3.7L	4V	2010 - 2012	DSP	●	●	●
MKT	3.7L	4V	2010 - 2012	FCIM	●	●	●
MKT	3.7L	4V	2010 - 2012	GEM / SJB	●	●	●



Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
MKT	3. 7L	4V	2010 - 2012	HCM	●	●	●
MKT	3. 7L	4V	2010 - 2012	HCM-2	●	●	●
MKT	3. 7L	4V	2010 - 2012	HUD	●	●	●
MKT	3. 7L	4V	2010 - 2012	HVAC	●	●	●
MKT	3. 7L	4V	2010 - 2012	IHCM	●	●	●
MKT	3. 7L	4V	2010 - 2012	IPC	●	●	●
MKT	3. 7L	4V	2010 - 2012	LTM	●	●	●
MKT	3. 7L	4V	2010 - 2012	OCSM	●	●	●
MKT	3. 7L	4V	2010 - 2012	PAM	●	●	●
MKT	3. 7L	4V	2010 - 2012	PCM	●	●	●
MKT	3. 7L	4V	2010 - 2012	PCSM-2	●	●	●
MKT	3. 7L	4V	2010 - 2012	PSCM	●	●	●
MKT	3. 7L	4V	2010 - 2012	RCM	●	●	●
MKT	3. 7L	4V	2010 - 2012	RETM	●	●	●
MKT	3. 7L	4V	2010 - 2012	RFA	●	●	●
MKT	3. 7L	4V	2010 - 2012	RHVAC	●	●	●
MKT	3. 7L	4V	2010 - 2012	SASM	●	●	●
MKT	3. 7L	4V	2010 - 2012	SOD-L	●	●	●
MKT	3. 7L	4V	2010 - 2012	SOD-R	●	●	●
MKT	3. 7L	4V	2011 - 2012	GPSM	●	●	●
MKT	3. 7L	TiVCT	2013	BCM#1	●	●	●
MKT	3. 7L	TiVCT	2013	C-CM	●	●	●
MKT	3. 7L	TiVCT	2013	DCSM	●	●	●
MKT	3. 7L	TiVCT	2013	IPC	●	●	●
MKT	3. 7L	TiVCT	2013	IPM-A	●	●	●
MKT	3. 7L	TiVCT	2013	OCSM	●	●	●
MKT	3. 7L	TiVCT	2013	PCM	●	●	●
MKT	3. 7L	TiVCT	2013 - 2014	ABS	●	●	●
MKT	3. 7L	TiVCT	2013 - 2014	ACM	●	●	●
MKT	3. 7L	TiVCT	2013 - 2014	APIM	●	●	●
MKT	3. 7L	TiVCT	2013 - 2014	DDM	●	●	●
MKT	3. 7L	TiVCT	2013 - 2014	DSM	●	●	●
MKT	3. 7L	TiVCT	2013 - 2014	DSP	●	●	●
MKT	3. 7L	TiVCT	2013 - 2014	FCIM	●	●	●
MKT	3. 7L	TiVCT	2013 - 2014	GPSM	●	●	●
MKT	3. 7L	TiVCT	2013 - 2014	HCM	●	●	●
MKT	3. 7L	TiVCT	2013 - 2014	HSWM	●	●	●
MKT	3. 7L	TiVCT	2013 - 2014	HUD	●	●	●
MKT	3. 7L	TiVCT	2013 - 2014	HVAC	●	●	●
MKT	3. 7L	TiVCT	2013 - 2014	LTM	●	●	●
MKT	3. 7L	TiVCT	2013 - 2014	PAM	●	●	●
MKT	3. 7L	TiVCT	2013 - 2014	PCSM-2	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
MKT	3.7L	TiVCT	2013 - 2014	PSCM	●	●	●
MKT	3.7L	TiVCT	2013 - 2014	RACM	●	●	●
MKT	3.7L	TiVCT	2013 - 2014	RCM	●	●	●
MKT	3.7L	TiVCT	2013 - 2014	RFA	●	●	●
MKT	3.7L	TiVCT	2013 - 2014	RHVAC	●	●	●
MKT	3.7L	TiVCT	2013 - 2014	RTM	●	●	●
MKT	3.7L	TiVCT	2013 - 2014	SCCM	●	●	●
MKT	3.7L	TiVCT	2013 - 2014	SOD-L	●	●	●
MKT	3.7L	TiVCT	2013 - 2014	SOD-R	●	●	●
MKT	3.7L	TiVCT	2013 - 2014	VDM	●	●	●
MKT	Other	Other	2012	4X4	●	●	●
MKT	Other	Other	2012	C-CM	●	●	●
MKT	Other	Other	2012	DCSM	●	●	●
MKT	Other	Other	2012	GEM / SJB	●	●	●
MKT	Other	Other	2012	HCM-2	●	●	●
MKT	Other	Other	2012	ILCM	●	●	●
MKT	Other	Other	2012	IPC	●	●	●
MKT	Other	Other	2012	OCSM	●	●	●
MKT	Other	Other	2012	RETM	●	●	●
MKT	Other	Other	2012	SASM	●	●	●
MKT	Other	Other	2012 - 2014	ABS	●	●	●
MKT	Other	Other	2012 - 2014	ACM	●	●	●
MKT	Other	Other	2012 - 2014	APIM	●	●	●
MKT	Other	Other	2012 - 2014	DDM	●	●	●
MKT	Other	Other	2012 - 2014	DSM	●	●	●
MKT	Other	Other	2012 - 2014	DSP	●	●	●
MKT	Other	Other	2012 - 2014	FCIM	●	●	●
MKT	Other	Other	2012 - 2014	GPSM	●	●	●
MKT	Other	Other	2012 - 2014	HCM	●	●	●
MKT	Other	Other	2012 - 2014	HUD	●	●	●
MKT	Other	Other	2012 - 2014	HVAC	●	●	●
MKT	Other	Other	2012 - 2014	LTM	●	●	●
MKT	Other	Other	2012 - 2014	PAM	●	●	●
MKT	Other	Other	2012 - 2014	PCSM-2	●	●	●
MKT	Other	Other	2012 - 2014	PSCM	●	●	●
MKT	Other	Other	2012 - 2014	RCM	●	●	●
MKT	Other	Other	2012 - 2014	RFA	●	●	●
MKT	Other	Other	2012 - 2014	RHVAC	●	●	●
MKT	Other	Other	2012 - 2014	SOD-L	●	●	●
MKT	Other	Other	2012 - 2014	SOD-R	●	●	●
MKT	Other	Other	2014	HSWM	●	●	●
MKT	Other	Other	2014	RACM	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
MKT	Other	Other	2014	RTM	●	●	●
MKT	Other	Other	2014	SCCM	●	●	●
MKT	Other	Other	2014	VDM	●	●	●
MKX	3.5L	4V	2007	EATC	●	●	●
MKX	3.5L	4V	2007	GEM	●	●	●
MKX	3.5L	4V	2007 - 2010	4X4	●	●	●
MKX	3.5L	4V	2007 - 2010	ABS	●	●	●
MKX	3.5L	4V	2007 - 2010	ACM	●	●	●
MKX	3.5L	4V	2007 - 2010	DCSM	●	●	●
MKX	3.5L	4V	2007 - 2010	DSM	●	●	●
MKX	3.5L	4V	2007 - 2010	DSP	●	●	●
MKX	3.5L	4V	2007 - 2010	HCM	●	●	●
MKX	3.5L	4V	2007 - 2010	IC	●	●	●
MKX	3.5L	4V	2007 - 2010	LTM	●	●	●
MKX	3.5L	4V	2007 - 2010	OCSM	●	●	●
MKX	3.5L	4V	2007 - 2010	PAM	●	●	●
MKX	3.5L	4V	2007 - 2010	PCM	●	●	●
MKX	3.5L	4V	2007 - 2010	RCM	●	●	●
MKX	3.5L	4V	2007 - 2010	RETM	●	●	●
MKX	3.5L	4V	2007 - 2010	SASM	●	●	●
MKX	3.5L	4V	2007 - 2010	SDARS	●	●	●
MKX	3.5L	4V	2008 - 2010	APIM	●	●	●
MKX	3.5L	4V	2008 - 2010	GEM / SJB	●	●	●
MKX	3.5L	4V	2008 - 2010	HVAC	●	●	●
MKX	3.5L	4V	2010	GPSM	●	●	●
MKX	3.7L	TiVCT	2011 - 2012	TPM	●	●	●
MKX	3.7L	TiVCT	2011 - 2013	C-CM	●	●	●
MKX	3.7L	TiVCT	2011 - 2013	HVAC	●	●	●
MKX	3.7L	TiVCT	2011 - 2013	OCSM	●	●	●
MKX	3.7L	TiVCT	2011 - 2013	PCM	●	●	●
MKX	3.7L	TiVCT	2011 - 2013	RCM	●	●	●
MKX	3.7L	TiVCT	2011 - 2013	SCCM	●	●	●
MKX	3.7L	TiVCT	2011 - 2014	ABS	●	●	●
MKX	3.7L	TiVCT	2011 - 2014	ACM	●	●	●
MKX	3.7L	TiVCT	2011 - 2014	APIM	●	●	●
MKX	3.7L	TiVCT	2011 - 2014	BCM#1	●	●	●
MKX	3.7L	TiVCT	2011 - 2014	DCSM	●	●	●
MKX	3.7L	TiVCT	2011 - 2014	DSM	●	●	●
MKX	3.7L	TiVCT	2011 - 2014	DSP	●	●	●
MKX	3.7L	TiVCT	2011 - 2014	FCDIM	●	●	●
MKX	3.7L	TiVCT	2011 - 2014	FCIM	●	●	●
MKX	3.7L	TiVCT	2011 - 2014	FLM	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
MKX	3.7L	TiVCT	2011 - 2014	GPSM	●	●	●
MKX	3.7L	TiVCT	2011 - 2014	HCM	●	●	●
MKX	3.7L	TiVCT	2011 - 2014	HSWM	●	●	●
MKX	3.7L	TiVCT	2011 - 2014	HUD	●	●	●
MKX	3.7L	TiVCT	2011 - 2014	IPC	●	●	●
MKX	3.7L	TiVCT	2011 - 2014	LTM	●	●	●
MKX	3.7L	TiVCT	2011 - 2014	PAM	●	●	●
MKX	3.7L	TiVCT	2011 - 2014	RFA	●	●	●
MKX	3.7L	TiVCT	2011 - 2014	SOD-L	●	●	●
MKX	3.7L	TiVCT	2011 - 2014	SOD-R	●	●	●
MKX	3.7L	TiVCT	2013 - 2014	RTM	●	●	●
MKX	Other	Other	2014	ABS	●	●	●
MKX	Other	Other	2014	ACM	●	●	●
MKX	Other	Other	2014	APIM	●	●	●
MKX	Other	Other	2014	BCM#1	●	●	●
MKX	Other	Other	2014	DCSM	●	●	●
MKX	Other	Other	2014	DSM	●	●	●
MKX	Other	Other	2014	DSP	●	●	●
MKX	Other	Other	2014	FCDIM	●	●	●
MKX	Other	Other	2014	FCIM	●	●	●
MKX	Other	Other	2014	FLM	●	●	●
MKX	Other	Other	2014	GPSM	●	●	●
MKX	Other	Other	2014	HCM	●	●	●
MKX	Other	Other	2014	HSWM	●	●	●
MKX	Other	Other	2014	HUD	●	●	●
MKX	Other	Other	2014	IPC	●	●	●
MKX	Other	Other	2014	LTM	●	●	●
MKX	Other	Other	2014	PAM	●	●	●
MKX	Other	Other	2014	RFA	●	●	●
MKX	Other	Other	2014	RTM	●	●	●
MKX	Other	Other	2014	SOD-L	●	●	●
MKX	Other	Other	2014	SOD-R	●	●	●
MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	C-CM	●	●	●
MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	GWM	●	●	●
MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	SCM-G	●	●	○
MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	SCM-H	●	●	○
MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	APIM	●	●	●
MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	DACM-C	●	●	●
MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	DSM	●	●	●
MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	DSP	●	●	●
MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	FCDIM	●	●	●
MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	GFM	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	HSWM	●	●	●
MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	HUD	●	●	●
MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	PCM	●	●	●
MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	RACM	●	●	○
MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	RCM	●	●	○
MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	RGTM	●	●	○
MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	SCCM	●	●	○
MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	SCM-E	●	●	○
MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	SOD-L	●	●	○
MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	SOD-R	●	●	○
MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	VDM	●	●	○
MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2014	ACM	●	●	●
MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2014	FCIM	●	●	●
MKZ	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2014	RTM	●	●	○
MKZ	2.0L	Full Hybrid Electric Vehicle	2013	C-CM	●	●	●
MKZ	2.0L	Full Hybrid Electric Vehicle	2013	GWM	●	●	●
MKZ	2.0L	Full Hybrid Electric Vehicle	2013	SCM-G	●	●	○
MKZ	2.0L	Full Hybrid Electric Vehicle	2013	SCM-H	●	●	○
MKZ	2.0L	Full Hybrid Electric Vehicle	2013 - 2014	ACCM#2	●	●	●
MKZ	2.0L	Full Hybrid Electric Vehicle	2013 - 2014	APIM	●	●	●
MKZ	2.0L	Full Hybrid Electric Vehicle	2013 - 2014	DACM-C	●	●	●
MKZ	2.0L	Full Hybrid Electric Vehicle	2013 - 2014	DSM	●	●	●
MKZ	2.0L	Full Hybrid Electric Vehicle	2013 - 2014	DSP	●	●	●
MKZ	2.0L	Full Hybrid Electric Vehicle	2013 - 2014	FCDIM	●	●	●
MKZ	2.0L	Full Hybrid Electric Vehicle	2013 - 2014	GFM	●	●	●
MKZ	2.0L	Full Hybrid Electric Vehicle	2013 - 2014	HSWM	●	●	●
MKZ	2.0L	Full Hybrid Electric Vehicle	2013 - 2014	HUD	●	●	●
MKZ	2.0L	Full Hybrid Electric Vehicle	2013 - 2014	RACM	●	●	○
MKZ	2.0L	Full Hybrid Electric Vehicle	2013 - 2014	RCM	●	●	○
MKZ	2.0L	Full Hybrid Electric Vehicle	2013 - 2014	RGTM	●	●	○
MKZ	2.0L	Full Hybrid Electric Vehicle	2013 - 2014	SCCM	●	●	○
MKZ	2.0L	Full Hybrid Electric Vehicle	2013 - 2014	SCM-E	●	●	○
MKZ	2.0L	Full Hybrid Electric Vehicle	2013 - 2014	SOD-L	●	●	○
MKZ	2.0L	Full Hybrid Electric Vehicle	2013 - 2014	SOD-R	●	●	○
MKZ	2.0L	Full Hybrid Electric Vehicle	2013 - 2014	VDM	●	●	○
MKZ	2.0L	Full Hybrid Electric Vehicle	2014	ACM	●	●	●
MKZ	2.0L	Full Hybrid Electric Vehicle	2014	FCIM	●	●	●
MKZ	2.0L	Full Hybrid Electric Vehicle	2014	RTM	●	●	○
MKZ	3.7L	TiVCT	2013	C-CM	●	●	●
MKZ	3.7L	TiVCT	2013	GWM	●	●	●
MKZ	3.7L	TiVCT	2013	SCM-G	●	●	○
MKZ	3.7L	TiVCT	2013	SCM-H	●	●	○

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
MKZ	3.7L	TiVCT	2013 - 2014	APIM	●	●	●
MKZ	3.7L	TiVCT	2013 - 2014	DACM-C	●	●	●
MKZ	3.7L	TiVCT	2013 - 2014	DSM	●	●	●
MKZ	3.7L	TiVCT	2013 - 2014	DSP	●	●	●
MKZ	3.7L	TiVCT	2013 - 2014	FCDIM	●	●	●
MKZ	3.7L	TiVCT	2013 - 2014	GFM	●	●	●
MKZ	3.7L	TiVCT	2013 - 2014	HSWM	●	●	●
MKZ	3.7L	TiVCT	2013 - 2014	HUD	●	●	●
MKZ	3.7L	TiVCT	2013 - 2014	PCM	●	●	●
MKZ	3.7L	TiVCT	2013 - 2014	RACM	●	●	○
MKZ	3.7L	TiVCT	2013 - 2014	RCM	●	●	○
MKZ	3.7L	TiVCT	2013 - 2014	RGTM	●	●	○
MKZ	3.7L	TiVCT	2013 - 2014	SCCM	●	●	○
MKZ	3.7L	TiVCT	2013 - 2014	SCM-E	●	●	○
MKZ	3.7L	TiVCT	2013 - 2014	SOD-L	●	●	○
MKZ	3.7L	TiVCT	2013 - 2014	SOD-R	●	●	○
MKZ	3.7L	TiVCT	2013 - 2014	VDM	●	●	○
MKZ	3.7L	TiVCT	2014	ACM	●	●	●
MKZ	3.7L	TiVCT	2014	FCIM	●	●	●
MKZ	3.7L	TiVCT	2014	RTM	●	●	○
MKZ	Other	Other	2013	APIM	●	●	●
MKZ	Other	Other	2013	C-CM	●	●	●
MKZ	Other	Other	2013	DACM-C	●	●	●
MKZ	Other	Other	2013	DSM	●	●	●
MKZ	Other	Other	2013	DSP	●	●	●
MKZ	Other	Other	2013	FCDIM	●	●	●
MKZ	Other	Other	2013	GFM	●	●	●
MKZ	Other	Other	2013	GWM	●	●	●
MKZ	Other	Other	2013	HSWM	●	●	●
MKZ	Other	Other	2013	HUD	●	●	●
MKZ	Other	Other	2013	RACM	●	●	○
MKZ	Other	Other	2013	RCM	●	●	○
MKZ	Other	Other	2013	RGTM	●	●	○
MKZ	Other	Other	2013	SCCM	●	●	○
MKZ	Other	Other	2013	SCM-E	●	●	○
MKZ	Other	Other	2013	SCM-G	●	●	○
MKZ	Other	Other	2013	SCM-H	●	●	○
MKZ	Other	Other	2013	SOD-L	●	●	○
MKZ	Other	Other	2013	SOD-R	●	●	○
MKZ	Other	Other	2013	VDM	●	●	○
MONDEO	1.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	APIM	●	●	●
MONDEO	1.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	C-CM	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
MONDEO	1.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	DSP	●	●	●
MONDEO	1.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	FCIM	●	●	●
MONDEO	1.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	GPSM	●	●	●
MONDEO	1.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	GWM	●	●	●
MONDEO	1.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	HCM	●	●	●
MONDEO	1.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	HUD	●	●	●
MONDEO	1.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	RACM	●	●	○
MONDEO	1.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	RCM	●	●	○
MONDEO	1.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	RTM	●	●	○
MONDEO	1.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	SCCM	●	●	○
MONDEO	1.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	SCM-E	●	●	○
MONDEO	1.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	SOD-L	●	●	○
MONDEO	1.6L	DURATEC VCT	2007 - 2011	ABS	●	●	●
MONDEO	1.6L	DURATEC VCT	2007 - 2011	ACM	●	●	●
MONDEO	1.6L	DURATEC VCT	2007 - 2011	AHCM	●	●	●
MONDEO	1.6L	DURATEC VCT	2007 - 2011	BCMii	●	●	●
MONDEO	1.6L	DURATEC VCT	2007 - 2011	CCMii	●	●	●
MONDEO	1.6L	DURATEC VCT	2007 - 2011	CDP	●	●	●
MONDEO	1.6L	DURATEC VCT	2007 - 2011	CMR	●	●	●
MONDEO	1.6L	DURATEC VCT	2007 - 2011	DDM	●	●	●
MONDEO	1.6L	DURATEC VCT	2007 - 2011	DSM	●	●	●
MONDEO	1.6L	DURATEC VCT	2007 - 2011	HCM	●	●	●
MONDEO	1.6L	DURATEC VCT	2007 - 2011	HVAC	●	●	●
MONDEO	1.6L	DURATEC VCT	2007 - 2011	IPC	●	●	●
MONDEO	1.6L	DURATEC VCT	2007 - 2011	PAM	●	●	●
MONDEO	1.6L	DURATEC VCT	2007 - 2011	PBM	●	●	●
MONDEO	1.6L	DURATEC VCT	2007 - 2011	PCM	●	●	●
MONDEO	1.6L	DURATEC VCT	2007 - 2011	PDM	●	●	●
MONDEO	1.6L	DURATEC VCT	2007 - 2011	PSCM	●	●	●
MONDEO	1.6L	DURATEC VCT	2007 - 2011	RCM	●	●	●
MONDEO	1.6L	DURATEC VCT	2007 - 2011	RFA	●	●	●
MONDEO	1.6L	DURATEC VCT	2007 - 2011	SASM	●	●	●
MONDEO	1.6L	DURATEC VCT	2007 - 2011	SRM	●	●	●
MONDEO	1.6L	DURATEC VCT	2007 - 2011	TRM	●	●	●
MONDEO	1.6L	DURATEC VCT	2007 - 2011	VDM	●	●	●
MONDEO	1.6L	DURATEC VCT	2011	IPM-A	●	●	●
MONDEO	1.6L	DURATEC VCT	2011	RGTM	●	●	●
MONDEO	1.6L	DURATEC VCT	2011	RHVAC	●	●	●
MONDEO	1.6L	DURATEC VCT	2011	SOD-L	●	●	●
MONDEO	1.6L	DURATEC VCT	2011	SOD-R	●	●	●
MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	ABS	●	●	●
MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	ACM	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	AHCM	●	●	●
MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	BCMii	●	●	●
MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	CCMii	●	●	●
MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	CDP	●	●	●
MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	CMR	●	●	●
MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	DDM	●	●	●
MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	DSM	●	●	●
MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	HCM	●	●	●
MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	HVAC	●	●	●
MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	IPC	●	●	●
MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	IPM-A	●	●	●
MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	PAM	●	●	●
MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	PBM	●	●	●
MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	PCM	●	●	●
MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	PDM	●	●	●
MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	PSCM	●	●	●
MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	RCM	●	●	●
MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	RFA	●	●	●
MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	RGTM	●	●	●
MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	RHVAC	●	●	●
MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	SASM	●	●	●
MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	SOD-L	●	●	●
MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	SOD-R	●	●	●
MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	SRM	●	●	●
MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	TRM	●	●	●
MONDEO	1.6L	Duratorq Turbo Diesel Common Rail Injection	2011	VDM	●	●	●
MONDEO	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	ABS	●	●	●
MONDEO	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	ACM	●	●	●
MONDEO	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	AHCM	●	●	●
MONDEO	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	BCMii	●	●	●
MONDEO	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	CCMii	●	●	●
MONDEO	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	CDP	●	●	●
MONDEO	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	CMR	●	●	●
MONDEO	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	DDM	●	●	●
MONDEO	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	DSM	●	●	●
MONDEO	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	HCM	●	●	●
MONDEO	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	HVAC	●	●	●
MONDEO	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	IPC	●	●	●
MONDEO	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	IPM-A	●	●	●
MONDEO	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	PAM	●	●	●
MONDEO	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	PBM	●	●	●
MONDEO	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2011	PCM	●	●	●



Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
MONDEO	1. 6L	EcoBoost - Gas Turbocharged Direct Injection	2011	PDM	●	●	●
MONDEO	1. 6L	EcoBoost - Gas Turbocharged Direct Injection	2011	PSCM	●	●	●
MONDEO	1. 6L	EcoBoost - Gas Turbocharged Direct Injection	2011	RCM	●	●	●
MONDEO	1. 6L	EcoBoost - Gas Turbocharged Direct Injection	2011	RFA	●	●	●
MONDEO	1. 6L	EcoBoost - Gas Turbocharged Direct Injection	2011	RGTM	●	●	●
MONDEO	1. 6L	EcoBoost - Gas Turbocharged Direct Injection	2011	RHVAC	●	●	●
MONDEO	1. 6L	EcoBoost - Gas Turbocharged Direct Injection	2011	SASM	●	●	●
MONDEO	1. 6L	EcoBoost - Gas Turbocharged Direct Injection	2011	SOD-L	●	●	●
MONDEO	1. 6L	EcoBoost - Gas Turbocharged Direct Injection	2011	SOD-R	●	●	●
MONDEO	1. 6L	EcoBoost - Gas Turbocharged Direct Injection	2011	SRM	●	●	●
MONDEO	1. 6L	EcoBoost - Gas Turbocharged Direct Injection	2011	TRM	●	●	●
MONDEO	1. 6L	EcoBoost - Gas Turbocharged Direct Injection	2011	VDM	●	●	●
MONDEO	1. 6L	Zetec	1993 - 1999	ABS	●	●	●
MONDEO	1. 6L	Zetec	1993 - 1999	CSM	●	●	●
MONDEO	1. 6L	Zetec	1993 - 1999	PATS	●	●	●
MONDEO	1. 6L	Zetec	1997 - 1999	FFH	●	●	●
MONDEO	1. 6L	Zetec	1997 - 1999	PCM	●	●	●
MONDEO	1. 6L	Zetec	1998 - 1999	ABS/TCS	●	●	●
MONDEO	1. 8L	DURATEC-HE / I4	2001	ABS	●	●	●
MONDEO	1. 8L	DURATEC-HE / I4	2001	ABS/TCS	●	●	●
MONDEO	1. 8L	DURATEC-HE / I4	2001	ACM	●	●	●
MONDEO	1. 8L	DURATEC-HE / I4	2001	CDP	●	●	●
MONDEO	1. 8L	DURATEC-HE / I4	2001	CSM	●	●	●
MONDEO	1. 8L	DURATEC-HE / I4	2001	EATC	●	●	●
MONDEO	1. 8L	DURATEC-HE / I4	2001	GDM	●	●	●
MONDEO	1. 8L	DURATEC-HE / I4	2001	GEM	●	●	●
MONDEO	1. 8L	DURATEC-HE / I4	2001	HEC	●	●	●
MONDEO	1. 8L	DURATEC-HE / I4	2001	LHID	●	●	●
MONDEO	1. 8L	DURATEC-HE / I4	2001	NAV	●	●	●
MONDEO	1. 8L	DURATEC-HE / I4	2001	PATS	●	●	●
MONDEO	1. 8L	DURATEC-HE / I4	2001	PCM	●	●	●
MONDEO	1. 8L	DURATEC-HE / I4	2001	RCM	●	●	●
MONDEO	1. 8L	DURATEC-HE / I4	2001	RETM	●	●	●
MONDEO	1. 8L	DURATEC-HE / I4	2001	RHID	●	●	●
MONDEO	1. 8L	DURATEC-HE / I4	2001	SRM	●	●	●
MONDEO	1. 8L	DURATEC-SCi	2001	ABS	●	●	●
MONDEO	1. 8L	DURATEC-SCi	2001	ABS/TCS	●	●	●
MONDEO	1. 8L	DURATEC-SCi	2001	ACM	●	●	●
MONDEO	1. 8L	DURATEC-SCi	2001	CDP	●	●	●
MONDEO	1. 8L	DURATEC-SCi	2001	CSM	●	●	●
MONDEO	1. 8L	DURATEC-SCi	2001	EATC	●	●	●
MONDEO	1. 8L	DURATEC-SCi	2001	GDM	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
MONDEO	1.8L	DURATEC-SCi	2001	GEM	●	●	●
MONDEO	1.8L	DURATEC-SCi	2001	HEC	●	●	●
MONDEO	1.8L	DURATEC-SCi	2001	LHID	●	●	●
MONDEO	1.8L	DURATEC-SCi	2001	NAV	●	●	●
MONDEO	1.8L	DURATEC-SCi	2001	PATS	●	●	●
MONDEO	1.8L	DURATEC-SCi	2001	PCM	●	●	●
MONDEO	1.8L	DURATEC-SCi	2001	RCM	●	●	●
MONDEO	1.8L	DURATEC-SCi	2001	RETM	●	●	●
MONDEO	1.8L	DURATEC-SCi	2001	RHID	●	●	●
MONDEO	1.8L	DURATEC-SCi	2001	SRM	●	●	●
MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	2007	ABS	●	●	●
MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	2007	ACM	●	●	○
MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	2007	AHCM	●	●	●
MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	2007	BCMii	●	●	●
MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	2007	CCMii	●	●	●
MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	2007	CDP	●	●	●
MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	2007	CMR	●	●	●
MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	2007	DDM	●	●	●
MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	2007	DSM	●	●	●
MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	2007	HCM	●	●	●
MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	2007	HVAC	●	●	●
MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	2007	IPC	●	●	●
MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	2007	PAM	●	●	●
MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	2007	PBM	●	●	●
MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	2007	PCM	●	●	●
MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	2007	PDM	●	●	●
MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	2007	PSCM	●	●	●
MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	2007	RCM	●	●	●
MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	2007	RFA	●	●	●
MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	2007	SASM	●	●	●
MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	2007	SRM	●	●	●
MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	2007	TRM	●	●	●
MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	2007	VDM	●	●	●
MONDEO	1.8L	Endura-DE	1997	FFH	●	●	●
MONDEO	1.8L	Endura-DE	1997	PCM	○	○	●
MONDEO	1.8L	Endura-DE	1997 - Other	ABS	●	●	●
MONDEO	1.8L	Endura-DE	1997 - Other	CSM	●	●	●
MONDEO	1.8L	Endura-DE	1997 - Other	PATS	●	●	●
MONDEO	1.8L	Zetec	1993 - 2000	ABS	●	●	●
MONDEO	1.8L	Zetec	1993 - 2000	CSM	●	●	●
MONDEO	1.8L	Zetec	1993 - 2000	PATS	●	●	●
MONDEO	1.8L	Zetec	1997 - 1999	FFH	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
MONDEO	1. 8L	Zetec	1997 - 2000	PCM	●	●	●
MONDEO	1. 8L	Zetec	1998 - 2000	ABS/TCS	●	●	●
MONDEO	1. 8L	Zetec	2000	AFCM	●	●	●
MONDEO	2. 0L	DURATEC-HE / I4	2001	ABS/TCS	●	●	●
MONDEO	2. 0L	DURATEC-HE / I4	2001	CSM	●	●	●
MONDEO	2. 0L	DURATEC-HE / I4	2001	EATC	●	●	●
MONDEO	2. 0L	DURATEC-HE / I4	2001	GDM	●	●	●
MONDEO	2. 0L	DURATEC-HE / I4	2001	GEM	●	●	●
MONDEO	2. 0L	DURATEC-HE / I4	2001	HEC	●	●	●
MONDEO	2. 0L	DURATEC-HE / I4	2001	LHID	●	●	●
MONDEO	2. 0L	DURATEC-HE / I4	2001	NAV	●	●	●
MONDEO	2. 0L	DURATEC-HE / I4	2001	PATS	●	●	●
MONDEO	2. 0L	DURATEC-HE / I4	2001	RETM	●	●	●
MONDEO	2. 0L	DURATEC-HE / I4	2001	RHID	●	●	●
MONDEO	2. 0L	DURATEC-HE / I4	2001 - 2007	ABS	●	●	●
MONDEO	2. 0L	DURATEC-HE / I4	2001 - 2007	ACM	●	●	●
MONDEO	2. 0L	DURATEC-HE / I4	2001 - 2007	CDP	●	●	●
MONDEO	2. 0L	DURATEC-HE / I4	2001 - 2007	PCM	●	●	●
MONDEO	2. 0L	DURATEC-HE / I4	2001 - 2007	RCM	●	●	●
MONDEO	2. 0L	DURATEC-HE / I4	2001 - 2007	SRM	●	●	●
MONDEO	2. 0L	DURATEC-HE / I4	2007	AHCM	●	●	●
MONDEO	2. 0L	DURATEC-HE / I4	2007	BCMii	●	●	●
MONDEO	2. 0L	DURATEC-HE / I4	2007	CCMii	●	●	●
MONDEO	2. 0L	DURATEC-HE / I4	2007	CMR	●	●	●
MONDEO	2. 0L	DURATEC-HE / I4	2007	DDM	●	●	●
MONDEO	2. 0L	DURATEC-HE / I4	2007	DSM	●	●	●
MONDEO	2. 0L	DURATEC-HE / I4	2007	HCM	●	●	●
MONDEO	2. 0L	DURATEC-HE / I4	2007	HVAC	●	●	●
MONDEO	2. 0L	DURATEC-HE / I4	2007	IPC	●	●	●
MONDEO	2. 0L	DURATEC-HE / I4	2007	PAM	●	●	●
MONDEO	2. 0L	DURATEC-HE / I4	2007	PBM	●	●	●
MONDEO	2. 0L	DURATEC-HE / I4	2007	PDM	●	●	●
MONDEO	2. 0L	DURATEC-HE / I4	2007	PSCM	●	●	●
MONDEO	2. 0L	DURATEC-HE / I4	2007	RFA	●	●	●
MONDEO	2. 0L	DURATEC-HE / I4	2007	SASM	●	●	●
MONDEO	2. 0L	DURATEC-HE / I4	2007	TRM	●	●	●
MONDEO	2. 0L	DURATEC-HE / I4	2007	VDM	●	●	●
MONDEO	2. 0L	DURATORQ_DI	2001	ABS	●	●	●
MONDEO	2. 0L	DURATORQ_DI	2001	ABS/TCS	●	●	●
MONDEO	2. 0L	DURATORQ_DI	2001	ACM	●	●	●
MONDEO	2. 0L	DURATORQ_DI	2001	CDP	●	●	●
MONDEO	2. 0L	DURATORQ_DI	2001	CSM	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
MONDEO	2.0L	DURATORQ_DI	2001	EATC	●	●	●
MONDEO	2.0L	DURATORQ_DI	2001	FFH	●	●	●
MONDEO	2.0L	DURATORQ_DI	2001	FIP	●	●	●
MONDEO	2.0L	DURATORQ_DI	2001	GDM	●	●	●
MONDEO	2.0L	DURATORQ_DI	2001	GEM	●	●	●
MONDEO	2.0L	DURATORQ_DI	2001	HEC	●	●	●
MONDEO	2.0L	DURATORQ_DI	2001	LHID	●	●	●
MONDEO	2.0L	DURATORQ_DI	2001	NAV	●	●	●
MONDEO	2.0L	DURATORQ_DI	2001	PATS	●	●	●
MONDEO	2.0L	DURATORQ_DI	2001	PCM	●	●	●
MONDEO	2.0L	DURATORQ_DI	2001	RCM	●	●	●
MONDEO	2.0L	DURATORQ_DI	2001	RETM	●	●	●
MONDEO	2.0L	DURATORQ_DI	2001	RHID	●	●	●
MONDEO	2.0L	DURATORQ_DI	2001	SRM	●	●	●
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2001	ABS/TCS	●	●	●
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2001	CSM	●	●	●
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2001	EATC	●	●	●
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2001	FFH	●	●	●
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2001	GDM	●	●	●
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2001	GEM	●	●	●
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2001	HEC	●	●	●
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2001	ICU	○	○	●
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2001	LHID	●	●	●
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2001	NAV	●	●	●
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2001	PATS	●	●	●
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2001	RETM	●	●	●
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2001	RHID	●	●	●
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2001 - 2011	ABS	●	●	●
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2001 - 2011	ACM	●	●	●
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2001 - 2011	CDP	●	●	●
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2001 - 2011	PCM	●	●	●
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2001 - 2011	RCM	●	●	●
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2001 - 2011	SRM	●	●	●
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2001 - 2011	TCM	●	●	●
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2007 - 2011	AHCM	●	●	●
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2007 - 2011	BCMii	●	●	●
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2007 - 2011	CCMii	●	●	●
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2007 - 2011	CMR	●	●	●
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2007 - 2011	DDM	●	●	●
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2007 - 2011	DSM	●	●	●
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2007 - 2011	HCM	●	●	●
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2007 - 2011	HVAC	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2007 - 2011	IPC	●	●	●
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2007 - 2011	PAM	●	●	●
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2007 - 2011	PBM	●	●	●
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2007 - 2011	PDM	●	●	●
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2007 - 2011	PSCM	●	●	●
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2007 - 2011	RFA	●	●	●
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2007 - 2011	SASM	●	●	●
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2007 - 2011	TRM	●	●	●
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2007 - 2011	VDM	●	●	●
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	DABM	●	●	●
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	IPM-A	●	●	●
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	RGTM	●	●	●
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	RHVAC	●	●	●
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	SOD-L	●	●	●
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection	2011	SOD-R	●	●	●
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2007	PAM	●	●	●
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2007	RFA	●	●	●
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2007 - 2011	ABS	●	●	●
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2007 - 2011	ACM	●	●	○
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2007 - 2011	AHCM	●	●	●
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2007 - 2011	BCMii	●	●	●
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2007 - 2011	CCMii	●	●	●
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2007 - 2011	CDP	●	●	●
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2007 - 2011	CMR	●	●	●
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2007 - 2011	DDM	●	●	●
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2007 - 2011	DSM	●	●	●
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2007 - 2011	HCM	●	●	●
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2007 - 2011	HVAC	●	●	●
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2007 - 2011	IPC	●	●	●
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2007 - 2011	PBM	●	●	●
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2007 - 2011	PCM	●	●	●
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2007 - 2011	PDM	●	●	●
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2007 - 2011	PSCM	●	●	●
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2007 - 2011	RCM	●	●	●
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2007 - 2011	SASM	●	●	●
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2007 - 2011	SRM	●	●	●
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2007 - 2011	TCM	●	●	●
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2007 - 2011	TRM	●	●	●
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2007 - 2011	VDM	●	●	●
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2011	DABM	●	●	●
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2011	IPM-A	●	●	●
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2011	RGTM	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2011	RHVAC	●	●	●
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2011	SOD-L	●	●	●
MONDEO	2.0L	Duratorq Turbo Diesel Common Rail Injection StgV	2011	SOD-R	●	●	●
MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2007	PAM	●	●	●
MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2007	RFA	●	●	●
MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2007	TCM	●	●	●
MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2007 - 2011	ABS	●	●	●
MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2007 - 2011	ACM	●	●	○
MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2007 - 2011	AHCM	●	●	●
MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2007 - 2011	BCMii	●	●	●
MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2007 - 2011	CCMii	●	●	●
MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2007 - 2011	CDP	●	●	●
MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2007 - 2011	CMR	●	●	●
MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2007 - 2011	DDM	●	●	●
MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2007 - 2011	DSM	●	●	●
MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2007 - 2011	HVAC	●	●	●
MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2007 - 2011	IPC	●	●	●
MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2007 - 2011	PBM	●	●	●
MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2007 - 2011	PDM	●	●	●
MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2007 - 2011	PSCM	●	●	●
MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2007 - 2011	SASM	●	●	●
MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2007 - 2011	SRM	●	●	●
MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2007 - 2011	TRM	●	●	●
MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2007 - 2011	VDM	●	●	●
MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2007 - 2013	HCM	●	●	●
MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2007 - 2013	PCM	●	●	●
MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2007 - 2013	RCM	●	●	●
MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	DABM	●	●	●
MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	IPM-A	●	●	●
MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	RGTM	●	●	●
MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	RHVAC	●	●	●
MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011	SOD-R	●	●	●
MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2011 - 2013	SOD-L	●	●	●
MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	APIM	●	●	●
MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	C-CM	●	●	●
MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	DSP	●	●	●
MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	FCIM	●	●	●
MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	GPSM	●	●	●
MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	GWM	●	●	●
MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	HUD	●	●	●
MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	RACM	●	●	○
MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	RTM	●	●	○

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	SCCM	●	●	○
MONDEO	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	SCM-E	●	●	○
MONDEO	2.0L	Ecoboost GTDI Chinese market only	2007	PAM	●	●	●
MONDEO	2.0L	Ecoboost GTDI Chinese market only	2007	RFA	●	●	●
MONDEO	2.0L	Ecoboost GTDI Chinese market only	2007	TCM	●	●	●
MONDEO	2.0L	Ecoboost GTDI Chinese market only	2007 - 2011	ABS	●	●	●
MONDEO	2.0L	Ecoboost GTDI Chinese market only	2007 - 2011	ACM	●	●	○
MONDEO	2.0L	Ecoboost GTDI Chinese market only	2007 - 2011	AHCM	●	●	●
MONDEO	2.0L	Ecoboost GTDI Chinese market only	2007 - 2011	BCMii	●	●	●
MONDEO	2.0L	Ecoboost GTDI Chinese market only	2007 - 2011	CCMii	●	●	●
MONDEO	2.0L	Ecoboost GTDI Chinese market only	2007 - 2011	CDP	●	●	●
MONDEO	2.0L	Ecoboost GTDI Chinese market only	2007 - 2011	CMR	●	●	●
MONDEO	2.0L	Ecoboost GTDI Chinese market only	2007 - 2011	DDM	●	●	●
MONDEO	2.0L	Ecoboost GTDI Chinese market only	2007 - 2011	DSM	●	●	●
MONDEO	2.0L	Ecoboost GTDI Chinese market only	2007 - 2011	HCM	●	●	●
MONDEO	2.0L	Ecoboost GTDI Chinese market only	2007 - 2011	HVAC	●	●	●
MONDEO	2.0L	Ecoboost GTDI Chinese market only	2007 - 2011	IPC	●	●	●
MONDEO	2.0L	Ecoboost GTDI Chinese market only	2007 - 2011	PBM	●	●	●
MONDEO	2.0L	Ecoboost GTDI Chinese market only	2007 - 2011	PCM	●	●	●
MONDEO	2.0L	Ecoboost GTDI Chinese market only	2007 - 2011	PDM	●	●	●
MONDEO	2.0L	Ecoboost GTDI Chinese market only	2007 - 2011	PSCM	●	●	●
MONDEO	2.0L	Ecoboost GTDI Chinese market only	2007 - 2011	RCM	●	●	●
MONDEO	2.0L	Ecoboost GTDI Chinese market only	2007 - 2011	SASM	●	●	●
MONDEO	2.0L	Ecoboost GTDI Chinese market only	2007 - 2011	SRM	●	●	●
MONDEO	2.0L	Ecoboost GTDI Chinese market only	2007 - 2011	TRM	●	●	●
MONDEO	2.0L	Ecoboost GTDI Chinese market only	2007 - 2011	VDM	●	●	●
MONDEO	2.0L	Ecoboost GTDI Chinese market only	2011	DABM	●	●	●
MONDEO	2.0L	Ecoboost GTDI Chinese market only	2011	IPM-A	●	●	●
MONDEO	2.0L	Ecoboost GTDI Chinese market only	2011	RGTM	●	●	●
MONDEO	2.0L	Ecoboost GTDI Chinese market only	2011	RHVAC	●	●	●
MONDEO	2.0L	Ecoboost GTDI Chinese market only	2011	SOD-L	●	●	●
MONDEO	2.0L	Ecoboost GTDI Chinese market only	2011	SOD-R	●	●	●
MONDEO	2.0L	Zetec	1993 - 2000	ABS	●	●	●
MONDEO	2.0L	Zetec	1993 - 2000	CSM	●	●	●
MONDEO	2.0L	Zetec	1993 - 2000	PATS	●	●	●
MONDEO	2.0L	Zetec	1997 - 1999	FFH	●	●	●
MONDEO	2.0L	Zetec	1997 - 2000	PCM	●	●	●
MONDEO	2.0L	Zetec	1998 - 2000	ABS/TCS	●	●	●
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	2001	ABS/TCS	●	●	●
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	2001	CSM	●	●	●
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	2001	EATC	●	●	●
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	2001	FFH	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	2001	GDM	●	●	●
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	2001	GEM	●	●	●
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	2001	HEC	●	●	●
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	2001	ICU	○	○	●
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	2001	LHID	●	●	●
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	2001	NAV	●	●	●
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	2001	PATS	●	●	●
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	2001	RETM	●	●	●
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	2001	RHID	●	●	●
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	2001 - 2007	PCM	●	●	●
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	2001 - 2011	ABS	●	●	●
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	2001 - 2011	ACM	●	●	●
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	2001 - 2011	CDP	●	●	●
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	2001 - 2011	RCM	●	●	●
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	2001 - 2011	SRM	●	●	●
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	2007	PAM	●	●	●
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	2007	RFA	●	●	●
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	2007 - 2011	AHCM	●	●	●
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	2007 - 2011	BCMii	●	●	●
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	2007 - 2011	CCMii	●	●	●
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	2007 - 2011	CMR	●	●	●
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	2007 - 2011	DDM	●	●	●
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	2007 - 2011	DSM	●	●	●
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	2007 - 2011	HCM	●	●	●
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	2007 - 2011	HVAC	●	●	●
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	2007 - 2011	IPC	●	●	●
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	2007 - 2011	PBM	●	●	●
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	2007 - 2011	PDM	●	●	●
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	2007 - 2011	PSCM	●	●	●
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	2007 - 2011	SASM	●	●	●
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	2007 - 2011	TRM	●	●	●
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	2007 - 2011	VDM	●	●	●
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	2011	DABM	●	●	●
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	2011	IPM-A	●	●	●
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	2011	RGTM	●	●	●
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	2011	RHVAC	●	●	●
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	2011	SOD-L	●	●	●
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection	2011	SOD-R	●	●	●
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection StgV	2011	ABS	●	●	●
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection StgV	2011	ACM	●	●	○
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection StgV	2011	AHCM	●	●	●
MONDEO	2.2L	Duratorq Turbo Diesel Common Rail Injection StgV	2011	BCMii	●	●	●



Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	2011	CCMii	●	●	●
MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	2011	CDP	●	●	●
MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	2011	CMR	●	●	●
MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	2011	DABM	●	●	●
MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	2011	DDM	●	●	●
MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	2011	DSM	●	●	●
MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	2011	HCM	●	●	●
MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	2011	HVAC	●	●	●
MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	2011	IPC	●	●	●
MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	2011	IPM-A	●	●	●
MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	2011	PBM	●	●	●
MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	2011	PCM	●	●	●
MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	2011	PDM	●	●	●
MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	2011	PSCM	●	●	●
MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	2011	RCM	●	●	●
MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	2011	RGTM	●	●	●
MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	2011	RHVAC	●	●	●
MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	2011	SASM	●	●	●
MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	2011	SOD-L	●	●	●
MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	2011	SOD-R	●	●	●
MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	2011	SRM	●	●	●
MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	2011	TCM	●	●	●
MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	2011	TRM	●	●	●
MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection StgV	2011	VDM	●	●	●
MONDEO	2. 3L	DURATEC-HE / I4	2007 - 2011	ABS	●	●	●
MONDEO	2. 3L	DURATEC-HE / I4	2007 - 2011	ACM	●	●	○
MONDEO	2. 3L	DURATEC-HE / I4	2007 - 2011	AHCM	●	●	●
MONDEO	2. 3L	DURATEC-HE / I4	2007 - 2011	BCMii	●	●	●
MONDEO	2. 3L	DURATEC-HE / I4	2007 - 2011	CCMii	●	●	●
MONDEO	2. 3L	DURATEC-HE / I4	2007 - 2011	CDP	●	●	●
MONDEO	2. 3L	DURATEC-HE / I4	2007 - 2011	CMR	●	●	●
MONDEO	2. 3L	DURATEC-HE / I4	2007 - 2011	DDM	●	●	●
MONDEO	2. 3L	DURATEC-HE / I4	2007 - 2011	DSM	●	●	●
MONDEO	2. 3L	DURATEC-HE / I4	2007 - 2011	HCM	●	●	●
MONDEO	2. 3L	DURATEC-HE / I4	2007 - 2011	HVAC	●	●	●
MONDEO	2. 3L	DURATEC-HE / I4	2007 - 2011	IPC	●	●	●
MONDEO	2. 3L	DURATEC-HE / I4	2007 - 2011	PAM	●	●	●
MONDEO	2. 3L	DURATEC-HE / I4	2007 - 2011	PBM	●	●	●
MONDEO	2. 3L	DURATEC-HE / I4	2007 - 2011	PCM	●	●	●
MONDEO	2. 3L	DURATEC-HE / I4	2007 - 2011	PDM	●	●	●
MONDEO	2. 3L	DURATEC-HE / I4	2007 - 2011	PSCM	●	●	●
MONDEO	2. 3L	DURATEC-HE / I4	2007 - 2011	RCM	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
MONDEO	2. 3L	DURATEC-HE / I4	2007 - 2011	RFA	●	●	●
MONDEO	2. 3L	DURATEC-HE / I4	2007 - 2011	SASM	●	●	●
MONDEO	2. 3L	DURATEC-HE / I4	2007 - 2011	SRM	●	●	●
MONDEO	2. 3L	DURATEC-HE / I4	2007 - 2011	TCM	●	●	●
MONDEO	2. 3L	DURATEC-HE / I4	2007 - 2011	TRM	●	●	●
MONDEO	2. 3L	DURATEC-HE / I4	2007 - 2011	VDM	●	●	●
MONDEO	2. 3L	DURATEC-HE / I4	2011	DABM	●	●	●
MONDEO	2. 3L	DURATEC-HE / I4	2011	IPM-A	●	●	●
MONDEO	2. 3L	DURATEC-HE / I4	2011	RGTM	●	●	●
MONDEO	2. 3L	DURATEC-HE / I4	2011	RHVAC	●	●	●
MONDEO	2. 3L	DURATEC-HE / I4	2011	SOD-L	●	●	●
MONDEO	2. 3L	DURATEC-HE / I4	2011	SOD-R	●	●	●
MONDEO	2. 5L	Duratec-VE	1994 - 2001	ABS	●	●	●
MONDEO	2. 5L	Duratec-VE	1994 - 2001	CSM	●	●	●
MONDEO	2. 5L	Duratec-VE	1994 - 2001	PATS	●	●	●
MONDEO	2. 5L	Duratec-VE	1997 - 1999	FFH	●	●	●
MONDEO	2. 5L	Duratec-VE	1997 - 2001	PCM	●	●	●
MONDEO	2. 5L	Duratec-VE	1998 - 2001	ABS/TCS	●	●	●
MONDEO	2. 5L	Duratec-VE	2001	ACM	●	●	●
MONDEO	2. 5L	Duratec-VE	2001	CDP	●	●	●
MONDEO	2. 5L	Duratec-VE	2001	EATC	●	●	●
MONDEO	2. 5L	Duratec-VE	2001	GDM	●	●	●
MONDEO	2. 5L	Duratec-VE	2001	GEM	●	●	●
MONDEO	2. 5L	Duratec-VE	2001	HEC	●	●	●
MONDEO	2. 5L	Duratec-VE	2001	LHID	●	●	●
MONDEO	2. 5L	Duratec-VE	2001	NAV	●	●	●
MONDEO	2. 5L	Duratec-VE	2001	RCM	●	●	●
MONDEO	2. 5L	Duratec-VE	2001	RETM	●	●	●
MONDEO	2. 5L	Duratec-VE	2001	RHID	●	●	●
MONDEO	2. 5L	Duratec-VE	2001	SRM	●	●	●
MONDEO	2. 5L	I5	2007	ABS	●	●	●
MONDEO	2. 5L	I5	2007	ACM	●	●	○
MONDEO	2. 5L	I5	2007	AHCM	●	●	●
MONDEO	2. 5L	I5	2007	BCM i i	●	●	●
MONDEO	2. 5L	I5	2007	CCM i i	●	●	●
MONDEO	2. 5L	I5	2007	CDP	●	●	●
MONDEO	2. 5L	I5	2007	CMR	●	●	●
MONDEO	2. 5L	I5	2007	DDM	●	●	●
MONDEO	2. 5L	I5	2007	DSM	●	●	●
MONDEO	2. 5L	I5	2007	HCM	●	●	●
MONDEO	2. 5L	I5	2007	HVAC	●	●	●
MONDEO	2. 5L	I5	2007	IPC	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
MONDEO	2.5L	I5	2007	PAM	●	●	●
MONDEO	2.5L	I5	2007	PBM	●	●	●
MONDEO	2.5L	I5	2007	PCM	●	●	●
MONDEO	2.5L	I5	2007	PDM	●	●	●
MONDEO	2.5L	I5	2007	PSCM	●	●	●
MONDEO	2.5L	I5	2007	RCM	●	●	●
MONDEO	2.5L	I5	2007	RFA	●	●	●
MONDEO	2.5L	I5	2007	SASM	●	●	●
MONDEO	2.5L	I5	2007	SRM	●	●	●
MONDEO	2.5L	I5	2007	TRM	●	●	●
MONDEO	2.5L	I5	2007	VDM	●	●	●
MONDEO	3.0L	Duratec SE	2001	ABS	●	●	●
MONDEO	3.0L	Duratec SE	2001	ABS/TCS	●	●	●
MONDEO	3.0L	Duratec SE	2001	ACM	●	●	●
MONDEO	3.0L	Duratec SE	2001	CDP	●	●	●
MONDEO	3.0L	Duratec SE	2001	CSM	●	●	●
MONDEO	3.0L	Duratec SE	2001	EATC	●	●	●
MONDEO	3.0L	Duratec SE	2001	GDM	●	●	●
MONDEO	3.0L	Duratec SE	2001	GEM	●	●	●
MONDEO	3.0L	Duratec SE	2001	HEC	●	●	●
MONDEO	3.0L	Duratec SE	2001	LHID	●	●	●
MONDEO	3.0L	Duratec SE	2001	NAV	●	●	●
MONDEO	3.0L	Duratec SE	2001	PATS	●	●	●
MONDEO	3.0L	Duratec SE	2001	PCM	●	●	●
MONDEO	3.0L	Duratec SE	2001	RCM	●	●	●
MONDEO	3.0L	Duratec SE	2001	RETM	●	●	●
MONDEO	3.0L	Duratec SE	2001	RHID	●	●	●
MONDEO	3.0L	Duratec SE	2001	SRM	●	●	●
MONDEO	3.0L	Duratec-ST	2001	ABS	●	●	●
MONDEO	3.0L	Duratec-ST	2001	ABS/TCS	●	●	●
MONDEO	3.0L	Duratec-ST	2001	ACM	●	●	●
MONDEO	3.0L	Duratec-ST	2001	CDP	●	●	●
MONDEO	3.0L	Duratec-ST	2001	CSM	●	●	●
MONDEO	3.0L	Duratec-ST	2001	EATC	●	●	●
MONDEO	3.0L	Duratec-ST	2001	GDM	●	●	●
MONDEO	3.0L	Duratec-ST	2001	GEM	●	●	●
MONDEO	3.0L	Duratec-ST	2001	HEC	●	●	●
MONDEO	3.0L	Duratec-ST	2001	LHID	●	●	●
MONDEO	3.0L	Duratec-ST	2001	NAV	●	●	●
MONDEO	3.0L	Duratec-ST	2001	PATS	●	●	●
MONDEO	3.0L	Duratec-ST	2001	PCM	●	●	●
MONDEO	3.0L	Duratec-ST	2001	RCM	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
MONDEO	3. 0L	Duratec-ST	2001	RETM	●	●	●
MONDEO	3. 0L	Duratec-ST	2001	RHID	●	●	●
MONDEO	3. 0L	Duratec-ST	2001	SRM	●	●	●
Marauder	4. 6L	4V	2003 - 2004	ABS/TCS	●	●	●
Marauder	4. 6L	4V	2003 - 2004	DDM	●	●	●
Marauder	4. 6L	4V	2003 - 2004	EATC	●	●	●
Marauder	4. 6L	4V	2003 - 2004	LCM	●	●	●
Marauder	4. 6L	4V	2003 - 2004	PCM	●	●	●
Marauder	4. 6L	4V	2003 - 2004	RASM	●	●	●
Marauder	4. 6L	4V	2003 - 2004	RCM	●	●	●
Marauder	4. 6L	4V	2003 - 2004	VAPS	●	●	●
Mariner	2. 3L	DURATEC-HE / I4	2006 - 2007	4X4	●	●	●
Mariner	2. 3L	DURATEC-HE / I4	2006 - 2007	ABS	●	●	●
Mariner	2. 3L	DURATEC-HE / I4	2006 - 2007	GEM	●	●	●
Mariner	2. 3L	DURATEC-HE / I4	2006 - 2007	IC	●	●	●
Mariner	2. 3L	DURATEC-HE / I4	2006 - 2007	PAM	●	●	●
Mariner	2. 3L	DURATEC-HE / I4	2006 - 2007	PCM	●	●	●
Mariner	2. 3L	DURATEC-HE / I4	2006 - 2007	RCM	●	●	●
Mariner	3. 0L	4V	2006 - 2007	4X4	●	●	●
Mariner	3. 0L	4V	2006 - 2007	ABS	●	●	●
Mariner	3. 0L	4V	2006 - 2007	GEM	●	●	●
Mariner	3. 0L	4V	2006 - 2007	IC	●	●	●
Mariner	3. 0L	4V	2006 - 2007	PAM	●	●	●
Mariner	3. 0L	4V	2006 - 2007	PCM	●	●	●
Mariner	3. 0L	4V	2006 - 2007	RCM	●	●	●
Mark LT	5. 4L	3V	2006 - 2007	EATC	●	●	●
Mark LT	5. 4L	3V	2006 - 2008	4X4	●	●	●
Mark LT	5. 4L	3V	2006 - 2008	ABS	●	●	●
Mark LT	5. 4L	3V	2006 - 2008	DSM	●	●	●
Mark LT	5. 4L	3V	2006 - 2008	IC	●	●	●
Mark LT	5. 4L	3V	2006 - 2008	PAM	●	●	●
Mark LT	5. 4L	3V	2006 - 2008	PCM	●	●	●
Mark LT	5. 4L	3V	2006 - 2008	RCM	●	●	●
Mark LT	5. 4L	3V	2006 - 2008	VSM	●	●	●
Mark LT	5. 4L	3V	2008	HVAC	●	●	●
Mark LT	5. 4L	3V	2008	RETM	●	●	●
Mark VIII	4. 6L	4V	1996 - 1998	ABS/TCS	●	●	●
Mark VIII	4. 6L	4V	1996 - 1998	CPM	●	●	●
Mark VIII	4. 6L	4V	1996 - 1998	DDM	●	●	●
Mark VIII	4. 6L	4V	1996 - 1998	DSM	●	●	●
Mark VIII	4. 6L	4V	1996 - 1998	HEC	●	●	●
Mark VIII	4. 6L	4V	1996 - 1998	PCM	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Mark VIII	4. 6L	4V	1996 - 1998	PSM	●	●	●
Mark VIII	4. 6L	4V	1996 - 1998	SCIL	●	●	●
Mark VIII	4. 6L	4V	1997 - 1998	EATC	●	●	●
Mark VIII	4. 6L	4V	1997 - 1998	MC	●	●	●
Milan	2. 3L	DURATEC-HE / I4	2006 - 2007	EATC	●	●	●
Milan	2. 3L	DURATEC-HE / I4	2006 - 2007	GEM	●	●	●
Milan	2. 3L	DURATEC-HE / I4	2006 - 2009	ABS	●	●	●
Milan	2. 3L	DURATEC-HE / I4	2006 - 2009	ACM	●	●	●
Milan	2. 3L	DURATEC-HE / I4	2006 - 2009	IC	●	●	●
Milan	2. 3L	DURATEC-HE / I4	2006 - 2009	OCSM	●	●	●
Milan	2. 3L	DURATEC-HE / I4	2006 - 2009	PCM	●	●	●
Milan	2. 3L	DURATEC-HE / I4	2006 - 2009	RCM	●	●	●
Milan	2. 3L	DURATEC-HE / I4	2006 - 2009	TCM	●	●	●
Milan	2. 3L	DURATEC-HE / I4	2007 - 2009	4X4	●	●	●
Milan	2. 3L	DURATEC-HE / I4	2007 - 2009	SDARS	●	●	●
Milan	2. 3L	DURATEC-HE / I4	2008 - 2009	APIM	●	●	●
Milan	2. 3L	DURATEC-HE / I4	2008 - 2009	GEM / SJB	●	●	●
Milan	2. 3L	DURATEC-HE / I4	2008 - 2009	HVAC	●	●	●
Milan	2. 3L	DURATEC-HE / I4	2008 - 2009	PAM	●	●	●
Milan	2. 5L	DURATEC-HE / I4	2010 - 2011	4X4	●	●	●
Milan	2. 5L	DURATEC-HE / I4	2010 - 2011	ABS	●	●	●
Milan	2. 5L	DURATEC-HE / I4	2010 - 2011	ACM	●	●	●
Milan	2. 5L	DURATEC-HE / I4	2010 - 2011	APIM	●	●	●
Milan	2. 5L	DURATEC-HE / I4	2010 - 2011	DSP	●	●	●
Milan	2. 5L	DURATEC-HE / I4	2010 - 2011	FCIM	●	●	●
Milan	2. 5L	DURATEC-HE / I4	2010 - 2011	FDIM	●	●	●
Milan	2. 5L	DURATEC-HE / I4	2010 - 2011	GEM / SJB	●	●	●
Milan	2. 5L	DURATEC-HE / I4	2010 - 2011	GPSM	●	●	●
Milan	2. 5L	DURATEC-HE / I4	2010 - 2011	HVAC	●	●	●
Milan	2. 5L	DURATEC-HE / I4	2010 - 2011	IPC	●	●	●
Milan	2. 5L	DURATEC-HE / I4	2010 - 2011	OCSM	●	●	●
Milan	2. 5L	DURATEC-HE / I4	2010 - 2011	PAM	●	●	●
Milan	2. 5L	DURATEC-HE / I4	2010 - 2011	PCM	●	●	●
Milan	2. 5L	DURATEC-HE / I4	2010 - 2011	PSCM	●	●	●
Milan	2. 5L	DURATEC-HE / I4	2010 - 2011	RCM	●	●	●
Milan	2. 5L	DURATEC-HE / I4	2010 - 2011	SOD-L	●	●	●
Milan	2. 5L	DURATEC-HE / I4	2010 - 2011	SOD-R	●	●	●
Milan	2. 5L	HEV / ATKINSON 4V	2010 - 2011	4X4	●	●	●
Milan	2. 5L	HEV / ATKINSON 4V	2010 - 2011	ABS	●	●	●
Milan	2. 5L	HEV / ATKINSON 4V	2010 - 2011	ACCM#2	●	●	●
Milan	2. 5L	HEV / ATKINSON 4V	2010 - 2011	ACM	●	●	●
Milan	2. 5L	HEV / ATKINSON 4V	2010 - 2011	APIM	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Milan	2.5L	HEV / ATKINSON 4V	2010 - 2011	BECM	●	●	●
Milan	2.5L	HEV / ATKINSON 4V	2010 - 2011	DCDC	●	●	●
Milan	2.5L	HEV / ATKINSON 4V	2010 - 2011	DSP	●	●	●
Milan	2.5L	HEV / ATKINSON 4V	2010 - 2011	FCIM	●	●	●
Milan	2.5L	HEV / ATKINSON 4V	2010 - 2011	FDIM	●	●	●
Milan	2.5L	HEV / ATKINSON 4V	2010 - 2011	GEM / SJB	●	●	●
Milan	2.5L	HEV / ATKINSON 4V	2010 - 2011	GPSM	●	●	●
Milan	2.5L	HEV / ATKINSON 4V	2010 - 2011	HVAC	●	●	●
Milan	2.5L	HEV / ATKINSON 4V	2010 - 2011	IPC	●	●	●
Milan	2.5L	HEV / ATKINSON 4V	2010 - 2011	OCSM	●	●	●
Milan	2.5L	HEV / ATKINSON 4V	2010 - 2011	PAM	●	●	●
Milan	2.5L	HEV / ATKINSON 4V	2010 - 2011	PCM	●	●	●
Milan	2.5L	HEV / ATKINSON 4V	2010 - 2011	PSCM	●	●	●
Milan	2.5L	HEV / ATKINSON 4V	2010 - 2011	RCM	●	●	●
Milan	2.5L	HEV / ATKINSON 4V	2010 - 2011	SOD-L	●	●	●
Milan	2.5L	HEV / ATKINSON 4V	2010 - 2011	SOD-R	●	●	●
Milan	2.5L	HEV / ATKINSON 4V	2010 - 2011	TCM	●	●	●
Milan	3.0L	4V	2006 - 2007	EATC	●	●	●
Milan	3.0L	4V	2006 - 2007	GEM	●	●	●
Milan	3.0L	4V	2006 - 2009	IC	●	●	●
Milan	3.0L	4V	2006 - 2009	TCM	●	●	●
Milan	3.0L	4V	2006 - 2011	ABS	●	●	●
Milan	3.0L	4V	2006 - 2011	ACM	●	●	●
Milan	3.0L	4V	2006 - 2011	OCSM	●	●	●
Milan	3.0L	4V	2006 - 2011	PCM	●	●	●
Milan	3.0L	4V	2006 - 2011	RCM	●	●	●
Milan	3.0L	4V	2007 - 2009	SDARS	●	●	●
Milan	3.0L	4V	2007 - 2011	4X4	●	●	●
Milan	3.0L	4V	2008 - 2011	APIM	●	●	●
Milan	3.0L	4V	2008 - 2011	GEM / SJB	●	●	●
Milan	3.0L	4V	2008 - 2011	HVAC	●	●	●
Milan	3.0L	4V	2008 - 2011	PAM	●	●	●
Milan	3.0L	4V	2010 - 2011	DSP	●	●	●
Milan	3.0L	4V	2010 - 2011	FCIM	●	●	●
Milan	3.0L	4V	2010 - 2011	FDIM	●	●	●
Milan	3.0L	4V	2010 - 2011	GPSM	●	●	●
Milan	3.0L	4V	2010 - 2011	IPC	●	●	●
Milan	3.0L	4V	2010 - 2011	PSCM	●	●	●
Milan	3.0L	4V	2010 - 2011	SOD-L	●	●	●
Milan	3.0L	4V	2010 - 2011	SOD-R	●	●	●
Montego	3.0L	4V	2006 - 2007	4X4	●	●	●
Montego	3.0L	4V	2006 - 2007	ABS	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Montego	3.0L	4V	2006 - 2007	ACM	●	●	●
Montego	3.0L	4V	2006 - 2007	DSM	●	●	●
Montego	3.0L	4V	2006 - 2007	EATC	●	●	●
Montego	3.0L	4V	2006 - 2007	GEM	●	●	●
Montego	3.0L	4V	2006 - 2007	IC	●	●	●
Montego	3.0L	4V	2006 - 2007	PAM	●	●	●
Montego	3.0L	4V	2006 - 2007	PCM	●	●	●
Montego	3.0L	4V	2006 - 2007	RCM	●	●	●
Montego	3.0L	4V	2006 - 2007	RETM	●	●	●
Montego	3.0L	4V	2006 - 2007	TCM	●	●	●
Montego	3.0L	4V	2007	SDARS	●	●	●
Motorhome / Stripped Chassis / Step Van	6.8L	2V	2004	ABS/TCS	●	●	●
Motorhome / Stripped Chassis / Step Van	6.8L	2V	2004	PCM	●	●	●
Motorhome / Stripped Chassis / Step Van	6.8L	3V	2006 - 2011	ABS/TCS	●	●	●
Motorhome / Stripped Chassis / Step Van	6.8L	3V	2006 - 2012	PCM	●	●	●
Motorhome / Stripped Chassis / Step Van	6.8L	3V	2006 - 2014	IC	●	●	●
Motorhome / Stripped Chassis / Step Van	6.8L	3V	2012	ABS	●	●	●
Motorhome / Stripped Chassis / Step Van	Other	Other	2014	IC	●	●	●
Mountaineer	4.0L	2V	2006 - 2007	EATC	●	●	●
Mountaineer	4.0L	2V	2006 - 2007	GEM	●	●	●
Mountaineer	4.0L	2V	2006 - 2010	4X4	●	●	●
Mountaineer	4.0L	2V	2006 - 2010	ABS	●	●	●
Mountaineer	4.0L	2V	2006 - 2010	ACM	●	●	●
Mountaineer	4.0L	2V	2006 - 2010	DSM	●	●	●
Mountaineer	4.0L	2V	2006 - 2010	IC	●	●	●
Mountaineer	4.0L	2V	2006 - 2010	OCSM	●	●	●
Mountaineer	4.0L	2V	2006 - 2010	PAM	●	●	●
Mountaineer	4.0L	2V	2006 - 2010	PCM	●	●	●
Mountaineer	4.0L	2V	2006 - 2010	PRB	●	●	●
Mountaineer	4.0L	2V	2006 - 2010	RCM	●	●	●
Mountaineer	4.0L	2V	2006 - 2010	RETM	●	●	●
Mountaineer	4.0L	2V	2006 - 2010	SDARS	●	●	●
Mountaineer	4.0L	2V	2008 - 2010	APIM	●	●	●
Mountaineer	4.0L	2V	2008 - 2010	GEM / SJB	●	●	●
Mountaineer	4.0L	2V	2008 - 2010	HVAC	●	●	●
Mountaineer	4.0L	2V	2010	GPSM	●	●	●
Mountaineer	4.0L	V6 SOHC	1998 - 2000	ARC	●	●	●
Mountaineer	4.0L	V6 SOHC	1998 - 2000	IAB	●	●	●
Mountaineer	4.0L	V6 SOHC	1998 - 2000	PATS	●	●	●
Mountaineer	4.0L	V6 SOHC	1998 - 2000	RAP	●	●	●
Mountaineer	4.0L	V6 SOHC	1998 - 2002	GEM	●	●	●
Mountaineer	4.0L	V6 SOHC	1998 - 2003	ABS/TCS	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Mountaineer	4.0L	V6 SOHC	1998 - 2005	DSM	●	●	●
Mountaineer	4.0L	V6 SOHC	1998 - 2005	EATC	●	●	●
Mountaineer	4.0L	V6 SOHC	1998 - 2005	PCM	●	●	●
Mountaineer	4.0L	V6 SOHC	1999 - 2005	PAM	●	●	●
Mountaineer	4.0L	V6 SOHC	2002	CSM	●	●	●
Mountaineer	4.0L	V6 SOHC	2002 - 2003	HEC	●	●	●
Mountaineer	4.0L	V6 SOHC	2002 - 2005	4X4	●	●	●
Mountaineer	4.0L	V6 SOHC	2002 - 2005	IC	●	●	●
Mountaineer	4.0L	V6 SOHC	2002 - 2005	RCM	●	●	●
Mountaineer	4.0L	V6 SOHC	2002 - 2005	TPM	●	●	●
Mountaineer	4.0L	V6 SOHC	2003 - 2005	VSM	●	●	●
Mountaineer	4.0L	V6 SOHC	2004 - 2005	ABS	●	●	●
Mountaineer	4.6L	2V	2002	CSM	●	●	●
Mountaineer	4.6L	2V	2002	GEM	●	●	●
Mountaineer	4.6L	2V	2002 - 2003	ABS/TCS	●	●	●
Mountaineer	4.6L	2V	2002 - 2003	HEC	●	●	●
Mountaineer	4.6L	2V	2002 - 2005	4X4	●	●	●
Mountaineer	4.6L	2V	2002 - 2005	DSM	●	●	●
Mountaineer	4.6L	2V	2002 - 2005	EATC	●	●	●
Mountaineer	4.6L	2V	2002 - 2005	IC	●	●	●
Mountaineer	4.6L	2V	2002 - 2005	PAM	●	●	●
Mountaineer	4.6L	2V	2002 - 2005	PCM	●	●	●
Mountaineer	4.6L	2V	2002 - 2005	RCM	●	●	●
Mountaineer	4.6L	2V	2002 - 2005	TPM	●	●	●
Mountaineer	4.6L	2V	2003 - 2005	VSM	●	●	●
Mountaineer	4.6L	2V	2004 - 2005	ABS	●	●	●
Mountaineer	4.6L	3V	2006 - 2007	EATC	●	●	●
Mountaineer	4.6L	3V	2006 - 2007	GEM	●	●	●
Mountaineer	4.6L	3V	2006 - 2010	4X4	●	●	●
Mountaineer	4.6L	3V	2006 - 2010	ABS	●	●	●
Mountaineer	4.6L	3V	2006 - 2010	ACM	●	●	●
Mountaineer	4.6L	3V	2006 - 2010	DSM	●	●	●
Mountaineer	4.6L	3V	2006 - 2010	IC	●	●	●
Mountaineer	4.6L	3V	2006 - 2010	OCSM	●	●	●
Mountaineer	4.6L	3V	2006 - 2010	PAM	●	●	●
Mountaineer	4.6L	3V	2006 - 2010	PCM	●	●	●
Mountaineer	4.6L	3V	2006 - 2010	PRB	●	●	●
Mountaineer	4.6L	3V	2006 - 2010	RCM	●	●	●
Mountaineer	4.6L	3V	2006 - 2010	RETM	●	●	●
Mountaineer	4.6L	3V	2006 - 2010	SDARS	●	●	●
Mountaineer	4.6L	3V	2006 - 2010	TCM	●	●	●
Mountaineer	4.6L	3V	2008 - 2010	APIM	●	●	●



Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Mountaineer	4.6L	3V	2008 - 2010	GEM / SJB	●	●	●
Mountaineer	4.6L	3V	2008 - 2010	HVAC	●	●	●
Mountaineer	4.6L	3V	2010	GPSM	●	●	●
Mountaineer	5.0L	Other	1997 - 2000	ABS/TCS	●	●	●
Mountaineer	5.0L	Other	1997 - 2000	ARC	●	●	●
Mountaineer	5.0L	Other	1997 - 2000	GEM	●	●	●
Mountaineer	5.0L	Other	1997 - 2000	IAB	●	●	●
Mountaineer	5.0L	Other	1997 - 2000	PCM	●	●	●
Mountaineer	5.0L	Other	1997 - 2000	RAP	●	●	●
Mountaineer	5.0L	Other	1998 - 2000	DSM	●	●	●
Mountaineer	5.0L	Other	1998 - 2000	EATC	●	●	●
Mountaineer	5.0L	Other	1998 - 2000	PATS	●	●	●
Mountaineer	5.0L	Other	1999 - 2000	PAM	●	●	●
Mustang	3.7L	TiVCT	2011 - 2013	ACM	●	●	●
Mustang	3.7L	TiVCT	2011 - 2013	PSCM	●	●	●
Mustang	3.7L	TiVCT	2011 - 2014	ABS	●	●	●
Mustang	3.7L	TiVCT	2011 - 2014	APIM	●	●	●
Mustang	3.7L	TiVCT	2011 - 2014	BCM-B	●	●	●
Mustang	3.7L	TiVCT	2011 - 2014	FCIM	●	●	●
Mustang	3.7L	TiVCT	2011 - 2014	FDIM	●	●	●
Mustang	3.7L	TiVCT	2011 - 2014	GEM / SJB	●	●	●
Mustang	3.7L	TiVCT	2011 - 2014	GPSM	●	●	●
Mustang	3.7L	TiVCT	2011 - 2014	HVAC	●	●	●
Mustang	3.7L	TiVCT	2011 - 2014	IPC	●	●	●
Mustang	3.7L	TiVCT	2011 - 2014	OCSM	●	●	●
Mustang	3.7L	TiVCT	2011 - 2014	PCM	●	●	●
Mustang	3.7L	TiVCT	2011 - 2014	RCM	●	●	●
Mustang	3.7L	TiVCT	2012 - 2013	PAM	●	●	●
Mustang	3.8L	Other	1994 - 2004	ABS/TCS	●	●	●
Mustang	3.8L	Other	1994 - 2004	PCM	●	●	●
Mustang	3.8L	Other	1996 - 1998	IAB	●	●	●
Mustang	3.8L	Other	1996 - 1998	PATS	●	●	●
Mustang	3.8L	Other	1999 - 2004	GEM	●	●	●
Mustang	3.8L	Other	1999 - 2004	HEC	●	●	●
Mustang	3.8L	Other	1999 - 2004	RCM	●	●	●
Mustang	3.9L	Other	2004	ABS/TCS	●	●	●
Mustang	3.9L	Other	2004	GEM	●	●	●
Mustang	3.9L	Other	2004	HEC	●	●	●
Mustang	3.9L	Other	2004	PCM	●	●	●
Mustang	3.9L	Other	2004	RCM	●	●	●
Mustang	4.0L	V6 SOHC	2005 - 2007	GEM	●	●	●
Mustang	4.0L	V6 SOHC	2005 - 2009	IC	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Mustang	4.0L	V6 SOHC	2005 - 2010	ABS	●	●	●
Mustang	4.0L	V6 SOHC	2005 - 2010	ACM	●	●	●
Mustang	4.0L	V6 SOHC	2005 - 2010	PCM	●	●	●
Mustang	4.0L	V6 SOHC	2005 - 2010	RCM	●	●	●
Mustang	4.0L	V6 SOHC	2007 - 2009	SDARS	●	●	●
Mustang	4.0L	V6 SOHC	2008 - 2010	GEM / SJB	●	●	●
Mustang	4.0L	V6 SOHC	2009 - 2010	APIM	●	●	●
Mustang	4.0L	V6 SOHC	2010	BCM-B	●	●	●
Mustang	4.0L	V6 SOHC	2010	FCIM	●	●	●
Mustang	4.0L	V6 SOHC	2010	FDIM	●	●	●
Mustang	4.0L	V6 SOHC	2010	GPSM	●	●	●
Mustang	4.0L	V6 SOHC	2010	HVAC	●	●	●
Mustang	4.0L	V6 SOHC	2010	IPC	●	●	●
Mustang	4.0L	V6 SOHC	2010	OCSM	●	●	●
Mustang	4.6L	2V	1996 - 1998	IAB	●	●	●
Mustang	4.6L	2V	1996 - 1998	PATS	●	●	●
Mustang	4.6L	2V	1996 - 2004	ABS/TCS	●	●	●
Mustang	4.6L	2V	1996 - 2004	PCM	●	●	●
Mustang	4.6L	2V	1999 - 2004	GEM	●	●	●
Mustang	4.6L	2V	1999 - 2004	HEC	●	●	●
Mustang	4.6L	2V	1999 - 2004	RCM	●	●	●
Mustang	4.6L	3V	2005 - 2007	GEM	●	●	●
Mustang	4.6L	3V	2005 - 2009	IC	●	●	●
Mustang	4.6L	3V	2005 - 2010	ABS	●	●	●
Mustang	4.6L	3V	2005 - 2010	ACM	●	●	●
Mustang	4.6L	3V	2005 - 2010	PCM	●	●	●
Mustang	4.6L	3V	2005 - 2010	RCM	●	●	●
Mustang	4.6L	3V	2007 - 2009	SDARS	●	●	●
Mustang	4.6L	3V	2008 - 2010	GEM / SJB	●	●	●
Mustang	4.6L	3V	2009 - 2010	APIM	●	●	●
Mustang	4.6L	3V	2010	BCM-B	●	●	●
Mustang	4.6L	3V	2010	FCIM	●	●	●
Mustang	4.6L	3V	2010	FDIM	●	●	●
Mustang	4.6L	3V	2010	GPSM	●	●	●
Mustang	4.6L	3V	2010	HVAC	●	●	●
Mustang	4.6L	3V	2010	IPC	●	●	●
Mustang	4.6L	3V	2010	OCSM	●	●	●
Mustang	4.6L	4V	1996 - 1998	IAB	●	●	●
Mustang	4.6L	4V	1996 - 1998	PATS	●	●	●
Mustang	4.6L	4V	1996 - 2004	ABS/TCS	●	●	●
Mustang	4.6L	4V	1996 - 2004	PCM	●	●	●
Mustang	4.6L	4V	1999 - 2004	GEM	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Mustang	4. 6L	4V	1999 - 2004	HEC	●	●	●
Mustang	4. 6L	4V	1999 - 2004	RCM	●	●	●
Mustang	4. 6L	Other	1996 - 1997	ABS/TCS	●	●	●
Mustang	4. 6L	Other	1996 - 1997	PATS	●	●	●
Mustang	4. 6L	Other	1996 - 1997	PCM	●	●	●
Mustang	5. 0L	BOSS	2012 - 2013	ABS	●	●	●
Mustang	5. 0L	BOSS	2012 - 2013	ACM	●	●	●
Mustang	5. 0L	BOSS	2012 - 2013	APIM	●	●	●
Mustang	5. 0L	BOSS	2012 - 2013	BCM-B	●	●	●
Mustang	5. 0L	BOSS	2012 - 2013	FCIM	●	●	●
Mustang	5. 0L	BOSS	2012 - 2013	FDIM	●	●	●
Mustang	5. 0L	BOSS	2012 - 2013	GEM / SJB	●	●	●
Mustang	5. 0L	BOSS	2012 - 2013	GPSM	●	●	●
Mustang	5. 0L	BOSS	2012 - 2013	HVAC	●	●	●
Mustang	5. 0L	BOSS	2012 - 2013	IPC	●	●	●
Mustang	5. 0L	BOSS	2012 - 2013	OCSM	●	●	●
Mustang	5. 0L	BOSS	2012 - 2013	PAM	●	●	●
Mustang	5. 0L	BOSS	2012 - 2013	PCM	●	●	●
Mustang	5. 0L	BOSS	2012 - 2013	PSCM	●	●	●
Mustang	5. 0L	BOSS	2012 - 2013	RCM	●	●	●
Mustang	5. 0L	TiVCT	2011 - 2013	ACM	●	●	●
Mustang	5. 0L	TiVCT	2011 - 2013	PSCM	●	●	●
Mustang	5. 0L	TiVCT	2011 - 2014	ABS	●	●	●
Mustang	5. 0L	TiVCT	2011 - 2014	APIM	●	●	●
Mustang	5. 0L	TiVCT	2011 - 2014	BCM-B	●	●	●
Mustang	5. 0L	TiVCT	2011 - 2014	FCIM	●	●	●
Mustang	5. 0L	TiVCT	2011 - 2014	FDIM	●	●	●
Mustang	5. 0L	TiVCT	2011 - 2014	GEM / SJB	●	●	●
Mustang	5. 0L	TiVCT	2011 - 2014	GPSM	●	●	●
Mustang	5. 0L	TiVCT	2011 - 2014	HVAC	●	●	●
Mustang	5. 0L	TiVCT	2011 - 2014	IPC	●	●	●
Mustang	5. 0L	TiVCT	2011 - 2014	OCSM	●	●	●
Mustang	5. 0L	TiVCT	2011 - 2014	PCM	●	●	●
Mustang	5. 0L	TiVCT	2011 - 2014	RCM	●	●	●
Mustang	5. 0L	TiVCT	2012 - 2013	PAM	●	●	●
Mustang	5. 4L	4V	2007	GEM	●	●	●
Mustang	5. 4L	4V	2007 - 2009	IC	●	●	●
Mustang	5. 4L	4V	2007 - 2009	SDARS	●	●	●
Mustang	5. 4L	4V	2007 - 2012	ABS	●	●	●
Mustang	5. 4L	4V	2007 - 2012	ACM	●	●	●
Mustang	5. 4L	4V	2007 - 2012	PCM	●	●	●
Mustang	5. 4L	4V	2007 - 2012	RCM	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Mustang	5.4L	4V	2008 - 2012	GEM / SJB	●	●	●
Mustang	5.4L	4V	2009 - 2012	APIM	●	●	●
Mustang	5.4L	4V	2010 - 2012	BCM-B	●	●	●
Mustang	5.4L	4V	2010 - 2012	FCIM	●	●	●
Mustang	5.4L	4V	2010 - 2012	FDIM	●	●	●
Mustang	5.4L	4V	2010 - 2012	GPSM	●	●	●
Mustang	5.4L	4V	2010 - 2012	HVAC	●	●	●
Mustang	5.4L	4V	2010 - 2012	IPC	●	●	●
Mustang	5.4L	4V	2010 - 2012	OCSM	●	●	●
Mustang	5.4L	4V	2011 - 2012	PSCM	●	●	●
Mustang	5.4L	4V	2012	PAM	●	●	●
Mustang	5.4L	Other	2000	ABS/TCS	●	●	●
Mustang	5.4L	Other	2000	PCM	●	●	●
Mustang	5.8L	4V	2013	ABS	●	●	●
Mustang	5.8L	4V	2013	ACM	●	●	●
Mustang	5.8L	4V	2013	APIM	●	●	●
Mustang	5.8L	4V	2013	BCM-B	●	●	●
Mustang	5.8L	4V	2013	FCIM	●	●	●
Mustang	5.8L	4V	2013	FDIM	●	●	●
Mustang	5.8L	4V	2013	GEM / SJB	●	●	●
Mustang	5.8L	4V	2013	GPSM	●	●	●
Mustang	5.8L	4V	2013	HVAC	●	●	●
Mustang	5.8L	4V	2013	IPC	●	●	●
Mustang	5.8L	4V	2013	OCSM	●	●	●
Mustang	5.8L	4V	2013	PAM	●	●	●
Mustang	5.8L	4V	2013	PCM	●	●	●
Mustang	5.8L	4V	2013	PSCM	●	●	●
Mustang	5.8L	4V	2013	RCM	●	●	●
Mustang	5.8L	4V	2013	VDM	●	●	●
Mustang	Other	Other	2014	ABS	●	●	●
Mustang	Other	Other	2014	APIM	●	●	●
Mustang	Other	Other	2014	BCM-B	●	●	●
Mustang	Other	Other	2014	FCIM	●	●	●
Mustang	Other	Other	2014	FDIM	●	●	●
Mustang	Other	Other	2014	GEM / SJB	●	●	●
Mustang	Other	Other	2014	GPSM	●	●	●
Mustang	Other	Other	2014	HVAC	●	●	●
Mustang	Other	Other	2014	IPC	●	●	●
Mustang	Other	Other	2014	OCSM	●	●	●
Mustang	Other	Other	2014	PCM	●	●	●
Mustang	Other	Other	2014	RCM	●	●	●
Mystique	2.0L	Zetec	1996 - 2000	ABS/TCS	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Mystique	2.0L	Zetec	1996 - 2000	CSM	●	●	●
Mystique	2.0L	Zetec	1996 - 2000	PCM	●	●	●
Mystique	2.0L	Zetec	1997 - 1998	PATS	●	●	●
Mystique	2.0L	Zetec	1999 - 2000	RCM	●	●	●
Mystique	2.5L	Duratec-VE	1996 - 2000	ABS/TCS	●	●	●
Mystique	2.5L	Duratec-VE	1996 - 2000	CSM	●	●	●
Mystique	2.5L	Duratec-VE	1996 - 2000	PCM	●	●	●
Mystique	2.5L	Duratec-VE	1997 - 1998	PATS	●	●	●
Mystique	2.5L	Duratec-VE	1999 - 2000	RCM	●	●	●
NOVO KA	1.0L	FFV	2008 - 2011	IC	●	●	●
NOVO KA	1.0L	FFV	2008 - 2011	PCM	●	●	●
NOVO KA	1.0L	FFV	2008 - 2011	RCM	●	●	●
NOVO KA	1.0L	FFV	2008 - 2011	RKE	●	●	●
NOVO KA	1.0L	FFV	2009 - 2011	TBM	●	●	●
NOVO KA	1.0L	Zetec Rocam	2008 - 2009	IC	●	●	●
NOVO KA	1.0L	Zetec Rocam	2008 - 2009	PCM	●	●	●
NOVO KA	1.0L	Zetec Rocam	2008 - 2009	RCM	●	●	●
NOVO KA	1.0L	Zetec Rocam	2008 - 2009	RKE	●	●	●
NOVO KA	1.0L	Zetec Rocam	2009	TBM	●	●	●
NOVO KA	1.6L	FFV	2008 - 2011	IC	●	●	●
NOVO KA	1.6L	FFV	2008 - 2011	PCM	●	●	●
NOVO KA	1.6L	FFV	2008 - 2011	RCM	●	●	●
NOVO KA	1.6L	FFV	2008 - 2011	RKE	●	●	●
NOVO KA	1.6L	FFV	2009 - 2011	TBM	●	●	●
NOVO KA	1.6L	Zetec Rocam	2008 - 2009	IC	●	●	●
NOVO KA	1.6L	Zetec Rocam	2008 - 2009	PCM	●	●	●
NOVO KA	1.6L	Zetec Rocam	2008 - 2009	RCM	●	●	●
NOVO KA	1.6L	Zetec Rocam	2008 - 2009	RKE	●	●	●
NOVO KA	1.6L	Zetec Rocam	2009	TBM	●	●	●
NOVO KA	Other	Other	2008	IC	●	●	●
NOVO KA	Other	Other	2008	PCM	●	●	●
NOVO KA	Other	Other	2008	RCM	●	●	●
NOVO KA	Other	Other	2008	RKE	●	●	●
Navigator	5.4L	3V	2005 - 2006	NAV	●	●	●
Navigator	5.4L	3V	2005 - 2006	VSM	●	●	●
Navigator	5.4L	3V	2005 - 2007	EATC	●	●	●
Navigator	5.4L	3V	2005 - 2010	4X4	●	●	●
Navigator	5.4L	3V	2005 - 2011	TCM	●	●	●
Navigator	5.4L	3V	2005 - 2012	PAM	●	●	●
Navigator	5.4L	3V	2005 - 2014	ABS	●	●	●
Navigator	5.4L	3V	2005 - 2014	DCSM	●	●	●
Navigator	5.4L	3V	2005 - 2014	DSM	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Navigator	5. 4L	3V	2005 - 2014	IC	●	●	●
Navigator	5. 4L	3V	2005 - 2014	LTM	●	●	●
Navigator	5. 4L	3V	2005 - 2014	PCM	●	●	●
Navigator	5. 4L	3V	2005 - 2014	RCM	●	●	●
Navigator	5. 4L	3V	2005 - 2014	VDM	●	●	●
Navigator	5. 4L	3V	2007	GEM	●	●	●
Navigator	5. 4L	3V	2007 - 2012	RETM	●	●	●
Navigator	5. 4L	3V	2007 - 2014	ACM	●	●	●
Navigator	5. 4L	3V	2007 - 2014	DSP	●	●	●
Navigator	5. 4L	3V	2007 - 2014	PRB	●	●	●
Navigator	5. 4L	3V	2007 - 2014	RCU	●	●	●
Navigator	5. 4L	3V	2007 - 2014	SDARS	●	●	●
Navigator	5. 4L	3V	2008 - 2014	APIM	●	●	●
Navigator	5. 4L	3V	2008 - 2014	GEM / SJB	●	●	●
Navigator	5. 4L	3V	2008 - 2014	HVAC	●	●	●
Navigator	5. 4L	3V	2010 - 2012	GPSM	●	●	●
Navigator	5. 4L	3V	2010 - 2014	TCCM	●	●	●
Navigator	5. 4L	3V	2013 - 2014	TBC	●	●	●
Navigator	5. 4L	4V	1999 - 2000	4WAS	●	●	●
Navigator	5. 4L	4V	1999 - 2000	GEM	●	●	●
Navigator	5. 4L	4V	1999 - 2000	RAP	●	●	●
Navigator	5. 4L	4V	1999 - 2004	ABS/TCS	●	●	●
Navigator	5. 4L	4V	1999 - 2004	DSM	●	●	●
Navigator	5. 4L	4V	1999 - 2004	EATC	●	●	●
Navigator	5. 4L	4V	1999 - 2004	HEC	●	●	●
Navigator	5. 4L	4V	1999 - 2004	PCM	●	●	●
Navigator	5. 4L	4V	1999 - 2004	RCM	●	●	●
Navigator	5. 4L	4V	2000 - 2004	PAM	●	●	●
Navigator	5. 4L	4V	2003 - 2004	4X4	●	●	●
Navigator	5. 4L	4V	2003 - 2004	DCSM	●	●	●
Navigator	5. 4L	4V	2003 - 2004	LTM	●	●	●
Navigator	5. 4L	4V	2003 - 2004	NAV	●	●	●
Navigator	5. 4L	4V	2003 - 2004	PCSM	●	●	●
Navigator	5. 4L	4V	2003 - 2004	TPM	●	●	●
Navigator	5. 4L	4V	2003 - 2004	VDM	●	●	●
Navigator	5. 4L	4V	2003 - 2004	VSM	●	●	●
Navigator	5. 4L	Other	1998	4WAS	●	●	●
Navigator	5. 4L	Other	1998	ABS/TCS	●	●	●
Navigator	5. 4L	Other	1998	DSM	●	●	●
Navigator	5. 4L	Other	1998	GEM	●	●	●
Navigator	5. 4L	Other	1998	IAB	●	●	●
Navigator	5. 4L	Other	1998	PATS	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Navigator	5. 4L	Other	1998	PCM	●	●	●
Navigator	5. 4L	Other	1998	RAP	●	●	●
Navigator	5. 4L	Other	1998	RCC	●	●	●
Navigator	Other	Other	2013	ABS	●	●	●
Navigator	Other	Other	2013	ACM	●	●	●
Navigator	Other	Other	2013	APIM	●	●	●
Navigator	Other	Other	2013	DCSM	●	●	●
Navigator	Other	Other	2013	DSM	●	●	●
Navigator	Other	Other	2013	DSP	●	●	●
Navigator	Other	Other	2013	GEM / SJB	●	●	●
Navigator	Other	Other	2013	HVAC	●	●	●
Navigator	Other	Other	2013	IC	●	●	●
Navigator	Other	Other	2013	LTM	●	●	●
Navigator	Other	Other	2013	PCM	●	●	●
Navigator	Other	Other	2013	PRB	●	●	●
Navigator	Other	Other	2013	RCM	●	●	●
Navigator	Other	Other	2013	RCU	●	●	●
Navigator	Other	Other	2013	SDARS	●	●	●
Navigator	Other	Other	2013	TBC	●	●	●
Navigator	Other	Other	2013	TCCM	●	●	●
Navigator	Other	Other	2013	VDM	●	●	●
Navigator L	5. 4L	3V	2007	EATC	●	●	●
Navigator L	5. 4L	3V	2007	GEM	●	●	●
Navigator L	5. 4L	3V	2007 - 2010	4X4	●	●	●
Navigator L	5. 4L	3V	2007 - 2011	TCM	●	●	●
Navigator L	5. 4L	3V	2007 - 2012	PAM	●	●	●
Navigator L	5. 4L	3V	2007 - 2012	PCM	●	●	●
Navigator L	5. 4L	3V	2007 - 2012	RETM	●	●	●
Navigator L	5. 4L	3V	2007 - 2014	ABS	●	●	●
Navigator L	5. 4L	3V	2007 - 2014	ACM	●	●	●
Navigator L	5. 4L	3V	2007 - 2014	DCSM	●	●	●
Navigator L	5. 4L	3V	2007 - 2014	DSM	●	●	●
Navigator L	5. 4L	3V	2007 - 2014	DSP	●	●	●
Navigator L	5. 4L	3V	2007 - 2014	IC	●	●	●
Navigator L	5. 4L	3V	2007 - 2014	LTM	●	●	●
Navigator L	5. 4L	3V	2007 - 2014	PRB	●	●	●
Navigator L	5. 4L	3V	2007 - 2014	RCM	●	●	●
Navigator L	5. 4L	3V	2007 - 2014	RCU	●	●	●
Navigator L	5. 4L	3V	2007 - 2014	SDARS	●	●	●
Navigator L	5. 4L	3V	2007 - 2014	VDM	●	●	●
Navigator L	5. 4L	3V	2008 - 2014	APIM	●	●	●
Navigator L	5. 4L	3V	2008 - 2014	GEM / SJB	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Navigator L	5. 4L	3V	2008 - 2014	HVAC	●	●	●
Navigator L	5. 4L	3V	2010 - 2012	GPSM	●	●	●
Navigator L	5. 4L	3V	2010 - 2014	TCCM	●	●	●
Navigator L	5. 4L	3V	2013 - 2014	TBC	●	●	●
Navigator L	Other	Other	2013	ABS	●	●	●
Navigator L	Other	Other	2013	ACM	●	●	●
Navigator L	Other	Other	2013	APIM	●	●	●
Navigator L	Other	Other	2013	DCSM	●	●	●
Navigator L	Other	Other	2013	DSM	●	●	●
Navigator L	Other	Other	2013	DSP	●	●	●
Navigator L	Other	Other	2013	GEM / SJB	●	●	●
Navigator L	Other	Other	2013	HVAC	●	●	●
Navigator L	Other	Other	2013	IC	●	●	●
Navigator L	Other	Other	2013	LTM	●	●	●
Navigator L	Other	Other	2013	PRB	●	●	●
Navigator L	Other	Other	2013	RCM	●	●	●
Navigator L	Other	Other	2013	RCU	●	●	●
Navigator L	Other	Other	2013	SDARS	●	●	●
Navigator L	Other	Other	2013	TBC	●	●	●
Navigator L	Other	Other	2013	TCCM	●	●	●
Navigator L	Other	Other	2013	VDM	●	●	●
PREMACY / IXION	1. 8L	FP	1999	ABS	●	●	●
PREMACY / IXION	1. 8L	FP	1999 - 2002	PCM	●	●	●
PREMACY / IXION	1. 8L	FP	2002	ABS/TCS	●	●	●
PREMACY / IXION	1. 8L	FP_DE	1999	ABS	●	●	●
PREMACY / IXION	1. 8L	FP_DE	1999	PCM	●	●	●
PREMACY / IXION	2. 0L	FS	2001	ABS/TCS	●	●	●
PREMACY / IXION	2. 0L	FS	2001	PCM	●	●	●
PREMACY / IXION	2. 0L	RF-T	1999	ABS	●	●	●
PREMACY / IXION	2. 0L	RF-T	1999	PCM	●	●	●
PROBE / MX-6	2. 0L	Other	1996 - 1997	PCM	●	●	●
PROBE / MX-6	2. 5L	KL	1996 - 1997	PCM	●	●	●
Puma	1. 4L	Zetec-SE	1998 - 1999	ABS/TCS	●	●	●
Puma	1. 4L	Zetec-SE	1998 - 1999	HEC	●	●	●
Puma	1. 4L	Zetec-SE	1998 - 1999	PATS	○	○	●
Puma	1. 4L	Zetec-SE	1998 - 1999	PCM	●	●	●
Puma	1. 4L	Zetec-SE	1999	GEM	●	●	●
Puma	1. 6L	Zetec-SE	2001	ABS/TCS	●	●	●
Puma	1. 6L	Zetec-SE	2001	GEM	●	●	●
Puma	1. 6L	Zetec-SE	2001	HEC	●	●	●
Puma	1. 6L	Zetec-SE	2001	PATS	●	●	●
Puma	1. 6L	Zetec-SE	2001	PCM	●	●	●



Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Puma	1. 7L	Zetec-SE	1997 - 2001	ABS/TCS	●	●	●
Puma	1. 7L	Zetec-SE	1997 - 2001	HEC	●	●	●
Puma	1. 7L	Zetec-SE	1997 - 2001	PATS	●	●	●
Puma	1. 7L	Zetec-SE	1997 - 2001	PCM	●	●	●
Puma	1. 7L	Zetec-SE	1999 - 2001	GEM	●	●	●
ROADSTER / MX-5	1. 6L	B6	2000	ABS	●	●	●
ROADSTER / MX-5	1. 6L	B6	2002	ABS/TCS	●	●	●
ROADSTER / MX-5	1. 6L	B6	2002	PCM	●	●	●
ROADSTER / MX-5	1. 8L	BP	2000	ABS	●	●	●
ROADSTER / MX-5	1. 8L	BP	2002	ABS/TCS	●	●	●
ROADSTER / MX-5	1. 8L	BP	2002	PCM	●	●	●
ROADSTER / MX-5	1. 8L	BP Turbo	2003	ABS/TCS	●	●	●
ROADSTER / MX-5	1. 8L	BP Turbo	2003	PCM	●	●	●
ROADSTER / MX-5	2. 0L	LF	2005 - 2008	ABS	●	●	●
ROADSTER / MX-5	2. 0L	LF	2005 - 2008	IC	●	●	●
ROADSTER / MX-5	2. 0L	LF	2005 - 2008	PCM	●	●	●
ROADSTER / MX-5	2. 0L	LF	2005 - 2008	RCM	●	●	●
ROADSTER / MX-5	2. 0L	LF	2005 - 2008	RHT	●	●	●
ROADSTER / MX-5	2. 0L	LF	2005 - 2008	RKE	●	●	●
ROADSTER / MX-5	2. 0L	LF	2005 - 2008	TCM	●	●	●
Ranger	2. 3L	DURATEC-HE / I4	2006 - 2009	4X4	●	●	●
Ranger	2. 3L	DURATEC-HE / I4	2006 - 2009	ABS/TCS	●	●	●
Ranger	2. 3L	DURATEC-HE / I4	2006 - 2009	GEM	●	●	●
Ranger	2. 3L	DURATEC-HE / I4	2006 - 2009	IC	●	●	●
Ranger	2. 3L	DURATEC-HE / I4	2006 - 2009	PCM	●	●	●
Ranger	2. 3L	DURATEC-HE / I4	2006 - 2009	RCM	●	●	●
Ranger	2. 3L	DURATEC-HE / I4	2009	TBM	●	●	●
Ranger	3. 0L	I4 DSL Electronic	2005	4X4	●	●	●
Ranger	3. 0L	I4 DSL Electronic	2005	ABS/TCS	●	●	●
Ranger	3. 0L	I4 DSL Electronic	2005	GEM	●	●	●
Ranger	3. 0L	I4 DSL Electronic	2005	IC	●	●	●
Ranger	3. 0L	I4 DSL Electronic	2005	PCM	●	●	●
Ranger	3. 0L	I4 DSL Electronic	2005	RCM	●	●	●
Ranger	3. 0L	I4 DSL Electronic	2005	TBM	●	●	●
Ranger / Courier / Mazda B Series /Bravo	4. 0L	V6 SOHC	2003	ABS/TCS	●	●	●
Ranger / Courier / Mazda B Series /Bravo	4. 0L	V6 SOHC	2003	ESOF	●	●	●
Ranger / Courier / Mazda B Series /Bravo	4. 0L	V6 SOHC	2003	PCM	●	●	●
Ranger / Mazda B-Series / Courier	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2011	ABS	●	●	●
Ranger / Mazda B-Series / Courier	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2011	ACM	●	●	●
Ranger / Mazda B-Series / Courier	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2011	BCMii	●	●	●
Ranger / Mazda B-Series / Courier	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2011	DDM	●	●	●
Ranger / Mazda B-Series / Courier	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2011	FCDIM	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Ranger / Mazda B-Series / Courier	2.2L	Duratorq Turbo Diesel Common Rail Injection	2011	HVAC	●	●	●
Ranger / Mazda B-Series / Courier	2.2L	Duratorq Turbo Diesel Common Rail Injection	2011	IPC	●	●	●
Ranger / Mazda B-Series / Courier	2.2L	Duratorq Turbo Diesel Common Rail Injection	2011	PAM	●	●	●
Ranger / Mazda B-Series / Courier	2.2L	Duratorq Turbo Diesel Common Rail Injection	2011	PCM	●	●	●
Ranger / Mazda B-Series / Courier	2.2L	Duratorq Turbo Diesel Common Rail Injection	2011	PDM	●	●	●
Ranger / Mazda B-Series / Courier	2.2L	Duratorq Turbo Diesel Common Rail Injection	2011	RCM	●	●	●
Ranger / Mazda B-Series / Courier	2.2L	Duratorq Turbo Diesel Common Rail Injection	2011	SRM	●	●	●
Ranger / Mazda B-Series / Courier	2.2L	Duratorq Turbo Diesel Common Rail Injection	2011	TBM	●	●	●
Ranger / Mazda B-Series / Courier	2.2L	Duratorq Turbo Diesel Common Rail Injection	2011	TCM	●	●	●
Ranger / Mazda B-Series / Courier	2.2L	Duratorq Turbo Diesel Common Rail Injection	2011	TRM	●	●	●
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2004 - 2007	GEM	●	●	●
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2004 - 2009	ABS/TCS	●	●	●
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2004 - 2011	4X4	●	●	●
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2004 - 2011	IC	●	●	●
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2004 - 2011	PCM	●	●	●
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2004 - 2011	RCM	●	●	●
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2005	TPM	●	●	●
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2007 - 2011	OCSM	●	●	●
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2007 - 2011	SDARS	●	●	●
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2008 - 2011	GEM / SJB	●	●	●
Ranger / Mazda B-Series / Courier	2.3L	DURATEC-HE / I4	2010 - 2011	ABS	●	●	●
Ranger / Mazda B-Series / Courier	2.3L	OHC	1995 - 1997	ABS/TCS	●	●	●
Ranger / Mazda B-Series / Courier	2.3L	OHC	1995 - 1997	GEM	●	●	●
Ranger / Mazda B-Series / Courier	2.3L	OHC	1995 - 1997	PCM	●	●	●
Ranger / Mazda B-Series / Courier	2.3L	OHC	1995 - 1997	RAP	●	●	●
Ranger / Mazda B-Series / Courier	2.3L	OHC	1996 - 1997	IAB	●	●	●
Ranger / Mazda B-Series / Courier	2.3L	Other	1996 - 2003	ABS/TCS	●	●	●
Ranger / Mazda B-Series / Courier	2.3L	Other	1996 - 2003	GEM	●	●	●
Ranger / Mazda B-Series / Courier	2.3L	Other	1996 - 2003	PCM	●	●	●
Ranger / Mazda B-Series / Courier	2.3L	Other	2001	PATS	●	●	●
Ranger / Mazda B-Series / Courier	2.3L	Other	2001 - 2003	4X4	●	●	●
Ranger / Mazda B-Series / Courier	2.3L	Other	2001 - 2003	RAP	●	●	●
Ranger / Mazda B-Series / Courier	2.3L	Other	2001 - 2003	RCM	●	●	●
Ranger / Mazda B-Series / Courier	2.5L	DURATEC-HE / I4	2011	ABS	●	●	●
Ranger / Mazda B-Series / Courier	2.5L	DURATEC-HE / I4	2011	ACM	●	●	●
Ranger / Mazda B-Series / Courier	2.5L	DURATEC-HE / I4	2011	BCM i i	●	●	●
Ranger / Mazda B-Series / Courier	2.5L	DURATEC-HE / I4	2011	DDM	●	●	●
Ranger / Mazda B-Series / Courier	2.5L	DURATEC-HE / I4	2011	FCDIM	●	●	●
Ranger / Mazda B-Series / Courier	2.5L	DURATEC-HE / I4	2011	HVAC	●	●	●
Ranger / Mazda B-Series / Courier	2.5L	DURATEC-HE / I4	2011	IPC	●	●	●
Ranger / Mazda B-Series / Courier	2.5L	DURATEC-HE / I4	2011	PAM	●	●	●
Ranger / Mazda B-Series / Courier	2.5L	DURATEC-HE / I4	2011	PCM	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Ranger / Mazda B-Series / Courier	2.5L	DURATEC-HE / I4	2011	PDM	●	●	●
Ranger / Mazda B-Series / Courier	2.5L	DURATEC-HE / I4	2011	RCM	●	●	●
Ranger / Mazda B-Series / Courier	2.5L	DURATEC-HE / I4	2011	SRM	●	●	●
Ranger / Mazda B-Series / Courier	2.5L	DURATEC-HE / I4	2011	TBM	●	●	●
Ranger / Mazda B-Series / Courier	2.5L	DURATEC-HE / I4	2011	TCM	●	●	●
Ranger / Mazda B-Series / Courier	2.5L	DURATEC-HE / I4	2011	TRM	●	●	●
Ranger / Mazda B-Series / Courier	2.5L	Other	1998	IAB	●	●	●
Ranger / Mazda B-Series / Courier	2.5L	Other	1998 - 2001	ABS/TCS	●	●	●
Ranger / Mazda B-Series / Courier	2.5L	Other	1998 - 2001	GEM	●	●	●
Ranger / Mazda B-Series / Courier	2.5L	Other	1998 - 2001	PCM	●	●	●
Ranger / Mazda B-Series / Courier	2.5L	Other	1998 - 2001	RAP	●	●	●
Ranger / Mazda B-Series / Courier	2.5L	Other	1999 - 2001	PATS	●	●	●
Ranger / Mazda B-Series / Courier	2.5L	Other	1999 - 2001	RCM	●	●	●
Ranger / Mazda B-Series / Courier	2.5L	Other	2001	4X4	●	●	●
Ranger / Mazda B-Series / Courier	2.8L	Other	2001	4X4	●	●	●
Ranger / Mazda B-Series / Courier	2.8L	Other	2001	ABS/TCS	●	●	●
Ranger / Mazda B-Series / Courier	2.8L	Other	2001	GEM	●	●	●
Ranger / Mazda B-Series / Courier	2.8L	Other	2001	PATS	●	●	●
Ranger / Mazda B-Series / Courier	2.8L	Other	2001	PCM	●	●	●
Ranger / Mazda B-Series / Courier	2.8L	Other	2001	RAP	●	●	●
Ranger / Mazda B-Series / Courier	2.8L	Other	2001	RCM	●	●	●
Ranger / Mazda B-Series / Courier	3.0L	FFV	1999 - 2000	ABS/TCS	●	●	●
Ranger / Mazda B-Series / Courier	3.0L	FFV	1999 - 2000	GEM	●	●	●
Ranger / Mazda B-Series / Courier	3.0L	FFV	1999 - 2000	PATS	●	●	●
Ranger / Mazda B-Series / Courier	3.0L	FFV	1999 - 2000	PCM	●	●	●
Ranger / Mazda B-Series / Courier	3.0L	FFV	1999 - 2000	RAP	●	●	●
Ranger / Mazda B-Series / Courier	3.0L	FFV	1999 - 2000	RCM	●	●	●
Ranger / Mazda B-Series / Courier	3.0L	Other	1995 - 2003	RAP	●	●	●
Ranger / Mazda B-Series / Courier	3.0L	Other	1995 - 2007	GEM	●	●	●
Ranger / Mazda B-Series / Courier	3.0L	Other	1995 - 2008	ABS/TCS	●	●	●
Ranger / Mazda B-Series / Courier	3.0L	Other	1995 - 2008	PCM	●	●	●
Ranger / Mazda B-Series / Courier	3.0L	Other	1996 - 1998	IAB	●	●	●
Ranger / Mazda B-Series / Courier	3.0L	Other	1999 - 2008	RCM	●	●	●
Ranger / Mazda B-Series / Courier	3.0L	Other	2000 - 2001	PATS	●	●	●
Ranger / Mazda B-Series / Courier	3.0L	Other	2001 - 2008	4X4	●	●	●
Ranger / Mazda B-Series / Courier	3.0L	Other	2004 - 2008	IC	●	●	●
Ranger / Mazda B-Series / Courier	3.0L	Other	2005	TPM	●	●	●
Ranger / Mazda B-Series / Courier	3.0L	Other	2007 - 2008	OCSM	●	●	●
Ranger / Mazda B-Series / Courier	3.0L	Other	2007 - 2008	SDARS	●	●	●
Ranger / Mazda B-Series / Courier	3.0L	Other	2008	GEM / SJB	●	●	●
Ranger / Mazda B-Series / Courier	3.2L	Duratorq Turbo Diesel Common Rail Injection	2011	ABS	●	●	●
Ranger / Mazda B-Series / Courier	3.2L	Duratorq Turbo Diesel Common Rail Injection	2011	ACM	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Ranger / Mazda B-Series / Courier	3.2L	Duratorq Turbo Diesel Common Rail Injection	2011	BCMii	●	●	●
Ranger / Mazda B-Series / Courier	3.2L	Duratorq Turbo Diesel Common Rail Injection	2011	DDM	●	●	●
Ranger / Mazda B-Series / Courier	3.2L	Duratorq Turbo Diesel Common Rail Injection	2011	FCDIM	●	●	●
Ranger / Mazda B-Series / Courier	3.2L	Duratorq Turbo Diesel Common Rail Injection	2011	HVAC	●	●	●
Ranger / Mazda B-Series / Courier	3.2L	Duratorq Turbo Diesel Common Rail Injection	2011	IPC	●	●	●
Ranger / Mazda B-Series / Courier	3.2L	Duratorq Turbo Diesel Common Rail Injection	2011	PAM	●	●	●
Ranger / Mazda B-Series / Courier	3.2L	Duratorq Turbo Diesel Common Rail Injection	2011	PCM	●	●	●
Ranger / Mazda B-Series / Courier	3.2L	Duratorq Turbo Diesel Common Rail Injection	2011	PDM	●	●	●
Ranger / Mazda B-Series / Courier	3.2L	Duratorq Turbo Diesel Common Rail Injection	2011	RCM	●	●	●
Ranger / Mazda B-Series / Courier	3.2L	Duratorq Turbo Diesel Common Rail Injection	2011	SRM	●	●	●
Ranger / Mazda B-Series / Courier	3.2L	Duratorq Turbo Diesel Common Rail Injection	2011	TBM	●	●	●
Ranger / Mazda B-Series / Courier	3.2L	Duratorq Turbo Diesel Common Rail Injection	2011	TCM	●	●	●
Ranger / Mazda B-Series / Courier	3.2L	Duratorq Turbo Diesel Common Rail Injection	2011	TRM	●	●	●
Ranger / Mazda B-Series / Courier	4.0L	Other	1995 - 2002	ABS/TCS	●	●	●
Ranger / Mazda B-Series / Courier	4.0L	Other	1995 - 2002	GEM	●	●	●
Ranger / Mazda B-Series / Courier	4.0L	Other	1995 - 2002	PCM	●	●	●
Ranger / Mazda B-Series / Courier	4.0L	Other	1995 - 2002	RAP	●	●	●
Ranger / Mazda B-Series / Courier	4.0L	Other	1996 - 1998	IAB	●	●	●
Ranger / Mazda B-Series / Courier	4.0L	Other	1999 - 2001	PATS	●	●	●
Ranger / Mazda B-Series / Courier	4.0L	Other	1999 - 2002	RCM	●	●	●
Ranger / Mazda B-Series / Courier	4.0L	Other	2001 - 2002	4X4	●	●	●
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2003	RAP	●	●	●
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2003 - 2007	GEM	●	●	●
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2003 - 2009	ABS/TCS	●	●	●
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2003 - 2011	4X4	●	●	●
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2003 - 2011	PCM	●	●	●
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2003 - 2011	RCM	●	●	●
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2004 - 2011	IC	●	●	●
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2005	TPM	●	●	●
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2007 - 2011	OCSM	●	●	●
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2007 - 2011	SDARS	●	●	●
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2008 - 2011	GEM / SJB	●	●	●
Ranger / Mazda B-Series / Courier	4.0L	V6 SOHC	2010 - 2011	ABS	●	●	●
Ranger / Mazda B-Series / Courier	Other	Other	2004	4X4	●	●	●
Ranger / Mazda B-Series / Courier	Other	Other	2004	ABS/TCS	●	●	●
Ranger / Mazda B-Series / Courier	Other	Other	2004	GEM	●	●	●
Ranger / Mazda B-Series / Courier	Other	Other	2004	IC	●	●	●
Ranger / Mazda B-Series / Courier	Other	Other	2004	PCM	●	●	●
Ranger / Mazda B-Series / Courier	Other	Other	2004 - 2011	RCM	●	●	●
Ranger / Mazda B-Series / Courier	Other	Other	2011	ABS	●	●	●
Ranger / Mazda B-Series / Courier	Other	Other	2011	ACM	●	●	●
Ranger / Mazda B-Series / Courier	Other	Other	2011	BCMii	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Ranger / Mazda B-Series / Courier	Other	Other	2011	DDM	●	●	●
Ranger / Mazda B-Series / Courier	Other	Other	2011	FCDIM	●	●	●
Ranger / Mazda B-Series / Courier	Other	Other	2011	HVAC	●	●	●
Ranger / Mazda B-Series / Courier	Other	Other	2011	IPC	●	●	●
Ranger / Mazda B-Series / Courier	Other	Other	2011	PAM	●	●	●
Ranger / Mazda B-Series / Courier	Other	Other	2011	PDM	●	●	●
Ranger / Mazda B-Series / Courier	Other	Other	2011	SRM	●	●	●
Ranger / Mazda B-Series / Courier	Other	Other	2011	TBM	●	●	●
Ranger / Mazda B-Series / Courier	Other	Other	2011	TCM	●	●	●
Ranger / Mazda B-Series / Courier	Other	Other	2011	TRM	●	●	●
S.A. Courier	1. 6L	FFV	2007 - 2011	PCM	●	●	●
S.A. Courier	1. 6L	FFV	2009 - 2011	IC	●	●	●
S.A. Courier	1. 6L	FFV	2009 - 2011	TBM	●	●	●
S.A. Courier	1. 6L	Zetec Rocam	2009	IC	●	●	●
S.A. Courier	1. 6L	Zetec Rocam	2009	PCM	●	●	●
S.A. Courier	1. 6L	Zetec Rocam	2009	TBM	●	●	●
S.A. Fiesta	1. 0L	FFV	2006 - 2010	ABS/TCS	●	●	●
S.A. Fiesta	1. 0L	FFV	2006 - 2010	IC	●	●	●
S.A. Fiesta	1. 0L	FFV	2006 - 2010	PCM	●	●	●
S.A. Fiesta	1. 0L	FFV	2006 - 2010	RCM	●	●	●
S.A. Fiesta	1. 0L	FFV	2006 - 2010	RKE	●	●	●
S.A. Fiesta	1. 0L	FFV	2010	TBM	●	●	●
S.A. Fiesta	1. 0L	Zetec Rocam	2002	ABS/TCS	●	●	●
S.A. Fiesta	1. 0L	Zetec Rocam	2002	IC	●	●	●
S.A. Fiesta	1. 0L	Zetec Rocam	2002	PCM	●	●	●
S.A. Fiesta	1. 0L	Zetec Rocam	2002	RCM	●	●	●
S.A. Fiesta	1. 0L	Zetec Rocam	2002	RKE	●	●	●
S.A. Fiesta	1. 4L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2011	ABS/TCS	●	●	●
S.A. Fiesta	1. 4L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2011	IC	●	●	●
S.A. Fiesta	1. 4L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2011	PCM	●	●	●
S.A. Fiesta	1. 4L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2011	RCM	●	●	●
S.A. Fiesta	1. 4L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2011	RKE	●	●	●
S.A. Fiesta	1. 6L	FFV	2002 - 2011	ABS/TCS	●	●	●
S.A. Fiesta	1. 6L	FFV	2002 - 2011	IC	●	●	●
S.A. Fiesta	1. 6L	FFV	2002 - 2011	PCM	●	●	●
S.A. Fiesta	1. 6L	FFV	2002 - 2011	RCM	●	●	●
S.A. Fiesta	1. 6L	FFV	2002 - 2011	RKE	●	●	●
S.A. Fiesta	1. 6L	FFV	2011	TBM	●	●	●
S.A. Fiesta	1. 6L	Zetec Rocam	2002 - 2009	ABS/TCS	●	●	●
S.A. Fiesta	1. 6L	Zetec Rocam	2002 - 2009	IC	●	●	●
S.A. Fiesta	1. 6L	Zetec Rocam	2002 - 2009	PCM	●	●	●
S.A. Fiesta	1. 6L	Zetec Rocam	2002 - 2009	RCM	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
S.A. Fiesta	1. 6L	Zetec Rocam	2002 - 2009	RKE	●	●	●
SCRUM (2005 / 9) DG64V / DG64W	660cc	K6A	2005	ABS	●	●	●
SCRUM (2005 / 9) DG64V / DG64W	660cc	K6A	2005	PCM	●	●	●
SCRUM (2005 / 9) DG64V / DG64W	660cc	K6A	2005	RCM	●	●	●
SCRUM (2005 / 9) DG64V / DG64W	660cc	K6A_T	2005	ABS	●	●	●
SCRUM (2005 / 9) DG64V / DG64W	660cc	K6A_T	2005	PCM	●	●	●
SCRUM (2005 / 9) DG64V / DG64W	660cc	K6A_T	2005	RCM	●	●	●
SCRUM (2005 / 9) DG64V / DG64W	660cc	K6A_T	2005	TCM	●	●	●
Sable	3. 0L	2V	2003	ABS/TCS	●	●	●
Sable	3. 0L	2V	2003 - 2005	EATC	●	●	●
Sable	3. 0L	2V	2003 - 2005	GEM	●	●	●
Sable	3. 0L	2V	2003 - 2005	PCM	●	●	●
Sable	3. 0L	2V	2003 - 2005	RCM	●	●	●
Sable	3. 0L	2V	2004 - 2005	ABS	●	●	●
Sable	3. 0L	2V	2004 - 2005	IC	●	●	●
Sable	3. 0L	4V	1996 - 1999	IAB	●	●	●
Sable	3. 0L	4V	1996 - 1999	PATS	●	●	●
Sable	3. 0L	4V	1996 - 1999	RAP	●	●	●
Sable	3. 0L	4V	1996 - 1999	RCC	●	●	●
Sable	3. 0L	4V	1996 - 2003	ABS/TCS	●	●	●
Sable	3. 0L	4V	1996 - 2005	GEM	●	●	●
Sable	3. 0L	4V	1996 - 2005	PCM	●	●	●
Sable	3. 0L	4V	2000 - 2005	EATC	●	●	●
Sable	3. 0L	4V	2000 - 2005	RCM	●	●	●
Sable	3. 0L	4V	2004 - 2005	ABS	●	●	●
Sable	3. 0L	4V	2004 - 2005	IC	●	●	●
Sable	3. 0L	FFV	2000 - 2003	ABS/TCS	●	●	●
Sable	3. 0L	FFV	2000 - 2003	EATC	●	●	●
Sable	3. 0L	FFV	2000 - 2003	GEM	●	●	●
Sable	3. 0L	FFV	2000 - 2003	PCM	●	●	●
Sable	3. 0L	FFV	2000 - 2003	RCM	●	●	●
Sable	3. 0L	Other	1996 - 1999	IAB	●	●	●
Sable	3. 0L	Other	1996 - 1999	PATS	●	●	●
Sable	3. 0L	Other	1996 - 1999	RAP	●	●	●
Sable	3. 0L	Other	1996 - 1999	RCC	●	●	●
Sable	3. 0L	Other	1996 - 2002	ABS/TCS	●	●	●
Sable	3. 0L	Other	1996 - 2002	GEM	●	●	●
Sable	3. 0L	Other	1996 - 2002	PCM	●	●	●
Sable	3. 0L	Other	2000 - 2002	EATC	●	●	●
Sable	3. 0L	Other	2000 - 2002	RCM	●	●	●
Sable	3. 5L	4V	2008 - 2009	4X4	●	●	●
Sable	3. 5L	4V	2008 - 2009	ABS	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Sable	3.5L	4V	2008 - 2009	ACM	●	●	●
Sable	3.5L	4V	2008 - 2009	APIM	●	●	●
Sable	3.5L	4V	2008 - 2009	DSM	●	●	●
Sable	3.5L	4V	2008 - 2009	GEM / SJB	●	●	●
Sable	3.5L	4V	2008 - 2009	HVAC	●	●	●
Sable	3.5L	4V	2008 - 2009	IC	●	●	●
Sable	3.5L	4V	2008 - 2009	OCSM	●	●	●
Sable	3.5L	4V	2008 - 2009	PAM	●	●	●
Sable	3.5L	4V	2008 - 2009	PCM	●	●	●
Sable	3.5L	4V	2008 - 2009	RCM	●	●	●
Sable	3.5L	4V	2008 - 2009	RETM	●	●	●
Sable	3.5L	4V	2008 - 2009	SDARS	●	●	●
Sable	3.5L	4V	2008 - 2009	SECM	●	●	●
Street Ka	1.6L	DURATEC 8V	2003	ABS/TCS	●	●	●
Street Ka	1.6L	DURATEC 8V	2003	CSM	●	●	●
Street Ka	1.6L	DURATEC 8V	2003	ECS	●	●	○
Street Ka	1.6L	DURATEC 8V	2003	GEM	●	●	●
Street Ka	1.6L	DURATEC 8V	2003	PCM	●	●	●
TITAN (Isuzu OEM)	3.0L	4JJ1_T	2007 - 2011	ABS	●	●	●
TITAN (Isuzu OEM)	3.0L	4JJ1_T	2007 - 2011	GEM	●	●	●
TITAN (Isuzu OEM)	3.0L	4JJ1_T	2007 - 2011	PATS	●	●	●
TITAN (Isuzu OEM)	3.0L	4JJ1_T	2007 - 2011	PCM	●	●	●
TITAN (Isuzu OEM)	3.0L	4JJ1_T	2007 - 2011	RCM	●	●	●
TITAN (Isuzu OEM)	3.0L	4JJ1_T	2007 - 2011	TCM	●	●	●
TITAN (Isuzu OEM)	3.1L	4JG2	2004	PCM	●	●	●
TITAN (Isuzu OEM)	3.1L	4JG2 LPG	2004	PCM	●	●	●
TITAN (Isuzu OEM)	4.3L	4HF1 CNG	2004	PCM	●	●	●
TITAN (Isuzu OEM)	4.6L	4HG1 LPG	2004	PCM	●	●	●
TITAN (Isuzu OEM)	4.6L	4HV1 CNG	2004 - 2011	PCM	●	●	●
TITAN (Isuzu OEM)	4.6L	4HV1 CNG	2004 - 2011	TCM	●	●	●
TITAN (Isuzu OEM)	4.6L	4HV1 CNG	2007 - 2011	ABS	●	●	●
TITAN (Isuzu OEM)	4.6L	4HV1 CNG	2007 - 2011	GEM	●	●	●
TITAN (Isuzu OEM)	4.6L	4HV1 CNG	2007 - 2011	RCM	●	●	●
TITAN (Isuzu OEM)	4.8L	4HL1	2004	PCM	●	●	●
TITAN (Isuzu OEM)	4.8L	4HL1	2004	TCM	●	●	●
TITAN (Isuzu OEM)	4.8L	4HL1_T	2004	PCM	●	●	●
TITAN (Isuzu OEM)	4.8L	4HL1_T	2004	TCM	●	●	●
TITAN (Isuzu OEM)	5.2L	4HK1_T	2007	ABS	●	●	●
TITAN (Isuzu OEM)	5.2L	4HK1_T	2007	GEM	●	●	●
TITAN (Isuzu OEM)	5.2L	4HK1_T	2007	PATS	●	●	●
TITAN (Isuzu OEM)	5.2L	4HK1_T	2007	PCM	●	●	●
TITAN (Isuzu OEM)	5.2L	4HK1_T	2007	RCM	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
TITAN (Isuzu OEM)	5.2L	4HK1_T	2007	TCM	●	●	●
Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	ACM	●	●	●
Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	BCM#1	●	●	●
Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	C-CM	●	●	●
Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	FCDIM	●	●	●
Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	HCM	●	●	●
Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	IPC	●	●	●
Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013	OCSM	●	●	●
Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	ABS	●	●	●
Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	APIM	●	●	●
Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	DCSM	●	●	●
Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	DDM	●	●	●
Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	DSM	●	●	●
Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	DSP	●	●	●
Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	FCIM	●	●	●
Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	GFM	●	●	●
Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	GPSM	●	●	●
Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	HSWM	●	●	●
Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	HUD	●	●	●
Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	HVAC	●	●	●
Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	IPM-A	●	●	●
Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	PAM	●	●	●
Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	PCM	●	●	●
Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	PSCM	●	●	●
Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	RACM	●	●	●
Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	RCM	●	●	●
Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	RFA	●	●	●
Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	RTM	●	●	●
Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	SCCM	●	●	●
Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	SOD-L	●	●	●
Taurus	2.0L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	SOD-R	●	●	●
Taurus	3.0L	2V	2003	ABS/TCS	●	●	●
Taurus	3.0L	2V	2003 - 2007	EATC	●	●	●
Taurus	3.0L	2V	2003 - 2007	GEM	●	●	●
Taurus	3.0L	2V	2003 - 2007	PCM	●	●	●
Taurus	3.0L	2V	2003 - 2007	RCM	●	●	●
Taurus	3.0L	2V	2004 - 2007	ABS	●	●	●
Taurus	3.0L	2V	2004 - 2007	IC	●	●	●
Taurus	3.0L	4V	1996 - 1999	IAB	●	●	●
Taurus	3.0L	4V	1996 - 1999	PATS	●	●	●
Taurus	3.0L	4V	1996 - 1999	RAP	●	●	●
Taurus	3.0L	4V	1996 - 1999	RCC	●	●	●



Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Taurus	3.0L	4V	1996 - 2003	ABS/TCS	●	●	●
Taurus	3.0L	4V	1996 - 2005	GEM	●	●	●
Taurus	3.0L	4V	1996 - 2005	PCM	●	●	●
Taurus	3.0L	4V	2000 - 2005	EATC	●	●	●
Taurus	3.0L	4V	2000 - 2005	RCM	●	●	●
Taurus	3.0L	4V	2004 - 2005	ABS	●	●	●
Taurus	3.0L	4V	2004 - 2005	IC	●	●	●
Taurus	3.0L	FFV	1996 - 1999	IAB	●	●	●
Taurus	3.0L	FFV	1996 - 1999	PATS	●	●	●
Taurus	3.0L	FFV	1996 - 1999	RAP	●	●	●
Taurus	3.0L	FFV	1996 - 1999	RCC	●	●	●
Taurus	3.0L	FFV	1996 - 2003	ABS/TCS	●	●	●
Taurus	3.0L	FFV	1996 - 2003	GEM	●	●	●
Taurus	3.0L	FFV	1996 - 2003	PCM	●	●	●
Taurus	3.0L	FFV	2000 - 2003	EATC	●	●	●
Taurus	3.0L	FFV	2000 - 2003	RCM	●	●	●
Taurus	3.0L	Other	1996 - 1999	IAB	●	●	●
Taurus	3.0L	Other	1996 - 1999	PATS	●	●	●
Taurus	3.0L	Other	1996 - 1999	RAP	●	●	●
Taurus	3.0L	Other	1996 - 1999	RCC	●	●	●
Taurus	3.0L	Other	1996 - 2002	ABS/TCS	●	●	●
Taurus	3.0L	Other	1996 - 2002	GEM	●	●	●
Taurus	3.0L	Other	1996 - 2002	PCM	●	●	●
Taurus	3.0L	Other	2000 - 2002	EATC	●	●	●
Taurus	3.0L	Other	2000 - 2002	RCM	●	●	●
Taurus	3.4L	Other	1997	ABS/TCS	●	●	●
Taurus	3.4L	Other	1997	GEM	●	●	●
Taurus	3.4L	Other	1997	PATS	●	●	●
Taurus	3.4L	Other	1997	PCM	●	●	●
Taurus	3.4L	SHO	1996 - 1998	GEM	●	●	●
Taurus	3.4L	SHO	1996 - 1998	IAB	●	●	●
Taurus	3.4L	SHO	1996 - 1998	SARC	●	●	●
Taurus	3.4L	SHO	1996 - 1999	ABS/TCS	●	●	●
Taurus	3.4L	SHO	1996 - 1999	PATS	●	●	●
Taurus	3.4L	SHO	1996 - 1999	PCM	●	●	●
Taurus	3.4L	SHO	1996 - 1999	RAP	●	●	●
Taurus	3.4L	SHO	1996 - 1999	RCC	●	●	●
Taurus	3.5L	4V	2008 - 2009	IC	●	●	●
Taurus	3.5L	4V	2008 - 2009	SDARS	●	●	●
Taurus	3.5L	4V	2008 - 2009	SECM	●	●	●
Taurus	3.5L	4V	2008 - 2012	4X4	●	●	●
Taurus	3.5L	4V	2008 - 2012	ABS	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Taurus	3.5L	4V	2008 - 2012	ACM	●	●	●
Taurus	3.5L	4V	2008 - 2012	APIM	●	●	●
Taurus	3.5L	4V	2008 - 2012	DSM	●	●	●
Taurus	3.5L	4V	2008 - 2012	GEM / SJB	●	●	●
Taurus	3.5L	4V	2008 - 2012	HVAC	●	●	●
Taurus	3.5L	4V	2008 - 2012	OCSM	●	●	●
Taurus	3.5L	4V	2008 - 2012	PAM	●	●	●
Taurus	3.5L	4V	2008 - 2012	PCM	●	●	●
Taurus	3.5L	4V	2008 - 2012	RCM	●	●	●
Taurus	3.5L	4V	2008 - 2012	RETM	●	●	●
Taurus	3.5L	4V	2010 - 2012	C-CM	●	●	●
Taurus	3.5L	4V	2010 - 2012	DCSM	●	●	●
Taurus	3.5L	4V	2010 - 2012	DDM	●	●	●
Taurus	3.5L	4V	2010 - 2012	DSP	●	●	●
Taurus	3.5L	4V	2010 - 2012	FCIM	●	●	●
Taurus	3.5L	4V	2010 - 2012	FDIM	●	●	●
Taurus	3.5L	4V	2010 - 2012	GPSM	●	●	●
Taurus	3.5L	4V	2010 - 2012	HCM	●	●	●
Taurus	3.5L	4V	2010 - 2012	HCM-2	●	●	●
Taurus	3.5L	4V	2010 - 2012	HUD	●	●	●
Taurus	3.5L	4V	2010 - 2012	ILCM	●	●	●
Taurus	3.5L	4V	2010 - 2012	IPC	●	●	●
Taurus	3.5L	4V	2010 - 2012	PSCM	●	●	●
Taurus	3.5L	4V	2010 - 2012	RFA	●	●	●
Taurus	3.5L	4V	2010 - 2012	SASM	●	●	●
Taurus	3.5L	4V	2010 - 2012	SOD-L	●	●	●
Taurus	3.5L	4V	2010 - 2012	SOD-R	●	●	●
Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2012	4X4	●	●	●
Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2012	FDIM	●	●	●
Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2012	GEM / SJB	●	●	●
Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2012	HCM-2	●	●	●
Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2012	ILCM	●	●	●
Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2012	RETM	●	●	●
Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2012	SASM	●	●	●
Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2013	ACM	●	●	●
Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2013	C-CM	●	●	●
Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2013	HCM	●	●	●
Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2013	IPC	●	●	●
Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2013	OCSM	●	●	●
Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2014	ABS	●	●	●
Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2014	APIM	●	●	●
Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2014	DCSM	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2014	DDM	●	●	●
Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2014	DSM	●	●	●
Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2014	DSP	●	●	●
Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2014	FCIM	●	●	●
Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2014	GPSM	●	●	●
Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2014	HUD	●	●	●
Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2014	HVAC	●	●	●
Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2014	PAM	●	●	●
Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2014	PCM	●	●	●
Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2014	PSCM	●	●	●
Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2014	RCM	●	●	●
Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2014	RFA	●	●	●
Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2014	SOD-L	●	●	●
Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2010 - 2014	SOD-R	●	●	●
Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	BCM#1	●	●	●
Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013	FCDIM	●	●	●
Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	GFM	●	●	●
Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	HSWM	●	●	●
Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	IPM-A	●	●	●
Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	RACM	●	●	●
Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	RTM	●	●	●
Taurus	3.5L	EcoBoost - Gas Turbocharged Direct Injection	2013 - 2014	SCCM	●	●	●
Taurus	3.5L	TiVCT	2013	ACM	●	●	●
Taurus	3.5L	TiVCT	2013	BCM#1	●	●	●
Taurus	3.5L	TiVCT	2013	C-CM	●	●	●
Taurus	3.5L	TiVCT	2013	FCDIM	●	●	●
Taurus	3.5L	TiVCT	2013	HCM	●	●	●
Taurus	3.5L	TiVCT	2013	IPC	●	●	●
Taurus	3.5L	TiVCT	2013	OCSM	●	●	●
Taurus	3.5L	TiVCT	2013 - 2014	ABS	●	●	●
Taurus	3.5L	TiVCT	2013 - 2014	APIM	●	●	●
Taurus	3.5L	TiVCT	2013 - 2014	DCSM	●	●	●
Taurus	3.5L	TiVCT	2013 - 2014	DDM	●	●	●
Taurus	3.5L	TiVCT	2013 - 2014	DSM	●	●	●
Taurus	3.5L	TiVCT	2013 - 2014	DSP	●	●	●
Taurus	3.5L	TiVCT	2013 - 2014	FCIM	●	●	●
Taurus	3.5L	TiVCT	2013 - 2014	GFM	●	●	●
Taurus	3.5L	TiVCT	2013 - 2014	GPSM	●	●	●
Taurus	3.5L	TiVCT	2013 - 2014	HSWM	●	●	●
Taurus	3.5L	TiVCT	2013 - 2014	HUD	●	●	●
Taurus	3.5L	TiVCT	2013 - 2014	HVAC	●	●	●
Taurus	3.5L	TiVCT	2013 - 2014	IPM-A	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Taurus	3.5L	TiVCT	2013 - 2014	PAM	●	●	●
Taurus	3.5L	TiVCT	2013 - 2014	PCM	●	●	●
Taurus	3.5L	TiVCT	2013 - 2014	PSCM	●	●	●
Taurus	3.5L	TiVCT	2013 - 2014	RACM	●	●	●
Taurus	3.5L	TiVCT	2013 - 2014	RCM	●	●	●
Taurus	3.5L	TiVCT	2013 - 2014	RFA	●	●	●
Taurus	3.5L	TiVCT	2013 - 2014	RTM	●	●	●
Taurus	3.5L	TiVCT	2013 - 2014	SCCM	●	●	●
Taurus	3.5L	TiVCT	2013 - 2014	SOD-L	●	●	●
Taurus	3.5L	TiVCT	2013 - 2014	SOD-R	●	●	●
Taurus	3.7L	TiVCT	2013	C-CM	●	●	●
Taurus	3.7L	TiVCT	2013 - 2014	ABS	●	●	●
Taurus	3.7L	TiVCT	2013 - 2014	APIM	●	●	●
Taurus	3.7L	TiVCT	2013 - 2014	DCSM	●	●	●
Taurus	3.7L	TiVCT	2013 - 2014	DDM	●	●	●
Taurus	3.7L	TiVCT	2013 - 2014	DSM	●	●	●
Taurus	3.7L	TiVCT	2013 - 2014	DSP	●	●	●
Taurus	3.7L	TiVCT	2013 - 2014	FCIM	●	●	●
Taurus	3.7L	TiVCT	2013 - 2014	GFM	●	●	●
Taurus	3.7L	TiVCT	2013 - 2014	HSWM	●	●	●
Taurus	3.7L	TiVCT	2013 - 2014	HUD	●	●	●
Taurus	3.7L	TiVCT	2013 - 2014	HVAC	●	●	●
Taurus	3.7L	TiVCT	2013 - 2014	PAM	●	●	●
Taurus	3.7L	TiVCT	2013 - 2014	PCM	●	●	●
Taurus	3.7L	TiVCT	2013 - 2014	PSCM	●	●	●
Taurus	3.7L	TiVCT	2013 - 2014	RACM	●	●	●
Taurus	3.7L	TiVCT	2013 - 2014	RFA	●	●	●
Taurus	3.7L	TiVCT	2013 - 2014	RTM	●	●	●
Taurus	3.7L	TiVCT	2013 - 2014	SOD-L	●	●	●
Taurus	3.7L	TiVCT	2013 - 2014	SOD-R	●	●	●
Taurus	3.7L	TiVCT	2014	GPSM	●	●	●
Taurus	3.7L	TiVCT	2014	IPM-A	●	●	●
Taurus	3.7L	TiVCT	2014	RCM	●	●	●
Taurus	3.7L	TiVCT	2014	SCCM	●	●	●
Taurus	Other	Other	2012	4X4	●	●	●
Taurus	Other	Other	2012	ABS	●	●	●
Taurus	Other	Other	2012	ACM	●	●	●
Taurus	Other	Other	2012	APIM	●	●	●
Taurus	Other	Other	2012	C-CM	●	●	●
Taurus	Other	Other	2012	DCSM	●	●	●
Taurus	Other	Other	2012	DDM	●	●	●
Taurus	Other	Other	2012	DSM	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Taurus	Other	Other	2012	DSP	●	●	●
Taurus	Other	Other	2012	FCIM	●	●	●
Taurus	Other	Other	2012	FDIM	●	●	●
Taurus	Other	Other	2012	GEM / SJB	●	●	●
Taurus	Other	Other	2012	GPSM	●	●	●
Taurus	Other	Other	2012	HCM	●	●	●
Taurus	Other	Other	2012	HCM-2	●	●	●
Taurus	Other	Other	2012	HUD	●	●	●
Taurus	Other	Other	2012	HVAC	●	●	●
Taurus	Other	Other	2012	ILCM	●	●	●
Taurus	Other	Other	2012	IPC	●	●	●
Taurus	Other	Other	2012	OCSM	●	●	●
Taurus	Other	Other	2012	PAM	●	●	●
Taurus	Other	Other	2012	PCM	●	●	●
Taurus	Other	Other	2012	PSCM	●	●	●
Taurus	Other	Other	2012	RCM	●	●	●
Taurus	Other	Other	2012	RETM	●	●	●
Taurus	Other	Other	2012	RFA	●	●	●
Taurus	Other	Other	2012	SASM	●	●	●
Taurus	Other	Other	2012	SOD-L	●	●	●
Taurus	Other	Other	2012	SOD-R	●	●	●
Taurus X	3.5L	4V	2008 - 2009	4X4	●	●	●
Taurus X	3.5L	4V	2008 - 2009	ABS	●	●	●
Taurus X	3.5L	4V	2008 - 2009	ACM	●	●	●
Taurus X	3.5L	4V	2008 - 2009	APIM	●	●	●
Taurus X	3.5L	4V	2008 - 2009	DSM	●	●	●
Taurus X	3.5L	4V	2008 - 2009	GEM / SJB	●	●	●
Taurus X	3.5L	4V	2008 - 2009	HVAC	●	●	●
Taurus X	3.5L	4V	2008 - 2009	IC	●	●	●
Taurus X	3.5L	4V	2008 - 2009	LTM	●	●	●
Taurus X	3.5L	4V	2008 - 2009	OCSM	●	●	●
Taurus X	3.5L	4V	2008 - 2009	PAM	●	●	●
Taurus X	3.5L	4V	2008 - 2009	PCM	●	●	●
Taurus X	3.5L	4V	2008 - 2009	RCM	●	●	●
Taurus X	3.5L	4V	2008 - 2009	RETM	●	●	●
Taurus X	3.5L	4V	2008 - 2009	SDARS	●	●	●
Taurus X	3.5L	4V	2008 - 2009	SECM	●	●	●
Telstar	1.8L	Other	Other	PCM	●	●	●
Telstar	2.0L	Other	Other	PCM	●	●	●
Telstar	2.5L	Other	Other	PCM	●	●	●
Thunderbird	3.8L	Other	1996 - 1997	PCM	●	●	●
Thunderbird	3.9L	4V	2002 - 2005	ABS/TCS	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Thunderbird	3.9L	4V	2002 - 2005	ACM	●	●	●
Thunderbird	3.9L	4V	2002 - 2005	DDM	●	●	●
Thunderbird	3.9L	4V	2002 - 2005	EATC	●	●	●
Thunderbird	3.9L	4V	2002 - 2005	GEM	●	●	●
Thunderbird	3.9L	4V	2002 - 2005	HEC	●	●	●
Thunderbird	3.9L	4V	2002 - 2005	PCM	●	●	●
Thunderbird	3.9L	4V	2002 - 2005	RCM	●	●	●
Thunderbird	3.9L	4V	2002 - 2005	REM	●	●	●
Thunderbird	4.6L	2V	1994 - 1997	PCM	●	●	●
Thunderbird	4.6L	Other	1996	PCM	●	●	●
Titan	4.0L	TF	2000 - 2002	PCM	●	●	●
Town Car	4.6L	2V	1995 - 2004	ABS/TCS	●	●	●
Town Car	4.6L	2V	1995 - 2007	EATC	●	●	●
Town Car	4.6L	2V	1995 - 2011	DDM	●	●	●
Town Car	4.6L	2V	1995 - 2011	DSM	●	●	●
Town Car	4.6L	2V	1995 - 2011	LCM	●	●	●
Town Car	4.6L	2V	1995 - 2011	PCM	●	●	●
Town Car	4.6L	2V	1996 - 1998	IAB	●	●	●
Town Car	4.6L	2V	1998 - 2003	CPM	●	●	●
Town Car	4.6L	2V	1998 - 2004	NGSC	●	●	●
Town Car	4.6L	2V	1998 - 2005	ACM	●	●	●
Town Car	4.6L	2V	1998 - 2005	HEC	●	●	●
Town Car	4.6L	2V	1998 - 2006	RASM	●	●	●
Town Car	4.6L	2V	1999 - 2011	RCM	●	●	●
Town Car	4.6L	2V	2002 - 2003	RESCU	●	●	●
Town Car	4.6L	2V	2003 - 2010	MC	●	●	●
Town Car	4.6L	2V	2003 - 2010	NAV	●	●	●
Town Car	4.6L	2V	2003 - 2011	LTM	●	●	●
Town Car	4.6L	2V	2003 - 2011	PAM	●	●	●
Town Car	4.6L	2V	2005 - 2011	ABS	●	●	●
Town Car	4.6L	2V	2006 - 2011	IC	●	●	●
Town Car	4.6L	2V	2006 - 2011	RATC	●	●	●
Town Car	4.6L	2V	2007 - 2011	VDM	●	●	●
Town Car	4.6L	2V	2008 - 2011	HVAC	●	●	●
Tracer	1.9L	1.4 PT-E SFI	1996	ABS/TCS	●	●	●
Tracer	1.9L	1.4 PT-E SFI	1996	PCM	●	●	●
Tracer	1.9L	1.4 PT-E SFI	1996	RAP	●	●	●
Tracer	2.0L	SPI	1997 - 1999	ABS/TCS	●	●	●
Tracer	2.0L	SPI	1997 - 1999	PCM	●	●	●
Tracer	2.0L	SPI	1997 - 1999	RAP	●	●	●
Tracer	2.0L	SPI	1998	ECS	●	●	●
Tracer	2.0L	SPI	1999	IAB	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Transit	2.2L	Duratorq Turbo Diesel Common Rail Injection	2014	APIM	●	●	●
Transit	2.2L	Duratorq Turbo Diesel Common Rail Injection	2014	AWD#1	●	●	●
Transit	2.2L	Duratorq Turbo Diesel Common Rail Injection	2014	CCMi i	●	●	●
Transit	2.2L	Duratorq Turbo Diesel Common Rail Injection	2014	FCIM	●	●	●
Transit	2.2L	Duratorq Turbo Diesel Common Rail Injection	2014	HCM	●	●	●
Transit	2.2L	Duratorq Turbo Diesel Common Rail Injection	2014	PAM	●	●	●
Transit	2.2L	Duratorq Turbo Diesel Common Rail Injection	2014	SASM	●	●	●
Transit	2.2L	Duratorq Turbo Diesel Common Rail Injection	2014	TRM	●	●	●
Transit	2.2L	Duratorq Turbo Diesel Common Rail Injection StgV	2014	APIM	●	●	●
Transit	2.2L	Duratorq Turbo Diesel Common Rail Injection StgV	2014	AWD#1	●	●	●
Transit	2.2L	Duratorq Turbo Diesel Common Rail Injection StgV	2014	CCMi i	●	●	●
Transit	2.2L	Duratorq Turbo Diesel Common Rail Injection StgV	2014	FCIM	●	●	●
Transit	2.2L	Duratorq Turbo Diesel Common Rail Injection StgV	2014	HCM	●	●	●
Transit	2.2L	Duratorq Turbo Diesel Common Rail Injection StgV	2014	PAM	●	●	●
Transit	2.2L	Duratorq Turbo Diesel Common Rail Injection StgV	2014	SASM	●	●	●
Transit	2.2L	Duratorq Turbo Diesel Common Rail Injection StgV	2014	TRM	●	●	●
Transit	2.2L	TDCi_StgVI	2014	APIM	●	●	●
Transit	2.2L	TDCi_StgVI	2014	AWD#1	●	●	●
Transit	2.2L	TDCi_StgVI	2014	CCMi i	●	●	●
Transit	2.2L	TDCi_StgVI	2014	FCIM	●	●	●
Transit	2.2L	TDCi_StgVI	2014	HCM	●	●	●
Transit	2.2L	TDCi_StgVI	2014	PAM	●	●	●
Transit	2.2L	TDCi_StgVI	2014	SASM	●	●	●
Transit	2.2L	TDCi_StgVI	2014	TRM	●	●	●
Transit	3.2L	Duratorq Turbo Diesel Common Rail Injection	2014	TCM	●	●	●
Transit Connect	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2014	AHCM	●	●	●
Transit Connect	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2014	APIM	●	●	●
Transit Connect	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2014	BCMi i	●	●	●
Transit Connect	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2014	DDM	●	●	●
Transit Connect	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2014	GPSM	●	●	●
Transit Connect	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2014	HCM	●	●	●
Transit Connect	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2014	HVAC	●	●	●
Transit Connect	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2014	PCM	●	●	●
Transit Connect	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2014	PDM	●	●	●
Transit Connect	1.0L	EcoBoost - Gas Turbocharged Direct Injection	2014	TRM	●	●	●
Transit Connect	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	2014	AHCM	●	●	●
Transit Connect	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	2014	APIM	●	●	●
Transit Connect	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	2014	BCMi i	●	●	●
Transit Connect	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	2014	DDM	●	●	●
Transit Connect	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	2014	GPSM	●	●	●
Transit Connect	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	2014	HCM	●	●	●
Transit Connect	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	2014	HVAC	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Transit Connect	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	2014	PCM	●	●	●
Transit Connect	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	2014	PDM	●	●	●
Transit Connect	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	2014	TRM	●	●	●
Transit Connect	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2014	AHCM	●	●	●
Transit Connect	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2014	APIM	●	●	●
Transit Connect	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2014	BCMii	●	●	●
Transit Connect	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2014	DDM	●	●	●
Transit Connect	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2014	GPSM	●	●	●
Transit Connect	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2014	HCM	●	●	●
Transit Connect	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2014	HVAC	●	●	●
Transit Connect	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2014	PDM	●	●	●
Transit Connect	1.6L	EcoBoost - Gas Turbocharged Direct Injection	2014	TRM	●	●	●
Transit Connect	1.6L	TDCi ECO III	2014	AHCM	●	●	●
Transit Connect	1.6L	TDCi ECO III	2014	APIM	●	●	●
Transit Connect	1.6L	TDCi ECO III	2014	BCMii	●	●	●
Transit Connect	1.6L	TDCi ECO III	2014	DDM	●	●	●
Transit Connect	1.6L	TDCi ECO III	2014	GPSM	●	●	●
Transit Connect	1.6L	TDCi ECO III	2014	HCM	●	●	●
Transit Connect	1.6L	TDCi ECO III	2014	HVAC	●	●	●
Transit Connect	1.6L	TDCi ECO III	2014	PCM	●	●	●
Transit Connect	1.6L	TDCi ECO III	2014	PDM	●	●	●
Transit Connect	1.6L	TDCi ECO III	2014	TRM	●	●	●
Transit Connect	2.0L	2.0 DOHC SFI (8V)	1995 - 1997	PATS	●	●	●
Transit Connect	2.0L	2.0 DOHC SFI (8V)	1995 - 1999	ABS	●	●	●
Transit Connect	2.0L	2.0 DOHC SFI (8V)	1995 - 1999	ABS/TCS	●	●	●
Transit Connect	2.0L	2.0 DOHC SFI (8V)	1995 - 1999	CSM	●	●	●
Transit Connect	2.0L	2.0 DOHC SFI (8V)	1995 - 1999	PCM	●	●	●
Transit Connect	2.0L	2.0 DOHC SFI (8V)	1999	AFCM	●	●	●
Transit Connect	2.0L	DURATEC-HE / I4	2010 - 2012	ABS	●	●	●
Transit Connect	2.0L	DURATEC-HE / I4	2010 - 2012	ACM	●	●	●
Transit Connect	2.0L	DURATEC-HE / I4	2010 - 2012	GEM / SJB	●	●	●
Transit Connect	2.0L	DURATEC-HE / I4	2010 - 2012	IC	●	●	●
Transit Connect	2.0L	DURATEC-HE / I4	2010 - 2012	OCSM	●	●	●
Transit Connect	2.0L	DURATEC-HE / I4	2010 - 2012	PAM	●	●	●
Transit Connect	2.0L	DURATEC-HE / I4	2010 - 2012	PCM	●	●	●
Transit Connect	2.0L	DURATEC-HE / I4	2010 - 2012	RCM	●	●	●
Transit Connect	2.0L	DURATEC-HE / I4	2010 - 2012	SRM	●	●	●
Transit Connect	2.0L	DURATEC-HE / I4	2010 - 2012	VSM	●	●	●
Transit Connect	2.0L	DURATEC-HE / I4	2012	APIM	●	●	●
Transit Connect	2.0L	DURATORQ_DI	2001	ABS/TCS	●	●	●
Transit Connect	2.0L	DURATORQ_DI	2001	CSM	●	●	●
Transit Connect	2.0L	DURATORQ_DI	2001	EPB	●	●	●



Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Transit Connect	2.0L	DURATORQ_DI	2001	FFH	●	●	●
Transit Connect	2.0L	DURATORQ_DI	2001	FIP	●	●	●
Transit Connect	2.0L	DURATORQ_DI	2001	HEC	●	●	●
Transit Connect	2.0L	DURATORQ_DI	2001	PAM	●	●	●
Transit Connect	2.0L	DURATORQ_DI	2001	PATS	●	●	●
Transit Connect	2.0L	DURATORQ_DI	2001	PCM	●	●	●
Transit Connect	2.0L	DURATORQ_DI	2001	RASM	●	●	●
Transit Connect	2.0L	DURATORQ_DI	2001	RCM	●	●	●
Transit Connect	2.0L	DURATORQ_DI	2001	TCM	●	●	●
Transit Connect	2.0L	Duratorq Turbo Diesel Common Rail Injection	2001	ABS/TCS	●	●	●
Transit Connect	2.0L	Duratorq Turbo Diesel Common Rail Injection	2001	CSM	●	●	●
Transit Connect	2.0L	Duratorq Turbo Diesel Common Rail Injection	2001	FFH	●	●	●
Transit Connect	2.0L	Duratorq Turbo Diesel Common Rail Injection	2001	FIP	●	●	●
Transit Connect	2.0L	Duratorq Turbo Diesel Common Rail Injection	2001	HEC	●	●	●
Transit Connect	2.0L	Duratorq Turbo Diesel Common Rail Injection	2001	ICU	○	○	●
Transit Connect	2.0L	Duratorq Turbo Diesel Common Rail Injection	2001	PAM	●	●	●
Transit Connect	2.0L	Duratorq Turbo Diesel Common Rail Injection	2001	PCM	●	●	●
Transit Connect	2.0L	Duratorq Turbo Diesel Common Rail Injection	2001	RASM	●	●	●
Transit Connect	2.0L	Duratorq Turbo Diesel Common Rail Injection	2001	RCM	●	●	●
Transit Connect	2.0L	Duratorq Turbo Diesel Common Rail Injection	2001	TCM	●	●	●
Transit Connect	2.2L	Duratorq Turbo Diesel Common Rail Injection	2006	ABS	●	●	●
Transit Connect	2.2L	Duratorq Turbo Diesel Common Rail Injection	2006	ABS/TCS	●	●	●
Transit Connect	2.2L	Duratorq Turbo Diesel Common Rail Injection	2006	ACM	●	●	●
Transit Connect	2.2L	Duratorq Turbo Diesel Common Rail Injection	2006	BCMii	●	●	●
Transit Connect	2.2L	Duratorq Turbo Diesel Common Rail Injection	2006	CSM	●	●	●
Transit Connect	2.2L	Duratorq Turbo Diesel Common Rail Injection	2006	FFH	●	●	●
Transit Connect	2.2L	Duratorq Turbo Diesel Common Rail Injection	2006	IPC	●	●	●
Transit Connect	2.2L	Duratorq Turbo Diesel Common Rail Injection	2006	PAM	●	●	●
Transit Connect	2.2L	Duratorq Turbo Diesel Common Rail Injection	2006	PCM	●	●	●
Transit Connect	2.2L	Duratorq Turbo Diesel Common Rail Injection	2006	RCM	●	●	●
Transit Connect	2.2L	Duratorq Turbo Diesel Common Rail Injection	2006	SRM	●	●	●
Transit Connect	2.2L	Duratorq Turbo Diesel Common Rail Inj Stage V	2006	ABS	●	●	●
Transit Connect	2.2L	Duratorq Turbo Diesel Common Rail Inj Stage V	2006	ABS/TCS	●	●	●
Transit Connect	2.2L	Duratorq Turbo Diesel Common Rail Inj Stage V	2006	ACM	●	●	●
Transit Connect	2.2L	Duratorq Turbo Diesel Common Rail Inj Stage V	2006	BCMii	●	●	●
Transit Connect	2.2L	Duratorq Turbo Diesel Common Rail Inj Stage V	2006	CSM	●	●	●
Transit Connect	2.2L	Duratorq Turbo Diesel Common Rail Inj Stage V	2006	FFH	●	●	●
Transit Connect	2.2L	Duratorq Turbo Diesel Common Rail Inj Stage V	2006	IPC	●	●	●
Transit Connect	2.2L	Duratorq Turbo Diesel Common Rail Inj Stage V	2006	PAM	●	●	●
Transit Connect	2.2L	Duratorq Turbo Diesel Common Rail Inj Stage V	2006	PCM	●	●	●
Transit Connect	2.2L	Duratorq Turbo Diesel Common Rail Inj Stage V	2006	RCM	●	●	●
Transit Connect	2.2L	Duratorq Turbo Diesel Common Rail Inj Stage V	2006	SRM	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Transit Connect	2.2L	Duratorq_Turbo_Diesel_Common_Rail_Injection	2006	ABS	●	●	●
Transit Connect	2.2L	Duratorq_Turbo_Diesel_Common_Rail_Injection	2006	ABS/TCS	●	●	●
Transit Connect	2.2L	Duratorq_Turbo_Diesel_Common_Rail_Injection	2006	ACM	●	●	●
Transit Connect	2.2L	Duratorq_Turbo_Diesel_Common_Rail_Injection	2006	BCMii	●	●	●
Transit Connect	2.2L	Duratorq_Turbo_Diesel_Common_Rail_Injection	2006	CSM	●	●	●
Transit Connect	2.2L	Duratorq_Turbo_Diesel_Common_Rail_Injection	2006	FFH	●	●	●
Transit Connect	2.2L	Duratorq_Turbo_Diesel_Common_Rail_Injection	2006	IPC	●	●	●
Transit Connect	2.2L	Duratorq_Turbo_Diesel_Common_Rail_Injection	2006	PAM	●	●	●
Transit Connect	2.2L	Duratorq_Turbo_Diesel_Common_Rail_Injection	2006	PCM	●	●	●
Transit Connect	2.2L	Duratorq_Turbo_Diesel_Common_Rail_Injection	2006	RCM	●	●	●
Transit Connect	2.2L	Duratorq_Turbo_Diesel_Common_Rail_Injection	2006	SRM	●	●	●
Transit Connect	2.3L	DOHC SFI (16V)	2001	ABS/TCS	●	●	●
Transit Connect	2.3L	DOHC SFI (16V)	2001	CSM	●	●	●
Transit Connect	2.3L	DOHC SFI (16V)	2001	HEC	●	●	●
Transit Connect	2.3L	DOHC SFI (16V)	2001	PAM	●	●	●
Transit Connect	2.3L	DOHC SFI (16V)	2001	PATS	●	●	●
Transit Connect	2.3L	DOHC SFI (16V)	2001	PCM	●	●	●
Transit Connect	2.3L	DOHC SFI (16V)	2001	RASM	●	●	●
Transit Connect	2.3L	DOHC SFI (16V)	2001	RCM	●	●	●
Transit Connect	2.3L	DURATEC-HE / I4	2006	ABS	●	●	●
Transit Connect	2.3L	DURATEC-HE / I4	2006	ABS/TCS	●	●	●
Transit Connect	2.3L	DURATEC-HE / I4	2006	ACM	●	●	●
Transit Connect	2.3L	DURATEC-HE / I4	2006	BCMii	●	●	●
Transit Connect	2.3L	DURATEC-HE / I4	2006	CSM	●	●	●
Transit Connect	2.3L	DURATEC-HE / I4	2006	FFH	●	●	●
Transit Connect	2.3L	DURATEC-HE / I4	2006	IPC	●	●	●
Transit Connect	2.3L	DURATEC-HE / I4	2006	PAM	●	●	●
Transit Connect	2.3L	DURATEC-HE / I4	2006	PCM	●	●	●
Transit Connect	2.3L	DURATEC-HE / I4	2006	RCM	●	●	●
Transit Connect	2.3L	DURATEC-HE / I4	2006	SRM	●	●	●
Transit Connect	2.4L	DURATORQ_DI	2000	ABS/TCS	●	●	●
Transit Connect	2.4L	DURATORQ_DI	2000	CSM	●	●	●
Transit Connect	2.4L	DURATORQ_DI	2000	EPB	●	●	●
Transit Connect	2.4L	DURATORQ_DI	2000	FFH	●	●	●
Transit Connect	2.4L	DURATORQ_DI	2000	FIP	●	●	●
Transit Connect	2.4L	DURATORQ_DI	2000	HEC	●	●	●
Transit Connect	2.4L	DURATORQ_DI	2000	PAM	●	●	●
Transit Connect	2.4L	DURATORQ_DI	2000	PATS	●	●	●
Transit Connect	2.4L	DURATORQ_DI	2000	PCM	●	●	●
Transit Connect	2.4L	DURATORQ_DI	2000	RASM	●	●	●
Transit Connect	2.4L	DURATORQ_DI	2000	RCM	●	●	●
Transit Connect	2.4L	DURATORQ_DI	2000	TCM	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Transit Connect	2.4L	Duratorq Turbo Diesel Common Rail Injection	2000	HEC	●	●	●
Transit Connect	2.4L	Duratorq Turbo Diesel Common Rail Injection	2000	ICU	○	○	●
Transit Connect	2.4L	Duratorq Turbo Diesel Common Rail Injection	2000 - 2006	ABS/TCS	●	●	●
Transit Connect	2.4L	Duratorq Turbo Diesel Common Rail Injection	2000 - 2006	CSM	●	●	●
Transit Connect	2.4L	Duratorq Turbo Diesel Common Rail Injection	2000 - 2006	FFH	●	●	●
Transit Connect	2.4L	Duratorq Turbo Diesel Common Rail Injection	2000 - 2006	PAM	●	●	●
Transit Connect	2.4L	Duratorq Turbo Diesel Common Rail Injection	2000 - 2006	PCM	●	●	●
Transit Connect	2.4L	Duratorq Turbo Diesel Common Rail Injection	2000 - 2006	RCM	●	●	●
Transit Connect	2.4L	Duratorq Turbo Diesel Common Rail Injection	2006	ABS	●	●	●
Transit Connect	2.4L	Duratorq Turbo Diesel Common Rail Injection	2006	ACM	●	●	●
Transit Connect	2.4L	Duratorq Turbo Diesel Common Rail Injection	2006	BCMii	●	●	●
Transit Connect	2.4L	Duratorq Turbo Diesel Common Rail Injection	2006	IPC	●	●	●
Transit Connect	2.4L	Duratorq Turbo Diesel Common Rail Injection	2006	SRM	●	●	●
Transit Connect	2.4L	Duratorq Turbo Diesel Common Rail Injection	2006	TBM	●	●	●
Transit Connect	2.5L	2.5 turbo diesel engines with EPIC	Other	ABS	●	●	●
Transit Connect	2.5L	2.5 turbo diesel engines with EPIC	Other	ABS/TCS	●	●	●
Transit Connect	2.5L	2.5 turbo diesel engines with EPIC	Other	CSM	●	●	●
Transit Connect	2.5L	2.5 turbo diesel engines with EPIC	Other	PCM	●	●	●
Transit Connect	2.5L	IVCT	2014	DDM	●	●	●
Transit Connect	2.5L	IVCT	2014	FCIM	●	●	●
Transit Connect	2.5L	IVCT	2014	GPSM	●	●	●
Transit Connect	2.5L	IVCT	2014	HCM	●	●	●
Transit Connect	2.5L	IVCT	2014	HVAC	●	●	●
Transit Connect	2.5L	IVCT	2014	OCSM	●	●	●
Transit Connect	2.5L	IVCT	2014	PAM	●	●	○
Transit Connect	2.5L	IVCT	2014	PCM	●	●	●
Transit Connect	2.5L	IVCT	2014	PDM	●	●	●
Transit Connect	2.5L	IVCT	2014	PSCM	●	●	●
Transit Connect	2.5L	IVCT	2014	TRM	●	●	●
Transit Connect	28kWh	Battery_Electric_Vehicle	2011	SRM	●	●	●
Transit Connect	28kWh	Battery_Electric_Vehicle	2011 - 2013	ABS	●	●	●
Transit Connect	28kWh	Battery_Electric_Vehicle	2011 - 2013	ACCM#2	●	●	●
Transit Connect	28kWh	Battery_Electric_Vehicle	2011 - 2013	ACM	●	●	●
Transit Connect	28kWh	Battery_Electric_Vehicle	2011 - 2013	GEM / SJB	●	●	●
Transit Connect	28kWh	Battery_Electric_Vehicle	2011 - 2013	IC	●	●	●
Transit Connect	28kWh	Battery_Electric_Vehicle	2011 - 2013	OCSM	●	●	●
Transit Connect	28kWh	Battery_Electric_Vehicle	2011 - 2013	PAM	●	●	●
Transit Connect	28kWh	Battery_Electric_Vehicle	2011 - 2013	PSCM	●	●	●
Transit Connect	28kWh	Battery_Electric_Vehicle	2011 - 2013	RCM	●	●	●
Transit Connect	28kWh	Battery_Electric_Vehicle	2011 - 2013	VSM	●	●	●
Transit Connect	28kWh	Battery_Electric_Vehicle	2013	APIM	●	●	●
Transit Connect	3.2L	Duratorq Turbo Diesel Common Rail Injection	2006	ABS	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Transit Connect	3.2L	Duratorq Turbo Diesel Common Rail Injection	2006	ABS/TCS	●	●	●
Transit Connect	3.2L	Duratorq Turbo Diesel Common Rail Injection	2006	ACM	●	●	●
Transit Connect	3.2L	Duratorq Turbo Diesel Common Rail Injection	2006	BCMii	●	●	●
Transit Connect	3.2L	Duratorq Turbo Diesel Common Rail Injection	2006	CSM	●	●	●
Transit Connect	3.2L	Duratorq Turbo Diesel Common Rail Injection	2006	FFH	●	●	●
Transit Connect	3.2L	Duratorq Turbo Diesel Common Rail Injection	2006	IPC	●	●	●
Transit Connect	3.2L	Duratorq Turbo Diesel Common Rail Injection	2006	PAM	●	●	●
Transit Connect	3.2L	Duratorq Turbo Diesel Common Rail Injection	2006	PCM	●	●	●
Transit Connect	3.2L	Duratorq Turbo Diesel Common Rail Injection	2006	RCM	●	●	●
Transit Connect	3.2L	Duratorq Turbo Diesel Common Rail Injection	2006	SRM	●	●	●
Transit Connect	3.2L	Duratorq Turbo Diesel Common Rail Injection	2006	ABS	●	●	●
Transit Connect	3.2L	Duratorq Turbo Diesel Common Rail Injection	2006	ABS/TCS	●	●	●
Transit Connect	3.2L	Duratorq Turbo Diesel Common Rail Injection	2006	ACM	●	●	●
Transit Connect	3.2L	Duratorq Turbo Diesel Common Rail Injection	2006	BCMii	●	●	●
Transit Connect	3.2L	Duratorq Turbo Diesel Common Rail Injection	2006	CSM	●	●	●
Transit Connect	3.2L	Duratorq Turbo Diesel Common Rail Injection	2006	FFH	●	●	●
Transit Connect	3.2L	Duratorq Turbo Diesel Common Rail Injection	2006	IPC	●	●	●
Transit Connect	3.2L	Duratorq Turbo Diesel Common Rail Injection	2006	PAM	●	●	●
Transit Connect	3.2L	Duratorq Turbo Diesel Common Rail Injection	2006	PCM	●	●	●
Transit Connect	3.2L	Duratorq Turbo Diesel Common Rail Injection	2006	RCM	●	●	●
Transit Connect	3.2L	Duratorq Turbo Diesel Common Rail Injection	2006	SRM	●	●	●
Transit Connect	Other	Other	2013	ABS	●	●	●
Transit Connect	Other	Other	2013	ACM	●	●	●
Transit Connect	Other	Other	2013	APIM	●	●	●
Transit Connect	Other	Other	2013	GEM / SJB	●	●	●
Transit Connect	Other	Other	2013	IC	●	●	●
Transit Connect	Other	Other	2013	OCSM	●	●	●
Transit Connect	Other	Other	2013	PAM	●	●	●
Transit Connect	Other	Other	2013	RCM	●	●	●
Transit Connect	Other	Other	2013	VSM	●	●	●
Transit Connect / Tourneo Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002	HEC	●	●	●
Transit Connect / Tourneo Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002	ICU	○	○	●
Transit Connect / Tourneo Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2007	ABS/TCS	●	●	●
Transit Connect / Tourneo Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2007	CSM	●	●	●
Transit Connect / Tourneo Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2007	ECS	●	●	●
Transit Connect / Tourneo Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2009	FFH	●	●	●
Transit Connect / Tourneo Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2009	PAM	●	●	●
Transit Connect / Tourneo Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002 - 2009	PCM	●	●	●
Transit Connect / Tourneo Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	2007 - 2009	ABS	●	●	●
Transit Connect / Tourneo Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	2007 - 2009	ACM	●	●	●
Transit Connect / Tourneo Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	2007 - 2009	IC	●	●	●
Transit Connect / Tourneo Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	2007 - 2009	SRM	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Transit Connect / Tourneo Connect	1. 8L	Duratorq Turbo Diesel Common Rail Injection	2009	GEM	●	●	●
Transit Connect / Tourneo Connect	1. 8L	Duratorq Turbo Diesel Common Rail Injection	2009	RCM	●	●	●
Transit Connect / Tourneo Connect	1. 8L	Endura DI	2002	ABS/TCS	●	●	●
Transit Connect / Tourneo Connect	1. 8L	Endura DI	2002	CSM	●	●	●
Transit Connect / Tourneo Connect	1. 8L	Endura DI	2002	ECS	●	●	●
Transit Connect / Tourneo Connect	1. 8L	Endura DI	2002	FFH	●	●	●
Transit Connect / Tourneo Connect	1. 8L	Endura DI	2002	FIP	●	●	●
Transit Connect / Tourneo Connect	1. 8L	Endura DI	2002	HEC	●	●	●
Transit Connect / Tourneo Connect	1. 8L	Endura DI	2002	PAM	●	●	●
Transit Connect / Tourneo Connect	1. 8L	Endura DI	2002	PCM	●	●	●
Transit Connect / Tourneo Connect	1. 8L	Zetec	2002	ABS/TCS	●	●	●
Transit Connect / Tourneo Connect	1. 8L	Zetec	2002	AFCM	●	●	●
Transit Connect / Tourneo Connect	1. 8L	Zetec	2002	CSM	●	●	●
Transit Connect / Tourneo Connect	1. 8L	Zetec	2002	ECS	●	●	●
Transit Connect / Tourneo Connect	1. 8L	Zetec	2002	FFH	●	●	●
Transit Connect / Tourneo Connect	1. 8L	Zetec	2002	HEC	●	●	●
Transit Connect / Tourneo Connect	1. 8L	Zetec	2002	PAM	●	●	●
Transit Connect / Tourneo Connect	1. 8L	Zetec	2002	PCM	●	●	●
V362	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2012	ABS	●	●	●
V362	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2012	ACM	●	●	●
V362	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2012	AHCM	●	●	●
V362	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2012	APIM	●	●	●
V362	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2012	BCMii	●	●	●
V362	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2012	CCMii	●	●	●
V362	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2012	FCDIM	●	●	●
V362	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2012	GPSM	●	●	●
V362	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2012	HCM	●	●	●
V362	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2012	HVAC	●	●	●
V362	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2012	IPC	●	●	●
V362	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2012	IPM-A	●	●	●
V362	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2012	IPM-B	●	●	●
V362	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2012	PAM	●	●	●
V362	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2012	PCM	●	●	●
V362	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2012	RCM	●	●	●
V362	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2012	SASM	●	●	●
V362	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2012	TBC	●	●	●
VX-1	1. 4L	K14B	Other	ABS	●	●	●
VX-1	1. 4L	K14B	Other	BCM#1	●	●	●
Villager	3. 3L	Other	2001 - 2002	PCM	●	●	●
Windstar	3. 0L	V6 OHV	1995 - 1998	GEM	●	●	●
Windstar	3. 0L	V6 OHV	1995 - 1999	ABS/TCS	●	●	●
Windstar	3. 0L	V6 OHV	1995 - 1999	PCM	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Windstar	3.0L	V6 OHV	1996 - 1998	IAB	●	●	●
Windstar	3.0L	V6 OHV	1996 - 1998	PATS	●	●	●
Windstar	3.0L	V6 OHV	1998	RAP	●	●	●
Windstar	3.0L	V6 OHV	1999	DDM	●	●	●
Windstar	3.0L	V6 OHV	1999	FEM	●	●	●
Windstar	3.0L	V6 OHV	1999	IC	●	●	●
Windstar	3.0L	V6 OHV	1999	MC	●	●	●
Windstar	3.0L	V6 OHV	1999	NGSC	●	●	●
Windstar	3.0L	V6 OHV	1999	PAM	●	●	●
Windstar	3.0L	V6 OHV	1999	RCM	●	●	●
Windstar	3.0L	V6 OHV	1999	REM	●	●	●
Windstar	3.8L	V6 OHV	1995 - 1998	GEM	●	●	●
Windstar	3.8L	V6 OHV	1995 - 2003	ABS/TCS	●	●	●
Windstar	3.8L	V6 OHV	1995 - 2003	PCM	●	●	●
Windstar	3.8L	V6 OHV	1996 - 1998	IAB	●	●	●
Windstar	3.8L	V6 OHV	1996 - 1998	PATS	●	●	●
Windstar	3.8L	V6 OHV	1998	RAP	●	●	●
Windstar	3.8L	V6 OHV	1999 - 2003	DDM	●	●	●
Windstar	3.8L	V6 OHV	1999 - 2003	FEM	●	●	●
Windstar	3.8L	V6 OHV	1999 - 2003	IC	●	●	●
Windstar	3.8L	V6 OHV	1999 - 2003	LPSDM	●	●	●
Windstar	3.8L	V6 OHV	1999 - 2003	MC	●	●	●
Windstar	3.8L	V6 OHV	1999 - 2003	NGSC	●	●	●
Windstar	3.8L	V6 OHV	1999 - 2003	PAM	●	●	●
Windstar	3.8L	V6 OHV	1999 - 2003	RCM	●	●	●
Windstar	3.8L	V6 OHV	1999 - 2003	REM	●	●	●
Windstar	3.8L	V6 OHV	1999 - 2003	RPSDM	●	●	●
Windstar	3.8L	V6 OHV	2000 - 2003	DSM	●	●	●
Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	2011 - 2012	4X4	●	●	●
Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	2011 - 2012	ABS	●	●	●
Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	2011 - 2012	ACCM#2	●	●	●
Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	2011 - 2012	ACM	●	●	●
Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	2011 - 2012	APIM	●	●	●
Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	2011 - 2012	BECM	●	●	●
Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	2011 - 2012	DCDC	●	●	●
Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	2011 - 2012	DCSM	●	●	●
Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	2011 - 2012	DDM	●	●	●
Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	2011 - 2012	DSM	●	●	●
Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	2011 - 2012	DSP	●	●	●
Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	2011 - 2012	FCIM	●	●	●
Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	2011 - 2012	FDIM	●	●	●
Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	2011 - 2012	GEM / SJB	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	2011 - 2012	GPSM	●	●	●
Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	2011 - 2012	HCM	●	●	●
Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	2011 - 2012	HVAC	●	●	●
Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	2011 - 2012	ILCM	●	●	●
Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	2011 - 2012	IPC	●	●	●
Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	2011 - 2012	OCSM	●	●	●
Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	2011 - 2012	PAM	●	●	●
Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	2011 - 2012	PCM	●	●	●
Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	2011 - 2012	PSCM	●	●	●
Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	2011 - 2012	RCM	●	●	●
Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	2011 - 2012	SOD-L	●	●	●
Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	2011 - 2012	SOD-R	●	●	●
Zephyr/MKZ	2.5L	HEV / ATKINSON 4V	2011 - 2012	TCM	●	●	●
Zephyr/MKZ	3.0L	4V	2006	ABS	●	●	●
Zephyr/MKZ	3.0L	4V	2006	ACM	●	●	●
Zephyr/MKZ	3.0L	4V	2006	DCSM	●	●	●
Zephyr/MKZ	3.0L	4V	2006	DDM	●	●	●
Zephyr/MKZ	3.0L	4V	2006	DSM	●	●	●
Zephyr/MKZ	3.0L	4V	2006	DSP	●	●	●
Zephyr/MKZ	3.0L	4V	2006	EATC	●	●	●
Zephyr/MKZ	3.0L	4V	2006	GEM	●	●	●
Zephyr/MKZ	3.0L	4V	2006	IC	●	●	●
Zephyr/MKZ	3.0L	4V	2006	OCSM	●	●	●
Zephyr/MKZ	3.0L	4V	2006	PCM	●	●	●
Zephyr/MKZ	3.0L	4V	2006	RCM	●	●	●
Zephyr/MKZ	3.0L	4V	2006	TCM	●	●	●
Zephyr/MKZ	3.5L	4V	2007	EATC	●	●	●
Zephyr/MKZ	3.5L	4V	2007	GEM	●	●	●
Zephyr/MKZ	3.5L	4V	2007 - 2009	IC	●	●	●
Zephyr/MKZ	3.5L	4V	2007 - 2009	SDARS	●	●	●
Zephyr/MKZ	3.5L	4V	2007 - 2012	4X4	●	●	●
Zephyr/MKZ	3.5L	4V	2007 - 2012	ABS	●	●	●
Zephyr/MKZ	3.5L	4V	2007 - 2012	ACM	●	●	●
Zephyr/MKZ	3.5L	4V	2007 - 2012	DCSM	●	●	●
Zephyr/MKZ	3.5L	4V	2007 - 2012	DDM	●	●	●
Zephyr/MKZ	3.5L	4V	2007 - 2012	DSM	●	●	●
Zephyr/MKZ	3.5L	4V	2007 - 2012	DSP	●	●	●
Zephyr/MKZ	3.5L	4V	2007 - 2012	OCSM	●	●	●
Zephyr/MKZ	3.5L	4V	2007 - 2012	PCM	●	●	●
Zephyr/MKZ	3.5L	4V	2007 - 2012	RCM	●	●	●
Zephyr/MKZ	3.5L	4V	2007 - 2012	TCM	●	●	●
Zephyr/MKZ	3.5L	4V	2008 - 2012	APIM	●	●	●

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data
Zephyr/MKZ	3.5L	4V	2008 - 2012	GEM / SJB	●	●	●
Zephyr/MKZ	3.5L	4V	2008 - 2012	HVAC	●	●	●
Zephyr/MKZ	3.5L	4V	2008 - 2012	PAM	●	●	●
Zephyr/MKZ	3.5L	4V	2010 - 2012	FCIM	●	●	●
Zephyr/MKZ	3.5L	4V	2010 - 2012	FDIM	●	●	●
Zephyr/MKZ	3.5L	4V	2010 - 2012	GPSM	●	●	●
Zephyr/MKZ	3.5L	4V	2010 - 2012	HCM	●	●	●
Zephyr/MKZ	3.5L	4V	2010 - 2012	IILCM	●	●	●
Zephyr/MKZ	3.5L	4V	2010 - 2012	IPC	●	●	●
Zephyr/MKZ	3.5L	4V	2010 - 2012	SOD-L	●	●	●
Zephyr/MKZ	3.5L	4V	2010 - 2012	SOD-R	●	●	●
Zephyr/MKZ	Other	Other	2012	4X4	●	●	●
Zephyr/MKZ	Other	Other	2012	ABS	●	●	●
Zephyr/MKZ	Other	Other	2012	ACM	●	●	●
Zephyr/MKZ	Other	Other	2012	APIM	●	●	●
Zephyr/MKZ	Other	Other	2012	DCSM	●	●	●
Zephyr/MKZ	Other	Other	2012	DDM	●	●	●
Zephyr/MKZ	Other	Other	2012	DSM	●	●	●
Zephyr/MKZ	Other	Other	2012	DSP	●	●	●
Zephyr/MKZ	Other	Other	2012	FCIM	●	●	●
Zephyr/MKZ	Other	Other	2012	FDIM	●	●	●
Zephyr/MKZ	Other	Other	2012	GEM / SJB	●	●	●
Zephyr/MKZ	Other	Other	2012	GPSM	●	●	●
Zephyr/MKZ	Other	Other	2012	HCM	●	●	●
Zephyr/MKZ	Other	Other	2012	HVAC	●	●	●
Zephyr/MKZ	Other	Other	2012	IILCM	●	●	●
Zephyr/MKZ	Other	Other	2012	IPC	●	●	●
Zephyr/MKZ	Other	Other	2012	OCSM	●	●	●
Zephyr/MKZ	Other	Other	2012	PAM	●	●	●
Zephyr/MKZ	Other	Other	2012	RCM	●	●	●
Zephyr/MKZ	Other	Other	2012	SOD-L	●	●	●
Zephyr/MKZ	Other	Other	2012	SOD-R	●	●	●