

MaxiDiag_GM_V6. 02 Function List (Note:For reference only)

NOTES:

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.
- ▲ This function is the new feature in this version.

Year	Menu1	Menu2	Menu3	Menu4			ive ECU ata Info.
(D) 2013	Passenger Car	Holden	Others	Malibu	•	•	• •
(D) 2013	Passenger Car	Daewoo	Alpheon	Powertrain	•	•	• •
(D) 2013	Passenger Car	Daewoo	Alpheon	Chassis	•	•	• •
(D) 2013	Passenger Car	Daewoo	Alpheon	Body	•	•	• •
(D) 2013	Passenger Car	Chevrolet	Z	Malibu	•	•	• •
(D) 2013	Passenger Car	Chevrolet	Y	Powertrain	•	•	• •
(D) 2013	Passenger Car	Chevrolet	Y	Chassis	•	•	• •
(D) 2013	Passenger Car	Chevrolet	Y	Body	•	•	• •
(D) 2013	Passenger Car	Chevrolet	W	Powertrain	•	•	• •
(D) 2013	Passenger Car	Chevrolet	W	Chassis	•	•	• •
	Passenger Car	Chevrolet	T	Other Mode	•	•	• •
	Passenger Car	Chevrolet	T	Aveo	•	•	• •
(D) 2013	Passenger Car	Chevrolet	S	Powertrain	•	•	• •
(D) 2013	Passenger Car	Chevrolet	S	Chassis	•	•	• •
(D) 2013	Passenger Car	Chevrolet	S	Body	•	•	• •
(D) 2013	Passenger Car	Chevrolet	Others	S10	•	•	• •
(D) 2013	Passenger Car	Chevrolet	M	Powertrain	•	•	• •
(D) 2013	Passenger Car	Chevrolet	M	Chassis	•	•	• •
	Passenger Car	Chevrolet	M	Body	•	•	• •
(D) 2013	Passenger Car	Chevrolet	J	Cobalt	•	•	• •
(D) 2013	Passenger Car	Chevrolet	F	Powertrain	•	•	• •
(D) 2013	Passenger Car	Chevrolet	F	Chassis	•	•	• •
(D) 2013	Passenger Car	Chevrolet	F	Body	•	•	• •
(D) 2013	Passenger Car	Cadillac	D	CTS	•	•	• •
	Passenger Car	Cadillac	A	ATS	•	•	• •
(D) 2013	Passenger Car	Cadillac	1	XTS	•	•	• •
(D) 2013	Passenger Car	Buick	Р	Verano	•	•	• •
	Passenger Car	Buick	G	Regal	•	•	• •
	Passenger Car	Buick	G	Lacrosse	•	•	• •
	LD Trk, MPV, Incomplete		Others	Captiva 5	•	•	• •
	LD Trk, MPV, Incomplete	GMC Truck	L	Terrain	•	•	• •
	LD Trk, MPV, Incomplete	GMC Truck	8	Express/Savana	•	•	• •
	LD Trk, MPV, Incomplete	GMC Truck	8	Express Access/Savana Pro	•	•	• •
	LD Trk, MPV, Incomplete	GMC Truck	7	Express/Savana	•	•	• •
	LD Trk, MPV, Incomplete		7	Express Access/Savana Pro	•	•	• •
	LD Trk, MPV, Incomplete		2	Yukon XL	•	•	• •
	LD Trk, MPV, Incomplete		2	Yukon Hybrid	•	•	• •

Year Menu1	Menu2	Menu3	Menu4	Read codes	Erase Codes		ECU Info.
(D) 2013 LD Trk, MPV, Incomplete	GMC Truck	2	Yukon	•	•	•	•
(D) 2013 LD Trk, MPV, Incomplete	GMC Truck	2	Sierra Hybrid		•	•	•
(D) 2013 LD Trk, MPV, Incomplete		2	Sierra		•	•	•
(D) 2013 LD Trk, MPV, Incomplete	GMC Truck	1	Yukon XL		•	•	•
(D) 2013 LD Trk, MPV, Incomplete	GMC Truck	1	Yukon Hybrid	•	•	•	•
(D) 2013 LD Trk, MPV, Incomplete		1	Yukon	•	•	•	•
(D) 2013 LD Trk, MPV, Incomplete	GMC Truck	1	Sierra Hybrid	•	•	•	•
(D) 2013 LD Trk, MPV, Incomplete		1	Sierra				
(D) 2013 LD Trk, MPV, Incomplete	Chevrolet Truck	P	Orlando	•	•	•	•
(D) 2013 LD Trk, MPV, Incomplete	Chevrolet Truck	K	Tahoe Hybrid	•	•	•	•
(D) 2013 LD Trk, MPV, Incomplete		K	Tahoe		•	•	•
(D) 2013 LD Trk, MPV, Incomplete	Chevrolet Truck	K	Suburban		•	•	•
(D) 2013 LD Trk, MPV, Incomplete	Chevrolet Truck	K	Silverado Hybrid	•	•	•	•
(D) 2013 LD Trk, MPV, Incomplete		K	Silverado		•	•	•
(D) 2013 LD Trk, MPV, Incomplete		K	Cheyenne		•	•	•
(D) 2013 LD Trk, MPV, Incomplete		K	Avalanche	•	•	•	•
(D) 2013 LD Trk, MPV, Incomplete		Н	Express/Savana	•	•	•	•
(D) 2013 LD Trk, MPV, Incomplete		Н	Express Access/Savana Pro	•	•	•	•
(D) 2013 LD Trk, MPV, Incomplete		G	Express/Savana	•	•	•	
(D) 2013 LD Trk, MPV, Incomplete		G	Express Access/Savana Pro	•	•	•	•
(D) 2013 LD Trk, MPV, Incomplete		С	Tahoe Hybrid	•	•	•	•
(D) 2013 LD Trk, MPV, Incomplete		С	Tahoe	•	•	•	•
(D) 2013 LD Trk, MPV, Incomplete		С	Suburban	•	•	•	•
(D) 2013 LD Trk, MPV, Incomplete		С	Silverado Hybrid	•	•	•	•
(D) 2013 LD Trk, MPV, Incomplete		С	Silverado		•	•	•
(D) 2013 LD Trk, MPV, Incomplete		C	Cheyenne		•	•	•
(D) 2013 LD Trk, MPV, Incomplete		C	Captiva 1		•	•	•
(D) 2013 LD Trk, MPV, Incomplete		C	Avalanche		•	•	•
(D) 2013 LD Trk, MPV, Incomplete		N	SRX		•	•	•
(D) 2013 LD Trk, MPV, Incomplete		4	Escalade Hybrid			•	•
(D) 2013 LD Trk, MPV, Incomplete		4	Escalade		•	•	•
(D) 2013 LD Trk, MPV, Incomplete		3	Escalade Hybrid		•	•	•
(D) 2013 LD Trk, MPV, Incomplete		3	Escalade		•	•	•
(D) 2013 LD Trk, MPV, Incomplete		ĪT	Encore		•	•	•
(C) 2012 Workhorse		Powertrain	(E) 6. OL V8 L96	•	•	•	•
(C) 2012 Workhorse	D - W42 Series	Powertrain	(D) 4.8L V8 L20	•	•	•	•
(C) 2012 Workhorse	6 - W22 Series	Chassis	Electronic Brake Control Module	•	•	•	•
(C) 2012 Passenger Car	Holden	S	Powertrain	•	•	•	•
(C) 2012 Passenger Car	Holden	S	Chassis	•	•	•	•
(C) 2012 Passenger Car	Holden	S	Body	•	•	•	•
(C) 2012 Passenger Car	Holden	Others	Barina Spark	•	•	•	•
(C) 2012 Passenger Car	Daewoo	Alpheon	Powertrain	•	•	•	•
(C) 2012 Passenger Car	Daewoo	Alpheon	Chassis		•	•	
(C) 2012 Passenger Car	Daewoo	Alpheon	Body			•	
(C) 2012 Passenger Car	Chevrolet	Z	Malibu 2				
(c) 2012 ji assenger Car	OHEATOTER	L	Maiibu Z	•	_		

Year	Menu1	Menu2	Menu3	Menu4		Erase Codes		ECU Info.
(C) 2012	Passenger Car	Chevrolet	Z	Malibu 1	•	•	•	•
	Passenger Car	Chevrolet	Y	Powertrain	•	•	•	•
	Passenger Car	Chevrolet	Y	Chassis	•	•	•	•
	Passenger Car	Chevrolet	Y	Body	•	•	•	•
(C) 2012	Passenger Car	Chevrolet	W	Powertrain			•	
(C) 2012	Passenger Car	Chevrolet	W	Chassis	•	•		
(C) 2012	Passenger Car	Chevrolet	T	Other Mode	•	•		
(C) 2012	Passenger Car	Chevrolet	T	Aveo	•	•	•	
(C) 2012	Passenger Car	Chevrolet	S	Sail				
(C) 2012	Passenger Car	Chevrolet	S	Chevy				
(C) 2012	Passenger Car	Chevrolet	S	Aveo				
(C) 2012	Passenger Car	Chevrolet	R	Volt				
(C) 2012	Passenger Car	Chevrolet	P	Control Unit			•	
(C) 2012	Passenger Car	Chevrolet	Others	S10				
(C) 2012	Passenger Car	Chevrolet	Others	Beat				
(C) 2012	Passenger Car	Chevrolet	N	Powertrain	•	•	•	
(C) 2012	Passenger Car	Chevrolet	N	Chassis				
(C) 2012	Passenger Car	Chevrolet	N	Body				
(C) 2012	Passenger Car	Chevrolet	M	Powertrain				
(C) 2012	Passenger Car	Chevrolet	M	Chassis	•	•	•	
(C) 2012	Passenger Car	Chevrolet	M	Body	•	•	•	
(C) 2012	Passenger Car	Chevrolet	K	Powertrain	•	•	•	
(C) 2012	Passenger Car	Chevrolet	K	Chassis			•	
(C) 2012	Passenger Car	Chevrolet	K	Body	•	•	•	
(C) 2012	Passenger Car	Chevrolet	J	Sonic			•	
(C) 2012	Passenger Car	Chevrolet	Ј	Other Mode	•	•	•	
(C) 2012	Passenger Car	Chevrolet	Ј	Cobalt	•	•	•	
(C) 2012	Passenger Car	Chevrolet	F	Powertrain				
(C) 2012	Passenger Car	Chevrolet	F	Chassis	•	•	•	
(C) 2012	Passenger Car	Chevrolet	F	Body	•	•	•	
(C) 2012	Passenger Car	Chevrolet	C	Spark				
(C) 2012	Passenger Car	Cadillac	Powertrain	(P) 6.2L V8 LSA				
(C) 2012	Passenger Car	Cadillac	Powertrain	(5) 3. OL V6 LFW				
(C) 2012	Passenger Car	Cadillac	Powertrain	(3) 3.6L V6 LFX				
(C) 2012	Passenger Car	Cadillac	Chassis	Parking Brake Control Module				
	Passenger Car	Cadillac	Chassis	Electronic Suspension Control				
(C) 2012	Passenger Car	Cadillac	Chassis	Electronic Brake Control Module	•	•	•	
(C) 2012	Passenger Car	Cadillac	Body	Others	•	•	•	
(C) 2012	Passenger Car	Cadillac	Body	(P) 6.2L V8 LSA	•	•	•	•
(C) 2012	Passenger Car	Buick	P	Verano			•	
	Passenger Car	Buick	Н	Powertrain	•	•	•	
(C) 2012	Passenger Car	Buick	Н	Chassis	•	•	•	
	Passenger Car	Buick	Н	Body	•	•	•	
	Passenger Car	Buick	G	Regal	•	•	•	
	Passenger Car	Buick	G	Lacrosse	•	•	•	•

Year Menu1	Menu2	Menu3	Menu4		Erase Codes		ECU Info.
(C) 2012 LD Trk, MPV, Incomplete	Holden	Others	Captiva 5	•	•	•	
(C) 2012 LD Trk, MPV, Incomplete		V	Powertrain	•	•		•
(C) 2012 LD Trk, MPV, Incomplete		V	Chassis	•			
(C) 2012 LD Trk, MPV, Incomplete		V	Body	•	•	•	•
(C) 2012 LD Trk, MPV, Incomplete		R	Powertrain	•	•	•	•
(C) 2012 LD Trk, MPV, Incomplete	GMC Truck	R	Chassis	•	•	•	•
(C) 2012 LD Trk, MPV, Incomplete	GMC Truck	R	Body	•	•	•	•
(C) 2012 LD Trk, MPV, Incomplete	GMC Truck	L	Terrain	•		•	
(C) 2012 LD Trk, MPV, Incomplete	GMC Truck	8	Express/Savana	•		•	
(C) 2012 LD Trk, MPV, Incomplete		8	Express Access/Savana Pro	•	•	•	
(C) 2012 LD Trk, MPV, Incomplete	GMC Truck	7	Express/Savana	•	•	•	
(C) 2012 LD Trk, MPV, Incomplete	GMC Truck	7	Express Access/Savana Pro	•		•	
(C) 2012 LD Trk, MPV, Incomplete	GMC Truck	6	Powertrain	•		•	
(C) 2012 LD Trk, MPV, Incomplete	GMC Truck	6	Chassis	•		•	
(C) 2012 LD Trk, MPV, Incomplete		5	Powertrain	•		•	
(C) 2012 LD Trk, MPV, Incomplete	GMC Truck	5	Chassis	•		•	
(C) 2012 LD Trk, MPV, Incomplete	GMC Truck	2	Yukon XL	•		•	
(C) 2012 LD Trk, MPV, Incomplete	GMC Truck	2	Yukon Hybrid	•		•	
(C) 2012 LD Trk, MPV, Incomplete	GMC Truck	2	Yukon	•		•	
(C) 2012 LD Trk, MPV, Incomplete	GMC Truck	2	Sierra Hybrid	•		•	
(C) 2012 LD Trk, MPV, Incomplete	GMC Truck	2	Sierra	•	•	•	
(C) 2012 LD Trk, MPV, Incomplete	GMC Truck	1	Yukon XL	•	•	•	
(C) 2012 LD Trk, MPV, Incomplete	GMC Truck	1	Yukon Hybrid	•	•	•	
(C) 2012 LD Trk, MPV, Incomplete	GMC Truck	1	Yukon	•	•	•	
(C) 2012 LD Trk, MPV, Incomplete	GMC Truck	1	Sierra Hybrid	•	•	•	
(C) 2012 LD Trk, MPV, Incomplete	GMC Truck	1	Sierra	•	•	•	
(C) 2012 LD Trk, MPV, Incomplete	Chevrolet Truck	V	Powertrain	•	•	•	
(C) 2012 LD Trk, MPV, Incomplete	Chevrolet Truck	V	Chassis	•		•	
(C) 2012 LD Trk, MPV, Incomplete	Chevrolet Truck	V	Body	•		•	
(C) 2012 LD Trk, MPV, Incomplete	Chevrolet Truck	T	Powertrain	•		•	
(C) 2012 LD Trk, MPV, Incomplete	Chevrolet Truck	T	Chassis	•		•	
(C) 2012 LD Trk, MPV, Incomplete	Chevrolet Truck	S	Powertrain	•			
(C) 2012 LD Trk, MPV, Incomplete	Chevrolet Truck	S	Chassis	•		•	
(C) 2012 LD Trk, MPV, Incomplete		R	Powertrain	•		•	
(C) 2012 LD Trk, MPV, Incomplete	Chevrolet Truck	R	Chassis	•			
(C) 2012 LD Trk, MPV, Incomplete	Chevrolet Truck	R	Body	•			
(C) 2012 LD Trk, MPV, Incomplete	Chevrolet Truck	P	Orlando	•			
(C) 2012 LD Trk, MPV, Incomplete	Chevrolet Truck	L	Equinox	•			
(C) 2012 LD Trk, MPV, Incomplete	Chevrolet Truck	L	Captiva Sport	•	•	•	
(C) 2012 LD Trk, MPV, Incomplete	Chevrolet Truck	K	Tahoe Hybrid	•	•	•	
(C) 2012 LD Trk, MPV, Incomplete	Chevrolet Truck	K	Tahoe	•		•	
(C) 2012 LD Trk, MPV, Incomplete		K	Suburban	•		•	
(C) 2012 LD Trk, MPV, Incomplete	Chevrolet Truck	K	Silverado Hybrid	•		•	
(C) 2012 LD Trk, MPV, Incomplete	Chevrolet Truck	K	Silverado	•		•	
(C) 2012 LD Trk, MPV, Incomplete	Chevrolet Truck	K	Cheyenne	•		•	

Year Menu1	Menu2	Menu3	Menu4		Erase Codes		ECU Info.
(C) 2012 LD Trk, MPV, Incomplete	Chevrolet Truck	Н	Express/Savana		•	•	•
(C) 2012 LD Trk, MPV, Incomplete		H	Express Access/Savana Pro		•	•	
(C) 2012 LD Trk, MPV, Incomplete		Ct.	Express/Savana		•	•	
(C) 2012 LD Trk, MPV, Incomplete		<u>C</u> 1	Express Access/Savana Pro		•	•	
(C) 2012 LD Trk, MPV, Incomplete		C	Tahoe Hybrid		•	•	
(C) 2012 LD Trk, MPV, Incomplete		C	Tahoe		•	•	
(C) 2012 LD Trk, MPV, Incomplete		C	Suburban		•	•	
(C) 2012 LD Trk, MPV, Incomplete		С	Silverado Hybrid	•	•	•	
(C) 2012 LD Trk, MPV, Incomplete		С	Silverado		•	•	•
(C) 2012 LD Trk, MPV, Incomplete		С	Cheyenne	•	•	•	•
(C) 2012 LD Trk, MPV, Incomplete		С	Captiva 1		•	•	•
(C) 2012 LD Trk, MPV, Incomplete		С	Avalanche	•	•	•	•
(C) 2012 LD Trk, MPV, Incomplete		N300	Powertrain	•	•	•	•
(C) 2012 LD Trk, MPV, Incomplete		N300	Chassis	•	•	•	•
(C) 2012 LD Trk, MPV, Incomplete		N300	Body		•	•	•
(C) 2012 LD Trk, MPV, Incomplete		N200	Powertrain		•	•	•
(C) 2012 LD Trk, MPV, Incomplete		N200	Chassis	•	•	•	•
(C) 2012 LD Trk, MPV, Incomplete		N200	Body	•	•	•	•
(C) 2012 LD Trk, MPV, Incomplete		N	Control Unit	•	•	•	•
(C) 2012 LD Trk, MPV, Incomplete		4	Escalade Hybrid		•	•	•
(C) 2012 LD Trk, MPV, Incomplete		4	Escalade		•	•	
(C) 2012 LD Trk, MPV, Incomplete		3	Escalade Hybrid		•	•	•
(C) 2012 LD Trk, MPV, Incomplete		3	Escalade	•	•	•	•
(C) 2012 LD Trk, MPV, Incomplete		V	Powertrain		•	•	•
(C) 2012 LD Trk, MPV, Incomplete		V	Chassis		•	•	
(C) 2012 LD Trk, MPV, Incomplete		V	Body		•	•	•
(C) 2012 LD Trk, MPV, Incomplete		R	Powertrain		•	•	•
(C) 2012 LD Trk, MPV, Incomplete		R	Chassis	•	•	•	•
(C) 2012 LD Trk, MPV, Incomplete		R	Body	•	•	•	•
		Powertrain	(E) 6. OL V8 L96	•	•	•	•
		Powertrain	(D) 4.8L V8 L20	•	•	•	•
		Powertrain	Powertrain Control Module	•	•	•	•
		Powertrain	Powertrain Control Module	•	•	•	•
		Chassis	Electronic Brake Control Module	•	•	•	•
	6 - W20 Series	Powertrain	Powertrain Control Module	•	•	•	•
	Holden	S	Powertrain	•	•	•	•
	Holden	S	Chassis	•	•	•	•
	Holden	S	Body	•	•	•	•
		Others	Barina Spark	•	•	•	•
	Holden	L	Powertrain	•	•	•	•
	Holden	L	Chassis	•	•	•	•
	Holden	L	Body	•	•	•	•
		Alpheon	Powertrain Powertrain	•	•	•	
		Alpheon	Chassis	•	•	•	
		Alpheon	Body	•	•	•	

Year	Menu1	Menu2	Menu3	Menu4		Erase Codes		ECU Info.
(B) 2011	Passenger Car	Chevrolet	Z	Powertrain	•	•	•	•
	Passenger Car	Chevrolet	Z	Chassis	•	•	•	
(B) 2011	Passenger Car	Chevrolet	Z	Body	•	•		
(B) 2011	Passenger Car	Chevrolet	Y	Powertrain	•	•		
(B) 2011	Passenger Car	Chevrolet	Y	Chassis	•	•	•	
(B) 2011	Passenger Car	Chevrolet	Y	Body	•	•		
(B) 2011	Passenger Car	Chevrolet	W	Powertrain	•	•	•	
(B) 2011	Passenger Car	Chevrolet	W	Chassis		•		
(B) 2011	Passenger Car	Chevrolet	T	Powertrain		•	•	
(B) 2011	Passenger Car	Chevrolet	T	Chassis		•		
(B) 2011	Passenger Car	Chevrolet	T	Body		•		
(B) 2011	Passenger Car	Chevrolet	S	Sail		•		
(B) 2011	Passenger Car	Chevrolet	S	Chevy		•	•	
(B) 2011	Passenger Car	Chevrolet	S	Aveo		•		
(B) 2011	Passenger Car	Chevrolet	R	Volt		•		
(B) 2011	Passenger Car	Chevrolet	P	Control Unit	•	•	•	
(B) 2011	Passenger Car	Chevrolet	N	Powertrain	•	•	•	
(B) 2011	Passenger Car	Chevrolet	N	Chassis	•	•	•	
(B) 2011	Passenger Car	Chevrolet	N	Body		•		
(B) 2011	Passenger Car	Chevrolet	M	Powertrain	•	•	•	
(B) 2011	Passenger Car	Chevrolet	M	Chassis	•	•	•	
(B) 2011	Passenger Car	Chevrolet	M	Body	•	•	•	
(B) 2011	Passenger Car	Chevrolet	L	Powertrain	•	•	•	
(B) 2011	Passenger Car	Chevrolet	L	Chassis	•	•	•	
(B) 2011	Passenger Car	Chevrolet	L	Body		•	•	
(B) 2011	Passenger Car	Chevrolet	K	Powertrain	•	•	•	
(B) 2011	Passenger Car	Chevrolet	K	Chassis	•	•	•	
(B) 2011	Passenger Car	Chevrolet	K	Body	•	•	•	
(B) 2011	Passenger Car	Chevrolet	Ј	Powertrain	•	•	•	
(B) 2011	Passenger Car	Chevrolet	Ј	Chassis	•	•	•	
(B) 2011	Passenger Car	Chevrolet	Ј	Body		•	•	
(B) 2011	Passenger Car	Chevrolet	F	Powertrain		•	•	
(B) 2011	Passenger Car	Chevrolet	F	Chassis		•	•	
(B) 2011	Passenger Car	Chevrolet	F	Body		•	•	
	Passenger Car	Chevrolet	С	Spark		•	•	
	Passenger Car	Cadillac	K	Powertrain		•	•	
(B) 2011	Passenger Car	Cadillac	K	Chassis		•	•	
(B) 2011	Passenger Car	Cadillac	K	Body	•	•	•	•
	Passenger Car	Cadillac	D	STS	•	•	•	•
	Passenger Car	Cadillac	D	CTS	•	•	•	•
	Passenger Car	Buick	Н	Powertrain	•	•	•	•
	Passenger Car	Buick	Н	Chassis	•	•	•	•
	Passenger Car	Buick	Н	Body	•	•	•	•
	Passenger Car	Buick	G	Regal	•	•	•	•
	Passenger Car	Buick	G	Lacrosse	•	•	•	

Year Menu1	Menu2	Menu3	Menu4		Erase Codes		ECU Info.
(B) 2011 LD Trk, MPV, Incomplete	Holden	Others	Captiva 5	•	•	•	
(B) 2011 LD Trk, MPV, Incomplete		V	Powertrain		•	•	
(B) 2011 LD Trk, MPV, Incomplete		V	Chassis		•	•	
(B) 2011 LD Trk, MPV, Incomplete		R	Powertrain		•	•	
(B) 2011 LD Trk, MPV, Incomplete		R	Chassis	•	•	•	
(B) 2011 LD Trk, MPV, Incomplete	GMC Truck	R	Body	•	•	•	
(B) 2011 LD Trk, MPV, Incomplete		L	Terrain	•	•	•	
(B) 2011 LD Trk, MPV, Incomplete		8	Express/Savana	•	•	•	•
(B) 2011 LD Trk, MPV, Incomplete		8	Express Access/Savana Pro	•	•	•	
(B) 2011 LD Trk, MPV, Incomplete		7	Express/Savana	•	•	•	
(B) 2011 LD Trk, MPV, Incomplete		7	Express Access/Savana Pro	•	•	•	
(B) 2011 LD Trk, MPV, Incomplete		6	Powertrain	•	•	•	
(B) 2011 LD Trk, MPV, Incomplete		6	Chassis	•	•	•	
(B) 2011 LD Trk, MPV, Incomplete		6	Body	•	•	•	
(B) 2011 LD Trk, MPV, Incomplete		5	Powertrain	•	•	•	
(B) 2011 LD Trk, MPV, Incomplete		5	Chassis	•	•	•	
(B) 2011 LD Trk, MPV, Incomplete		5	Body	•	•	•	•
(B) 2011 LD Trk, MPV, Incomplete		2	Yukon XL	•	•	•	
(B) 2011 LD Trk, MPV, Incomplete		2	Yukon Hybrid	•	•	•	•
(B) 2011 LD Trk, MPV, Incomplete		2	Yukon	•	•	•	
(B) 2011 LD Trk, MPV, Incomplete		2	Sierra Hybrid	•	•	•	•
(B) 2011 LD Trk, MPV, Incomplete		2	Sierra	•	•	•	
(B) 2011 LD Trk, MPV, Incomplete		1	Yukon XL	•	•	•	
(B) 2011 LD Trk, MPV, Incomplete		1	Yukon Hybrid	•	•	•	
(B) 2011 LD Trk, MPV, Incomplete		1	Yukon	•	•	•	
(B) 2011 LD Trk, MPV, Incomplete		1	Sierra Hybrid	•	•	•	
(B) 2011 LD Trk, MPV, Incomplete		1	Sierra	•	•	•	
(B) 2011 LD Trk, MPV, Incomplete		V	Powertrain		•	•	
(B) 2011 LD Trk, MPV, Incomplete		V	Chassis	•	•	•	
(B) 2011 LD Trk, MPV, Incomplete		V	Body	•	•	•	•
(B) 2011 LD Trk, MPV, Incomplete		T	Powertrain	•	•	•	•
(B) 2011 LD Trk, MPV, Incomplete		T	Chassis	•	•	•	
(B) 2011 LD Trk, MPV, Incomplete	Chevrolet Truck	T	Body	•	•	•	
(B) 2011 LD Trk, MPV, Incomplete		S	Powertrain	•	•	•	•
(B) 2011 LD Trk, MPV, Incomplete		S	Chassis	•	•	•	•
(B) 2011 LD Trk, MPV, Incomplete		S	Body	•	•	•	•
(B) 2011 LD Trk, MPV, Incomplete		R	Powertrain		•	•	
(B) 2011 LD Trk, MPV, Incomplete		R	Chassis	•	•	•	•
(B) 2011 LD Trk, MPV, Incomplete		R	Body	•	•	•	•
(B) 2011 LD Trk, MPV, Incomplete		Р	Orlando	•	•	•	•
(B) 2011 LD Trk, MPV, Incomplete		L	Equinox	•	•	•	•
(B) 2011 LD Trk, MPV, Incomplete		L	Captiva Sport	•	•	•	•
(B) 2011 LD Trk, MPV, Incomplete		K	Tahoe Hybrid	•	•	•	•
(B) 2011 LD Trk, MPV, Incomplete		K	Tahoe	•	•	•	•
(B) 2011 LD Trk, MPV, Incomplete		K	Suburban	•	•	•	

Year Menu1	Menu2	Menu3	Menu4		Erase Codes		ECU Info.
(B) 2011 LD Trk, MPV, Incomplete	Chevrolet Truck	K	Silverado Hybrid	•	•	•	•
(B) 2011 LD Trk, MPV, Incomplete		K	Silverado	•	•	•	•
(B) 2011 LD Trk, MPV, Incomplete	Chevrolet Truck		Cheyenne	•	•	•	•
(B) 2011 LD Trk, MPV, Incomplete	Chevrolet Truck	K	Avalanche	•	•	•	•
(B) 2011 LD Trk, MPV, Incomplete		Н	Express/Savana	•	•	•	•
(B) 2011 LD Trk, MPV, Incomplete		Н	Express Access/Savana Pro	•	•		
(B) 2011 LD Trk, MPV, Incomplete	Chevrolet Truck	G	Express/Savana	•	•		
(B) 2011 LD Trk, MPV, Incomplete		G	Express Access/Savana Pro	•	•		
(B) 2011 LD Trk, MPV, Incomplete	Chevrolet Truck	C	Tahoe Hybrid	•	•		
(B) 2011 LD Trk, MPV, Incomplete	Chevrolet Truck	C	Tahoe	•	•		
(B) 2011 LD Trk, MPV, Incomplete		C	Suburban	•	•		
(B) 2011 LD Trk, MPV, Incomplete	Chevrolet Truck	C	Silverado Hybrid	•	•		
(B) 2011 LD Trk, MPV, Incomplete	Chevrolet Truck	C	Silverado		•	•	
(B) 2011 LD Trk, MPV, Incomplete	Chevrolet Truck		Cheyenne		•		•
(B) 2011 LD Trk, MPV, Incomplete		C	Captiva 1	•	•		
(B) 2011 LD Trk, MPV, Incomplete	Chevrolet Truck	C	Captiva	•	•		
(B) 2011 LD Trk, MPV, Incomplete	Chevrolet Truck	C	Avalanche	•	•		
(B) 2011 LD Trk, MPV, Incomplete	Chevrolet Truck	A	HHR Panel	•	•		
(B) 2011 LD Trk, MPV, Incomplete	Chevrolet Truck	A	HHR	•	•		
(B) 2011 LD Trk, MPV, Incomplete	Chevrolet MPV	N300	Powertrain	•	•		
(B) 2011 LD Trk, MPV, Incomplete		N300	Chassis	•	•		
(B) 2011 LD Trk, MPV, Incomplete		N300	Body	•	•	•	•
(B) 2011 LD Trk, MPV, Incomplete	Chevrolet MPV	N200	Powertrain	•	•		
(B) 2011 LD Trk, MPV, Incomplete		N200	Chassis	•	•	•	•
(B) 2011 LD Trk, MPV, Incomplete		N200	Body	•	•	•	•
(B) 2011 LD Trk, MPV, Incomplete		N	Control Unit	•	•	•	•
(B) 2011 LD Trk, MPV, Incomplete		4	Escalade Hybrid	•	•	•	•
(B) 2011 LD Trk, MPV, Incomplete		4	Escalade	•	•	•	•
(B) 2011 LD Trk, MPV, Incomplete		3	Escalade Hybrid	•	•	•	•
(B) 2011 LD Trk, MPV, Incomplete		3	Escalade	•	•	•	•
(B) 2011 LD Trk, MPV, Incomplete		V	Powertrain	•	•	•	•
(B) 2011 LD Trk, MPV, Incomplete		V	Chassis	•	•	•	•
(B) 2011 LD Trk, MPV, Incomplete		V	Body	•	•	•	•
(B) 2011 LD Trk, MPV, Incomplete	Buick	R	Powertrain	•	•	•	•
(B) 2011 LD Trk, MPV, Incomplete		R	Chassis	•	•	•	•
(B) 2011 LD Trk, MPV, Incomplete		R	Body	•	•	•	•
		Powertrain	(G) 8.1L V8 L18	•	•	•	•
		Powertrain	(G) 6. OL V8 L96	•	•	•	•
		Powertrain	(G) 8. 1L V8 L18	•	•	•	•
		Powertrain	(G) 6. OL V8 L96	•	•	•	•
		Powertrain	(G) 8. 1L V8 L18	•	•		•
		Powertrain	(G) 6. OL V8 L96	•	•	•	•
		Powertrain	(G) 8. 1L V8 L18	•	•	•	•
		Powertrain	(G) 6. OL V8 L96	•	•	•	•
		Powertrain	(K) 6. OL V8 LY6	•	•	•	•

Year Menu1	Menu2	Menu3	Menu4	Read Era		ECU Info.
(A) 2010 Workhorse	D - W42 Series	Powertrain	(A) 4.8L V8 L20	• •	•	•
(A) 2010 Workhorse	A - W24 Series	Powertrain	(G) 8.1L V8 L18	• •	•	•
(A) 2010 Workhorse	A - W24 Series	Powertrain	(G) 6.0L V8 L96	• •	•	•
(A) 2010 Workhorse	6 - W22 Series	Powertrain	(G) 8.1L V8 L18	• •	•	•
(A) 2010 Workhorse	6 - W22 Series	Powertrain	(G) 6. OL V8 L96	• •		
(A) 2010 Workhorse	6 - W22 Series	Chassis	Electronic Brake Control Module	• •		
(A) 2010 Workhorse	6 - W20 Series	Powertrain	(G) 8.1L V8 L18	• •		
(A) 2010 Workhorse	6 - W20 Series	Powertrain	(G) 6. OL V8 L96	• •		
(A) 2010 Passenger Car	Saturn	Z	Aura Hybrid	• •		
(A) 2010 Passenger Car	Saturn	Z	Aura	• •		•
(A) 2010 Passenger Car	Saturn	M	Chassis	• •		
(A) 2010 Passenger Car	Saturn	M	Body	• •		
(A) 2010 Passenger Car	Pontiac	Z	Powertrain	• •		
(A) 2010 Passenger Car	Pontiac	Z	Chassis	• •		
(A) 2010 Passenger Car	Pontiac	Т	Wave	• •		
(A) 2010 Passenger Car	Pontiac	Т	G3	• •		
(A) 2010 Passenger Car	Pontiac	S	Powertrain	• •		
(A) 2010 Passenger Car	Pontiac	S	Chassis	• •		
(A) 2010 Passenger Car	Pontiac	S	Body	• •		
(A) 2010 Passenger Car	Pontiac	M	Chassis	• •		
(A) 2010 Passenger Car	Pontiac	M	Body	• •		
(A) 2010 Passenger Car	Pontiac	K	Powertrain	• •		
(A) 2010 Passenger Car	Pontiac	K	Chassis	• •		
(A) 2010 Passenger Car	Pontiac	K	Body	• •		
(A) 2010 Passenger Car	Pontiac	A	Powertrain	• •		
(A) 2010 Passenger Car	Pontiac	A	Body	• •		
(A) 2010 Passenger Car	Holden	S	Chassis	• •		
(A) 2010 Passenger Car	Holden	S	Body	• •		
(A) 2010 Passenger Car	Holden	Others	Barina Spark	• •		
(A) 2010 Passenger Car	Holden	N	Powertrain	• •		
(A) 2010 Passenger Car	Holden	N	Chassis	• •		
(A) 2010 Passenger Car	Holden	N	Body	• •		•
(A) 2010 Passenger Car	Holden	L	Powertrain	• •		
(A) 2010 Passenger Car	Holden	L	Chassis	• •		
(A) 2010 Passenger Car	Holden	L	Body	• •		•
(A) 2010 Passenger Car	Daewoo	Lacetti	Transmission Control Module	• •		•
(A) 2010 Passenger Car	Daewoo	Lacetti	Trailer Interface Control Module	• •		
(A) 2010 Passenger Car	Daewoo	Lacetti	Telematics Communication Interface Control Module	• •	•	•
(A) 2010 Passenger Car	Daewoo	Lacetti	Steering Column Lock Control Module	• •	•	•
(A) 2010 Passenger Car	Daewoo	Lacetti	Remote Heater and Air Conditioning Control Module	• •	•	•
(A) 2010 Passenger Car	Daewoo	Lacetti	Radio	• •	•	•
(A) 2010 Passenger Car	Daewoo	Lacetti	Parking Assist Control Module	• •	•	•
(A) 2010 Passenger Car	Daewoo	Lacetti	Multimedia Player Interface Module	• •	•	

Year	Menu1	Menu2	Menu3	Menu4		Erase Codes		ECU Info.
(A) 2010	Passenger Car	Daewoo	Lacetti	Keyless Entry Control Module	•	•		
(A) 2010	Passenger Car	Daewoo	Lacetti	Instrument Cluster		•	•	
(A) 2010	Passenger Car	Daewoo	Lacetti	Inflatable Restraint Sensing and Diagnostic Module	•	•	•	•
(A) 2010	Passenger Car	Daewoo	Lacetti	Engine Control Module	•	•	•	•
	Passenger Car	Daewoo	Lacetti	Electronic Brake Control Module	•	•	•	•
(A) 2010	Passenger Car	Daewoo	Lacetti	Body Control Module	•	•	•	•
(A) 2010	Passenger Car	Chevrolet	Z	Malibu Hybrid	•	•		
(A) 2010	Passenger Car	Chevrolet	Z	Malibu	•	•	•	
(A) 2010	Passenger Car	Chevrolet	Y	Powertrain	•	•	•	
(A) 2010	Passenger Car	Chevrolet	Y	Chassis	•	•	•	
(A) 2010	Passenger Car	Chevrolet	Y	Body	•	•	•	
(A) 2010	Passenger Car	Chevrolet	W	Powertrain	•	•	•	
(A) 2010	Passenger Car	Chevrolet	W	Chassis	•	•	•	
(A) 2010	Passenger Car	Chevrolet	Т	Powertrain	•	•		
(A) 2010	Passenger Car	Chevrolet	T	Chassis	•	•		
(A) 2010	Passenger Car	Chevrolet	Т	Body	•	•		
(A) 2010	Passenger Car	Chevrolet	S	Sail	•	•	•	•
(A) 2010	Passenger Car	Chevrolet	S	Chevy	•	•	•	
(A) 2010	Passenger Car	Chevrolet	S	Aveo	•	•	•	
(A) 2010	Passenger Car	Chevrolet	P	Control Unit	•	•	•	
	Passenger Car	Chevrolet	Others	Beat	•	•	•	•
(A) 2010	Passenger Car	Chevrolet	N	Powertrain	•	•	•	•
	Passenger Car	Chevrolet	N	Chassis	•	•	•	•
	Passenger Car	Chevrolet	N	Body	•	•	•	
	Passenger Car	Chevrolet	L	Powertrain	•	•	•	
	Passenger Car	Chevrolet	L	Chassis	•	•	•	
	Passenger Car	Chevrolet	L	Body	•	•	•	
	Passenger Car	Chevrolet	K	Powertrain	•	•	•	
	Passenger Car	Chevrolet	K	Chassis	•	•	•	
(A) 2010	Passenger Car	Chevrolet	K	Body	•	•	•	
	Passenger Car	Chevrolet	J	Powertrain	•	•	•	
	Passenger Car	Chevrolet	J	Chassis	•	•	•	
	Passenger Car	Chevrolet	J	Body	•	•	•	
(A) 2010	Passenger Car	Chevrolet	F	Powertrain	•	•	•	
	Passenger Car	Chevrolet	F	Chassis	•	•		
	Passenger Car	Chevrolet	F	Body	•	•		
	Passenger Car	Chevrolet	С	Spark	•	•		
	Passenger Car	Chevrolet	A	Powertrain	•	•	•	•
	Passenger Car	Chevrolet	A	Body	•	•	•	•
	Passenger Car	Cadillac	K	Powertrain	•	•	•	•
	Passenger Car	Cadillac	K	Chassis	•	•	•	•
	Passenger Car	Cadillac	K	Body	•	•	•	•
	Passenger Car	Cadillac	D	STS	•	•	•	
	Passenger Car	Cadillac	D	CTS	•	•	•	

Year	Menu1	Menu2	Menu3	Menu4		Erase Codes		ECU Info.
(A) 2010	Passenger Car	Buick	Н	Powertrain	•	•	•	•
	Passenger Car	Buick	Н	Chassis	•	•	•	•
	Passenger Car	Buick	G	Lacrosse	•	•	•	•
(A) 2010	Passenger Car	Buick	G	Allure	•	•	•	•
(A) 2010	LD Trk, MPV, Incomplete	Vauxhall	Powertrain	(U) 2. OL L4 LMN	•	•	•	
	LD Trk, MPV, Incomplete	Vauxhall	Powertrain	(R) 2. OL L4 LLW	•	•	•	
(A) 2010	LD Trk, MPV, Incomplete	Vauxhall	Powertrain	(G) 3.2L V6 LU1	•	•	•	
(A) 2010	LD Trk, MPV, Incomplete	Vauxhall	Powertrain	(F) 2.4L L4 LD9	•	•	•	
(A) 2010	LD Trk, MPV, Incomplete	Vauxhall	Powertrain	(1) 2.4L L4 LE5				
(A) 2010	LD Trk, MPV, Incomplete	Vauxhall	Chassis	Power Steering Control Module				
(A) 2010	LD Trk, MPV, Incomplete	Vauxhall	Chassis	Electronic Brake Control Module	•	•	•	
(A) 2010	LD Trk, MPV, Incomplete	Vauxhall	Body	Uplevel Radio	•	•	•	
(A) 2010	LD Trk, MPV, Incomplete	Vauxhall	Body	Navigation Radio	•	•	•	
(A) 2010	LD Trk, MPV, Incomplete	Saturn	V	Powertrain	•	•	•	
(A) 2010	LD Trk, MPV, Incomplete	Saturn	V	Chassis	•	•	•	
(A) 2010	LD Trk, MPV, Incomplete	Saturn	V	Body	•	•	•	
(A) 2010	LD Trk, MPV, Incomplete	Saturn	R	Powertrain	•	•	•	
(A) 2010	LD Trk, MPV, Incomplete	Saturn	R	Chassis	•	•	•	
(A) 2010	LD Trk, MPV, Incomplete	Saturn	R	Body	•	•	•	
(A) 2010	LD Trk, MPV, Incomplete	Saturn	L	Powertrain	•	•	•	
(A) 2010	LD Trk, MPV, Incomplete	Saturn	L	Chassis	•	•	•	
(A) 2010	LD Trk, MPV, Incomplete	Saturn	L	Body	•	•	•	
(A) 2010	LD Trk, MPV, Incomplete	Ope1	Powertrain	(U) 2. OL L4 LMN	•	•	•	
(A) 2010	LD Trk, MPV, Incomplete	Ope1	Powertrain	(R) 2. OL L4 LLW	•	•	•	
(A) 2010	LD Trk, MPV, Incomplete	Opel	Powertrain	(G) 3.2L V6 LU1	•	•	•	
(A) 2010	LD Trk, MPV, Incomplete	Ope1	Powertrain	(F) 2.4L L4 LD9	•	•	•	
(A) 2010	LD Trk, MPV, Incomplete	Ope1	Powertrain	(1) 2.4L L4 LE5	•	•	•	
(A) 2010	LD Trk, MPV, Incomplete	Opel	Chassis	Power Steering Control Module	•	•	•	
(A) 2010	LD Trk, MPV, Incomplete	Opel	Chassis	Electronic Brake Control Module	•	•	•	
(A) 2010	LD Trk, MPV, Incomplete	Opel	Body	Uplevel Radio	•	•	•	
(A) 2010	LD Trk, MPV, Incomplete	Ope1	Body	Navigation Radio	•	•	•	
(A) 2010	LD Trk, MPV, Incomplete	Hummer	Hummer H3	Powertrain	•	•	•	
(A) 2010	LD Trk, MPV, Incomplete	Hummer	Hummer H3	Chassis	•	•	•	
	LD Trk, MPV, Incomplete		Hummer H3	Body	•	•	•	
(A) 2010	LD Trk, MPV, Incomplete	Hummer	Hummer H2	Powertrain	•	•	•	
	LD Trk, MPV, Incomplete		Hummer H2	Chassis	•	•	•	
(A) 2010	LD Trk, MPV, Incomplete	Hummer	Hummer H2	Body	•	•	•	
	LD Trk, MPV, Incomplete		Captiva Maxx	Powertrain	•	•	•	
$\overline{\text{(A)}} \ \overline{2010}$	LD Trk, MPV, Incomplete	Holden	Captiva Maxx	Chassis	•	•	•	
(A) 2010	LD Trk, MPV, Incomplete	Holden	Captiva Maxx	Body	•	•	•	
$\overline{\text{(A)}} \ \overline{2010}$	LD Trk, MPV, Incomplete	Holden	Captiva	Powertrain	•	•	•	
	LD Trk, MPV, Incomplete		Captiva	Body	•	•	•	
	LD Trk, MPV, Incomplete		V	Powertrain	•	•	•	•
	LD Trk, MPV, Incomplete		V	Chassis	•	•	•	•
	LD Trk, MPV, Incomplete		V	Body	•	•	•	

Year Menu1	Menu2	Menu3	Menu4		Erase Codes		ECU Info.
(A) 2010 LD Trk, MPV, Incomplete	GMC Truck	Т	Powertrain	•	•	•	
(A) 2010 LD Trk, MPV, Incomplete		T	Chassis		•	•	•
(A) 2010 LD Trk, MPV, Incomplete		S	Powertrain			•	
(A) 2010 LD Trk, MPV, Incomplete		S	Chassis		•	•	•
(A) 2010 LD Trk, MPV, Incomplete		R	Powertrain	•	•	•	•
(A) 2010 LD Trk, MPV, Incomplete		R	Chassis	•	•	•	•
(A) 2010 LD Trk, MPV, Incomplete		R	Body	•	•	•	•
(A) 2010 LD Trk, MPV, Incomplete	GMC Truck	L	Terrain	•	•	•	
(A) 2010 LD Trk, MPV, Incomplete	GMC Truck	K	Yukon XL	•	•	•	
(A) 2010 LD Trk, MPV, Incomplete	GMC Truck	K	Yukon Hybrid	•	•	•	
(A) 2010 LD Trk, MPV, Incomplete	GMC Truck	K	Yukon	•	•	•	
(A) 2010 LD Trk, MPV, Incomplete	GMC Truck	K	Sierra Hybrid	•	•	•	
(A) 2010 LD Trk, MPV, Incomplete	GMC Truck	K	Sierra			•	
(A) 2010 LD Trk, MPV, Incomplete	GMC Truck	Н	Express/Savana		•	•	
(A) 2010 LD Trk, MPV, Incomplete	GMC Truck	Н	Express Access/Savana Pro			•	
(A) 2010 LD Trk, MPV, Incomplete	GMC Truck	G	Express/Savana			•	
(A) 2010 LD Trk, MPV, Incomplete	GMC Truck	G	Express Access/Savana Pro			•	
(A) 2010 LD Trk, MPV, Incomplete	GMC Truck	D	Powertrain			•	
(A) 2010 LD Trk, MPV, Incomplete	GMC Truck	D	Chassis			•	
(A) 2010 LD Trk, MPV, Incomplete	GMC Truck	D	Body	•	•	•	
(A) 2010 LD Trk, MPV, Incomplete	GMC Truck	С	Yukon XL	•	•	•	
(A) 2010 LD Trk, MPV, Incomplete	GMC Truck	С	Yukon Hybrid	•	•	•	
(A) 2010 LD Trk, MPV, Incomplete	GMC Truck	С	Yukon	•	•	•	
(A) 2010 LD Trk, MPV, Incomplete	GMC Truck	С	Sierra Hybrid	•	•	•	
(A) 2010 LD Trk, MPV, Incomplete	GMC Truck	С	Sierra	•	•	•	
(A) 2010 LD Trk, MPV, Incomplete	Chevrolet Truck	V	Powertrain	•	•	•	
(A) 2010 LD Trk, MPV, Incomplete	Chevrolet Truck	V	Chassis	•	•	•	
(A) 2010 LD Trk, MPV, Incomplete	Chevrolet Truck	T	Powertrain			•	
(A) 2010 LD Trk, MPV, Incomplete	Chevrolet Truck	T	Chassis	•	•	•	
(A) 2010 LD Trk, MPV, Incomplete	Chevrolet Truck	S	Powertrain			•	
(A) 2010 LD Trk, MPV, Incomplete	Chevrolet Truck	S	Chassis			•	
(A) 2010 LD Trk, MPV, Incomplete	Chevrolet Truck	R	Powertrain		•		
(A) 2010 LD Trk, MPV, Incomplete	Chevrolet Truck	R	Chassis		•	•	
(A) 2010 LD Trk, MPV, Incomplete		R	Body		•	•	
(A) 2010 LD Trk, MPV, Incomplete	Chevrolet Truck	L	Equinox		•		
(A) 2010 LD Trk, MPV, Incomplete	Chevrolet Truck	L	Captiva Sport		•		
(A) 2010 LD Trk, MPV, Incomplete	Chevrolet Truck	K	Tahoe Hybrid		•		
(A) 2010 LD Trk, MPV, Incomplete	Chevrolet Truck	K	Tahoe		•		
(A) 2010 LD Trk, MPV, Incomplete	Chevrolet Truck	K	Suburban	•	•	•	
(A) 2010 LD Trk, MPV, Incomplete	Chevrolet Truck	K	Silverado Hybrid	•	•	•	
(A) 2010 LD Trk, MPV, Incomplete	Chevrolet Truck	K	Silverado	•			
(A) 2010 LD Trk, MPV, Incomplete	Chevrolet Truck	K	Avalanche	•			
(A) 2010 LD Trk, MPV, Incomplete	Chevrolet Truck	Н	Express/Savana	•			
(A) 2010 LD Trk, MPV, Incomplete	Chevrolet Truck	Н	Express Access/Savana Pro	•			
(A) 2010 LD Trk, MPV, Incomplete	Chevrolet Truck	G	Express/Savana				

Year Menu1	Menu2	Menu3	Menu4	Read codes	Erase Codes	Live Data	ECU Info.
(A) 2010 LD Trk, MPV, Incomplete	Chevrolet Truck	G	Express Access/Savana Pro		•	•	•
(A) 2010 LD Trk, MPV, Incomplete		C	Tahoe Hybrid	•	•	•	•
(A) 2010 LD Trk, MPV, Incomplete		С	Tahoe	•	•	•	•
(A) 2010 LD Trk, MPV, Incomplete		С	Suburban	•	•	•	•
(A) 2010 LD Trk, MPV, Incomplete		С	Silverado Hybrid	•	•	•	•
(A) 2010 LD Trk, MPV, Incomplete		С	Silverado	•	•	•	•
(A) 2010 LD Trk, MPV, Incomplete		С	Captiva	•	•	•	•
(A) 2010 LD Trk, MPV, Incomplete		С	Avalanche	•	•	•	•
(A) 2010 LD Trk, MPV, Incomplete		A	HHR Panel	•	•	•	•
(A) 2010 LD Trk, MPV, Incomplete		A	HHR	•		•	
(A) 2010 LD Trk, MPV, Incomplete	Chevrolet MPV	Powertrain	(A) 1.2L L4 LAQ	•	•	•	•
(A) 2010 LD Trk, MPV, Incomplete		Chassis	Electronic Brake Control Module	•	•	•	•
(A) 2010 LD Trk, MPV, Incomplete		Body	Supplemental Inflatable Restraint	•	•	•	•
(A) 2010 LD Trk, MPV, Incomplete		Limousine	Powertrain	•	•	•	•
(A) 2010 LD Trk, MPV, Incomplete	Cadillac Incomplete	Limousine	Chassis	•	•	•	•
(A) 2010 LD Trk, MPV, Incomplete		Limousine	Body	•	•	•	•
(A) 2010 LD Trk, MPV, Incomplete	Cadillac Incomplete	Hearse	Powertrain	•	•	•	•
(A) 2010 LD Trk, MPV, Incomplete		Hearse	Chassis	•	•	•	•
(A) 2010 LD Trk, MPV, Incomplete		Hearse	Body	•	•	•	•
(A) 2010 LD Trk, MPV, Incomplete		N	Control Unit	•	•	•	•
(A) 2010 LD Trk, MPV, Incomplete		K	Escalade Hybrid	•	•	•	•
(A) 2010 LD Trk, MPV, Incomplete		K	Escalade	•	•	•	•
(A) 2010 LD Trk, MPV, Incomplete		С	Escalade Hybrid	•	•	•	•
(A) 2010 LD Trk, MPV, Incomplete		С	Escalade	•	•	•	•
(A) 2010 LD Trk, MPV, Incomplete		V	Powertrain	•	•	•	•
(A) 2010 LD Trk, MPV, Incomplete		V	Chassis	•	•	•	•
(A) 2010 LD Trk, MPV, Incomplete		V	Body	•	•	•	•
(A) 2010 LD Trk, MPV, Incomplete		R	Powertrain	•	•	•	•
(A) 2010 LD Trk, MPV, Incomplete		R	Chassis	•	•	•	•
(A) 2010 LD Trk, MPV, Incomplete		R	Body	•	•	•	•
	G - W62 Series	Powertrain	(G) 8.1L V8 L18	•	•	•	•
(9) 2009 Workhorse	F - R26 Series	Powertrain	(G) 8.1L V8 L18	•	•	•	•
	E - W18 Series	Powertrain	(G) 8.1L V8 L18	•	•	•	•
	E - W16 Series	Powertrain	(G) 8.1L V8 L18	•	•	•	•
		Powertrain	(8) 4.8L V8 LY2	•	•	•	•
	D - W42 Series	Powertrain	(7) 6. 0L V8 LY6	•	•	•	•
	A - W24 Series	Powertrain	(G) 8.1L V8 L18	•	•	•	•
	6 - W22 Series	Powertrain	(G) 8. 1L V8 L18	•	•	•	•
		Chassis	Electronic Brake Control Module	•	•	•	•
	6 - W20 Series	Powertrain	(G) 8. 1L V8 L18	•	•	•	•
	Saturn	Z	Aura Hybrid	•	•	•	•
	Saturn	Z	Aura	•	•	•	•
	Saturn	M	Chassis	•	•	•	•
	Saturn	M	Body	•	•	•	•
	Pontiac	Z	Powertrain	•	•	•	

Year	Menu1	Menu2	Menu3	Menu4		Erase Codes	Live Data	ECU Info.
(9) 2009	Passenger Car	Pontiac	Z	Chassis	•	•	•	•
	Passenger Car	Pontiac	Z	Body	•		•	•
	Passenger Car	Pontiac	T	Wave	•		•	•
	Passenger Car	Pontiac	T	G3				•
	Passenger Car	Pontiac	S	Powertrain	•	•	•	•
	Passenger Car	Pontiac	S	Chassis	•	•	•	•
	Passenger Car	Pontiac	S	Body				
	Passenger Car	Pontiac	M	Chassis				
(9) 2009	Passenger Car	Pontiac	M	Body				•
(9) 2009	Passenger Car	Pontiac	K	Powertrain				
(9) 2009	Passenger Car	Pontiac	K	Chassis	•	•	•	
(9) 2009	Passenger Car	Pontiac	K	Body	•	•	•	•
	Passenger Car	Pontiac	E	Powertrain		•	•	
	Passenger Car	Pontiac	Е	Chassis	•	•	•	•
	Passenger Car	Pontiac	Е	Body	•	•	•	•
	Passenger Car	Pontiac	A	Body	•	•	•	
	Passenger Car	Holden	S	Chassis	•			
	Passenger Car	Holden	S	Body	•	•		•
	Passenger Car	Holden	N	Powertrain	•	•	•	•
	Passenger Car	Holden	N	Chassis	•	•		•
		Holden	N	Body	•	•		•
	Passenger Car	Holden	I	Powertrain	•	•		
	Passenger Car	Holden	I .	Chassis	•	•		•
	Passenger Car	Holden	I .	Body	•		•	•
	Passenger Car	Chevrolet	7	Malibu Hybrid				
	Passenger Car	Chevrolet	7	Malibu Malibu				
	Passenger Car	Chevrolet	V V	Powertrain				
		Chevrolet	y v					
	Passenger Car		Y	Chassis Body			•	
	Passenger Car	Chevrolet	Y W	ž	_	_	_	
	Passenger Car	Chevrolet	W	Powertrain	•	•	•	•
	Passenger Car	Chevrolet	W	Chassis	•	•	•	•
		Chevrolet	<u> </u>	Powertrain	•	•	•	•
		Chevrolet	T m	Chassis	•	•	•	•
(9) 2009	Passenger Car	Chevrolet	T	Body	•	•	•	•
		Chevrolet	S	Chevy	•	•	•	•
		Chevrolet	S	Aveo	•	•	•	•
		Chevrolet	N L	Powertrain	•	•	•	•
		Chevrolet	N	Chassis	•	•		•
		Chevrolet	N	Body	•	•	•	•
	Passenger Car	Chevrolet	L	Powertrain	•	•		•
	Passenger Car	Chevrolet	L	Chassis	•	•	•	•
	Passenger Car	Chevrolet	L	Body	•	•	•	•
	Passenger Car	Chevrolet	K	Spark	•	•	•	•
	Passenger Car	Chevrolet	K	Joy	•	•		•
(9) 2009	Passenger Car	Chevrolet	Ј	Powertrain	•		•	

Year	Menu1	Menu2	Menu3	Menu4		Erase Codes		ECU Info.
(9) 2009	Passenger Car	Chevrolet	J	Chassis	•	•	•	
(9) 2009	Passenger Car	Chevrolet	J	Body	•	•	•	
(9) 2009	Passenger Car	Chevrolet	A	Powertrain	•	•	•	
(9) 2009	Passenger Car	Chevrolet	A	Body	•	•	•	•
(9) 2009	Passenger Car	Cadillac	Y	Powertrain	•	•	•	•
	Passenger Car	Cadillac	Y	Chassis	•	•	•	
	Passenger Car	Cadillac	Y	Body	•	•	•	•
	Passenger Car	Cadillac	K	Powertrain	•	•	•	•
	Passenger Car	Cadillac	K	Chassis	•	•	•	•
(9) 2009	Passenger Car	Cadillac	K	Body	•	•	•	
	Passenger Car	Cadillac	D	STS	•	•	•	
(9) 2009	Passenger Car	Cadillac	D	SLS	•	•	•	
(9) 2009	Passenger Car	Cadillac	D	CTS	•	•	•	•
	Passenger Car	Buick	W	LaCrosse	•	•	•	
	Passenger Car	Buick	W	Allure	•	•	•	
(9) 2009	Passenger Car	Buick	J	Powertrain	•			
(9) 2009	Passenger Car	Buick	J	Chassis	•			
(9) 2009	Passenger Car	Buick	J	Body	•			
	Passenger Car	Buick	Н	Powertrain	•			
(9) 2009	Passenger Car	Buick	Н	Chassis	•			
(9) 2009	Passenger Car	Buick	Н	Body	•			
(9) 2009	Medium Duty Truck	GMC Truck	T - B7 Chassis	Powertrain	•			
(9) 2009	Medium Duty Truck	GMC Truck	T - B7 Chassis	Chassis	•	•		
	Medium Duty Truck	GMC Truck	D - C Series	Powertrain	•			
	Medium Duty Truck	GMC Truck	D - C Series	Chassis	•			
(9) 2009	Medium Duty Truck	GMC Truck	D - C Series	Body	•			
(9) 2009	Medium Duty Truck	GMC Truck	C - WT5500	Powertrain	•			
	Medium Duty Truck	GMC Truck	C - WT5500	Chassis	•			
	Medium Duty Truck	GMC Truck	C - T Series	Powertrain	•			
(9) 2009	Medium Duty Truck	GMC Truck	C - T Series	Chassis	•			
(9) 2009	Medium Duty Truck	GMC Truck	C - T Series	Body	•			
	Medium Duty Truck	GMC Truck	B - W4 Series	Powertrain	•			
(9) 2009	Medium Duty Truck	GMC Truck	B - W4 Series	Chassis	•			
	Medium Duty Truck	GMC Truck	B - W4 Series	Body				
(9) 2009	Medium Duty Truck	Chevrolet Truck	T - B7 Chassis	Powertrain	•			
(9) 2009	Medium Duty Truck	Chevrolet Truck	T - B7 Chassis	Chassis	•		•	
(9) 2009	Medium Duty Truck	Chevrolet Truck	D - C Series	Powertrain	•		•	
(9) 2009	Medium Duty Truck	Chevrolet Truck	D - C Series	Chassis	•	•	•	•
(9) 2009	Medium Duty Truck	Chevrolet Truck	D - C Series	Body	•		•	
(9) 2009	Medium Duty Truck	Chevrolet Truck	C - WT5500	Powertrain	•			
$(9) \ \overline{2009}$	Medium Duty Truck	Chevrolet Truck	C - WT5500	Chassis	•		•	
	Medium Duty Truck	Chevrolet Truck	C - T Series	Powertrain	•		•	
	Medium Duty Truck	Chevrolet Truck	C - T Series	Chassis	•		•	
	Medium Duty Truck	Chevrolet Truck	C - T Series	Body	•		•	
$(9) \ \ 2009$	Medium Duty Truck	Chevrolet Truck	B - W4 Series	Powertrain	•		•	

Year	Menu1	Menu2	Menu3	Menu4	Read I		Live Data	ECU Info.
(9) 2009	Medium Duty Truck	Chevrolet Truck	B - W4 Series	Chassis	•	•	•	
(9) 2009	Medium Duty Truck	Chevrolet Truck	B - W4 Series	Body	•	•	•	
	LD Trk, MPV, Incomplete	Vauxhall	Powertrain	(U) 2. OL L4 LMN	•	•	•	
		Vauxhall	Powertrain	(R) 2. OL L4 LLW	•		•	
		Vauxhall	Powertrain	(P) 3.2L V6 LU1			•	
		Vauxhall	Powertrain	(F) 2.4L L4 LD9				
		Vauxhall	Chassis	Power Steering Control Module				
		Vauxhall	Chassis	Electronic Brake Control Module				•
		Vauxhall	Body	Manual HVAC				
		Vauxhall	Body	Auto. HVAC	•			
		Saturn	V	Powertrain				
		Saturn	V	Chassis	•			
		Saturn	V	Body	•			
		Saturn	R	Powertrain				
		Saturn	R	Chassis				
		Saturn	R	Body				
		Saturn	L	VUE Hybrid				
		Saturn	L	VUE				
		SAAB	Powertrain	(S) 4.2L L6 LL8				
		SAAB	Powertrain	(M) 5.3L V8 LH6				
		SAAB	Powertrain	(H) 6. OL V8 LS2				
		SAAB	Chassis	Electronic Brake Control Module				
		SAAB	Body	Uplevel Radio				
		SAAB	Body	Navigation Radio				
		Pontiac APV	V	Powertrain				
(9) 2009	LD Trk, MPV, Incomplete	Pontiac APV	V	Chassis	•			
(9) 2009	LD Trk, MPV, Incomplete	Pontiac APV	V	Body				
(9) 2009	LD Trk, MPV, Incomplete	Pontiac APV	U	Powertrain	•			
(9) 2009	LD Trk, MPV, Incomplete	Pontiac APV	U	Chassis				
(9) 2009	LD Trk, MPV, Incomplete	Pontiac APV	U	Body				
(9) 2009	LD Trk, MPV, Incomplete	Pontiac APV	L	Powertrain				
(9) 2009	LD Trk, MPV, Incomplete	Pontiac APV	L	Chassis				
(9) 2009	LD Trk, MPV, Incomplete	Pontiac APV	L	Body				
	LD Trk, MPV, Incomplete		Powertrain	(U) 2. OL L4 LMN				
(9) 2009	LD Trk, MPV, Incomplete	Ope1	Powertrain	(R) 2. OL L4 LLW	•	•	•	
	LD Trk, MPV, Incomplete		Powertrain	(P) 3. 2L V6 LU1	•	•	•	
(9) 2009	LD Trk, MPV, Incomplete	Ope1	Powertrain	(F) 2.4L L4 LD9	•	•	•	
		Ope1	Chassis	Power Steering Control Module	•	•	•	
		Ope1	Chassis	Electronic Brake Control Module	•	•	•	
(9) 2009	LD Trk, MPV, Incomplete	Ope1	Body	Manual HVAC	•	•	•	
		Ope1	Body	Auto. HVAC	•	•	•	•
	LD Trk, MPV, Incomplete	Hummer	Hummer H3	ADM	•	•	•	•
(9) 2009	LD Trk, MPV, Incomplete	Hummer	Hummer H3	5GN/5GT	•	•	•	•
(9) 2009	LD Trk, MPV, Incomplete	Hummer	Hummer H2	Powertrain	•	•	•	•
	LD Trk, MPV, Incomplete		Hummer H2	Chassis	•	•	•	

Year Menu1	Menu2	Menu3	Menu4		Erase Codes		ECU Info.
(9) 2009 LD Trk, MPV, Incomplete	Hummer	Hummer H2	Body	•	•	•	•
(9) 2009 LD Trk, MPV, Incomplete		Captiva Maxx	Powertrain		•	•	•
(9) 2009 LD Trk, MPV, Incomplete	Holden	Captiva Maxx	Chassis		•	•	•
(9) 2009 LD Trk, MPV, Incomplete		Captiva Maxx	Body		•		
(9) 2009 LD Trk, MPV, Incomplete		Captiva	Powertrain		•		
(9) 2009 LD Trk, MPV, Incomplete	Holden	Captiva	Body		•		
(9) 2009 LD Trk, MPV, Incomplete	GMC Truck	V	Powertrain		•	•	•
(9) 2009 LD Trk, MPV, Incomplete	GMC Truck	V	Chassis		•	•	•
(9) 2009 LD Trk, MPV, Incomplete	GMC Truck	Т	Envoy		•	•	
(9) 2009 LD Trk, MPV, Incomplete	GMC Truck	Т	Canyon		•	•	
(9) 2009 LD Trk, MPV, Incomplete	GMC Truck	S	Envoy		•	•	
		S	Canyon	•	•	•	•
		R	Powertrain	•	•	•	•
		R	Chassis	•	•	•	•
		R	Body		•	•	
		K	Yukon XL		•		
		K	Yukon Hybrid		•	•	•
		K	Yukon		•	•	•
		K	Sierra Hybrid		•		•
		K	Sierra	•	•		•
		Н	Express/Savana		•		•
		Н	Express Access/Savana Pro	•	•	•	•
(9) 2009 LD Trk, MPV, Incomplete		C	Express/Savana		•	•	•
		G	Express Access/Savana Pro		•	•	•
		n	Powertrain		•		
		n	Chassis		•		
		n	Body		•		
		C	Yukon XL		•		
		C	Yukon Hybrid		•		
(9) 2009 LD Trk, MPV, Incomplete		C	Yukon				
(9) 2009 LD Trk, MPV, Incomplete		C	Sierra Hybrid				•
(9) 2009 LD Trk, MPV, Incomplete		lo	Sierra nybrid Sierra				
(9) 2009 LD Trk, MPV, Incomplete		lv	Powertrain				
		V					
		T	Chassis				-
(9) 2009 LD Trk, MPV, Incomplete		T	TrailBlazer	•			
(9) 2009 LD Trk, MPV, Incomplete		c	Colorado			•	•
(9) 2009 LD Trk, MPV, Incomplete		S C	TrailBlazer	•	•	•	•
(9) 2009 LD Trk, MPV, Incomplete		D D	Colorado	•	•	•	•
(9) 2009 LD Trk, MPV, Incomplete		N P	Powertrain	•	•	•	•
(9) 2009 LD Trk, MPV, Incomplete		N N	Chassis	•	•	•	•
(9) 2009 LD Trk, MPV, Incomplete		IK	Body	•	•	•	•
(9) 2009 LD Trk, MPV, Incomplete		L I-	Equinox	•	•	•	•
(9) 2009 LD Trk, MPV, Incomplete		L L.	Captiva Sport	•	•	•	•
(9) 2009 LD Trk, MPV, Incomplete		K L	Tahoe Hybrid	•	•	•	•
(9) 2009 LD Trk, MPV, Incomplete	Chevrolet Truck	<u>IK</u>	Tahoe		•	•	

Year	Menu1	Menu2	Menu3	Menu4		Erase Codes		ECU Info.
(9) 2009	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Suburban	•	•	•	•
(9) 2009	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Silverado Hybrid		•	•	•
(9) 2009	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Silverado			•	
(9) 2009	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Avalanche			•	
(9) 2009	LD Trk, MPV, Incomplete	Chevrolet Truck	Н	Express/Savana			•	
	LD Trk, MPV, Incomplete		H	Express Access/Savana Pro		•	•	
	LD Trk, MPV, Incomplete		G	Express/Savana		•	•	
	LD Trk, MPV, Incomplete		G	Express Access/Savana Pro		•		
(9) 2009	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Tahoe Hybrid				
	LD Trk, MPV, Incomplete		C	Tahoe				
	LD Trk, MPV, Incomplete		C	Suburban				
	LD Trk, MPV, Incomplete		C	Silverado Hybrid				
(9) 2009	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Silverado				
(9) 2009	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Captiva		•		
	LD Trk, MPV, Incomplete		C	Avalanche		•	•	
	LD Trk, MPV, Incomplete		A	HHR Panel		•	•	
(9) 2009	LD Trk, MPV, Incomplete	Chevrolet Truck	A	HHR (Europe)		•	•	
(9) 2009	LD Trk, MPV, Incomplete	Chevrolet Truck	A	HHR		•	•	
	LD Trk, MPV, Incomplete		V	Powertrain		•	•	
	LD Trk, MPV, Incomplete		V	Chassis		•	•	
	LD Trk, MPV, Incomplete		V	Body		•	•	
(9) 2009	LD Trk, MPV, Incomplete	Chevrolet MPV	U	Powertrain		•	•	
(9) 2009	LD Trk, MPV, Incomplete	Chevrolet MPV	U	Chassis		•	•	
	LD Trk, MPV, Incomplete		U	Body		•	•	
	LD Trk, MPV, Incomplete		C	Powertrain	•		•	
(9) 2009	LD Trk, MPV, Incomplete	Chevrolet MPV	C	Chassis			•	•
(9) 2009	LD Trk, MPV, Incomplete	Chevrolet MPV	C	Body	•		•	•
(9) 2009	LD Trk, MPV, Incomplete	Cadillac Incomplete	Limousine	Powertrain	•		•	
(9) 2009	LD Trk, MPV, Incomplete	Cadillac Incomplete	Limousine	Chassis			•	
(9) 2009	LD Trk, MPV, Incomplete	Cadillac Incomplete	Limousine	Body	•	•	•	•
(9) 2009	LD Trk, MPV, Incomplete	Cadillac Incomplete	Hearse	Powertrain			•	
	LD Trk, MPV, Incomplete		Hearse	Chassis			•	
	LD Trk, MPV, Incomplete		Hearse	Body			•	
(9) 2009	LD Trk, MPV, Incomplete	Cadillac	K	Escalade Hybrid			•	
(9) 2009	LD Trk, MPV, Incomplete	Cadillac	K	Escalade	•	•	•	•
	LD Trk, MPV, Incomplete		E	Powertrain	•	•	•	•
	LD Trk, MPV, Incomplete		E	Chassis	•	•	•	•
	LD Trk, MPV, Incomplete		E	Body	•	•	•	•
(9) 2009	LD Trk, MPV, Incomplete	Cadillac	C	Escalade Hybrid		•	•	
(9) 2009	LD Trk, MPV, Incomplete	Cadillac	C	Escalade		•	•	
(9) 2009	LD Trk, MPV, Incomplete	Buick	V	Powertrain		•	•	•
	LD Trk, MPV, Incomplete		V	Chassis	•	•	•	•
	LD Trk, MPV, Incomplete		V	Body	•	•	•	•
	LD Trk, MPV, Incomplete		R	Powertrain	•	•	•	•
	LD Trk, MPV, Incomplete		R	Chassis	•	•	•	

Year	Menu1	Menu2	Menu3	Menu4		Erase Codes	Live Data	ECU Info.
	LD Trk, MPV, Incomplete		R	Body	•	•	•	
		G - W62 Series	Powertrain	(G) 8.1L V8 L18		•	•	
	Workhorse	F - R26 Series	Powertrain	(G) 8.1L V8 L18		•	•	
		E - W18 Series	Powertrain	(G) 8.1L V8 L18		•	•	
		E - W16 Series	Powertrain	(G) 8.1L V8 L18		•	•	
		D - W42 Series	Powertrain	(8) 4.8L V8 LY2		•	•	
		D - W42 Series	Powertrain	(7) 6. OL V8 LY6		•		
	Workhorse	A - W24 Series	Powertrain	(G) 8.1L V8 L18				
		6 - W22 Series	Powertrain	(G) 8.1L V8 L18		•		
		6 - W22 Series	Chassis	Electronic Brake Control Module		lacktriangle		
(8) 2008	Workhorse	6 - W20 Series	Powertrain	(G) 8.1L V8 L18		•		
(8) 2008	Passenger Car	Saturn	Z	Aura Hybrid		•	•	
(8) 2008	Passenger Car	Saturn	Z	Aura		•	•	
(8) 2008	Passenger Car	Saturn	M	Chassis	•	•	•	
(8) 2008	Passenger Car	Saturn	M	Body		•	•	
	Passenger Car	Pontiac	Z	Powertrain	•	•	•	•
	Passenger Car	Pontiac	Z	Chassis	•	•	•	•
	Passenger Car	Pontiac	Z	Body	•	•	•	•
	Passenger Car	Pontiac	W	Powertrain		•		
	Passenger Car	Pontiac	W	Chassis	•	•	•	
	Passenger Car	Pontiac	T	Wave	•	•		•
	Passenger Car	Pontiac	Т	G3		•		
	Passenger Car	Pontiac	S	Powertrain		•		
	Passenger Car	Pontiac	S	Body		•		•
	Passenger Car	Pontiac	M	Chassis		•		•
	Passenger Car	Pontiac	M	Body		•		•
	Passenger Car	Pontiac	E IN	Powertrain Powertrain		•		
	Passenger Car	Pontiac	E E	Chassis		•		
	Passenger Car	Pontiac	Λ	Body		•		
	Passenger Car	Holden	C	Powertrain Powertrain				
		Holden	C C	Chassis				
		Holden	C C	Body				
		Holden	M					
		Holden	N N	Powertrain Chassis				
(8) 2008	Pagangan Con	Holden Holden	N N	Chassis Body				
			IV I		•			
		Holden	L	Powertrain	•	•	•	•
		Holden	L	Chassis	•	•	•	•
		Holden	L	Body	•	•	•	•
	Passenger Car	Chevrolet		Malibu Hybrid	•	•	•	•
	Passenger Car	Chevrolet	<u>Z</u>	Malibu	•	•	•	•
	Passenger Car	Chevrolet	<u>Z</u>	Classic	•	•	•	•
	Passenger Car	Chevrolet	Y 	Chassis	•	•	•	•
	Passenger Car	Chevrolet	W	Powertrain	•	•	•	•
		Chevrolet	W	Chassis	•	•	•	•
(8) 2008	Passenger Car	Chevrolet	<u>U</u>	Powertrain		•	•	

Year	Menu1	Menu2	Menu3	Menu4		Erase Codes		ECU Info.
(8) 2008	Passenger Car	Chevrolet	U	Chassis	•	•	•	•
	Passenger Car	Chevrolet	U	Body	•	•	•	•
	Passenger Car	Chevrolet	T	Powertrain	•		•	
	Passenger Car	Chevrolet	T	Chassis	•	•	•	•
	Passenger Car	Chevrolet	S	Chevy	•	•	•	•
	Passenger Car	Chevrolet	S	Aveo	•	•	•	•
	Passenger Car	Chevrolet	N	Powertrain	•	•	•	•
	Passenger Car	Chevrolet	N	Chassis	•	•	•	•
	Passenger Car	Chevrolet	L	Powertrain	•	•	•	•
	Passenger Car	Chevrolet	L	Chassis	•	•	•	•
	Passenger Car	Chevrolet	L	Body	•		•	•
	Passenger Car	Chevrolet	K	Spark	•		•	•
	Passenger Car	Chevrolet	K	Joy	•		•	•
	Passenger Car	Chevrolet	J	Powertrain				
	Passenger Car	Chevrolet	J	Chassis				
	Passenger Car	Chevrolet	A	Powertrain				
(8) 2008	Passenger Car	Chevrolet	A	Body				
(8) 2008	Passenger Car	Cadillac	Y	Powertrain				
(8) 2008	Passenger Car	Cadillac	Y	Chassis			•	
(8) 2008	Passenger Car	Cadillac	Y	Body				
(8) 2008	Passenger Car	Cadillac	K	Powertrain			•	
(8) 2008	Passenger Car	Cadillac	K	Chassis	•		•	
(8) 2008	Passenger Car	Cadillac	D	STS			•	
(8) 2008	Passenger Car	Cadillac	D	SLS	•		•	
(8) 2008	Passenger Car	Cadillac	D	CTS			•	
	Passenger Car	Buick	W	LaCrosse			•	
	Passenger Car	Buick	W	Allure	•		•	
	Passenger Car	Buick	J	Powertrain	•		•	
	Passenger Car	Buick	J	Chassis	•		•	•
	Passenger Car	Buick	Н	Powertrain	•	•	•	•
	Passenger Car	Buick	Н	Chassis	•		•	•
	Medium Duty Truck	GMC Truck	T - B7 Chassis	Powertrain	•	•	•	•
(8) 2008	Medium Duty Truck	GMC Truck	T - B7 Chassis	Chassis	•	•	•	•
	Medium Duty Truck	GMC Truck	D - C Series	Powertrain	•	•	•	•
	Medium Duty Truck	GMC Truck	D - C Series	Chassis	•	•	•	•
	Medium Duty Truck	GMC Truck	D - C Series	Body	•	•	•	•
	Medium Duty Truck	GMC Truck	C - WT5500	Powertrain	•	•	•	•
	Medium Duty Truck	GMC Truck	C - WT5500	Chassis	•	•	•	•
	Medium Duty Truck	GMC Truck	C - T Series	Powertrain	•	•	•	•
	Medium Duty Truck	GMC Truck	C - T Series	Chassis	•	•	•	•
	Medium Duty Truck	GMC Truck	C - T Series	Body	•	•	•	•
	Medium Duty Truck	GMC Truck	B - W4 Series	Powertrain	•	•	•	•
	Medium Duty Truck	GMC Truck	B - W4 Series	Chassis		•	•	
	Medium Duty Truck	GMC Truck	B - W4 Series	Body	•	•	•	
	Medium Duty Truck	Chevrolet Truck	T - B7 Chassis	Powertrain				

Year Menu1	Menu2	Menu3	Menu4	Read Eras		ECU Info.
(8) 2008 Medium Duty Truck	Chevrolet Truck	T - B7 Chassis	Chassis	• •	Data	•
(8) 2008 Medium Duty Truck	Chevrolet Truck	D - C Series	Powertrain	0 0		
(8) 2008 Medium Duty Truck	Chevrolet Truck	D - C Series	Chassis	0 0		
(8) 2008 Medium Duty Truck	Chevrolet Truck	D - C Series	Body	• •	•	•
(8) 2008 Medium Duty Truck	Chevrolet Truck	C - WT5500	Powertrain	• •	•	•
(8) 2008 Medium Duty Truck	Chevrolet Truck	C - WT5500	Chassis	• •	•	•
(8) 2008 Medium Duty Truck	Chevrolet Truck	C - T Series	Powertrain	• •	•	
(8) 2008 Medium Duty Truck	Chevrolet Truck	C - T Series	Chassis	• •	•	
(8) 2008 Medium Duty Truck	Chevrolet Truck	C - T Series	Body	• •	•	
(8) 2008 Medium Duty Truck	Chevrolet Truck	B - W4 Series	Powertrain	• •		
(8) 2008 Medium Duty Truck	Chevrolet Truck	B - W4 Series	Chassis	• •	•	
(8) 2008 Medium Duty Truck	Chevrolet Truck	B - W4 Series	Body	• •	•	
(8) 2008 LD Trk, MPV, Incom	mplete Vauxhall	Powertrain	(U) 2.0L L4 LMN	• •		
(8) 2008 LD Trk, MPV, Incom		Powertrain	(R) 2.0L L4 LLW	• •		
(8) 2008 LD Trk, MPV, Incom		Powertrain	(P) 3.2L V6 LU1	• •		
(8) 2008 LD Trk, MPV, Incom		Powertrain	(F) 2.4L L4 LD9	• •		
(8) 2008 LD Trk, MPV, Incom	mplete Vauxhall	Chassis	Power Steering Control Module	• •		
(8) 2008 LD Trk, MPV, Incom	mplete Vauxhall	Chassis	Electronic Brake Control Module	• •		
(8) 2008 LD Trk, MPV, Incom		Body	Manual HVAC	• •	•	•
(8) 2008 LD Trk, MPV, Incom		Body	Auto. HVAC	• •	•	•
(8) 2008 LD Trk, MPV, Incom		V	Powertrain	• •	•	
(8) 2008 LD Trk, MPV, Incom		V	Chassis	• •	•	
(8) 2008 LD Trk, MPV, Incom		V	Body	• •	•	•
(8) 2008 LD Trk, MPV, Incom		R	Powertrain	• •	•	•
(8) 2008 LD Trk, MPV, Incom		R	Chassis	• •	•	•
(8) 2008 LD Trk, MPV, Incom		R	Body	• •	•	•
(8) 2008 LD Trk, MPV, Incom		L	VUE Hybrid	• •	•	
(8) 2008 LD Trk, MPV, Incom		L	VUE	• •	•	
	nplete SAAB	Powertrain	(S) 4.2L L6 LL8	• •	•	
(8) 2008 LD Trk, MPV, Incom		Powertrain	(M) 5.3L V8 LH6	• •	•	•
(8) 2008 LD Trk, MPV, Incom		Powertrain	(H) 6. OL V8 LS2	• •	•	•
(8) 2008 LD Trk, MPV, Incom		Chassis	Electronic Brake Control Module	• •	•	•
(8) 2008 LD Trk, MPV, Incom		Body	Uplevel Radio	• •	•	•
(8) 2008 LD Trk, MPV, Incom		Body	Navigation Radio	• •	•	•
(8) 2008 LD Trk, MPV, Incom		V	Powertrain	• •	•	
(8) 2008 LD Trk, MPV, Incom		V	Chassis	• •	•	•
(8) 2008 LD Trk, MPV, Incom		V	Body	• •	•	•
(8) 2008 LD Trk, MPV, Incom		U	Powertrain	• •	•	•
(8) 2008 LD Trk, MPV, Incom		U	Chassis	• •	•	•
(8) 2008 LD Trk, MPV, Incom		U	Body	• •	•	•
(8) 2008 LD Trk, MPV, Incom		L -	Powertrain	• •	•	
(8) 2008 LD Trk, MPV, Incom		L	Chassis	• •	•	•
(8) 2008 LD Trk, MPV, Incom		L	Body	• •	•	•
(8) 2008 LD Trk, MPV, Incom		Powertrain	(U) 2. OL L4 LMN	• •	—	
(8) 2008 LD Trk, MPV, Incom	nplete Opel	Powertrain	(R) 2. OL L4 LLW	• •		

Year	Menu1	Menu2	Menu3	Menu4		Erase Codes		ECU Info.
(8) 2008	LD Trk, MPV, Incomplete	One1	Powertrain	(P) 3.2L V6 LU1	•	•	•	
	LD Trk, MPV, Incomplete		Powertrain	(F) 2. 4L L4 LD9	•	•	•	•
	LD Trk, MPV, Incomplete		Chassis	Power Steering Control Module			•	•
	LD Trk, MPV, Incomplete		Chassis	Electronic Brake Control Module			•	
	LD Trk, MPV, Incomplete		Body	Manual HVAC	•	•	•	
		Ope1	Body	Auto. HVAC	•	•	•	•
	LD Trk, MPV, Incomplete		Hummer H3	ADM	•	•	•	•
		Hummer	Hummer H3	5GT	•	•	•	•
	LD Trk, MPV, Incomplete		Hummer H2	Powertrain	•	•	•	•
(8) 2008	LD Trk, MPV, Incomplete	Hummer	Hummer H2	Chassis		•	•	
(8) 2008	LD Trk, MPV, Incomplete	Hummer	Hummer H2	Body		•	•	
	LD Trk, MPV, Incomplete		Captiva Maxx	Powertrain	•	•	•	•
		Holden	Captiva Maxx	Chassis	•	•	•	•
	LD Trk, MPV, Incomplete	Holden	Captiva Maxx	Body	•	•	•	•
	LD Trk, MPV, Incomplete		Captiva	Powertrain	•	•	•	•
		Holden	Captiva	Body	•	•	•	•
	LD Trk, MPV, Incomplete		V	Powertrain	•	•	•	•
	LD Trk, MPV, Incomplete		V	Chassis	•	•	•	•
	LD Trk, MPV, Incomplete		Т	Envoy	•	•	•	•
	LD Trk, MPV, Incomplete		T	Canyon	•	•	•	•
		GMC Truck	S	Envoy	•	•	•	•
	LD Trk, MPV, Incomplete		S	Canyon	•	•	•	•
	LD Trk, MPV, Incomplete		R	Powertrain	•	•	•	•
	LD Trk, MPV, Incomplete		R	Chassis	•	•	•	•
		GMC Truck	R	Body	•	•	•	•
	LD Trk, MPV, Incomplete		K	Yukon XL	•	•	•	•
	LD Trk, MPV, Incomplete		K	Yukon Hybrid	•	•	•	•
	LD Trk, MPV, Incomplete		K	Yukon	•	•	•	•
		GMC Truck	K	Sierra	•	•	•	•
		GMC Truck	Н	Express/Savana	•	•	•	•
	LD Trk, MPV, Incomplete	GMC Truck	Н	Express Access/Savana Pro	•	•	•	•
	LD Trk, MPV, Incomplete		G	Express/Savana	•	•	•	•
	LD Trk, MPV, Incomplete		G	Express Access/Savana Pro	•	•	•	•
	LD Trk, MPV, Incomplete		D	Powertrain	•	•	•	•
	LD Trk, MPV, Incomplete		D	Chassis	•	•	•	•
	LD Trk, MPV, Incomplete		D	Body	•	•	•	•
	LD Trk, MPV, Incomplete		С	Yukon XL	•	•	•	•
	LD Trk, MPV, Incomplete		С	Yukon Hybrid	•	•	•	•
	LD Trk, MPV, Incomplete		С	Yukon	•	•	•	•
	LD Trk, MPV, Incomplete		С	Sierra	•	•	•	•
	LD Trk, MPV, Incomplete		Т	TrailBlazer	•	•	•	•
	LD Trk, MPV, Incomplete		Т	Colorado	•	•	•	•
	LD Trk, MPV, Incomplete		S	TrailBlazer	•	•	•	•
	LD Trk, MPV, Incomplete		S	Colorado	•	•	•	•
	LD Trk, MPV, Incomplete		L	Equinox	•	•	•	•

Year Menul	Menu2	Menu3	Menu4	Read codes			ECU Info.
(8) 2008 LD Trk, MPV, Incomplete	Chevrolet Truck	L	Captiva Sport		•	•	•
(8) 2008 LD Trk, MPV, Incomplete	Chevrolet Truck	K	Tahoe Hybrid		•	•	•
(8) 2008 LD Trk, MPV, Incomplete	Chevrolet Truck	K	Tahoe				
(8) 2008 LD Trk, MPV, Incomplete	Chevrolet Truck	K	Suburban				
(8) 2008 LD Trk, MPV, Incomplete	Chevrolet Truck	K	Silverado				
(8) 2008 LD Trk, MPV, Incomplete	Chevrolet Truck	K	Avalanche			•	
(8) 2008 LD Trk, MPV, Incomplete		H	Express/Savana			•	
(8) 2008 LD Trk, MPV, Incomplete		H	Express Access/Savana Pro			•	
(8) 2008 LD Trk, MPV, Incomplete		G	Express/Savana		•		
(8) 2008 LD Trk, MPV, Incomplete		G	Express Access/Savana Pro		•		
(8) 2008 LD Trk, MPV, Incomplete		C	Tracker		•		
(8) 2008 LD Trk, MPV, Incomplete		C	Tahoe Hybrid		•		
(8) 2008 LD Trk, MPV, Incomplete		C	Tahoe		•		
(8) 2008 LD Trk, MPV, Incomplete		C	Suburban			•	
(8) 2008 LD Trk, MPV, Incomplete		C	Silverado			•	
(8) 2008 LD Trk, MPV, Incomplete		C	Captiva			•	
(8) 2008 LD Trk, MPV, Incomplete	Chevrolet Truck	C	Avalanche			•	
(8) 2008 LD Trk, MPV, Incomplete	Chevrolet Truck	A	Tracker			•	
(8) 2008 LD Trk, MPV, Incomplete		A	HHR Panel			•	
(8) 2008 LD Trk, MPV, Incomplete		A	HHR (Europe)			•	
(8) 2008 LD Trk, MPV, Incomplete		A	HHR				
(8) 2008 LD Trk, MPV, Incomplete	Chevrolet MPV	V	Powertrain			•	
(8) 2008 LD Trk, MPV, Incomplete		V	Chassis			•	
(8) 2008 LD Trk, MPV, Incomplete		U	Powertrain			•	
(8) 2008 LD Trk, MPV, Incomplete	Chevrolet MPV	U	Chassis			•	
(8) 2008 LD Trk, MPV, Incomplete	Cadillac Incomplete	Limousine	Powertrain				•
(8) 2008 LD Trk, MPV, Incomplete	Cadillac Incomplete	Limousine	Chassis			•	•
(8) 2008 LD Trk, MPV, Incomplete	Cadillac Incomplete	Limousine	Body			•	
(8) 2008 LD Trk, MPV, Incomplete	Cadillac Incomplete	Hearse	Powertrain				
(8) 2008 LD Trk, MPV, Incomplete	Cadillac Incomplete	Hearse	Chassis		•	•	•
(8) 2008 LD Trk, MPV, Incomplete	Cadillac Incomplete	Hearse	Body				
(8) 2008 LD Trk, MPV, Incomplete		K	Powertrain				
(8) 2008 LD Trk, MPV, Incomplete		K	Body				
(8) 2008 LD Trk, MPV, Incomplete	Cadillac	E	Powertrain		•	•	•
(8) 2008 LD Trk, MPV, Incomplete	Cadillac	E	Chassis		•	•	•
(8) 2008 LD Trk, MPV, Incomplete		E	Body		•	•	•
(8) 2008 LD Trk, MPV, Incomplete	Cadillac	C	Powertrain		•	•	•
(8) 2008 LD Trk, MPV, Incomplete	Cadillac	C	Body	•	•	•	
(8) 2008 LD Trk, MPV, Incomplete		V	Powertrain	•	•	•	•
(8) 2008 LD Trk, MPV, Incomplete		V	Chassis	•	•	•	•
(8) 2008 LD Trk, MPV, Incomplete		V	Body	•	•	•	•
(8) 2008 LD Trk, MPV, Incomplete		R	Powertrain	•	•	•	•
(8) 2008 LD Trk, MPV, Incomplete		R	Chassis	•	•	•	•
(8) 2008 LD Trk, MPV, Incomplete	Buick	R	Body	•	•	•	•
(7) 2007 Workhorse	G - W62 Series	Powertrain	(G) 8.1L V8 L18	•	•	•	•

Year	Menu1	Menu2	Menu3	Menu4		Erase Codes	Live Data	ECU Info.
	Workhorse	F - R26 Series	Powertrain	(G) 8.1L V8 L18	•	•	•	•
	Workhorse	E - W18 Series	Powertrain	(U) 6.0L V8 LQ4	•	•	•	•
	Workhorse	E - W18 Series	Powertrain	(G) 8.1L V8 L18	•	•	•	•
	Workhorse	E - W16 Series	Powertrain	(G) 8.1L V8 L18	•	•	•	•
	Workhorse	D - W42 Series	Powertrain	(V) 4.8L V8 LR4	•	•	•	•
	Workhorse	D - W42 Series	Powertrain	(U) 6.0L V8 LQ4	•	•	•	•
	Workhorse	A - W25 Series	Powertrain	(G) 8.1L V8 L18	•	•	•	•
	Workhorse	A - W24 Series	Powertrain	(G) 8.1L V8 L18		•	•	•
	Workhorse	6 - W22 Series	Powertrain	(G) 8.1L V8 L18	•	•	•	•
	Workhorse	6 - W22 Series	Chassis	Electronic Brake Control Module	•	•	•	•
	Passenger Car	(8) Saturn	Z	Aura Hybrid		•	•	•
	Passenger Car	(8) Saturn	Z	Aura		•	•	
(7) 2007	Passenger Car	(8) Saturn	M	Chassis		•	•	
(7) 2007	Passenger Car	(8) Saturn	M	Body	•	•	•	•
(7) 2007	Passenger Car	(8) Saturn	A	Powertrain				•
(7) 2007	Passenger Car	(8) Saturn	A	Chassis		•		
(7) 2007	Passenger Car	(8) Saturn	A	Body		•	•	•
(7) 2007	Passenger Car	(6) Cadillac	Y	(YX) XLR-V		•	•	
	Passenger Car	(6) Cadillac	Y	(YV) XLR	•	•	•	•
	Passenger Car	(6) Cadillac	K	Powertrain	•	•	•	•
	Passenger Car	(6) Cadillac	K	Chassis		•	•	•
	Passenger Car	(6) Cadillac	D	(DX) STS-V		•	•	•
	Passenger Car	(6) Cadillac	D	(DW) STS		•	•	
	Passenger Car	(6) Cadillac	D	(DR) CTS		•	•	
	Passenger Car	(6) Cadillac	D	(DP) CTS	•	•	•	•
	Passenger Car	(6) Cadillac	D	(DN) CTS-V	•	•	•	•
	Passenger Car	(6) Cadillac	D	(DM) CTS	•	•	•	•
	Passenger Car	(6) Cadillac	D	(DC) STS-V8	•	•	•	•
	Passenger Car	(4) Buick	W	LaCrosse	•	•	•	•
	Passenger Car	(4) Buick	W	Allure	•	•	•	•
	Passenger Car	(4) Buick	Н	Powertrain	•	•	•	•
	Passenger Car	(4) Buick	Н	Chassis		•	•	•
	Passenger Car	(3) Holden	Powertrain	(R) 2. OL L4 LLW		•	•	•
	Passenger Car	(3) Holden	Chassis	Electronic Brake Control Module	•	•	•	•
(7) 2007	Passenger Car	(3) Holden	Body	Supplemental Inflatable Restraint	•	•	•	
	Passenger Car	(3) Holden	Body	ISU	•	•	•	
	Passenger Car	(2) Pontiac	7	Powertrain	•	•	•	•
	Passenger Car	(2) Pontiac	7.	Chassis		•	•	
	Passenger Car	(2) Pontiac	W	Powertrain		•	•	
	Passenger Car	(2) Pontiac	W	Chassis		•	•	
	Passenger Car	(2) Pontiac	T					•
		(2) Ponting	T	Wave G3				
	Passenger Car	(2) Pontiac	C					_
	Passenger Car	(2) Pontiac	S C	Powertrain	•	•	•	•
	Passenger Car	(2) Pontiac	5	Chassis	•	•	•	•
(7) 2007	Passenger Car	(2) Pontiac	2	Body		•		

Year	Menu1	Menu2	Menu3	Menu4		Erase Codes		ECU Info.
(7) 2007	Passenger Car	(2) Pontiac	M	Chassis		•	•	
	Passenger Car	(2) Pontiac	M	Body				
(7) 2007	Passenger Car	(2) Pontiac	A	Chassis				
(7) 2007	Passenger Car	(2) Pontiac	A	Body				
(7) 2007	Passenger Car	(1) Chevrolet	Z	Powertrain				
(7) 2007	Passenger Car	(1) Chevrolet	Z	Chassis				
(7) 2007	Passenger Car	(1) Chevrolet	Y	Chassis				
(7) 2007	Passenger Car	(1) Chevrolet	W	WU Impala LTZ				
(7) 2007	Passenger Car	(1) Chevrolet	W	WT Impala LT 3.5 Sedan		•	•	
(7) 2007	Passenger Car	(1) Chevrolet	W	WS Impala Police Sedan		•	•	•
(7) 2007	Passenger Car	(1) Chevrolet	W	WL Monte Carlo SS			•	
	Passenger Car	(1) Chevrolet	W	WK Monte Carlo LT	•	•	•	•
	Passenger Car	(1) Chevrolet	W	W.J Monte Carlo LS	•	•	•	•
	Passenger Car	(1) Chevrolet	W	WD Impala SS		•	•	
	Passenger Car	(1) Chevrolet	W	WC Impala LT				
	Passenger Car	(1) Chevrolet	W	WB Impala LS		•		
	Passenger Car	(1) Chevrolet	V	Powertrain	•	•	•	•
	Passenger Car	(1) Chevrolet	V	Chassis		•		
	Passenger Car	(1) Chevrolet	V	Body		•		•
	Passenger Car	(1) Chevrolet	II	Powertrain				•
	Passenger Car	(1) Chevrolet	II	Chassis				
	Passenger Car	(1) Chevrolet	II	Body				
	Passenger Car	(1) Chevrolet	<u>Γ</u>	Chassis				
	Passenger Car	(1) Chevrolet	C	Chevy				
			S .				•	
	Passenger Car	(1) Chevrolet	N N	Aveo			•	
	Passenger Car	(1) Chevrolet	IN T	Powertrain			•	
	Passenger Car	(1) Chevrolet	L	Chassis	•	•	•	•
	Passenger Car	(1) Chevrolet	L	Body	•	•	•	•
	Passenger Car	(1) Chevrolet	K	Body	•	•	•	•
	Passenger Car	(1) Chevrolet	J	Powertrain	•	•	•	•
	Passenger Car	(1) Chevrolet	A	Powertrain	•	•	•	•
	Passenger Car	(1) Chevrolet	A	Chassis	•	•		•
	Passenger Car	(1) Chevrolet	A	Body	•	•		•
	Medium Duty Truck	(T) GMC Truck	T - B7 Chassis	Powertrain	•	•	•	•
		(T) GMC Truck	T - B7 Chassis	Chassis	•	•	•	•
	Medium Duty Truck	(T) GMC Truck	D - C Series	Powertrain	•	•		•
	Medium Duty Truck	(T) GMC Truck	D - C Series	Chassis		•		•
	Medium Duty Truck	(T) GMC Truck	D - C Series	Body	•	•	•	•
	Medium Duty Truck	(T) GMC Truck	C - WT5500	Powertrain	•	•	•	•
(7) 2007	Medium Duty Truck	(T) GMC Truck	C - WT5500	Chassis	•		•	•
(7) 2007	Medium Duty Truck	(T) GMC Truck	C - T Series	Powertrain			•	
(7) 2007	Medium Duty Truck	(T) GMC Truck	C - T Series	Chassis			•	
	Medium Duty Truck	(T) GMC Truck	C - T Series	Body	•		•	
	Medium Duty Truck	(T) GMC Truck	B - W4 Series	Powertrain	•	•	•	•
	Medium Duty Truck	(T) GMC Truck	B - W4 Series	Chassis	•	•	•	

Year	Menu1	Menu2	Menu3	Menu4	Read codes	Erase Codes	Live Data	ECU Info.
(7) 2007	Medium Duty Truck	(C) Chevrolet Truck	T - B7 Chassis	Powertrain	•	•	•	•
(7) 2007	Medium Duty Truck	(C) Chevrolet Truck	T - B7 Chassis	Chassis	•	•	•	•
(7) 2007	Medium Duty Truck	(C) Chevrolet Truck	D - C Series	Powertrain		•	•	
(7) 2007	Medium Duty Truck	(C) Chevrolet Truck	D - C Series	Chassis		•	•	
(7) 2007	Medium Duty Truck	(C) Chevrolet Truck	D - C Series	Body		•	•	
(7) 2007	Medium Duty Truck	(C) Chevrolet Truck	C - WT5500	Powertrain				
(7) 2007	Medium Duty Truck	(C) Chevrolet Truck	C - WT5500	Chassis				
	Medium Duty Truck	(C) Chevrolet Truck	C - T Series	Powertrain	•	•	•	
	Medium Duty Truck	(C) Chevrolet Truck	C - T Series	Chassis	•	•	•	
(7) 2007	Medium Duty Truck	(C) Chevrolet Truck	C - T Series	Body				
(7) 2007	Medium Duty Truck	(C) Chevrolet Truck	B - W4 Series	Powertrain				
(7) 2007	Medium Duty Truck	(C) Chevrolet Truck	B - W4 Series	Chassis		•		
(7) 2007	LD Trk, MPV, Incomplete	Saturn	Ζ	VUE Hybrid		•		
	LD Trk, MPV, Incomplete	Saturn	Ζ	VUE		•		
		Saturn	V	Relay				
(7) 2007	LD Trk, MPV, Incomplete	Saturn	V	Outlook		lacktriangle		
(7) 2007	LD Trk, MPV, Incomplete	Saturn	R	Powertrain		•		
(7) 2007	LD Trk, MPV, Incomplete	Saturn	R	Chassis		lacktriangle		
		SAAB	Powertrain	(S) 4.2L L6 LL8		•		
(7) 2007	LD Trk, MPV, Incomplete	SAAB	Powertrain	(M) 5.3L V8 LH6		•		
(7) 2007	LD Trk, MPV, Incomplete	SAAB	Chassis	Electronic Brake Control Module		•		
(7) 2007	LD Trk, MPV, Incomplete	SAAB	Body	Uplevel Radio		•		
(7) 2007	LD Trk, MPV, Incomplete	SAAB	Body	Navigation Radio		lacktriangle		
(7) 2007	LD Trk, MPV, Incomplete	Pontiac APV	V	Powertrain		•		
(7) 2007	LD Trk, MPV, Incomplete	Pontiac APV	V	Chassis		lacktriangle		
(7) 2007	LD Trk, MPV, Incomplete	Pontiac APV	U	Powertrain				
(7) 2007	LD Trk, MPV, Incomplete	Pontiac APV	U	Chassis		•		
(7) 2007	LD Trk, MPV, Incomplete	Pontiac APV	L	Powertrain		lacktriangle		
(7) 2007	LD Trk, MPV, Incomplete	Pontiac APV	L	Body		•		
(7) 2007	LD Trk, MPV, Incomplete	Hummer	Hummer H3	ADM		•		
		Hummer	Hummer H3	5GT				
		Hummer	Hummer H2	Powertrain				
(7) 2007	LD Trk, MPV, Incomplete	GMC Truck	V	Powertrain		•		
		GMC Truck	V	Chassis		•		
(7) 2007	LD Trk, MPV, Incomplete	GMC Truck	T	Envoy				
	LD Trk, MPV, Incomplete		T	Canyon				
(7) 2007	LD Trk, MPV, Incomplete	GMC Truck	S	Envoy		lacktriangle		
(7) 2007	LD Trk, MPV, Incomplete	GMC Truck	S	Canyon	•	•	•	
(7) 2007	LD Trk, MPV, Incomplete	GMC Truck	R	Powertrain	•	•	•	•
(7) 2007	LD Trk, MPV, Incomplete	GMC Truck	R	Chassis	•	•	•	•
		GMC Truck	P	Powertrain	•	•	•	
(7) 2007	LD Trk, MPV, Incomplete	GMC Truck	P	Body	•	•	•	
(7) 2007	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon XL	•	•	•	
(7) 2007	LD Trk, MPV, Incomplete	GMC Truck	K	Yukon	•	•	•	•
(7) 2007	LD Trk, MPV, Incomplete	GMC Truck	K	Sierra Classic		•	•	

Year	Menu1	Menu2	Menu3	Menu4				ECU Info.
(7) 2007	LD Trk, MPV, Incomplete	GMC Truck	K	Sierra	•	•	•	•
	LD Trk, MPV, Incomplete		Н	Express/Savana	•	•	•	•
	LD Trk, MPV, Incomplete	GMC Truck	Н	Express Access/Savana Pro	•	•	•	•
(7) 2007	LD Trk, MPV, Incomplete	GMC Truck	G	Express/Savana	•	•	•	•
		GMC Truck	G	Express Access/Savana Pro	•		•	
		GMC Truck	C	Yukon XL	•	•	•	
		GMC Truck	C	Yukon		•	•	
		GMC Truck	C	Sierra Classic		•		
		GMC Truck	C	Sierra				
	LD Trk, MPV, Incomplete		T	TrailBlazer				
	LD Trk, MPV, Incomplete		T	Colorado				
	LD Trk, MPV, Incomplete		S	TrailBlazer				
	LD Trk, MPV, Incomplete		S	Colorado	•			
	LD Trk, MPV, Incomplete		P	Powertrain				
	LD Trk, MPV, Incomplete		P	Body		•	•	
(7) 2007	LD Trk, MPV, Incomplete	Chevrolet Truck	L	Body		•	•	
	LD Trk, MPV, Incomplete		K	Tahoe		•	•	
(7) 2007	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Suburban		•	•	
	LD Trk, MPV, Incomplete		K	Silverado Classic		•	•	
(7) 2007	LD Trk, MPV, Incomplete	Chevrolet Truck	K	Avalanche		•	•	
	LD Trk, MPV, Incomplete		J	Powertrain		•	•	
(7) 2007	LD Trk, MPV, Incomplete	Chevrolet Truck	J	Chassis		•	•	
	LD Trk, MPV, Incomplete		J	Body		•	•	
	LD Trk, MPV, Incomplete		G	Express/Savana		•	•	
	LD Trk, MPV, Incomplete		G	Express Access/Savana Pro	•	•	•	
	LD Trk, MPV, Incomplete		E	Powertrain	•		•	•
(7) 2007	LD Trk, MPV, Incomplete	Chevrolet Truck	E	Chassis	•		•	•
	LD Trk, MPV, Incomplete		E	Body	•		•	•
	LD Trk, MPV, Incomplete		C	Tahoe	•		•	
	LD Trk, MPV, Incomplete		C	Suburban	•		•	
(7) 2007	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Silverado Classic	•		•	
	LD Trk, MPV, Incomplete		C	Silverado	•		•	
(7) 2007	LD Trk, MPV, Incomplete	Chevrolet Truck	C	Avalanche	•		•	
	LD Trk, MPV, Incomplete		A	Chassis	•		•	
(7) 2007	LD Trk, MPV, Incomplete	Chevrolet Truck	A	Body	•		•	
	LD Trk, MPV, Incomplete		V	Powertrain	•	•	•	•
(7) 2007	LD Trk, MPV, Incomplete	Chevrolet MPV	V	Chassis	•	•	•	•
	LD Trk, MPV, Incomplete		U	Powertrain	•	•	•	•
(7) 2007	LD Trk, MPV, Incomplete	Chevrolet MPV	U	Chassis		•	•	
(7) 2007	LD Trk, MPV, Incomplete	Cadillac Incomplete	Limousine	Powertrain	•	•	•	
(7) 2007	LD Trk, MPV, Incomplete	Cadillac Incomplete	Limousine	Chassis	•	•	•	•
	LD Trk, MPV, Incomplete		Limousine	Body	•	•	•	•
	LD Trk, MPV, Incomplete		Hearse	Powertrain	•	•	•	•
	LD Trk, MPV, Incomplete		Hearse	Chassis	•	•	•	•
	LD Trk, MPV, Incomplete		Hearse	Body	•	•	•	

Year Menu1	Menu2	Menu3	Menu4		Erase Codes		ECU Info.
(7) 2007 LD Trk, MPV, Incomplet	e Cadillac	K	Powertrain	•	•		
(7) 2007 LD Trk, MPV, Incomplet	e Cadillac	K	Chassis	•	•		
(7) 2007 LD Trk, MPV, Incomplet	e Cadillac	K	Body	•			
(7) 2007 LD Trk, MPV, Incomplet	e Cadillac	Е	Powertrain	•			
(7) 2007 LD Trk, MPV, Incomplet	e Cadillac	E	Chassis	•			
(7) 2007 LD Trk, MPV, Incomplet	e Cadillac	Е	Body	•		•	
(7) 2007 LD Trk, MPV, Incomplet	e Cadillac	C	Powertrain	•		•	
(7) 2007 LD Trk, MPV, Incomplet	e Cadillac	C	Chassis	•		•	
(7) 2007 LD Trk, MPV, Incomplet	e Cadillac	C	Body	•		•	
(7) 2007 LD Trk, MPV, Incomplet		V	Powertrain	•		•	
(7) 2007 LD Trk, MPV, Incomplet		V	Chassis	•		•	
(7) 2007 LD Trk, MPV, Incomplet		T	Powertrain	•		•	
(7) 2007 LD Trk, MPV, Incomplet		T	Chassis	•		•	
(7) 2007 LD Trk, MPV, Incomplet		S	Powertrain	•		•	
(7) 2007 LD Trk, MPV, Incomplet	e Buick	S	Chassis	•		•	
(7) 2007 LD Trk, MPV, Incomplet		A	Powertrain	•		•	
(7) 2007 LD Trk, MPV, Incomplet	e Buick	A	Chassis	•		•	
(6) 2006 Workhorse	E - W18 Series	Powertrain	(U) 6. OL V8 LQ4	•		•	
(6) 2006 Workhorse	E - W18 Series	Powertrain	(G) 8.1L V8 L18	•		•	
(6) 2006 Workhorse	D - W42 Series	Powertrain	(V) 4.8L V8 LR4	•		•	
(6) 2006 Workhorse	D - W42 Series	Powertrain	(U) 6. OL V8 LQ4	•			
(6) 2006 Workhorse	D - W42 Series	Powertrain	(3) 4.5L V6 L61 Diesel	•		•	
(6) 2006 Workhorse	C - FE20 Series	Powertrain	Powertrain Control Module	•		•	
(6) 2006 Workhorse	A - W24 Series	Powertrain	Powertrain Control Module	•		•	
(6) 2006 Workhorse	7 - W52 Series	Powertrain	Powertrain Control Module	•		•	
(6) 2006 Workhorse	7 - W52 Series	Chassis	Hydraulic 4WAL 4 Sensor	•			
(6) 2006 Workhorse	6 - W22 Series	Powertrain	6 Speed Automatic	•			
(6) 2006 Workhorse	6 - W22 Series	Powertrain	5 Speed Automatic	•			
(6) 2006 Workhorse	6 - W22 Series	Chassis	Hydraulic 4WAL 4 Sensor	•		•	
(6) 2006 Workhorse	1 - LF72 Series	Powertrain	Powertrain Control Module				
(6) 2006 Passenger Car	(8) Saturn	Powertrain	(P) 2. OL L4 LSJ	•		•	
(6) 2006 Passenger Car	(8) Saturn	Chassis	Electric Power Steering	•		•	
(6) 2006 Passenger Car	(8) Saturn	Chassis	Antilock Brake System	•		•	
(6) 2006 Passenger Car	(8) Saturn	Body	Vehicle Comm. Interface Module	•			
(6) 2006 Passenger Car	(8) Saturn	Body	Supplemental Inflatable Restraint	•		•	
(6) 2006 Passenger Car	(8) Saturn	Body	Radio				
(6) 2006 Passenger Car	(8) Saturn	Body	Instrument Panel Cluster				
(6) 2006 Passenger Car	(8) Saturn	Body	Digital Radio Receiver	•		•	
(6) 2006 Passenger Car	(8) Saturn	Body	Body Control Module	•	•	•	•
(6) 2006 Passenger Car	(6) Cadillac	Y	(YX) XLR-V	•		•	
(6) 2006 Passenger Car	(6) Cadillac	Y	(YV) XLR		•		
(6) 2006 Passenger Car	(6) Cadillac	K	Transmission/Transaxle		•		
(6) 2006 Passenger Car	(6) Cadillac	K	Suspension		•		
(6) 2006 Passenger Car	(6) Cadillac	K	Steering		•		
(6) 2006 Passenger Car	(6) Cadillac	K	Restraints	•	•	•	

Year	Menu1	Menu2	Menu3	Menu4		Erase Codes		ECU Info.
(6) 2006	Passenger Car	(6) Cadillac	K	HVAC	•	•	•	•
(6) 2006	Passenger Car	(6) Cadillac	K	Engine			•	
(6) 2006	Passenger Car	(6) Cadillac	K	Brakes			•	
(6) 2006	Passenger Car	(6) Cadillac	K	Body and Accessories			•	
(6) 2006	Passenger Car	(6) Cadillac	D	(DX) STS-V			•	
(6) 2006	Passenger Car	(6) Cadillac	D	(DW) STS			•	
(6) 2006	Passenger Car	(6) Cadillac	D	(DR) CTS			•	
(6) 2006	Passenger Car	(6) Cadillac	D	(DP) CTS	•		•	
(6) 2006	Passenger Car	(6) Cadillac	D	(DN) CTS-V	•			
(6) 2006	Passenger Car	(6) Cadillac	D	(DM) CTS	•		•	
(6) 2006	Passenger Car	(6) Cadillac	D	(DC) STS-V8	•	•	•	
(6) 2006	Passenger Car	(4) Buick	W	LaCrosse	•	•	•	•
(6) 2006	Passenger Car	(4) Buick	W	Allure	•	•	•	•
	Passenger Car	(4) Buick	J	Powertrain	•	•	•	•
	Passenger Car	(4) Buick	Īī	Chassis			•	
	Passenger Car	(4) Buick	Ī	Body			•	
	Passenger Car	(4) Buick	Н	Transmission/Transaxle	•	•	•	
	Passenger Car	(4) Buick	Н	Suspension		•	•	
	Passenger Car	(4) Buick	Н	Steering		•	•	
	Passenger Car	(4) Buick	Н	Restraints		•		
	Passenger Car	(4) Buick	Н	HVAC		•	•	
	Passenger Car	(4) Buick	Н	Engine		•	•	
	Passenger Car	(4) Buick	Н	Brakes		•	•	
	Passenger Car	(4) Buick	Ц	Body and Accessories				
	Passenger Car	(2) Pontiac	7.	Transmission/Transaxle				
	Passenger Car	(2) Pontiac	7.	Steering				
	Passenger Car	(2) Pontiac	7.	Restraints		•		
		(2) Pontiac	7.	HVAC		•		
	Passenger Car	(2) Pontiac	7	Engine				
	Passenger Car		7.			_	_	
	Passenger Car	(2) Pontiac	5	Brakes	•	•	•	•
	Passenger Car	(2) Pontiac	Z	Body and Accessories	•	•	•	•
	Passenger Car	(2) Pontiac	W	Transmission/Transaxle	•	•	•	•
	Passenger Car	(2) Pontiac	W	Restraints	•	•	•	•
(6) 2006	Passenger Car	(2) Pontiac	W	HVAC	•	•	•	
	Passenger Car	(2) Pontiac	W	Engine	•	•	•	
	Passenger Car	(2) Pontiac	W	Brakes	•	•	•	
	Passenger Car	(2) Pontiac	W	Body and Accessories	•	•	•	•
	Passenger Car	(2) Pontiac	V	Powertrain	•	•	•	•
	Passenger Car	(2) Pontiac	V	Chassis	•	•	•	•
	Passenger Car	(2) Pontiac	V	Body	•	•	•	•
	Passenger Car	(2) Pontiac	T	Powertrain	•	•	•	•
	Passenger Car	(2) Pontiac	T	Chassis	•	•	•	•
	Passenger Car	(2) Pontiac	T	Body	•	•	•	•
	Passenger Car	(2) Pontiac	S	Powertrain	•	•	•	•
(6) 2006	Passenger Car	(2) Pontiac	S	Chassis				

Year	Menu1	Menu2	Menu3	Menu4		Erase Codes	Live Data	ECU Info.
(6) 2006	Passenger Car	(2) Pontiac	S	Body	•	•	•	
	Passenger Car	(2) Pontiac	M	Transmission/Transaxle			•	
	Passenger Car	(2) Pontiac	M	Restraints			•	
(6) 2006	Passenger Car	(2) Pontiac	M	HVAC			•	
(6) 2006	Passenger Car	(2) Pontiac	M	Engine			•	
(6) 2006	Passenger Car	(2) Pontiac	M	Brakes			•	
(6) 2006	Passenger Car	(2) Pontiac	M	Body and Accessories			•	
(6) 2006	Passenger Car	(2) Pontiac	K	Powertrain			•	
(6) 2006	Passenger Car	(2) Pontiac	K	Chassis			•	
(6) 2006	Passenger Car	(2) Pontiac	K	Body	•	•	•	
(6) 2006	Passenger Car	(2) Pontiac	A	Transmission/Transaxle	•	•	•	
	Passenger Car	(2) Pontiac	A	Steering			•	
	Passenger Car	(2) Pontiac	A	Restraints		•	•	•
	Passenger Car	(2) Pontiac	A	HVAC	•	•	•	•
	Passenger Car	(2) Pontiac	A	Engine			•	
	Passenger Car	(2) Pontiac	A	Brakes			•	
	Passenger Car	(2) Pontiac	A	Body and Accessories			•	
	Passenger Car	(1) Chevrolet	7	Transmission/Transaxle	•	•		•
	Passenger Car	(1) Chevrolet	7	Steering	•			
	Passenger Car	(1) Chevrolet	7	Restraints			•	
	Passenger Car	(1) Chevrolet	7	HVAC				•
	Passenger Car	(1) Chevrolet	7	Engine				
	Passenger Car	(1) Chevrolet	7	Brakes				
	Passenger Car	(1) Chevrolet	7	Body and Accessories				
	Passenger Car	(1) Chevrolet	V V	Transmission/Transaxle				
	Passenger Car	(1) Chevrolet	y v					
			Y	Suspension				
	Passenger Car	(1) Chevrolet	Y	Steering		•		
	Passenger Car	(1) Chevrolet	Y	Restraints	•	•	•	•
	Passenger Car	(1) Chevrolet	Y	HVAC	•	•	•	•
	Passenger Car	(1) Chevrolet	Y **	Engine	•	•	•	•
	Passenger Car	(1) Chevrolet	Y 	Brakes	•	•	•	•
	Passenger Car	(1) Chevrolet	Y 	Body and Accessories	•	•	•	•
	Passenger Car	(1) Chevrolet	W 1	WU Impala LTZ	•	•	•	•
(6) 2006	Passenger Car	(1) Chevrolet	W	WT Impala LT 3.5 Sedan	•	•	•	•
		(1) Chevrolet	W 	WS Impala Police Sedan	•	•	•	•
	Passenger Car	(1) Chevrolet	W	WN Monte Carlo LTZ	•	•	•	•
	Passenger Car	(1) Chevrolet	W	WM Monte Carlo LT 3.5 Coupe	•		•	•
	Passenger Car	(1) Chevrolet	W	WL Monte Carlo SS			•	•
	Passenger Car	(1) Chevrolet	W	WK Monte Carlo LT	•	•	•	•
	Passenger Car	(1) Chevrolet	W	WJ Monte Carlo	•	•	•	•
	Passenger Car	(1) Chevrolet	W	WD Impala SS	•		•	
(6) 2006	Passenger Car	(1) Chevrolet	W	WC Impala LT				
	Passenger Car	(1) Chevrolet	W	WB Impala LS		•	•	
(6) 2006	Passenger Car	(1) Chevrolet	V	Powertrain		•	•	
	Passenger Car	(1) Chevrolet	V	Chassis		•	•	•

Year	Menu1	Menu2	Menu3	Menu4	Read codes	Erase Codes	Live Data	ECU Info.
(6) 2006	Passenger Car	(1) Chevrolet	V	Body	•		•	•
	Passenger Car	(1) Chevrolet	U	Powertrain	•	•	•	•
(6) 2006	Passenger Car	(1) Chevrolet	U	Chassis	•		•	•
(6) 2006	Passenger Car	(1) Chevrolet	U	Body	•			•
(6) 2006	Passenger Car	(1) Chevrolet	T	Powertrain	•	•	•	
(6) 2006	Passenger Car	(1) Chevrolet	T	Chassis	•	•		
(6) 2006	Passenger Car	(1) Chevrolet	T	Body	•	•		
(6) 2006	Passenger Car	(1) Chevrolet	S	Chevy	•			
(6) 2006	Passenger Car	(1) Chevrolet	S	Aveo	•		•	•
(6) 2006	Passenger Car	(1) Chevrolet	N	Powertrain	•		•	•
(6) 2006	Passenger Car	(1) Chevrolet	N	Chassis	•			
(6) 2006	Passenger Car	(1) Chevrolet	N	Body	•		•	•
(6) 2006	Passenger Car	(1) Chevrolet	L	Powertrain	•	•	•	•
(6) 2006	Passenger Car	(1) Chevrolet	L	Chassis	•	•		
(6) 2006	Passenger Car	(1) Chevrolet	L	Body	•	•		
(6) 2006	Passenger Car	(1) Chevrolet	K	Powertrain	•	•		•
(6) 2006	Passenger Car	(1) Chevrolet	K	Chassis	•	•	•	•
(6) 2006	Passenger Car	(1) Chevrolet	K	Body	•	•	•	•
(6) 2006	Passenger Car	(1) Chevrolet	J	Powertrain	•			
(6) 2006	Passenger Car	(1) Chevrolet	J	Chassis	•	•		
(6) 2006	Passenger Car	(1) Chevrolet	Ј	Body	•	•		•
(6) 2006	Passenger Car	(1) Chevrolet	A	Transmission/Transaxle	•	•	•	
(6) 2006	Passenger Car	(1) Chevrolet	A	Steering	•	•	•	•
(6) 2006	Passenger Car	(1) Chevrolet	A	Restraints	•	•	•	•
(6) 2006	Passenger Car	(1) Chevrolet	A	HVAC	•	•	•	•
(6) 2006	Passenger Car	(1) Chevrolet	A	Engine	•	•	•	•
(6) 2006	Passenger Car	(1) Chevrolet	A	Brakes	•	•	•	•
(6) 2006	Passenger Car	(1) Chevrolet	A	Body and Accessories	•	•	•	•
(6) 2006	Medium Duty Truck	Hummer H-1	Powertrain	(P) 6.6L V8 LLY Diesel	•	•	•	•
(6) 2006	Medium Duty Truck	Hummer H−1	Powertrain	(F) 6.5L V8 L65	•	•	•	•
(6) 2006	Medium Duty Truck	(T) GMC Truck	T - B7 Chassis	Powertrain	•	•	•	•
(6) 2006	Medium Duty Truck	(T) GMC Truck	T - B7 Chassis	Chassis	•	•	•	•
(6) 2006	Medium Duty Truck	(T) GMC Truck	D - C Series	Powertrain	•	•	•	•
(6) 2006	Medium Duty Truck	(T) GMC Truck	D - C Series	Chassis	•	•	•	•
(6) 2006	Medium Duty Truck	(T) GMC Truck	D - C Series	Body	•	•	•	•
(6) 2006	Medium Duty Truck	(T) GMC Truck	C - WT5500	Powertrain	•	•	•	•
(6) 2006	Medium Duty Truck	(T) GMC Truck	C - WT5500	Chassis	•	•	•	•
(6) 2006	Medium Duty Truck	(T) GMC Truck	C - T Series	Powertrain	•	•	•	•
(6) 2006	Medium Duty Truck	(T) GMC Truck	C - T Series	Chassis	•		•	•
	Medium Duty Truck	(T) GMC Truck	C - T Series	Body	•		•	
	Medium Duty Truck	(T) GMC Truck	B - W4 Series	Powertrain	•			
	Medium Duty Truck	(T) GMC Truck	B - W4 Series	Chassis	•			
	Medium Duty Truck	(C) Chevrolet Truck	T - B7 Chassis	Powertrain	•			
	Medium Duty Truck	(C) Chevrolet Truck	T - B7 Chassis	Chassis	•			
	Medium Duty Truck	(C) Chevrolet Truck	D - C Series	Powertrain	•	•	•	

Year Menu1	Menu2	Menu3	Menu4		Erase Codes		ECU Info.
(6) 2006 Medium Duty Truck	(C) Chevrolet Truck	D - C Series	Chassis	•	•	•	•
(6) 2006 Medium Duty Truck	(C) Chevrolet Truck	D - C Series	Body	•	•		
(6) 2006 Medium Duty Truck	(C) Chevrolet Truck	C - WT5500	Powertrain	•	•		
(6) 2006 Medium Duty Truck	(C) Chevrolet Truck	C - WT5500	Chassis	•		•	
(6) 2006 Medium Duty Truck	(C) Chevrolet Truck	C - T Series	Powertrain	•		•	
(6) 2006 Medium Duty Truck	(C) Chevrolet Truck	C - T Series	Chassis	•		•	
(6) 2006 Medium Duty Truck	(C) Chevrolet Truck	C - T Series	Body	•		•	
(6) 2006 Medium Duty Truck	(C) Chevrolet Truck	B - W4 Series	Powertrain	•		•	
(6) 2006 Medium Duty Truck	(C) Chevrolet Truck	B - W4 Series	Chassis	•	•	•	•
(6) 2006 LD Trk, MPV, Incomple	te (T) GMC Truck	T	Envoy XL	•	•	•	
(6) 2006 LD Trk, MPV, Incomple		T	Envoy	•	•	•	
(6) 2006 LD Trk, MPV, Incomple		Т	Canyon	•	•	•	
(6) 2006 LD Trk, MPV, Incomple		S	Envoy XL	•			
(6) 2006 LD Trk, MPV, Incomple		S	Envoy	•		•	
(6) 2006 LD Trk, MPV, Incomple		P	Powertrain	•	•	•	
(6) 2006 LD Trk, MPV, Incomple		K	Powertrain			•	
(6) 2006 LD Trk, MPV, Incomple		Н	Express/Savana			•	
(6) 2006 LD Trk, MPV, Incomple		Н	Express Access/Savana Pro			•	
(6) 2006 LD Trk, MPV, Incomple		C	Express/Savana TTO				
(6) 2006 LD Trk, MPV, Incomple		C	Express Access/Savana Pro				
(6) 2006 LD Trk, MPV, Incomple		C	Powertrain				
(6) 2006 LD Trk, MPV, Incomple		Hummer H3	Transmission/Transaxle				
(6) 2006 LD Trk, MPV, Incomple		Hummer H3	Suspension				
The state of the s		Hummer H3					
		·	Restraints HVAC				
		Hummer H3				_	
(6) 2006 LD Trk, MPV, Incomple		Hummer H3	Engine	<u>_</u>		•	•
(6) 2006 LD Trk, MPV, Incomple		Hummer H3	Driveline/Axle	•	•	•	•
(6) 2006 LD Trk, MPV, Incomple		Hummer H3	Brakes	•	•	•	•
(6) 2006 LD Trk, MPV, Incomple		Hummer H3	Body and Accessories	•	•	•	•
(6) 2006 LD Trk, MPV, Incomple		Hummer H2	Powertrain	•	•	•	•
(6) 2006 LD Trk, MPV, Incomple		Hummer H2	Chassis	•	•	•	•
(6) 2006 LD Trk, MPV, Incomple		X	Transmission/Transaxle	•	•	•	•
(6) 2006 LD Trk, MPV, Incomple		X	Restraints	•	•	•	•
(6) 2006 LD Trk, MPV, Incomple	te (N) Chevrolet MPV	X	HVAC	•	•	•	•
(6) 2006 LD Trk, MPV, Incomple		X	Engine	•	•	•	•
(6) 2006 LD Trk, MPV, Incomple		X	Brakes	•	•	•	
(6) 2006 LD Trk, MPV, Incomple		X	Body and Accessories	•	•	•	
(6) 2006 LD Trk, MPV, Incomple		V	Transmission/Transaxle	•	•	•	•
(6) 2006 LD Trk, MPV, Incomple		V	Restraints	•	•	•	•
(6) 2006 LD Trk, MPV, Incomple		V	HVAC	•	•	•	•
(6) 2006 LD Trk, MPV, Incomple		V	Engine	•	•	•	•
(6) 2006 LD Trk, MPV, Incomple	te (N) Chevrolet MPV	V	Brakes	•	•	•	•
(6) 2006 LD Trk, MPV, Incomple	te (N) Chevrolet MPV	V	Body and Accessories	•			
(6) 2006 LD Trk, MPV, Incomple	te (N) Chevrolet MPV	U	Transmission/Transaxle	•			
(6) 2006 LD Trk, MPV, Incomple	te (N) Chevrolet MPV	U	Restraints	•			

Year	Menu1	Menu2	Menu3	Menu4		Erase Codes	Live Data	ECU Info.
(6) 2006	LD Trk, MPV, Incomplete	(N) Chevrolet MPV	U	HVAC	•	•		
	LD Trk, MPV, Incomplete		U	Engine	•	•	•	
	LD Trk, MPV, Incomplete		U	Brakes	•	•	•	
	LD Trk, MPV, Incomplete		U	Body and Accessories	•	•	•	
		(M) Pontiac APV	X	Transmission/Transaxle	•	•	•	
		(M) Pontiac APV	X	Restraints	•	•	•	
		(M) Pontiac APV	X	HVAC		•		
		(M) Pontiac APV	X	Engine		•		
		(M) Pontiac APV	X	Brakes		•		
		(M) Pontiac APV	X	Body and Accessories		lacktriangle		
(6) 2006	LD Trk, MPV, Incomplete	(M) Pontiac APV	V	Transmission/Transaxle		•	•	•
(6) 2006	LD Trk, MPV, Incomplete	(M) Pontiac APV	V	Restraints		•	•	•
(6) 2006	LD Trk, MPV, Incomplete	(M) Pontiac APV	V	HVAC	•	•	•	
(6) 2006	LD Trk, MPV, Incomplete	(M) Pontiac APV	V	Engine	•	•	•	
		(M) Pontiac APV	V	Brakes	•	•	•	•
		(M) Pontiac APV	V	Body and Accessories	•	•	•	•
		(M) Pontiac APV	II	Transmission/Transaxle	•	•	•	
		(M) Pontiac APV		Restraints	•	•	•	•
		(M) Pontiac APV		HVAC	•	•	•	•
		(M) Pontiac APV	II	Engine	•	•		•
		(M) Pontiac APV	II	Brakes	•	•		•
		(M) Pontiac APV	II	Body and Accessories	•	•	•	
	LD Trk, MPV, Incomplete		I	Powertrain	•	•	•	•
		(M) Pontiac APV	I	Chassis	•	•		
		(M) Pontiac APV	I	Body	•	•		
		(E) Cadillac Incomplete	Limousina	Transmission/Transaxle	•			
		(E) Cadillac Incomplete		Suspension				
		(E) Cadillac Incomplete		Steering				
			Limousine	Restraints				
				HVAC				
			Limousine					
			Limousine	Engine	•		•	•
	LD Trk, MPV, Incomplete			Brakes	•	•	•	•
	LD Trk, MPV, Incomplete			Body and Accessories	•	•	•	•
	LD Trk, MPV, Incomplete			Transmission/Transaxle	•	•	•	•
	LD Trk, MPV, Incomplete			Suspension	•	•	•	
	LD Trk, MPV, Incomplete			Steering	•	•	•	•
	LD Trk, MPV, Incomplete		Hearse	Restraints	•	•	•	•
	LD Trk, MPV, Incomplete		Hearse	HVAC	•	•	•	•
	LD Trk, MPV, Incomplete		Hearse	Engine	•	•	•	•
	LD Trk, MPV, Incomplete		Hearse	Brakes	•	•	•	•
			Hearse	Body and Accessories	•	•	•	•
		(C) Chevrolet Truck	T	TrailBlazer EXT	•	•	•	•
	LD Trk, MPV, Incomplete		T	TrailBlazer	•	•	•	
	LD Trk, MPV, Incomplete		T	Colorado	•	•	•	
(6) 2006	LD Trk, MPV, Incomplete	(C) Chevrolet Truck	S	TrailBlazer EXT		•	lacksquare	

Year Menu1	Menu2	Menu3	Menu4		Erase Codes		ECU Info.
(6) 2006 LD Trk, MPV, Incomplete	(C) Chevrolet Truck	S	TrailBlazer	•	•	•	•
(6) 2006 LD Trk, MPV, Incomplete	(C) Chevrolet Truck	S	SSR	•			
(6) 2006 LD Trk, MPV, Incomplete	(C) Chevrolet Truck	P	Powertrain	•	•	•	
(6) 2006 LD Trk, MPV, Incomplete	(C) Chevrolet Truck	L	Powertrain	•			
(6) 2006 LD Trk, MPV, Incomplete	(C) Chevrolet Truck	L	Body	•			
(6) 2006 LD Trk, MPV, Incomplete	(C) Chevrolet Truck	K	Powertrain	•		•	
(6) 2006 LD Trk, MPV, Incomplete	(C) Chevrolet Truck	Н	Express/Savana	•	•	•	
(6) 2006 LD Trk, MPV, Incomplete	(C) Chevrolet Truck	Н	Express Access/Savana Pro	•	•	•	
(6) 2006 LD Trk, MPV, Incomplete	(C) Chevrolet Truck	G	Express/Savana	•	•	•	
(6) 2006 LD Trk, MPV, Incomplete	(C) Chevrolet Truck	G	Express Access/Savana Pro	•			
(6) 2006 LD Trk, MPV, Incomplete	(C) Chevrolet Truck	Е	Powertrain	•			
(6) 2006 LD Trk, MPV, Incomplete	(C) Chevrolet Truck	Е	Chassis	•			
(6) 2006 LD Trk, MPV, Incomplete	(C) Chevrolet Truck	Е	Body	•			
(6) 2006 LD Trk, MPV, Incomplete	(C) Chevrolet Truck	С	Powertrain	•	•		
(6) 2006 LD Trk, MPV, Incomplete	(C) Chevrolet Truck	A	Transmission/Transaxle	•		•	
(6) 2006 LD Trk, MPV, Incomplete	(C) Chevrolet Truck	A	Steering	•		•	
(6) 2006 LD Trk, MPV, Incomplete	(C) Chevrolet Truck	A	Restraints	•		•	
(6) 2006 LD Trk, MPV, Incomplete	(C) Chevrolet Truck	A	HVAC	•		•	
(6) 2006 LD Trk, MPV, Incomplete	(C) Chevrolet Truck	A	Engine	•		•	
(6) 2006 LD Trk, MPV, Incomplete	(C) Chevrolet Truck	A	Brakes	•		•	
(6) 2006 LD Trk, MPV, Incomplete	(C) Chevrolet Truck	A	Body and Accessories	•		•	
(6) 2006 LD Trk, MPV, Incomplete	(8) Saturn	Z	Powertrain	•		•	
(6) 2006 LD Trk, MPV, Incomplete	(8) Saturn	Z	Chassis	•		•	
(6) 2006 LD Trk, MPV, Incomplete	(8) Saturn	Z	Body	•		•	
(6) 2006 LD Trk, MPV, Incomplete	(8) Saturn	X	Transmission/Transaxle	•		•	
(6) 2006 LD Trk, MPV, Incomplete	(8) Saturn	X	Restraints	•			
(6) 2006 LD Trk, MPV, Incomplete	(8) Saturn	X	HVAC	•			
(6) 2006 LD Trk, MPV, Incomplete	(8) Saturn	X	Engine	•			
(6) 2006 LD Trk, MPV, Incomplete	(8) Saturn	X	Brakes	•			
(6) 2006 LD Trk, MPV, Incomplete	(8) Saturn	X	Body and Accessories	•			
(6) 2006 LD Trk, MPV, Incomplete	(8) Saturn	V	Transmission/Transaxle	•			
(6) 2006 LD Trk, MPV, Incomplete	(8) Saturn	V	Restraints	•			
(6) 2006 LD Trk, MPV, Incomplete	(8) Saturn	V	HVAC	•			
(6) 2006 LD Trk, MPV, Incomplete	(8) Saturn	V	Engine	•			
(6) 2006 LD Trk, MPV, Incomplete	(8) Saturn	V	Brakes	•	•	•	
(6) 2006 LD Trk, MPV, Incomplete		V	Body and Accessories	•			
(6) 2006 LD Trk, MPV, Incomplete	(6) Cadillac	K	Powertrain	•	•	•	
(6) 2006 LD Trk, MPV, Incomplete		Е	Powertrain	•		•	•
(6) 2006 LD Trk, MPV, Incomplete		Е	Chassis	•		•	•
(6) 2006 LD Trk, MPV, Incomplete	(6) Cadillac	С	Powertrain	•		•	•
(6) 2006 LD Trk, MPV, Incomplete		X	Transmission/Transaxle	•	•	•	•
(6) 2006 LD Trk, MPV, Incomplete		X	Restraints	•	•	•	•
(6) 2006 LD Trk, MPV, Incomplete		X	HVAC	•	•	•	•
(6) 2006 LD Trk, MPV, Incomplete		X	Engine	•	•	•	•
(6) 2006 LD Trk, MPV, Incomplete	(5) Buick	X	Brakes	•		•	•

Year Menu1	Menu2	Menu3	Menu4		Erase Codes		ECU Info.
(6) 2006 LD Trk, MPV, Incomplete	(5) Buick	X	Body and Accessories	•	•	•	•
(6) 2006 LD Trk, MPV, Incomplete		V	Transmission/Transaxle	•	•	•	•
(6) 2006 LD Trk, MPV, Incomplete	(5) Buick	V	Restraints	•	•	•	•
(6) 2006 LD Trk, MPV, Incomplete	(5) Buick	V	HVAC	•	•	•	•
(6) 2006 LD Trk, MPV, Incomplete	(5) Buick	V	Engine	•	•	•	•
(6) 2006 LD Trk, MPV, Incomplete	(5) Buick	V	Brakes	•	•	•	•
(6) 2006 LD Trk, MPV, Incomplete	(5) Buick	V	Body and Accessories	•	•	•	•
(6) 2006 LD Trk, MPV, Incomplete	(5) Buick	Т	Chassis	•	•	•	
(6) 2006 LD Trk, MPV, Incomplete	(5) Buick	S	Powertrain	•	•		
(6) 2006 LD Trk, MPV, Incomplete	(5) Buick	S	Chassis	•	•	•	•
(6) 2006 LD Trk, MPV, Incomplete		В	Powertrain	•	•	•	•
(6) 2006 LD Trk, MPV, Incomplete		В	Chassis	•	•	•	•
(6) 2006 LD Trk, MPV, Incomplete		A	Powertrain	•	•	•	
(6) 2006 LD Trk, MPV, Incomplete		A	Chassis	•	•	•	
(6) 2006 LD Trk, MPV, Incomplete		Powertrain	(S) 4.2L L6 LL8	•	•	•	
(6) 2006 LD Trk, MPV, Incomplete		Powertrain	(M) 5.3L V8 LH6	•	•	•	
(6) 2006 LD Trk, MPV, Incomplete		Chassis	ABS/TCS/VSES	•	•	•	
(6) 2006 LD Trk, MPV, Incomplete		Body	Uplevel Radio	•	•	•	
(6) 2006 LD Trk, MPV, Incomplete		Body	Navigation Radio		•	•	
(5) 2005 Workhorse	A - W24 Series	Powertrain	(G) 8.1L V8 L18		•		
(5) 2005 Workhorse	7 - W52 Series	Powertrain	(G) 8. 1L V8 L18		•	•	
(5) 2005 Workhorse	7 - W52 Series	Chassis	Hydraulic 4WAL 4 Sensor		•	•	
(5) 2005 Workhorse	6 - W22 Series	Powertrain	(G) 8.1L V8 L18		•	•	
(5) 2005 Workhorse	6 - W22 Series	Chassis	Hydraulic 4WAL 4 Sensor		•	•	
(5) 2005 Workhorse	5 - P32 Series	Powertrain	(G) 8.1L V8 L18				
(5) 2005 Workhorse	5 - P32 Series 5 - P32 Series	Chassis	4WAL 3 Sensor		•		
(5) 2005 Workhorse	4 - P42 Series	Powertrain	(Y) 6.5L V8 L57		•		
(5) 2005 Workhorse	4 - P42 Series 4 - P42 Series	Powertrain	(X) 4.3L V6 LU3		•		
(5) 2005 Workhorse	4 - P42 Series 4 - P42 Series	Powertrain	(V) 4.8L V8 LR4				
(5) 2005 Workhorse (5) 2005 Workhorse	4 - P42 Series 4 - P42 Series		(U) 6. 0L V8 LQ4				
(5) 2005 Workhorse	4 - P42 Series 4 - P42 Series	Powertrain	(P) 3.9L L4 L4B Diesel				
(5) 2005 Workhorse	-	Powertrain	4WAL 3 Sensor				
(5) 2005 Workhorse	4 - P42 Series 1 - LF72 Series	Chassis	(2) 6.6L V8 LLY Diesel				
` /		Powertrain	Powertrain				
(5) 2005 Passenger Car(5) 2005 Passenger Car	(8) Saturn	J IT				•	•
	(8) Saturn	J T	Chassis	•	•	•	
(5) 2005 Passenger Car	(8) Saturn	J	Body	•	•	•	•
(5) 2005 Passenger Car	(8) Saturn	A	Powertrain	•	•	•	•
(5) 2005 Passenger Car	(8) Saturn	A	Chassis	•	•	•	•
(5) 2005 Passenger Car	(8) Saturn	A	Body The state of	•	•	•	•
(5) 2005 Passenger Car	(6) Cadillac	Y	Transmission/Transaxle	•	•	•	•
(5) 2005 Passenger Car	(6) Cadillac	Y	Suspension	•	•	•	•
(5) 2005 Passenger Car	(6) Cadillac	Y	Steering	•	•	•	•
(5) 2005 Passenger Car	(6) Cadillac	Y	Restraints	•	•	•	•
(5) 2005 Passenger Car	(6) Cadillac	Y	HVAC	•	•	•	•
(5) 2005 Passenger Car	(6) Cadillac	Υ	Engine	•			

Year Menu1	Menu2	Menu3	Menu4		Erase Codes		ECU Info.
(5) 2005 Passenger Car	(6) Cadillac	Y	Brakes	•	•	•	•
(5) 2005 Passenger Car	(6) Cadillac	Y	Body and Accessories	•	•	•	
(5) 2005 Passenger Car	(6) Cadillac	K	(KF) DTS	•	•		
(5) 2005 Passenger Car	(6) Cadillac	K	(KE) DHS	•	•		
(5) 2005 Passenger Car	(6) Cadillac	K	(KD) Deville	•	•		
(5) 2005 Passenger Car	(6) Cadillac	D	(DW) STS	•	•		
(5) 2005 Passenger Car	(6) Cadillac	D	(DR) CTS	•	•		
(5) 2005 Passenger Car	(6) Cadillac	D	(DP) CTS	•	•	•	
(5) 2005 Passenger Car	(6) Cadillac	D	(DN) CTS-V	•	•	•	
(5) 2005 Passenger Car	(6) Cadillac	D	(DM) CTS	•	•		
(5) 2005 Passenger Car	(6) Cadillac	D	(DC) STS-V8	•	•		
(5) 2005 Passenger Car	(4) Buick	W	LaCrosse	•	•		
(5) 2005 Passenger Car	(4) Buick	W	Century	•	•		
(5) 2005 Passenger Car	(4) Buick	W	Allure	•	•	•	
(5) 2005 Passenger Car	(4) Buick	Н	(HR) LeSabre Limited	•	•	•	
(5) 2005 Passenger Car	(4) Buick	Н	(HP) LeSabre Custom	•	•	•	
(5) 2005 Passenger Car	(4) Buick	С	Powertrain	•	•	•	•
(5) 2005 Passenger Car	(4) Buick	С	Chassis	•	•	•	•
(5) 2005 Passenger Car	(4) Buick	С	Body	•	•	•	•
(5) 2005 Passenger Car	(2) Pontiac	Z	Steering	•	•	•	•
(5) 2005 Passenger Car	(2) Pontiac	Z	Restraints	•	•	•	
(5) 2005 Passenger Car	(2) Pontiac	Z	HVAC	•	•	•	
(5) 2005 Passenger Car	(2) Pontiac	Z	Engine	•			•
(5) 2005 Passenger Car	(2) Pontiac	Z	Brakes	•			•
(5) 2005 Passenger Car	(2) Pontiac	Z	Body and Accessories	•			
(5) 2005 Passenger Car	(2) Pontiac	W	Transmission/Transaxle	•			•
(5) 2005 Passenger Car	(2) Pontiac	W	Restraints	•	•	•	•
(5) 2005 Passenger Car	(2) Pontiac	W	HVAC	•	•	•	•
(5) 2005 Passenger Car	(2) Pontiac	W	Engine	•		•	•
(5) 2005 Passenger Car	(2) Pontiac	W	Brakes	•	•	•	•
(5) 2005 Passenger Car	(2) Pontiac	W	Body and Accessories	•	•	•	•
(5) 2005 Passenger Car	(2) Pontiac	V	Powertrain	•	•	•	•
(5) 2005 Passenger Car	(2) Pontiac	V	Chassis	•	•		•
(5) 2005 Passenger Car	(2) Pontiac	V	Body	•	•	•	•
(5) 2005 Passenger Car	(2) Pontiac	Т	Chassis	•	•	•	
(5) 2005 Passenger Car	(2) Pontiac	Т	Body	•	•	•	•
(5) 2005 Passenger Car	(2) Pontiac	S	Powertrain	•	•	•	
(5) 2005 Passenger Car	(2) Pontiac	S	Chassis	•	•	•	
(5) 2005 Passenger Car	(2) Pontiac	S	Body		•	•	•
(5) 2005 Passenger Car	(2) Pontiac	N	Powertrain	•	•	•	•
(5) 2005 Passenger Car	(2) Pontiac	N	Chassis				•
(5) 2005 Passenger Car	(2) Pontiac	N	Body				
(5) 2005 Passenger Car	(2) Pontiac	M	Powertrain				
(5) 2005 Passenger Car	(2) Pontiac	M	Chassis				
(5) 2005 Passenger Car	(2) Pontiac (2) Pontiac	M	Body				
(a) Zuub [rassenger Car	(4) rontlac	IVI	IDOGA				

Year Menu1	Menu2	Menu3	Menu4		Erase Codes		ECU Info.
(5) 2005 Passenger Car	(2) Pontiac	Ј	Chassis	•	•	•	
(5) 2005 Passenger Car	(2) Pontiac	Ј	Body	•	•	•	
(5) 2005 Passenger Car	(2) Pontiac	Н	(HZ) Bonneville GXP	•		•	
(5) 2005 Passenger Car	(2) Pontiac	Н	(HY) Bonneville SLE	•		•	
(5) 2005 Passenger Car	(2) Pontiac	Н	(HX) Bonneville SE	•		•	
(5) 2005 Passenger Car	(2) Pontiac	A	Transmission/Transaxle	•	•	•	
(5) 2005 Passenger Car	(2) Pontiac	A	Steering	•	•	•	
(5) 2005 Passenger Car	(2) Pontiac	A	Restraints	•	•	•	
(5) 2005 Passenger Car	(2) Pontiac	A	HVAC	•	•	•	
(5) 2005 Passenger Car	(2) Pontiac	A	Engine	•	•	•	
(5) 2005 Passenger Car	(2) Pontiac	A	Brakes	•	•	•	
(5) 2005 Passenger Car	(2) Pontiac	A	Body and Accessories	•	•	•	
(5) 2005 Passenger Car	(1) Chevrolet	Z	Transmission/Transaxle	•	•	•	
(5) 2005 Passenger Car	(1) Chevrolet	Z	Steering	•	•	•	
(5) 2005 Passenger Car	(1) Chevrolet	Z	Restraints	•	•	•	
(5) 2005 Passenger Car	(1) Chevrolet	Z	HVAC	•	•	•	
(5) 2005 Passenger Car	(1) Chevrolet	Z	Engine	•		•	
(5) 2005 Passenger Car	(1) Chevrolet	Z	Brakes	•	•	•	•
(5) 2005 Passenger Car	(1) Chevrolet	Z	Body and Accessories	•		•	
(5) 2005 Passenger Car	(1) Chevrolet	Y	Transmission/Transaxle	•	•	•	•
(5) 2005 Passenger Car	(1) Chevrolet	Y	Suspension	•	•	•	•
(5) 2005 Passenger Car	(1) Chevrolet	Y	Steering	•	•	•	•
(5) 2005 Passenger Car	(1) Chevrolet	У	Restraints	•	•	•	
(5) 2005 Passenger Car	(1) Chevrolet	У	HVAC	•	•	•	
(5) 2005 Passenger Car	(1) Chevrolet	У	Engine	•	•	•	
(5) 2005 Passenger Car	(1) Chevrolet	Y	Brakes	•			
(5) 2005 Passenger Car	(1) Chevrolet	Y	Body and Accessories	•			
(5) 2005 Passenger Car	(1) Chevrolet	W	Powertrain	•	•	•	
(5) 2005 Passenger Car	(1) Chevrolet	W	Chassis	•			
(5) 2005 Passenger Car	(1) Chevrolet	W	Body	•		•	
(5) 2005 Passenger Car	(1) Chevrolet	V	Powertrain	•		•	
(5) 2005 Passenger Car	(1) Chevrolet	V	Chassis	•		•	
(5) 2005 Passenger Car	(1) Chevrolet	V	Body	•		•	
(5) 2005 Passenger Car	(1) Chevrolet	Ü	Powertrain	•	•		
(5) 2005 Passenger Car	(1) Chevrolet	IJ	Chassis	•	•	•	
(5) 2005 Passenger Car	(1) Chevrolet	IJ	Body	•	•	•	
(5) 2005 Passenger Car	(1) Chevrolet	Т	Chassis	•	•	•	
(5) 2005 Passenger Car	(1) Chevrolet	T	Body	•	•	•	
(5) 2005 Passenger Car	(1) Chevrolet	S	Aveo	•	•	•	
(5) 2005 Passenger Car	(1) Chevrolet	N	Optra	•	•	•	
(5) 2005 Passenger Car	(1) Chevrolet	N	Classic	•	•	•	
(5) 2005 Passenger Car	(1) Chevrolet	M	Powertrain		•		
(5) 2005 Passenger Car	(1) Chevrolet	M	Chassis		•		
(5) 2005 Passenger Car	(1) Chevrolet	M	Body				
(5) 2005 Passenger Car	(1) Chevrolet	1 1/1	Powertrain				
(a) 4000 frassenger Car	I(1) cuestoter	įL	Lower rrain				

Year	Menu1	Menu2	Menu3	Menu4		Erase Codes		ECU Info.
(5) 2005	Passenger Car	(1) Chevrolet	L	Chassis	•	•	•	
(5) 2005	Passenger Car	(1) Chevrolet	L	Body	•	•	•	
(5) 2005		(1) Chevrolet	J	Optra	•	•	•	
(5) 2005	Passenger Car	(1) Chevrolet	Ј	Cavalier				•
(5) 2005	Passenger Car	(1) Chevrolet	A	Transmission/Transaxle				•
	Passenger Car	(1) Chevrolet	A	Steering	•	•		
		(1) Chevrolet	A	Restraints				
(5) 2005		(1) Chevrolet	A	HVAC				•
(5) 2005	Passenger Car	(1) Chevrolet	A	Engine				•
	Passenger Car	(1) Chevrolet	A	Brakes				•
(5) 2005	Passenger Car	(1) Chevrolet	A	Body and Accessories				•
(5) 2005	Medium Duty Truck	(T) GMC Truck	T - B7 Chassis	Powertrain				
(5) 2005	Medium Duty Truck	(T) GMC Truck	T - B7 Chassis	Chassis				
(5) 2005	Medium Duty Truck	(T) GMC Truck	D - C Series	Powertrain				•
(5) 2005	Medium Duty Truck	(T) GMC Truck	D - C Series	Chassis				•
(5) 2005	Medium Duty Truck	(T) GMC Truck	D - C Series	Body				•
(5) 2005	Medium Duty Truck	(T) GMC Truck	C - WT5500	Powertrain				•
(5) 2005	Medium Duty Truck	(T) GMC Truck	C - WT5500	Chassis			•	
(5) 2005	Medium Duty Truck	(T) GMC Truck	C - T Series	Powertrain				•
(5) 2005	Medium Duty Truck	(T) GMC Truck	C - T Series	Chassis				•
(5) 2005	Medium Duty Truck	(T) GMC Truck	C - T Series	Body			•	
(5) 2005	Medium Duty Truck	(T) GMC Truck	B - W4 Series	Powertrain			•	
(5) 2005	Medium Duty Truck	(T) GMC Truck	B - W4 Series	Chassis			•	•
(5) 2005	Medium Duty Truck	(C) Chevrolet Truck	T - B7 Chassis	Powertrain				•
(5) 2005	Medium Duty Truck	(C) Chevrolet Truck	T - B7 Chassis	Chassis			•	•
(5) 2005	Medium Duty Truck	(C) Chevrolet Truck	D - C Series	Powertrain			•	•
(5) 2005	Medium Duty Truck	(C) Chevrolet Truck	D - C Series	Chassis			•	•
(5) 2005	Medium Duty Truck	(C) Chevrolet Truck	D - C Series	Body			•	
(5) 2005	Medium Duty Truck	(C) Chevrolet Truck	C - WT5500	Powertrain			•	
(5) 2005	Medium Duty Truck	(C) Chevrolet Truck	C - WT5500	Chassis			•	
(5) 2005	Medium Duty Truck	(C) Chevrolet Truck	C - T Series	Powertrain			•	
(5) 2005	Medium Duty Truck	(C) Chevrolet Truck	C - T Series	Chassis			•	
(5) 2005	Medium Duty Truck	(C) Chevrolet Truck	C - T Series	Body			•	•
	Medium Duty Truck	(C) Chevrolet Truck	B - W4 Series	Powertrain	•	•	•	•
(5) 2005	Medium Duty Truck	(C) Chevrolet Truck	B - W4 Series	Chassis	•	•	•	•
	LD Trk, MPV, Incomplete		T	Sonoma		•	•	•
	LD Trk, MPV, Incomplete		Т	Jimmy	•	•	•	•
	LD Trk, MPV, Incomplete		Т	Envoy XUV	•	•	•	•
(5) 2005	LD Trk, MPV, Incomplete	(T) GMC Truck	Т	Envoy XL	•	•	•	•
	LD Trk, MPV, Incomplete		Т	Envoy	•	•	•	•
	LD Trk, MPV, Incomplete		Т	Canyon	•	•	•	•
	LD Trk, MPV, Incomplete		S	Sonoma	•	•	•	•
	LD Trk, MPV, Incomplete		S	Jimmy	•	•	•	•
	LD Trk, MPV, Incomplete		S	Envoy XUV	•	•	•	•
	LD Trk, MPV, Incomplete		S	Envoy XL	•	•	•	•

Year Menu1	Menu2	Menu3	Menu4		Erase Codes		ECU Info.
(5) 2005 LD Trk, MPV, Incomplete	(T) GMC Truck	S	Envoy		•	•	•
(5) 2005 LD Trk, MPV, Incomplete		Р	Powertrain	•	•	•	•
(5) 2005 LD Trk, MPV, Incomplete	(T) GMC Truck	М	Powertrain	•	•	•	•
(5) 2005 LD Trk, MPV, Incomplete	(T) GMC Truck	М	Chassis	•	•	•	•
(5) 2005 LD Trk, MPV, Incomplete	(T) GMC Truck	М	Body	•	•	•	•
(5) 2005 LD Trk, MPV, Incomplete	(T) GMC Truck	L	Powertrain	•	•	•	•
(5) 2005 LD Trk, MPV, Incomplete	(T) GMC Truck	L	Chassis	•	•	•	•
(5) 2005 LD Trk, MPV, Incomplete	(T) GMC Truck	L	Body	•	•	•	•
(5) 2005 LD Trk, MPV, Incomplete	(T) GMC Truck	К	Powertrain	•	•	•	•
(5) 2005 LD Trk, MPV, Incomplete	(T) GMC Truck	Н	Express/Savana	•	•	•	•
(5) 2005 LD Trk, MPV, Incomplete	(T) GMC Truck	Н	Express Access/Savana Pro		•	•	•
(5) 2005 LD Trk, MPV, Incomplete	(T) GMC Truck	G	Express/Savana				
(5) 2005 LD Trk, MPV, Incomplete	(T) GMC Truck	G	Express Access/Savana Pro				
(5) 2005 LD Trk, MPV, Incomplete	(T) GMC Truck	C	Powertrain	•	•	•	•
(5) 2005 LD Trk, MPV, Incomplete		Powertrain	(U) 6. OL V8 LQ4		•		
(5) 2005 LD Trk, MPV, Incomplete	(R) Hummer	Chassis	Air Suspension		•		•
(5) 2005 LD Trk, MPV, Incomplete	(R) Hummer	Chassis	ABS		•		•
(5) 2005 LD Trk, MPV, Incomplete	(N) Chevrolet MPV	Х	Transmission/Transaxle		•		•
(5) 2005 LD Trk, MPV, Incomplete		X	Restraints		•		•
(5) 2005 LD Trk, MPV, Incomplete	(N) Chevrolet MPV	X	HVAC		•		•
(5) 2005 LD Trk, MPV, Incomplete	(N) Chevrolet MPV	Y	Engine		•		•
(5) 2005 LD Trk, MPV, Incomplete	(N) Chevrolet MPV	Y	Brakes		•	•	•
(5) 2005 LD Trk, MPV, Incomplete		Y	Body and Accessories		•		•
(5) 2005 LD Trk, MPV, Incomplete	(N) Chevrolet MPV	V	Venture		•		
(5) 2005 LD Trk, MPV, Incomplete	(N) Chevrolet MPV	V	Uplander		•		
(5) 2005 LD Trk, MPV, Incomplete	(N) Chevrolet MPV	II	Transmission/Transaxle		•	•	•
(5) 2005 LD Trk, MPV, Incomplete		II	Restraints		•	•	•
(5) 2005 LD Trk, MPV, Incomplete		II	HVAC		•		•
(5) 2005 LD Trk, MPV, Incomplete	(N) Chevrolet MPV	II	Engine				
(5) 2005 LD Trk, MPV, Incomplete		II	Brakes				•
(5) 2005 LD Trk, MPV, Incomplete		II	Body and Accessories		•		•
(5) 2005 LD Trk, MPV, Incomplete		V	Transmission/Transaxle				•
(5) 2005 LD Trk, MPV, Incomplete		V V	Restraints				
(5) 2005 LD Trk, MPV, Incomplete		X	HVAC				
(5) 2005 LD Trk, MPV, Incomplete		X	Engine	•	•	•	
(5) 2005 LD Trk, MPV, Incomplete		X	Brakes		•	•	
(5) 2005 LD Trk, MPV, Incomplete		X	Body and Accessories			•	
(5) 2005 LD Trk, MPV, Incomplete		V	Montana SV6			•	
(5) 2005 LD Trk, MPV, Incomplete		V	Montana Svo				
(5) 2005 LD Trk, MPV, Incomplete		I T	Transmission/Transaxle		•		
		U II					
(5) 2005 LD Trk, MPV, Incomplete		U II	Restraints HVAC				
(5) 2005 LD Trk, MPV, Incomplete		U II		— <u> </u>			
(5) 2005 LD Trk, MPV, Incomplete		U	Engine	•	•	•	•
(5) 2005 LD Trk, MPV, Incomplete		U	Brakes	•	•	•	•
(5) 2005 LD Trk, MPV, Incomplete	(M) PONTIAC APV	ĮU	Body and Accessories	•	•		

Year Menu1	Menu2	Menu3	Menu4	Read codes		Live Data	ECU Info.
(5) 2005 LD Trk, MPV, Incomplete	(M) Pontiac APV	В	Powertrain			•	
(5) 2005 LD Trk, MPV, Incomplete		В	Chassis				
(5) 2005 LD Trk, MPV, Incomplete		В	Body		•	•	
		A	Powertrain	•	•	•	
	(M) Pontiac APV	A	Chassis		•	•	
	(M) Pontiac APV	A	Body		•	•	
(5) 2005 LD Trk, MPV, Incomplete	(E) Cadillac Incomplete	Limousine	Powertrain		•	•	
(5) 2005 LD Trk, MPV, Incomplete	(E) Cadillac Incomplete	Limousine	Chassis	•	•	•	
	(E) Cadillac Incomplete	Limousine	Body				
		Hearse	Powertrain				
		Hearse	Chassis			•	
(5) 2005 LD Trk, MPV, Incomplete	(E) Cadillac Incomplete	Hearse	Body				
	(C) Chevrolet Truck	T	TrailBlazer EXT			•	
	(C) Chevrolet Truck	T	TrailBlazer		•	•	
(5) 2005 LD Trk, MPV, Incomplete	(C) Chevrolet Truck	T	Colorado			•	•
	(C) Chevrolet Truck	Т	Blazer	•	•	•	•
(5) 2005 LD Trk, MPV, Incomplete	(C) Chevrolet Truck	S	TrailBlazer EXT	•	•	•	•
(5) 2005 LD Trk, MPV, Incomplete	(C) Chevrolet Truck	S	TrailBlazer		•	•	•
	(C) Chevrolet Truck	S	SSR		•	•	
	(C) Chevrolet Truck	S	Blazer		•	•	•
(5) 2005 LD Trk, MPV, Incomplete	(C) Chevrolet Truck	P	Powertrain		•	•	•
(5) 2005 LD Trk, MPV, Incomplete	(C) Chevrolet Truck	M	Powertrain	•	•	•	•
	(C) Chevrolet Truck	M	Chassis		•	•	
	(C) Chevrolet Truck	M	Body			•	•
	(C) Chevrolet Truck	I I	Equinox		•		•
(5) 2005 LD Trk, MPV, Incomplete	(C) Chevrolet Truck	I	Astro		•	•	•
	(C) Chevrolet Truck	K.	Powertrain		•	•	•
	(C) Chevrolet Truck	T T	Powertrain		•	•	
	(C) Chevrolet Truck	IJ T	Body				
	(C) Chevrolet Truck	IJ Itt	Express/Savana				
	(C) Chevrolet Truck	л п					
		G	Express Access/Savana Pro				
			Express/Savana				
		G	Express Access/Savana Pro	— <u> </u>		_	
(5) 2005 LD Trk, MPV, Incomplete		E .	Powertrain	•	•	•	•
(5) 2005 LD Trk, MPV, Incomplete		E	Body	•	•	•	
(5) 2005 LD Trk, MPV, Incomplete			Powertrain	•	•	•	•
(5) 2005 LD Trk, MPV, Incomplete		<u>Z</u>	Powertrain	•	•	•	•
(5) 2005 LD Trk, MPV, Incomplete		Z	Chassis	•	•	•	•
(5) 2005 LD Trk, MPV, Incomplete		<u>L</u>	Body	•	•	•	•
(5) 2005 LD Trk, MPV, Incomplete		X L	Transmission/Transaxle	•	•	•	•
(5) 2005 LD Trk, MPV, Incomplete		X	Restraints	•	•	•	
(5) 2005 LD Trk, MPV, Incomplete		X	HVAC	•	•	•	
(5) 2005 LD Trk, MPV, Incomplete		X	Engine	•	•	•	•
(5) 2005 LD Trk, MPV, Incomplete		X	Brakes	•	•	•	•
(5) 2005 LD Trk, MPV, Incomplete	(8) Saturn	X	Body and Accessories	•			

Year Menul	Menu2	Menu3	Menu4		Erase Codes		ECU Info.
(5) 2005 LD Trk, MPV, Incomplete	(8) Saturn	V	Transmission/Transaxle	•	•	•	•
(5) 2005 LD Trk, MPV, Incomplete		V	Restraints	•	•	•	•
(5) 2005 LD Trk, MPV, Incomplete	(8) Saturn	V	HVAC	•	•		•
(5) 2005 LD Trk, MPV, Incomplete	(8) Saturn	V	Engine	•	•		•
(5) 2005 LD Trk, MPV, Incomplete	(8) Saturn	V	Brakes	•	•		
(5) 2005 LD Trk, MPV, Incomplete	(8) Saturn	V	Body and Accessories	•	•	•	
(5) 2005 LD Trk, MPV, Incomplete	(6) Cadillac	K	Powertrain	•	•	•	
(5) 2005 LD Trk, MPV, Incomplete	(6) Cadillac	E	Powertrain	•	•	•	
(5) 2005 LD Trk, MPV, Incomplete	(6) Cadillac	Е	Chassis				
(5) 2005 LD Trk, MPV, Incomplete	(6) Cadillac	C	Powertrain				
(5) 2005 LD Trk, MPV, Incomplete	(5) Buick	X	Transmission/Transaxle				
(5) 2005 LD Trk, MPV, Incomplete	(5) Buick	X	Restraints				
(5) 2005 LD Trk, MPV, Incomplete	(5) Buick	X	HVAC	•	•		
(5) 2005 LD Trk, MPV, Incomplete	(5) Buick	X	Engine				
(5) 2005 LD Trk, MPV, Incomplete	(5) Buick	X	Brakes				
(5) 2005 LD Trk, MPV, Incomplete	(5) Buick	X	Body and Accessories	•	•		
(5) 2005 LD Trk, MPV, Incomplete	(5) Buick	V	Transmission/Transaxle	•	•		
(5) 2005 LD Trk, MPV, Incomplete	(5) Buick	V	Restraints				
(5) 2005 LD Trk, MPV, Incomplete	(5) Buick	V	HVAC				
(5) 2005 LD Trk, MPV, Incomplete	(5) Buick	V	Engine	•	•	•	
(5) 2005 LD Trk, MPV, Incomplete	(5) Buick	V	Brakes	•	•	•	
(5) 2005 LD Trk, MPV, Incomplete	(5) Buick	V	Body and Accessories	•	•	•	
(5) 2005 LD Trk, MPV, Incomplete	(5) Buick	T	Chassis	•	•	•	
(5) 2005 LD Trk, MPV, Incomplete	(5) Buick	S	Powertrain	•	•		
(5) 2005 LD Trk, MPV, Incomplete	(5) Buick	В	Powertrain	•	•		
(5) 2005 LD Trk, MPV, Incomplete	(5) Buick	В	Chassis	•	•	•	
(5) 2005 LD Trk, MPV, Incomplete	(5) Buick	A	Powertrain	•	•	•	
(5) 2005 LD Trk, MPV, Incomplete	(5) Buick	A	Chassis	•	•		
(5) 2005 LD Trk, MPV, Incomplete	(3) SAAB	Powertrain	(S) 4.2L L6 LL8	•	•	•	
(5) 2005 LD Trk, MPV, Incomplete	(3) SAAB	Powertrain	(M) 5.3L V8 LH6	•	•		
(5) 2005 LD Trk, MPV, Incomplete	(3) SAAB	Chassis	ABS	•	•		
(5) 2005 LD Trk, MPV, Incomplete	(3) SAAB	Body	Without HID Headlamps	•	•		
(5) 2005 LD Trk, MPV, Incomplete	(3) SAAB	Body	With HID Headlamps	•	•		
	A - W24 Series	Powertrain	(G) 8.1L V8 L18	•	•		
(4) 2004 Workhorse	7 - W52 Series	Powertrain	(G) 8.1L V8 L18	•	•		
(4) 2004 Workhorse	7 - W52 Series	Chassis	Hydraulic 4WAL 4 Sensor	•	•		•
(4) 2004 Workhorse	6 - W22 Series	Powertrain	(G) 8.1L V8 L18	•	•		
(4) 2004 Workhorse	6 - W22 Series	Chassis	Hydraulic 4WAL 4 Sensor	•	•		•
(4) 2004 Workhorse	5 - P32 Series	Powertrain	(G) 8.1L V8 L18	•	•	•	•
(4) 2004 Workhorse	5 - P32 Series	Chassis	4WAL 3 Sensor	•	•	•	•
(4) 2004 Workhorse	4 - P42 Series	Powertrain	(Y) 6.5L V8 L57	•	•	•	•
(4) 2004 Workhorse	4 - P42 Series	Powertrain	(X) 4.3L V6 LU3	•	•	•	•
(4) 2004 Workhorse	4 - P42 Series	Powertrain	(V) 4.8L V8 LR4	•	•	•	•
(4) 2004 Workhorse	4 - P42 Series	Powertrain	(U) 6. 0L V8 LQ4	•	•	•	•
(4) 2004 Workhorse	4 - P42 Series	Powertrain	(R) 5.7L V8 L31	•	•	•	•

Year Menu1	Menu2	Menu3	Menu4		Erase Codes		ECU Info.
(4) 2004 Workhorse	4 - P42 Series	Powertrain	(P) 3.9L L4 L4B Diesel	•		•	•
(4) 2004 Workhorse	4 - P42 Series	Chassis	4WAL 3 Sensor	•	•	•	•
(4) 2004 Saturn	Z	Powertrain	(D) 2. 2L L4 L61	•			
(4) 2004 Saturn	Z	Powertrain	(4) 3.5L V6 L66	•	•		
(4) 2004 Saturn	Z	Chassis	Electric Power Steering	•			
(4) 2004 Saturn	Z	Chassis	Antilock Brake System	•	•	•	•
(4) 2004 Saturn	Z	Body	Supplemental Inflatable Restraint	•			•
(4) 2004 Saturn	Z	Body	Radio	•			
(4) 2004 Saturn	Z	Body	OnStar	•	•		•
(4) 2004 Saturn	Z	Body	Instrument Panel Cluster	•	•	•	•
(4) 2004 Saturn	Z	Body	Digital Radio Receiver	•			
(4) 2004 Saturn	7.	Body	Body Control Module				
(4) 2004 Saturn	Ī	Powertrain	(R) 3.0L V6 L81	•			•
(4) 2004 Saturn	T	Powertrain	(F) 2. 2L L4 L61		•		•
(4) 2004 Saturn	T	Chassis	Electronic Brake Control Module				
(4) 2004 Saturn	T	Body	Supplemental Inflatable Restraint				
(4) 2004 Saturn		Body	OnStar				
(4) 2004 Saturn	T	Body	Instrument Panel Cluster				•
(4) 2004 Saturn		Body	Body Control Module				
(4) 2004 Saturn	J T	Body	Auto. HVAC	+ +			
	J	ž	(P) 2.0L L4 LSJ	+ +			
(4) 2004 Saturn	A	Powertrain			_	•	•
(4) 2004 Saturn	A	Powertrain	(F) 2. 2L L4 L61	•	•	•	•
(4) 2004 Saturn	A	Chassis	Electric Power Steering	•	•	•	•
(4) 2004 Saturn	A	Chassis	Antilock Brake System	•	•	•	•
(4) 2004 Saturn	A	Body	Supplemental Inflatable Restraint	•	•	•	•
(4) 2004 Saturn	A	Body	Radio	•	•	•	•
(4) 2004 Saturn	A	Body	OnStar	•	•	•	•
(4) 2004 Saturn	A	Body	Instrument Panel Cluster	•	•	•	•
(4) 2004 Saturn	A	Body	Digital Radio Receiver	•	•		•
(4) 2004 Saturn	A	Body	Body Control Module	•	•	•	•
(4) 2004 Passenger		Y	Transmission/Transaxle	•	•	•	•
(4) 2004 Passenger		Y	Suspension	•			
(4) 2004 Passenger		Y	Steering	•			
(4) 2004 Passenger	Car (6) Cadillac	Y	Restraints	•			
(4) 2004 Passenger	Car (6) Cadillac	Y	HVAC	•		•	•
(4) 2004 Passenger		Y	Engine	•		•	•
(4) 2004 Passenger		Y	Brakes	•			•
(4) 2004 Passenger		Y	Body and Accessories	•	•	•	•
(4) 2004 Passenger		K	(KY) Seville STS	•	•	•	
(4) 2004 Passenger		K	(KS) Seville SLS	•	•	•	•
(4) 2004 Passenger		K	(KF) DTS		•	•	
(4) 2004 Passenger		K	(KE) DHS	•			
(4) 2004 Passenger		K	(KD) Deville	•			
(4) 2004 Passenger		D	(DR) CTS	 •			
(4) 2004 Passenger (4) 2004 Passenger		_	(DN) CTS-V				
(4) ZUU4 Passenger	tar (0) tadiiiac	D	[(DIN) C19-A				

Year	Menu1	Menu2	Menu3	Menu4		Erase Codes	Live Data	ECU Info.
(4) 2004	Passenger Car	(6) Cadillac	D	(DM) CTS	•	•	•	•
	Passenger Car	(4) Buick	W	Powertrain	•	•	•	•
(4) 2004	Passenger Car	(4) Buick	W	Chassis	•	•	•	
(4) 2004	Passenger Car	(4) Buick	W	Body				
(4) 2004	Passenger Car	(4) Buick	Н	(HR) LeSabre Limited		•	•	
	Passenger Car	(4) Buick	Н	(HP) LeSabre Custom		•	•	
(4) 2004	Passenger Car	(4) Buick	C	Powertrain				
(4) 2004	Passenger Car	(4) Buick	C	Chassis				
(4) 2004	Passenger Car	(4) Buick	C	Body				
(4) 2004	Passenger Car	(3) Oldsmobile	Powertrain	(F) 2.2L L4 L61		•	•	•
(4) 2004	Passenger Car	(3) Oldsmobile	Powertrain	(E) 3.4L V6 LA1	•	•	•	•
(4) 2004	Passenger Car	(3) Oldsmobile	Chassis	Electronic Brake Control Module		•	•	•
	Passenger Car	(3) Oldsmobile	Body	Supplemental Inflatable Restraint	•	•	•	•
	Passenger Car	(3) Oldsmobile	Body	Remote Function Actuation	•	•	•	•
	Passenger Car	(3) Oldsmobile	Body	Radio		•	•	
	Passenger Car	(3) Oldsmobile	Body	Instrument Panel Cluster	•	•		
	Passenger Car	(3) Oldsmobile	Body	Body Control Module	•	•	•	•
	Passenger Car	(2) Pontiac	W	Powertrain	•			•
	Passenger Car	(2) Pontiac	W	Chassis	•			•
	Passenger Car	(2) Pontiac	W	Body				•
	Passenger Car	(2) Pontiac	V	Powertrain				•
	Passenger Car	(2) Pontiac	V	Chassis				
	Passenger Car	(2) Pontiac	V	Body				
	Passenger Car	(2) Pontiac	S					
		(2) Pontiac	S .	Powertrain			•	
	Passenger Car	(2) Pontiac (2) Pontiac	5	Chassis				
	Passenger Car	(2) Pontiac	2	Body		_	•	
	Passenger Car	(2) Pontiac	IN and the second secon	Powertrain	•	•	•	•
	Passenger Car	(2) Pontiac	N N	Chassis	•	•	•	•
	Passenger Car	(2) Pontiac	N .,	Body	•	•	•	•
	Passenger Car	(2) Pontiac	<u>M</u>	Powertrain	•	•	•	•
	Passenger Car	(2) Pontiac	M	Chassis	•	•	•	•
	Passenger Car	(2) Pontiac	<u>M</u>	Body	•	•		•
	Passenger Car	(2) Pontiac	J	Powertrain		•	•	•
	Passenger Car	(2) Pontiac	J	Chassis	•	•	•	•
		(2) Pontiac	J	Body	•	•	•	•
	Passenger Car	(2) Pontiac	Н	(HZ) Bonneville GXP	•	•		•
	Passenger Car	(2) Pontiac	Н	(HY) Bonneville SLE	•	•	•	•
	Passenger Car	(2) Pontiac	Н	(HX) Bonneville SE	•	•	•	•
	Passenger Car	(1) Chevrolet	Z	Transmission/Transaxle	•	•	•	•
(4) 2004	Passenger Car	(1) Chevrolet	Ζ	Steering	•		•	
	Passenger Car	(1) Chevrolet	Z	Restraints		•	•	•
	Passenger Car	(1) Chevrolet	Z	HVAC	•	•	•	•
	Passenger Car	(1) Chevrolet	Z	Engine	•	•	•	•
	Passenger Car	(1) Chevrolet	Z	Brakes	•	•	•	•
		(1) Chevrolet	7.	Body and Accessories	•	•		

Year	Menu1	Menu2	Menu3	Menu4		Erase Codes		ECU Info.
(4) 2004	Passenger Car	(1) Chevrolet	Y	Powertrain	•	•	•	
(4) 2004	Passenger Car	(1) Chevrolet	Y	Chassis	•	•	•	
(4) 2004	Passenger Car	(1) Chevrolet	Y	Body	•			
(4) 2004	Passenger Car	(1) Chevrolet	W	Powertrain	•			
(4) 2004	Passenger Car	(1) Chevrolet	W	Chassis	•			
(4) 2004	Passenger Car	(1) Chevrolet	W	Body	•			
(4) 2004	Passenger Car	(1) Chevrolet	V	Powertrain	•			
(4) 2004	Passenger Car	(1) Chevrolet	V	Chassis	•			
(4) 2004	Passenger Car	(1) Chevrolet	V	Body	•			
(4) 2004	Passenger Car	(1) Chevrolet	U	Powertrain	•		•	
(4) 2004	Passenger Car	(1) Chevrolet	U	Chassis	•		•	
(4) 2004	Passenger Car	(1) Chevrolet	U	Body	•	•	•	
(4) 2004	Passenger Car	(1) Chevrolet	T	Chassis	•		•	
(4) 2004	Passenger Car	(1) Chevrolet	T	Body	•	•	•	
(4) 2004	Passenger Car	(1) Chevrolet	S	Monza	•	•	•	
(4) 2004	Passenger Car	(1) Chevrolet	S	Chevy	•		•	
(4) 2004	Passenger Car	(1) Chevrolet	S	Aveo	•	•	•	•
	Passenger Car	(1) Chevrolet	N	Optra Optra	•	•	•	•
	Passenger Car	(1) Chevrolet	N	Classic	•	•	•	•
	Passenger Car	(1) Chevrolet	N	Alero (Export)	•	•	•	•
	Passenger Car	(1) Chevrolet	М	Powertrain	•	•	•	
	Passenger Car	(1) Chevrolet	M	Chassis	•		•	
	Passenger Car	(1) Chevrolet	M	Body	•		•	
	Passenger Car	(1) Chevrolet	L	Powertrain	•		•	
	Passenger Car	(1) Chevrolet	Ī.	Chassis	•	•	•	
	Passenger Car	(1) Chevrolet	Ī.	Body	•	•	•	
	Passenger Car	(1) Chevrolet	Ţ	Optra	•	•	•	•
	Passenger Car	(1) Chevrolet	Ţ	Cavalier	•	•	•	
		Hummer H-1	Powertrain	Powertrain Control Module	•	•	•	
	Medium Duty Truck	(T) GMC Truck	T - B7 Chassis	Powertrain	•	•	•	
	Medium Duty Truck	(T) GMC Truck	T - B7 Chassis	Chassis	•	•	•	
	Medium Duty Truck	(T) GMC Truck	D - C Series	Powertrain	•	•	•	
	Medium Duty Truck	(T) GMC Truck	D - C Series	Chassis	•	•	•	
		(T) GMC Truck	D - C Series	Body	•	•	•	•
(4) 2004	Medium Duty Truck	(T) GMC Truck	C - WT5500	Powertrain	•	•	•	•
	Medium Duty Truck	(T) GMC Truck	C - WT5500	Chassis	•	•	•	•
	Medium Duty Truck	(T) GMC Truck	C - T Series	Powertrain	•	•	•	
	Medium Duty Truck	(T) GMC Truck	C - T Series	Chassis	•	•		
	Medium Duty Truck	(T) GMC Truck	C - T Series	Body	•	•	•	•
	Medium Duty Truck	(T) GMC Truck	B - W4 Series	Powertrain	•	•	•	
	Medium Duty Truck	(T) GMC Truck	B - W4 Series	Chassis	•	•	•	
	Medium Duty Truck	(C) Chevrolet Truck	T - B7 Chassis	Powertrain	•	•		
	Medium Duty Truck	(C) Chevrolet Truck	T - B7 Chassis	Chassis	•	•		
	Medium Duty Truck	(C) Chevrolet Truck	D - C Series	Powertrain	•			
	Medium Duty Truck	(C) Chevrolet Truck	D - C Series	Chassis				
(4) 2004	meatum Duty ITuck	(c) chearorer track	ν – ο series	UIIaSSTS			•	

Year	Menu1	Menu2	Menu3	Menu4		Erase Codes	Live Data	ECU Info.
(4) 2004	Medium Duty Truck	(C) Chevrolet Truck	D - C Series	Body	•	•	•	•
(4) 2004	Medium Duty Truck	(C) Chevrolet Truck	C - WT5500	Powertrain	•	•	•	•
(4) 2004	Medium Duty Truck	(C) Chevrolet Truck	C - WT5500	Chassis	•	•	•	
(4) 2004	Medium Duty Truck	(C) Chevrolet Truck	C - T Series	Powertrain	•	•	•	
(4) 2004	Medium Duty Truck	(C) Chevrolet Truck	C - T Series	Chassis	•	•	•	
	Medium Duty Truck	(C) Chevrolet Truck	C - T Series	Body			•	
(4) 2004	Medium Duty Truck	(C) Chevrolet Truck	B - W4 Series	Powertrain			•	
	Medium Duty Truck	(C) Chevrolet Truck	B - W4 Series	Chassis		•	•	•
		(T) GMC Truck	T	Sonoma		•	•	•
(4) 2004		(T) GMC Truck	T	Jimmy			•	
		(T) GMC Truck	T	Envoy XUV			•	
(4) 2004		(T) GMC Truck	T	Envoy XL			•	
		(T) GMC Truck	T	Envoy			•	
		(T) GMC Truck	T	Canyon			•	
		(T) GMC Truck	S	Sonoma			•	
(4) 2004		(T) GMC Truck	S	Jimmy			•	
(4) 2004		(T) GMC Truck	S	Envoy XUV			•	
(4) 2004		(T) GMC Truck	S	Envoy XL			•	
(4) 2004		(T) GMC Truck	S	Envoy			•	
(4) 2004		(T) GMC Truck	M	Powertrain			•	
(4) 2004		(T) GMC Truck	M	Chassis			•	
(4) 2004		(T) GMC Truck	M	Body			•	
(4) 2004		(T) GMC Truck	L	Powertrain			•	
(4) 2004		(T) GMC Truck	L	Chassis			•	
(4) 2004		(T) GMC Truck	L	Body			•	
(4) 2004	LD Trk, MPV, Incomplete	(T) GMC Truck	K	Powertrain				
(4) 2004	LD Trk, MPV, Incomplete	(T) GMC Truck	Н	Express/Savana		•	•	
(4) 2004		(T) GMC Truck	Н	Express Access/Savana Pro			•	
(4) 2004		(T) GMC Truck	G	Express/Savana			•	
(4) 2004		(T) GMC Truck	G	Express Access/Savana Pro			•	
		(T) GMC Truck	C	Powertrain			•	
		(R) Hummer	Powertrain	(U) 6.0L V8 LQ4			•	
		(R) Hummer	Chassis	Air Suspension			•	
	LD Trk, MPV, Incomplete		Chassis	ABS			•	
(4) 2004	LD Trk, MPV, Incomplete	(N) Chevrolet MPV	X	Powertrain			•	
(4) 2004	LD Trk, MPV, Incomplete	(N) Chevrolet MPV	X	Chassis		•	•	
(4) 2004	LD Trk, MPV, Incomplete	(N) Chevrolet MPV	X	Body			•	
	LD Trk, MPV, Incomplete		V	Powertrain	•	•	•	
$(4) \ \overline{2004}$	LD Trk, MPV, Incomplete	(N) Chevrolet MPV	V	Chassis	•	•	•	•
	LD Trk, MPV, Incomplete		V	Body	•	•	•	•
	LD Trk, MPV, Incomplete		U	Powertrain		•	•	•
	LD Trk, MPV, Incomplete		U	Chassis		•	•	•
	LD Trk, MPV, Incomplete		U	Body	•	•	•	•
$(4) \ \overline{2004}$	LD Trk, MPV, Incomplete	(M) Pontiac APV	X	Powertrain		•		
(4) 2004	LD Trk, MPV, Incomplete	(M) Pontiac APV	X	Chassis				

143 2004 D Trk, MFV, Incomplete QD Pontine AFV Y Powertrain	Read Erase Live codes Codes Data	Menu4	Menu2	Year Menu1
10 2004 D Trk, MFV, Incomplete O) Pontinc APV V Chassis O O		Body	(M) Pontiac APV	(4) 2004 LD Trk, MPV, Incomplete
10 2004 D Frk, NPV, Incomplete M) Pontiac APV V Body	• • •			
10 2004 D Trk, WP,	• • •			
44 2004 D Trk, MPV, Incomplete OP Portine APV D Chassis O O	• • •			
40 2004 D Trk, MPV, Incomplete 00 Pontiac APV U Body 0 0 0 0 0 0 0 0 0		Powertrain		
40 2004 D Trk, MPV, Incomplete 00 Pentiac APV B Powertrain			(M) Pontiac APV	(4) 2004 LD Trk, MPV, Incomplete
44 2004 D. Trk, MPV, Incomplete MD. Pontiac APV B Body ■ ■ ■ ■ ■ ■ ■ ■ ■			(M) Pontiac APV	(4) 2004 LD Trk, MPV, Incomplete
40 2004 D. Trk, MPV, Incomplete 40 Postiac APV A Powertrain 40 2004 D. Trk, MPV, Incomplete 40 Postiac APV A Chassis 40 2004 D. Trk, MPV, Incomplete 40 Postiac APV A Body 40 2004 D. Trk, MPV, Incomplete 40 Postiac APV A Body 40 2004 D. Trk, MPV, Incomplete 40 Postiac APV A Powertrain 40 2004 D. Trk, MPV, Incomplete 40 Postiac APV X Powertrain 40 2004 D. Trk, MPV, Incomplete 40 Postiac APV X Powertrain 40 2004 D. Trk, MPV, Incomplete 40 Postiac APV X Powertrain 40 2004 D. Trk, MPV, Incomplete 40 Postiac APV X Powertrain 40 2004 D. Trk, MPV, Incomplete 40 Postiac APV V Powertrain 40 2004 D. Trk, MPV, Incomplete 40 Postiac APV V Powertrain 40 2004 D. Trk, MPV, Incomplete 40 Postiac APV V Powertrain 40 2004 D. Trk, MPV, Incomplete 40 Postiac APV V Powertrain 40 2004 D. Trk, MPV, Incomplete 40 Postiac APV T Powertrain 40 2004 D. Trk, MPV, Incomplete 40 Postiac APV T Powertrain 40 2004 D. Trk, MPV, Incomplete 40 Postiac APV T Powertrain 40 2004 D. Trk, MPV, Incomplete 40 Postiac APV T Powertrain 40 2004 D. Trk, MPV, Incomplete 40 Postiac APV T Powertrain 40 2004 D. Trk, MPV, Incomplete 40 Postiac APV T Powertrain 40 2004 D. Trk, MPV, Incomplete 40 Postiac APV T Powertrain 40 2004 D. Trk, MPV, Incomplete 40 Postiac APV T Powertrain 40 2004 D. Trk, MPV, Incomplete 40 Postiac APV T Powertrain 40 2004 D. Trk, MPV, Incomplete 40 Postiac APV T Powertrain 40 2004 D. Trk, MPV, Incomplete 40 Postiac APV T Powertrain 40 2004 D. Trk, MPV, Incomplete 40 Postiac APV T TrailBlazer EXT 40 2004 D. Trk, MPV, Incomplete 40 Postiac APV T TrailBlazer EXT 40 2004 D. Trk, MPV, Incomplete 40 Postiac APV T TrailBlazer EXT 40 2004 D. Trk, MPV, Incomplete 40 Postiac APV T TrailBlazer EXT 40 2004 D. Trk, MPV, Incomplete 40 Postiac APV T TrailBlazer EXT 40 2		Powertrain	(M) Pontiac APV	(4) 2004 LD Trk, MPV, Incomplete
[4] 2004 LD Trk, MPV, Incomplete (4) 2004 LD Trk, MPV, Incomplete (3) Pontiac APV A Powertrain [4] 2004 LD Trk, MPV, Incomplete (4) 2004 LD Trk, MPV, Incomplete (3) Pontiac APV A Chassis ● [4] 2004 LD Trk, MPV, Incomplete (4) 2004 LD Trk, MPV, Incomplete (4) 2004 LD Trk, MPV, Incomplete (4) 2004 LD Trk, MPV, Incomplete (6) Oldsmobile APV X Powertrain ● ● [4] 2004 LD Trk, MPV, Incomplete (4) Data and transported (4) 2004 LD Trk, MPV, Incomplete (6) Oldsmobile APV X Chassis ● ● [4] 2004 LD Trk, MPV, Incomplete (7) Data and transported (8) Data and transported (9) Oldsmobile APV Y Powertrain ● ● [4] 2004 LD Trk, MPV, Incomplete (9) Oldsmobile APV Y Powertrain ● ● ● [4] 2004 LD Trk, MPV, Incomplete (9) Oldsmobile APV Y Powertrain ● ● ● [4] 2004 LD Trk, MPV, Incomplete (9) Oldsmobile APV Y Powertrain ● ● ● [4] 2004 LD Trk, MPV, Incomplete (9) Oldsmobile APV T Powertrain ● ● ● [4] 2004 LD Trk, MPV, Incomplete (9) Oldsmobile APV T Powertrain ● ● ● [4] 2004 LD Trk, MPV, Incomplete (9) Cadillac Incomplete (1) Cadillac Incomplete (1) Cadi		Chassis	(M) Pontiac APV	(4) 2004 LD Trk, MPV, Incomplete
49 2004 D Trk, MPV, Incomplete M) Pontiac APV A Body ● ● ● ● ● ● ● ● ● ● ●			(M) Pontiac APV	(4) 2004 LD Trk, MPV, Incomplete
40 2004 D Trk, MPV, Incomplete M) Pontiac APV X Powertrain ● ● ● ● ● ● ● ● ● ● ● ● ● ● ● ● ● ● ● ● ● ● ● ● ● ● ● ● ● ● ● ● ● ● ● ● ●		Powertrain	(M) Pontiac APV	
49 2004 LD Trk, MPV, Incomplete M) Pontiac APV X Powertrain Mode		Chassis	(M) Pontiac APV	(4) 2004 LD Trk, MPV, Incomplete
40 2004 LD Trk, MPV, Incomplete (H) Oldsmobile APV X Body ● ● ●			(M) Pontiac APV	(4) 2004 LD Trk, MPV, Incomplete
40 2004 LD Trk, MPV, Incomplete (H) Oldsmobile APV X Body ● ●		Powertrain	(H) Oldsmobile APV	(4) 2004 LD Trk, MPV, Incomplete
(4) 2004 LD Trk, MPV, Incomplete (H) Oldsmobile APV V Powertrain (4) 2004 LD Trk, MPV, Incomplete (H) Oldsmobile APV V Chassis ● ● (4) 2004 LD Trk, MPV, Incomplete (H) Oldsmobile APV V Chassis ● ● (4) 2004 LD Trk, MPV, Incomplete (H) Oldsmobile APV V Body ● ● (4) 2004 LD Trk, MPV, Incomplete (H) Oldsmobile APV T Powertrain ● ● (4) 2004 LD Trk, MPV, Incomplete (H) Oldsmobile APV T Chassis ● ● (4) 2004 LD Trk, MPV, Incomplete (H) Oldsmobile APV T Chassis ● ● (4) 2004 LD Trk, MPV, Incomplete (E) Cadillac Incomplete Limousine Powertrain ● ● (4) 2004 LD Trk, MPV, Incomplete (E) Cadillac Incomplete Limousine Chassis ● ● (4) 2004 LD Trk, MPV, Incomplete (E) Cadillac Incomplete Hearse Powertrain ● ● (4) 2004 LD Trk, MPV, Incomplete (E) Cadillac Incomplete Hearse Chassis ● ● (4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck<	• • •			
(4) 2004 LD Trk, MPV, Incomplete (H) Oldsmobile APV V Chassis ● ● ● ● ● ● ● ● ● ●	• • •			
(4) 2004 LD Trk, MPV, Incomplete (H) Oldsmobile APV V Body ● ● (4) 2004 LD Trk, MPV, Incomplete (H) Oldsmobile APV V Body ● ● (4) 2004 LD Trk, MPV, Incomplete (H) Oldsmobile APV T Powertrain ● ● (4) 2004 LD Trk, MPV, Incomplete (H) Oldsmobile APV T Chassis ● ● (4) 2004 LD Trk, MPV, Incomplete (H) Oldsmobile APV S Powertrain ● ● (4) 2004 LD Trk, MPV, Incomplete (E) Cadillac Incomplete Limousine Powertrain ● ● (4) 2004 LD Trk, MPV, Incomplete (E) Cadillac Incomplete Limousine Chassis ● ● (4) 2004 LD Trk, MPV, Incomplete (E) Cadillac Incomplete Hearse Powertrain ● ● (4) 2004 LD Trk, MPV, Incomplete (E) Cadillac Incomplete Hearse Powertrain ● ● (4) 2004 LD Trk, MPV, Incomplete (C) Cadillac Incomplete Hearse Body ● ● (4) 2004 LD Trk, MPV, Incomplete (C) Cadillac Incomplete Hearse Body ● ● (4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck T TrailBlaze	• • •	Powertrain		
(4) 2004 LD Trk, MPV, Incomplete (H) Oldsmobile APV T Powertrain (4) 2004 LD Trk, MPV, Incomplete (H) Oldsmobile APV T Powertrain (4) 2004 LD Trk, MPV, Incomplete (H) Oldsmobile APV T Chassis (4) 2004 LD Trk, MPV, Incomplete (H) Oldsmobile APV S Powertrain (4) 2004 LD Trk, MPV, Incomplete (E) Cadillac Incomplete Limousine Powertrain (4) 2004 LD Trk, MPV, Incomplete (E) Cadillac Incomplete Limousine Chassis (4) 2004 LD Trk, MPV, Incomplete (E) Cadillac Incomplete Limousine Body (4) 2004 LD Trk, MPV, Incomplete (E) Cadillac Incomplete Limousine Body (4) 2004 LD Trk, MPV, Incomplete (E) Cadillac Incomplete Hearse Powertrain (4) 2004 LD Trk, MPV, Incomplete (E) Cadillac Incomplete Hearse Chassis (4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck T TrailBlazer EXT (4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck T TrailBlazer ● (4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck T TrailBlazer ● (4) 2004 LD Trk, MPV, Incomplete <td< td=""><td></td><td></td><td></td><td></td></td<>				
(4) 2004 LD Trk, MPV, Incomplete (H) Oldsmobile APV T Powertrain ● ● (4) 2004 LD Trk, MPV, Incomplete (H) Oldsmobile APV T Chassis ● ● (4) 2004 LD Trk, MPV, Incomplete (H) Oldsmobile APV S Powertrain ● ● (4) 2004 LD Trk, MPV, Incomplete (E) Cadillac Incomplete Limousine Powertrain ● ● (4) 2004 LD Trk, MPV, Incomplete (E) Cadillac Incomplete Limousine Chassis ● ● (4) 2004 LD Trk, MPV, Incomplete (E) Cadillac Incomplete Limousine Body ● ● (4) 2004 LD Trk, MPV, Incomplete (E) Cadillac Incomplete Limousine Body ● ● (4) 2004 LD Trk, MPV, Incomplete (E) Cadillac Incomplete Limousine Body ● ● (4) 2004 LD Trk, MPV, Incomplete (E) Cadillac Incomplete Hearse Chassis ● ● (4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck T TrailBlazer EXT ● ● (4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck T S10 ● ● (4) 2004	• • •			
(4) 2004 LD Trk, MPV, Incomplete (H) Oldsmobile APV T Chassis ● ● ● (4) 2004 LD Trk, MPV, Incomplete (H) Oldsmobile APV S Powertrain ● ● ● (4) 2004 LD Trk, MPV, Incomplete (E) Cadillac Incomplete Limousine Chassis ● ● (4) 2004 LD Trk, MPV, Incomplete (E) Cadillac Incomplete Limousine Body ● ● (4) 2004 LD Trk, MPV, Incomplete (E) Cadillac Incomplete Hearse Powertrain ● ● (4) 2004 LD Trk, MPV, Incomplete (E) Cadillac Incomplete Hearse Powertrain ● ● (4) 2004 LD Trk, MPV, Incomplete (E) Cadillac Incomplete Hearse Powertrain ● ● ● (4) 2004 LD Trk, MPV, Incomplete (E) Cadillac Incomplete Hearse Chassis ● ● ● (4) 2004 LD Trk, MPV, Incomplete (E) Cadillac Incomplete Hearse Body ● ● ● (4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck T TrailBlazer EXT ● ● (4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck S <td>• • •</td> <td>i -</td> <td></td> <td></td>	• • •	i -		
(4) 2004 LD Trk, MPV, Incomplete (H) Oldsmobile APV S Powertrain ● ● (4) 2004 LD Trk, MPV, Incomplete (E) Cadillac Incomplete Limousine Chassis ● ● (4) 2004 LD Trk, MPV, Incomplete (E) Cadillac Incomplete Limousine Body ● ● (4) 2004 LD Trk, MPV, Incomplete (E) Cadillac Incomplete Limousine Body ● ● (4) 2004 LD Trk, MPV, Incomplete (E) Cadillac Incomplete Hearse Powertrain ● ● (4) 2004 LD Trk, MPV, Incomplete (E) Cadillac Incomplete Hearse Powertrain ● ● (4) 2004 LD Trk, MPV, Incomplete (E) Cadillac Incomplete Hearse Chassis ● ● (4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck T TrailBlazer EXT ● ● (4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck T S10 ● ● (4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck T Blazer ● ● (4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck S TrailBlazer ● ● (4) 20	• • •			
(4) 2004 LD Trk, MPV, Incomplete (E) Cadillac Incomplete Limousine Powertrain (4) 2004 LD Trk, MPV, Incomplete (E) Cadillac Incomplete Limousine Chassis ● ● (4) 2004 LD Trk, MPV, Incomplete (E) Cadillac Incomplete Limousine Body ● ● (4) 2004 LD Trk, MPV, Incomplete (E) Cadillac Incomplete Hearse Powertrain ● ● (4) 2004 LD Trk, MPV, Incomplete (E) Cadillac Incomplete Hearse Chassis ● ● (4) 2004 LD Trk, MPV, Incomplete (E) Cadillac Incomplete Hearse Body ● ● (4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck T TrailBlazer EXT ● ● (4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck T S10 ● ● (4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck T Blazer ● ● (4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck S TrailBlazer ● ● (4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck S TrailBlazer ● ● (4) 2004 LD Trk, MPV, Incomplete	• • •			
(4) 2004 LD Trk, MPV, Incomplete (E) Cadillac Incomplete Limousine Chassis (4) 2004 LD Trk, MPV, Incomplete (E) Cadillac Incomplete Limousine Body (4) 2004 LD Trk, MPV, Incomplete (E) Cadillac Incomplete Hearse Powertrain (4) 2004 LD Trk, MPV, Incomplete (E) Cadillac Incomplete Hearse Chassis (4) 2004 LD Trk, MPV, Incomplete (E) Cadillac Incomplete Hearse Body (4) 2004 LD Trk, MPV, Incomplete (E) Cadillac Incomplete Hearse (4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck TrailBlazer EXT (4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck TrailBlazer (4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck TrailBlazer (4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck TrailBlazer (4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck TrailBlazer (4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck S (4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck S (4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck S (4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck S (4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck	• • •			
(4) 2004 LD Trk, MPV, Incomplete(E) Cadillac IncompleteLimousineBody●●(4) 2004 LD Trk, MPV, Incomplete(E) Cadillac IncompleteHearsePowertrain●●(4) 2004 LD Trk, MPV, Incomplete(E) Cadillac IncompleteHearseChassis●●(4) 2004 LD Trk, MPV, Incomplete(E) Cadillac IncompleteHearseBody●●(4) 2004 LD Trk, MPV, Incomplete(C) Chevrolet TruckTTrailBlazer EXT●●(4) 2004 LD Trk, MPV, Incomplete(C) Chevrolet TruckTTrailBlazer●●(4) 2004 LD Trk, MPV, Incomplete(C) Chevrolet TruckTS10●●(4) 2004 LD Trk, MPV, Incomplete(C) Chevrolet TruckTColorado●●(4) 2004 LD Trk, MPV, Incomplete(C) Chevrolet TruckTBlazer●●(4) 2004 LD Trk, MPV, Incomplete(C) Chevrolet TruckSTrailBlazer EXT●●(4) 2004 LD Trk, MPV, Incomplete(C) Chevrolet TruckSTrailBlazer●●(4) 2004 LD Trk, MPV, Incomplete(C) Chevrolet TruckSSSR●●(4) 2004 LD Trk, MPV, Incomplete(C) Chevrolet TruckSSSR●●(4) 2004 LD Trk, MPV, Incomplete(C) Chevrolet TruckSSI0●●(4) 2004 LD Trk, MPV, Incomplete(C) Chevrolet TruckSBlazer●●(4) 2004 LD Trk, MPV, Incomplete(C) Chevrolet TruckSBlazer●●(4)	• • •			
(4) 2004 LD Trk, MPV, Incomplete (E) Cadillac Incomplete Hearse Powertrain ● ● (4) 2004 LD Trk, MPV, Incomplete (E) Cadillac Incomplete Hearse Chassis ● ● (4) 2004 LD Trk, MPV, Incomplete (E) Cadillac Incomplete Hearse Body ● ● (4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck T TrailBlazer EXT ● ● (4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck T S10 ● ● (4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck T Colorado ● ● (4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck T Blazer ● ● (4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck S TrailBlazer EXT ● ● (4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck S TrailBlazer ● ● (4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck S SSR ● ● (4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck S SSR ● ● (4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck S S10 ● ● (4) 2004 LD Trk, MPV, Incomplete (C)	• • •			
(4) 2004 LD Trk, MPV, Incomplete (E) Cadillac Incomplete Hearse Chassis ● ● (4) 2004 LD Trk, MPV, Incomplete (E) Cadillac Incomplete Hearse Body ● ● (4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck T TrailBlazer EXT ● ● (4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck T S10 ● ● (4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck T Colorado ● ● (4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck T Blazer ● ● (4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck S TrailBlazer EXT ● ● (4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck S TrailBlazer ● ● (4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck S TrailBlazer ● ● (4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck S SSR ● ● (4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck S SSR ● ● (4) 2004 LD Trk, MPV, Incomplete (C)	• • •	ř		
(4) 2004 LD Trk, MPV, Incomplete (E) Cadillac Incomplete Hearse Body ● <t< td=""><td>• • •</td><td></td><td></td><td></td></t<>	• • •			
(4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck T TrailBlazer EXT ● ● (4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck T TrailBlazer ● ● (4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck T S10 ● ● (4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck T Colorado ● ● (4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck T Blazer ● ● (4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck S TrailBlazer EXT ● ● (4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck S TrailBlazer ● ● (4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck S SSR ● ● (4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck S S10 ● ● (4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck S S10 ● ● (4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck S Blazer ● ● (4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck S Blazer ● ●				
(4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck T TrailBlazer ● ● (4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck T S10 ● ● (4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck T Colorado ● ● (4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck T Blazer ● ● (4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck S TrailBlazer EXT ● ● (4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck S TrailBlazer ● ● (4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck S SSR ● ● (4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck S S10 ● ● (4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck S Blazer ● ● (4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck S Blazer ● ● (4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck S Blazer ● ●	• • •	ř		
(4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck T S10 ● ● (4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck T Colorado ● ● (4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck TrailBlazer ● ● (4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck S TrailBlazer E (4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck S TrailBlazer ● ● (4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck S SSR ● ● (4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck S S10 ● ● (4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck S Blazer ● ● (4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck S Blazer ● ● (4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck S Blazer ● ● (4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck S Blazer ● ●	• • •			
(4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck T Colorado ● ● ● (4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck T Blazer ● ● ● (4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck S TrailBlazer ● ● ● (4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck S SSR ● ● ● (4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck S S10 ● ● ● (4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck S Blazer ● ● (4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck S Blazer ● ● (4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck S Blazer ● ● (4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck S Blazer ● ●	• • •			
(4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck TrailBlazer EXT ● ● ● (4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck S TrailBlazer EXT ● ● ● (4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck S SSR ● ● ● (4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck S S10 ● ● ● (4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck S Blazer ● ● ● (4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck S Blazer ● ● ● (4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck S Blazer ● ● ● (4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck S Blazer ● ● ●				
(4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck S TrailBlazer EXT ● ● ● (4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck S TrailBlazer ● ● ● (4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck S SSR ● ● ● (4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck S Blazer ● ● (4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck S Blazer ● ● (4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck M Powertrain ● ●	• • •			
(4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck S SSR ● ● ● (4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck S S10 ● ● ● (4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck S Blazer ● ● ● (4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck M Powertrain ● ●				
(4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck S S10 ● ● ● (4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck S Blazer ● ● ● (4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck M Powertrain ● ●				
(4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck S Blazer ● ● (4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck M Powertrain ● ●				· · · · · · · · · · · · · · · · · · ·
(4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck M Powertrain				T T T T T T T T T T T T T T T T T T T
				T T T T T T T T T T T T T T T T T T T
(4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck M Chassis		Chassis	(C) Chevrolet Truck	(4) 2004 LD Trk, MPV, Incomplete
(4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck M Body				T T T T T T T T T T T T T T T T T T T
(4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck L Powertrain		*		
(4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck L Chassis				
(4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck L Body				
(4) 2004 LD Trk, MPV, Incomplete (C) Chevrolet Truck K Powertrain		*		

Year	Menu1	Menu2	Menu3	Menu4	Read Er		Live Data	ECU Info.
(4) 2004	LD Trk, MPV, Incomplete	(C) Chevrolet Truck	Ј	Powertrain	•	•	•	•
		(C) Chevrolet Truck	J	Chassis	•	•	•	•
(4) 2004	LD Trk, MPV, Incomplete	(C) Chevrolet Truck	Ј	Body	•	•	•	•
(4) 2004	LD Trk, MPV, Incomplete	(C) Chevrolet Truck	Н	Express/Savana	•	•	•	•
(4) 2004	LD Trk, MPV, Incomplete	(C) Chevrolet Truck	Н	Express Access/Savana Pro	•	•	•	
(4) 2004	LD Trk, MPV, Incomplete	(C) Chevrolet Truck	G	Express/Savana	•	•	•	
(4) 2004	LD Trk, MPV, Incomplete	(C) Chevrolet Truck	G	Express Access/Savana Pro	•	•	•	
(4) 2004	LD Trk, MPV, Incomplete	(C) Chevrolet Truck	E	Powertrain	•	•	•	
(4) 2004	LD Trk, MPV, Incomplete	(C) Chevrolet Truck	E	Chassis	•	•	•	•
(4) 2004	LD Trk, MPV, Incomplete	(C) Chevrolet Truck	E	Body	•	•	•	
(4) 2004	LD Trk, MPV, Incomplete	(C) Chevrolet Truck	C	Powertrain	•	•		
(4) 2004	LD Trk, MPV, Incomplete	(6) Cadillac	K	Powertrain	•	•		
(4) 2004	LD Trk, MPV, Incomplete	(6) Cadillac	E	Powertrain	•	•		
(4) 2004	LD Trk, MPV, Incomplete	(6) Cadillac	E	Chassis	•	•		
(4) 2004	LD Trk, MPV, Incomplete	(6) Cadillac	C	Powertrain	•	•		
(4) 2004	LD Trk, MPV, Incomplete	(5) Buick	T	Powertrain	•	•	•	
(4) 2004	LD Trk, MPV, Incomplete	(5) Buick	T	Chassis	•	•	•	
(4) 2004	LD Trk, MPV, Incomplete	(5) Buick	S	Powertrain	•	•		
(4) 2004	LD Trk, MPV, Incomplete	(5) Buick	В	Powertrain	•	•		
(4) 2004	LD Trk, MPV, Incomplete	(5) Buick	В	Chassis	•	•		
(4) 2004	LD Trk, MPV, Incomplete	(5) Buick	A	Powertrain	•	•	•	
(4) 2004	LD Trk, MPV, Incomplete	(5) Buick	A	Chassis	•	•	•	
(3) 2003	Saturn	Powertrain	(R) 3. 0L V6 L81	Powertrain Control Module	•	•	•	
(3) 2003	Saturn	Powertrain	(F) 2.2L L4 L61	J	•	•	•	
(3) 2003	Saturn	Powertrain	(F) 2.2L L4 L61	A	•	•	•	
(3) 2003	Saturn	Powertrain	(D) 2.2L L4 L61	Manual Transmission	•	•	•	
(3) 2003	Saturn	Powertrain	(D) 2.2L L4 L61	Automatic Transmission	•	•		
(3) 2003	Saturn	Powertrain	(B) 3. 0L V6 L81	Powertrain Control Module	•	•		
(3) 2003	Saturn	Chassis	Z	Electric Power Steering	•	•		
(3) 2003	Saturn	Chassis	Z	Antilock Brake System	•	•		
(3) 2003	Saturn	Chassis	J	Electronic Brake Control Module	•	•		
(3) 2003	Saturn	Chassis	A	Electronic Brake Control Module	•	•		
(3) 2003	Saturn	Chassis	A	Electric Power Steering	•	•		
	Saturn	Chassis	A	Antilock Brake System	•	•		
(3) 2003	Saturn	Body	Z	Supplemental Inflatable Restraint	•	•	•	•
(3) 2003		Body	Z	OnStar	•	•	•	
(3) 2003	Saturn	Body	Z	Instrument Panel Cluster	•	•	•	
(3) 2003		Body	Z	Body Control Module	•	•	•	•
(3) 2003	Saturn	Body	Ј	(LW)	•	•	•	•
(3) 2003	Saturn	Body	Ј	(LS)	•	•	•	•
(3) 2003		Body	A	Supplemental Inflatable Restraint	•	•	•	•
(3) 2003		Body	A	OnStar	•	•	•	•
(3) 2003		Body	A	Instrument Panel Cluster	•	•	•	•
(3) 2003		Body	A	Body Control Module	•	•	•	•
		Powertrain	(Z) 2. OL L4 L34	V	•	•	•	•

Year M	Menu1	Menu2	Menu3	Menu4	Read codes	Erase Codes	Live Data	ECU Info.
(3) 2003 F	Passenger Car	Powertrain	(Z) 2. OL L4 L34	L	•	•	•	•
	Passenger Car	Powertrain	(Y) 4.6L V8 LD8	Powertrain Control Module	•	•	•	•
	Passenger Car	Powertrain	(Y) 1.5L L4 LX6	Powertrain Control Module	•	•	•	•
	Passenger Car	Powertrain	(Y) 1.5L L4 LV8	(MFA) 4 Speed Automatic	•	•	•	•
	Passenger Car	Powertrain	(U) 1.6L L4 L91	(MFA) 4 Speed Automatic	•	•	•	•
	Passenger Car	Powertrain	(T) 1.2L L4 LY4	(MFA) 4 Speed Automatic	•	•	•	•
	Passenger Car	Powertrain	(P) 1.8L L4 L79	(MFA) 4 Speed Automatic	•	•	•	•
	Passenger Car	Powertrain	(M) 2.6L V6 LY9	Manual Transmission	•	•	•	•
	Passenger Car	Powertrain	(M) 2.6L V6 LY9	Automatic Transmission	•	•	•	•
(3) 2003 P	Passenger Car	Powertrain	(L) 2.5L L6 LBK	(MLS) 4 Speed Automatic			•	
(3) 2003 F	Passenger Car	Powertrain	(L) 1.8L L4 LNK	Manual			•	
(3) 2003 P	Passenger Car	Powertrain	(L) 1.8L L4 LNK	4 Speed Automatic			•	•
(3) 2003 F	Passenger Car	Powertrain	(K) 0.8L L3 LBF	16-Pin DLC			•	
(3) 2003 F	Passenger Car	Powertrain	(K) 0.8L L3 LBF	12-Pin DLC		•	•	•
(3) 2003 F	Passenger Car	Powertrain	(J) 3.1L V6 LG8	W	•	•	•	•
(3) 2003 F	Passenger Car	Powertrain	(J) 3. 1L V6 LG8	N		•	•	
(3) 2003 P	Passenger Car	Powertrain	(J) 1. 0L L4 LA2	Powertrain Control Module	•	•	•	•
	Passenger Car	Powertrain	(F) 2.2L L4 L61	N	•	•	•	•
	Passenger Car	Powertrain	(F) 2.2L L4 L61	I	•	•	•	•
	Passenger Car	Powertrain	(E) 3.4L V6 LA1	W	•	•	•	•
	Passenger Car	Powertrain	(E) 3. 4L V6 LA1	N		•	•	
	Passenger Car	Powertrain	(C) 4. OL V8 L47	Powertrain Control Module		•	•	
	Passenger Car	Powertrain	(A) 1.4L L4 LBJ	(MFA) 4 Speed Automatic	•	•	•	
	Passenger Car	Powertrain	(9) 4. 6L V8 L37	Powertrain Control Module	•	•	•	
	Passenger Car	Powertrain	(8) 1. 8L L4 LV6	Manual	•	•	•	•
	Passenger Car	Powertrain	(8) 1. 8L L4 LV6	4 Speed Automatic	•	•	•	•
	Passenger Car	Powertrain	(8) 1. 8L L4 L79	Powertrain Control Module	•	•	•	•
	Passenger Car	Powertrain	(7) 1.8L L4 L79	(MFA) 4 Speed Automatic	•	•	•	•
	Passenger Car	Powertrain	(7) 1. 4L L4 L95	(MFA) 4 Speed Automatic	•		•	•
	Passenger Car	Powertrain	(6) 2.2L L4 L42 Alternative Fuel	Powertrain Control Module	•	•	•	•
	Passenger Car	Powertrain	(6) 1. 6L L4 L91	(MFA) 4 Speed Automatic	•	•	•	•
	Passenger Car	Powertrain	(6) 1. 6L L4 L01	Manual Transmission	•	•	•	•
		Powertrain	(6) 1. 6L L4 L01	Automatic Transmission	•	•		•
		Powertrain	(4) 0. 8L L3 LBF	16-Pin DLC	•	•	•	•
		Powertrain	(4) 0.8L L3 LBF	12-Pin DLC	•	•	•	
		Powertrain	(3) 1. 8L L4 L79	(MFA) 4 Speed Automatic	•	•	•	
	Passenger Car	Powertrain	(1) 3. 8L V6 L67	w Speed Automatic		•	•	
				TT				
		Powertrain Powertrain		[]			•	
		Powertrain		Demonstration Control Western		•		
		Powertrain	(0) 1. 0L L4 LA2	Powertrain Control Module			•	•
		Chassis	Y	RTD	•	•	•	•
		Chassis	Y	ABS/TCS	•	•	•	•
		Chassis	W	(4) Buick	•	•	•	•
		Chassis	W	(2) Pontiac	•	•	•	•
(3) 2003 F	Passenger Car	Chassis	W	(1) Chevrolet		•		

Year Menu1	Menu2	Menu3	Menu4		Erase Codes		ECU Info.
(3) 2003 Passenger Car	Chassis	V	Without Traction Control	•	•	•	•
(3) 2003 Passenger Car	Chassis	V	With Traction Control		•	•	
(3) 2003 Passenger Car	Chassis	U	Electronic Brake Control Module		•	•	
(3) 2003 Passenger Car	Chassis	T	Antilock Brake System				
(3) 2003 Passenger Car	Chassis	S	(2) Pontiac				
(3) 2003 Passenger Car	Chassis	N	(3) Oldsmobile	•		•	
(3) 2003 Passenger Car	Chassis	N	(2) Pontiac	•		•	
(3) 2003 Passenger Car	Chassis	N	(1) Chevrolet	•		•	
(3) 2003 Passenger Car	Chassis	M	Electronic Brake Control Module	•		•	
(3) 2003 Passenger Car	Chassis	L	Without Traction Control				
(3) 2003 Passenger Car	Chassis	L	With Traction Control				
(3) 2003 Passenger Car	Chassis	K	(KY) Seville STS				
(3) 2003 Passenger Car	Chassis	K	(KS) Seville SLS				
(3) 2003 Passenger Car	Chassis	K	(KF) DTS				
(3) 2003 Passenger Car	Chassis	K	(KE) DHS				
(3) 2003 Passenger Car	Chassis	K	(KD) Deville	•	•	•	
(3) 2003 Passenger Car	Chassis	Ј	(2) Pontiac	•	•	•	
(3) 2003 Passenger Car	Chassis	Ј	(1) Chevrolet	•		•	
(3) 2003 Passenger Car	Chassis	Н	(HZ) Bonneville SSEi	•	•	•	•
(3) 2003 Passenger Car	Chassis	Н	(HY) Bonneville SLE	•		•	
(3) 2003 Passenger Car	Chassis	Н	(HX) Bonneville SE	•	•	•	•
(3) 2003 Passenger Car	Chassis	Н	(HR) LeSabre Limited	•	•	•	•
(3) 2003 Passenger Car	Chassis	Н	(HP) LeSabre Custom	•	•	•	
(3) 2003 Passenger Car	Chassis	G	Rear Integration Module	•	•	•	•
(3) 2003 Passenger Car	Chassis	G	DRP/ABS/TIM	•	•	•	
(3) 2003 Passenger Car	Chassis	D	(DU) CTS				
(3) 2003 Passenger Car	Chassis	D	(DR) CTS				
(3) 2003 Passenger Car	Chassis	D	(DM) CTS				
(3) 2003 Passenger Car	Chassis	D	(DG) CTS	•	•	•	
(3) 2003 Passenger Car	Chassis	C	DRP/ABS/TIM	•	•	•	
(3) 2003 Passenger Car	Body	Y	(3) Two-Door Convertible				
(3) 2003 Passenger Car	Body	Y	(2) Two-Door Hatchback/Liftback				
(3) 2003 Passenger Car	Body	Y	(1) Two-Door Coupe/Sedan				
(3) 2003 Passenger Car	Body	W	(4) Buick		•	•	
(3) 2003 Passenger Car	Body	W	(2) Pontiac	•	•	•	
(3) 2003 Passenger Car	Body	W	(1) Chevrolet	•	•	•	
(3) 2003 Passenger Car	Body	V	(1) Chevrolet	•		•	
(3) 2003 Passenger Car	Body	ŢŢ	(1) Chevrolet	•	•	•	
(3) 2003 Passenger Car	Body	T	(1) Chevrolet	•	•	•	
(3) 2003 Passenger Car	Body	S	(2) Pontiac	•	•	•	
(3) 2003 Passenger Car	Body	S	(1) Chevrolet			•	
(3) 2003 Passenger Car	Body	N	(3) Oldsmobile			•	
(3) 2003 Passenger Car	Body	N	(2) Pontiac			•	
(3) 2003 Passenger Car	Body	N	(1) Chevrolet	•			
(3) 2003 Passenger Car	Body	M	(2) Pontiac			•	
(a) 2003 rassenger car	μουαγ	IVI	(4) FUILLIAC				

Year Menul	Menu2	Menu3	Menu4		Erase Codes		ECU Info.
(3) 2003 Passenger Car	Body	M	(1) Chevrolet	•	•	•	
(3) 2003 Passenger Car	Body	L	(1) Chevrolet	•			
(3) 2003 Passenger Car	Body	K	(KY) Seville STS	•			
(3) 2003 Passenger Car	Body	K	(KS) Seville SLS	•			
(3) 2003 Passenger Car	Body	K	(KF) DTS	•		•	
(3) 2003 Passenger Car	Body	K	(KE) DHS	•			
(3) 2003 Passenger Car	Body	K	(KD) Deville	•			
(3) 2003 Passenger Car	Body	J	(2) Pontiac	•			
(3) 2003 Passenger Car	Body	J	(1) Chevrolet	•			
(3) 2003 Passenger Car	Body	Н	(4) Buick	•	•	•	
(3) 2003 Passenger Car	Body	Н	(2) Pontiac	•	•	•	
(3) 2003 Passenger Car	Body	G	Vehicle Theft Deterrent	•	•	•	
(3) 2003 Passenger Car	Body	G	Supplemental Inflatable Restraint	•	•	•	
(3) 2003 Passenger Car	Body	G	Remote Function Actuation	•	•	•	
(3) 2003 Passenger Car	Body	G	Rear Integration Module	•	•	•	
(3) 2003 Passenger Car	Body	G	Radio	•	•	•	
(3) 2003 Passenger Car	Body	G	OnStar	•	•	•	•
(3) 2003 Passenger Car	Body	G	Navigation Radio	•	•	•	•
(3) 2003 Passenger Car	Body	G	Memory Seat Module	•	•	•	•
(3) 2003 Passenger Car	Body	G	Instrument Panel Module	•	•	•	
(3) 2003 Passenger Car	Body	G	Instrument Panel Cluster	•	•	•	
(3) 2003 Passenger Car	Body	G	Driver Information Center		•	•	
(3) 2003 Passenger Car	Body	G	Driver Door Module		•	•	
(3) 2003 Passenger Car	Body	G	Dash Integration Module		•	•	
(3) 2003 Passenger Car	Body	G	CD Changer	•	•	•	
(3) 2003 Passenger Car	Body	D	(DU) CTS	•	•	•	
(3) 2003 Passenger Car	Body	D	(DR) CTS	•	•	•	
(3) 2003 Passenger Car	Body	D	(DM) CTS	•	•	•	
(3) 2003 Passenger Car	Body	D	(DG) CTS	•	•	•	
(3) 2003 Passenger Car	Body	C	Vehicle Theft Deterrent	•	•	•	
(3) 2003 Passenger Car	Body	C	Supplemental Inflatable Restraint	•	•	•	
(3) 2003 Passenger Car	Body	C	Remote Function Actuation	•	•	•	
(3) 2003 Passenger Car	Body	C	OnStar	•	•	•	
(3) 2003 Passenger Car	Body	C	Memory Seat Module	•	•	•	
(3) 2003 Passenger Car	Body	C	Instrument Panel Cluster	•	•	•	
(3) 2003 Passenger Car	Body	C	Heating and Air Conditioning	•	•	•	
(3) 2003 Passenger Car	Body	C	Driver Door Module	•	•	•	
(3) 2003 Passenger Car	Body	C	Cellular Telephone	•	•	•	
(3) 2003 Passenger Car	Body	C	Body Control Module	•	•	•	
(3) 2003 Medium Duty Truck	Powertrain	(U) 6. 0L V8 LQ4	4 Speed Automatic	•	•	•	
(3) 2003 Medium Duty Truck	Powertrain	(F) 6.5L V8 L65	Powertrain Control Module	•	•		
(3) 2003 Medium Duty Truck	Powertrain	(E) 8. 1L V8 L18	Manual	•			
(3) 2003 Medium Duty Truck	Powertrain	(E) 8. 1L V8 L18	5 Speed Automatic	•			
(3) 2003 Medium Duty Truck	Powertrain	(E) 8. 1L V8 L18	4 Speed Automatic				
(3) 2003 Medium Duty Truck	Powertrain	(4) 4.8L L4 Diesel	Powertrain Control Module				
(3) 2003 Meatum Duty Truck	rowertrain	(4) 4. OL L4 D1esei	rowertrain control module				

Year Menu1	Menu2	Menu3	Menu4			ive ECU Oata Info.
(3) 2003 Medium Duty Truck	Powertrain	(3) 7.8L L6 LG4	C6/C7/C8		•	• •
(3) 2003 Medium Duty Truck	Powertrain	(3) 7.8L L6 LG4	C - WT5500	•	•	• •
(3) 2003 Medium Duty Truck	Powertrain	(1) 6.6L V8 LB7 Diesel	Manual	•	•	• •
(3) 2003 Medium Duty Truck	Powertrain	(1) 6.6L V8 LB7 Diesel	5 Speed Automatic	•	•	•
(3) 2003 Medium Duty Truck	Chassis	T - B7 Chassis	Hydraulic 4WAL 4 Sensor	•	•	• •
(3) 2003 Medium Duty Truck	Chassis	D - C Series	Hydraulic 4WAL 4 Sensor	•	•	• •
(3) 2003 Medium Duty Truck	Chassis	C - WT5500	Electronic Brake Control Module	•	•	• •
(3) 2003 Medium Duty Truck	Chassis	C - T Series	Hydraulic 4WAL 4 Sensor	•	•	• •
(3) 2003 Medium Duty Truck	Chassis	B - W4 Series	Electronic Brake Control Module	•	•	• •
(3) 2003 Medium Duty Truck	Chassis	7 - W52 Series	Hydraulic 4WAL 4 Sensor	•		• •
(3) 2003 Medium Duty Truck	Chassis	6 - W22 Series	Hydraulic 4WAL 4 Sensor	•	•	• •
(3) 2003 Medium Duty Truck	Body	Hummer H-1	Uplevel Radio	•	•	• •
(3) 2003 Medium Duty Truck	Body	Hummer H-1	Base Radio	•		• •
(3) 2003 Medium Duty Truck	Body	D - C Series	Supplemental Inflatable Restraint	•		• •
(3) 2003 Medium Duty Truck	Body	D - C Series	Serial Data Gateway (If Equipped)	•		• •
(3) 2003 Medium Duty Truck	Body	D - C Series	Radio	•		• •
(3) 2003 Medium Duty Truck	Body	D - C Series	Instrument Panel Cluster	•		• •
(3) 2003 Medium Duty Truck	Body	D - C Series	Chime	•		• •
(3) 2003 LD Trk, MPV, Incomplete		Alternative Fuels	(U) 6.0L V8 LQ4 Dedicated G van	•		• •
(3) 2003 LD Trk, MPV, Incomplete		Alternative Fuels	(U) 6.0L V8 LQ4 Bi-Fuel G van	•		• •
(3) 2003 LD Trk, MPV, Incomplete		Alternative Fuels	(U) 6.0L V8 LQ4 Bi-Fuel	•		• •
(3) 2003 LD Trk, MPV, Incomplete		(X) 4.3L V6 LU3 (G Van)	Powertrain Control Module	•		• •
(3) 2003 LD Trk, MPV, Incomplete		(X) 4.3L V6 LU3 (C/K, only)	Manual			• •
(3) 2003 LD Trk, MPV, Incomplete		(X) 4.3L V6 LU3 (C/K, only)	4 Speed Automatic			• •
(3) 2003 LD Trk, MPV, Incomplete		(P) 5. 3L V8 LM4	2 Wheel Drive	$+$ \bullet $+$		• •
(3) 2003 LD Trk, MPV, Incomplete		(P) 5. 3L V8 LM4	2 Speed Active	+ • +		• •
(3) 2003 LD Trk, MPV, Incomplete		(P) 3.9L L4 L4B Diesel	Powertrain Control Module			• •
(3) 2003 LD Trk, MPV, Incomplete		(N) 6. 0L V8 LQ9	Powertrain Control Module	•		
(3) 2003 LD Trk, MPV, Incomplete	Powertrain	(F) 6.5L V8 L65	4 Speed Automatic			• •
(3) 2003 LD Trk, MPV, Incomplete		(6) 1. 6L L4 L01	Powertrain Control Module	+ • +		
(3) 2003 LD Trk, MPV, Incomplete (3) 2003 LD Trk, MPV, Incomplete	Powertrain Chassis	(4) 2.5L V6 LE8	Powertrain Control Module	+ + +		
(3) 2003 LD Trk, MPV, Incomplete (3) 2003 LD Trk, MPV, Incomplete		V	Electronic Brake Control Module Electronic Brake Control Module	+ + +		
(3) 2003 LD Trk, MPV, Incomplete		TT	Electronic Brake Control Module			
(3) 2003 LD Trk, MPV, Incomplete		T	4WAL 3 Sensor	•	_	• •
(3) 2003 LD Trk, MPV, Incomplete		S	Traction Assist (If Equipped)			• •
(3) 2003 LD Trk, MPV, Incomplete		S	4WAL 3 Sensor			• •
(3) 2003 LD Trk, MPV, Incomplete		p	4WAL 3 Sensor			• •
(3) 2003 LD Trk, MPV, Incomplete		N	Air Suspension			
(3) 2003 LD Trk, MPV, Incomplete		N	ABS			• •
(3) 2003 LD Trk, MPV, Incomplete		M	4WAL 3 Sensor			
(3) 2003 LD Trk, MPV, Incomplete		I.	4WAL 3 Sensor			
(3) 2003 LD Trk, MPV, Incomplete		Ţ	Electronic Brake Control Module			
(3) 2003 LD Trk, MPV, Incomplete		Н	(T) GMC Truck			
(3) 2003 LD Trk, MPV, Incomplete		Н	(E) Cadillac Incomplete			
(3) ZUUS ILD IIK, MEV, INCOMPTETE	UllaSS1S	[11	(E) Caulitae incomplete			

Year Menul	Menu2	Menu3	Menu4	Read Eras	se Live es Data	ECU Info.
(3) 2003 LD Trk, MPV, Incomplete	Chassis	Н	(C) Chevrolet Truck	• •	•	•
(3) 2003 LD Trk, MPV, Incomplete		G	(T) GMC Truck	• •	•	
(3) 2003 LD Trk, MPV, Incomplete		G	(C) Chevrolet Truck	• •	•	
(3) 2003 LD Trk, MPV, Incomplete		E	Electronic Brake Control Module	• •	•	
(3) 2003 LD Trk, MPV, Incomplete		В	Electronic Brake Control Module	• •	•	
(3) 2003 LD Trk, MPV, Incomplete		A	Electronic Brake Control Module	• •	•	•
(3) 2003 LD Trk, MPV, Incomplete		X	(N) Chevrolet MPV	• •	•	•
(3) 2003 LD Trk, MPV, Incomplete		X	(M) Pontiac APV	• •	•	
(3) 2003 LD Trk, MPV, Incomplete		X	(H) Oldsmobile APV	• •	•	•
(3) 2003 LD Trk, MPV, Incomplete		V	(N) Chevrolet MPV	• •	•	
(3) 2003 LD Trk, MPV, Incomplete		V	(M) Pontiac APV	• •	•	
(3) 2003 LD Trk, MPV, Incomplete		V	(H) Oldsmobile APV	• •	•	
(3) 2003 LD Trk, MPV, Incomplete		U	(N) Chevrolet MPV	• •	•	
(3) 2003 LD Trk, MPV, Incomplete		Ŭ	(M) Pontiac APV	• •	•	
(3) 2003 LD Trk, MPV, Incomplete		T	S/T Classic	• •	•	
(3) 2003 LD Trk, MPV, Incomplete		S	SSR	• •	•	
(3) 2003 LD Trk, MPV, Incomplete		S	S/T Classic	• •	•	
(3) 2003 LD Trk, MPV, Incomplete		N	Supplemental Inflatable Restraint	• •	•	
(3) 2003 LD Trk, MPV, Incomplete		N	Rear Seat Audio	• •	•	
(3) 2003 LD Trk, MPV, Incomplete		N	Radio	• •	•	
(3) 2003 LD Trk, MPV, Incomplete		N	Passenger Door Module	• •		
(3) 2003 LD Trk, MPV, Incomplete		N	OnStar	• •	•	
(3) 2003 LD Trk, MPV, Incomplete	Body	N	Instrument Panel Cluster	• •		
(3) 2003 LD Trk, MPV, Incomplete		N	Heating and Air Conditioning	• •		
(3) 2003 LD Trk, MPV, Incomplete		N	Driver Seat Module	• •		
(3) 2003 LD Trk, MPV, Incomplete	Body	N	Driver Door Module	• •	•	
(3) 2003 LD Trk, MPV, Incomplete	Body	N	Digital Radio Receiver	• •		
(3) 2003 LD Trk, MPV, Incomplete	Body	N	Body Control Module	• •		
(3) 2003 LD Trk, MPV, Incomplete	Body	N	Amplifier (Bose)	• •		
(3) 2003 LD Trk, MPV, Incomplete	Body	M	Supplemental Inflatable Restraint	• •		
(3) 2003 LD Trk, MPV, Incomplete	Body	M	Instrument Panel Cluster	• •		
(3) 2003 LD Trk, MPV, Incomplete	Body	M	Body Control Module	• •		
(3) 2003 LD Trk, MPV, Incomplete		L	Supplemental Inflatable Restraint	• •		
(3) 2003 LD Trk, MPV, Incomplete	Body	L	Instrument Panel Cluster	• •	•	•
(3) 2003 LD Trk, MPV, Incomplete	Body	L	Body Control Module	• •	•	•
(3) 2003 LD Trk, MPV, Incomplete		J	Supplemental Inflatable Restraint	• •	•	•
(3) 2003 LD Trk, MPV, Incomplete		Н	(T) GMC Truck	• •	•	•
(3) 2003 LD Trk, MPV, Incomplete		Н	(E) Cadillac Incomplete	• •	•	•
(3) 2003 LD Trk, MPV, Incomplete		Н	(C) Chevrolet Truck	• •	•	•
(3) 2003 LD Trk, MPV, Incomplete	Body	G	(T) GMC Truck	• •	•	•
(3) 2003 LD Trk, MPV, Incomplete		G	(C) Chevrolet Truck	• •	•	•
(3) 2003 LD Trk, MPV, Incomplete		E	Supplemental Inflatable Restraint	• •	•	•
(3) 2003 LD Trk, MPV, Incomplete		В	(7) Pontiac	• •	•	
	Body	A	(7) Pontiac	• •	•	•
(2) 2002 Saturn	Powertrain	(R) 3. OL V6 L81	Powertrain Control Module	• •	•	•

Year	Menu1	Menu2	Menu3	Menu4	Read I	Erase Codes	Live Data	ECU Info.
(2) 2002	Saturn	Powertrain	(F) 2.2L L4 L61	Manual			•	
	Saturn	Powertrain	(F) 2.2L L4 L61	4 Speed Automatic	•	•	•	
	Saturn	Powertrain	(D) 2.2L L4 L61	Manual Transmission			•	
(2) 2002	Saturn	Powertrain	(D) 2.2L L4 L61	Automatic Transmission	•			
	Saturn	Powertrain	(B) 3. 0L V6 L81	Powertrain Control Module	•	•	•	
	Saturn	Powertrain	(8) 1.9L L4 L24	Powertrain Control Module	•			
	Saturn	Powertrain	(7) 1.9L L4 LL0	Powertrain Control Module	•			
(2) 2002	Saturn	Chassis	Ζ	SUV	•			
(2) 2002	Saturn	Chassis	Z	S-Series				
(2) 2002	Saturn	Chassis	J	Electronic Brake Control Module				
(2) 2002	Saturn	Body	Z	SUV			•	
(2) 2002	Saturn	Body	Z	S-Series			•	
(2) 2002	Saturn	Body	Ј	Supplemental Inflatable Restraint	•	•	•	•
(2) 2002	Saturn	Body	J	OnStar	•		•	•
(2) 2002	Saturn	Body	J	Instrument Panel Cluster	•	•	•	•
	Saturn	Body	J	Body Control Module	•	•	•	•
	Saturn	Body	Ţ	Auto. HVAC	•	•	•	•
	Passenger Car	Powertrain	(Y) 4.6L V8 LD8	Powertrain Control Module		•	•	•
	Passenger Car	Powertrain	(T) 2.4L L4 LD9 Supercharged	T			•	
	Passenger Car	Powertrain	(T) 2.4L L4 LD9	N		•	•	•
	Passenger Car	Powertrain	(T) 2. 4L L4 LD9	Ī		•	•	•
	Passenger Car	Powertrain	(S) 5.7L V8 LS6	V	•	•	•	•
	Passenger Car	Powertrain	(K) 3.8L V6 L36	W				•
	Passenger Car	Powertrain	(K) 3.8L V6 L36	Н				•
	Passenger Car	Powertrain	(K) 3.8L V6 L36	F				•
	Passenger Car	Powertrain	(K) 3.8L V6 L36	C				•
	Passenger Car	Powertrain	(J) 3. 1L V6 LG8	W			•	•
	Passenger Car	Powertrain	(J) 3. 1L V6 LG8	M			•	•
	Passenger Car	Powertrain	(H) 3.5L V6 LX5	W				
	Passenger Car	Powertrain	(H) 3.5L V6 LX5	C				
	Passenger Car	Powertrain	(G) 5.7L V8 LS1	v				
	Passenger Car	Powertrain	(G) 5.7L V8 LS1					
	Passenger Car		(F) 2. 2L L4 L61	М				
		Powertrain		IN T		_	_	
(2) 2002	Passenger Car Passenger Car	Powertrain		w		•	•	
		Powertrain	(E) 3. 4L V6 LA1	W N	•		•	
	Passenger Car	Powertrain	(E) 3. 4L V6 LA1	N C + 1 W 1 1	•	•	•	•
	Passenger Car	Powertrain	(C) 4. OL V8 L47	Powertrain Control Module	•	•	•	•
	Passenger Car	Powertrain	(9) 4. 6L V8 L37	Powertrain Control Module	•	•	•	•
	Passenger Car	Powertrain	(8) 1. 8L L4 LV6	Manual	•	•	•	•
	Passenger Car	Powertrain	(8) 1. 8L L4 LV6	4 Speed Automatic	•	•	•	•
	Passenger Car	Powertrain	(8) 1. 8L L4 LV6	3 Speed Automatic	•	•	•	•
	Passenger Car	Powertrain	(6) 1.6L L4 L01	Manual Transmission	•	•	•	•
	Passenger Car	Powertrain	(6) 1.6L L4 L01	Automatic Transmission	•	•	•	•
	Passenger Car	Powertrain	(4) 2.2L L4 LN2 Alternative Fuel	Powertrain Control Module	•	•	•	•
(2) 2002	Passenger Car	Powertrain	(4) 2. 2L L4 LN2	<u>ļ</u> .J			•	

Year Menu1	Me	enu2	Menu3	Menu4		Erase Codes		ECU Info.
(2) 2002 Passenge	er Car Po			Manual Transmission		•	•	•
(2) 2002 Passenge				Automatic Transmission	•	•	•	•
(2) 2002 Passenge	er Car Po			Powertrain Control Module	•	•	•	
(2) 2002 Passenge	er Car Po		(1) 3.8L V6 L67	W	•	•	•	
(2) 2002 Passenge			(1) 3.8L V6 L67	Н	•	•	•	
(2) 2002 Passenge			(1) 3.8L V6 L67	C	•	•	•	
(2) 2002 Passenge		nassis		RTD				
(2) 2002 Passenge		nassis	Ý	ABS/TCS				
(2) 2002 Passenge	er Car Ch	nassis	V	(4) Buick				
(2) 2002 Passenge	er Car Ch	nassis		(3) Oldsmobile				
(2) 2002 Passenge	er Car Ch	nassis	V	(2) Pontiac				
(2) 2002 Passenge	er Car Ch	nassis	V	(1) Chevrolet				
(2) 2002 Passenge	er Car Ch	nassis	S	Electronic Brake Control Module				
(2) 2002 Passenge	er Car Ch	nassis	V	Electronic Brake Control Module	•	•	•	
(2) 2002 Passenge	er Car Ch	nassis	Κ	(KY) Seville STS		•	•	
(2) 2002 Passenge	er Car Ch	nassis l	Κ	(KS) Seville SLS	•	•	•	•
(2) 2002 Passenge		nassis		(KF) DTS	•	•	•	•
(2) 2002 Passenge		nassis	ζ	(KE) DHS	•	•	•	•
(2) 2002 Passenge		nassis	((KD) Deville	•	•	•	•
(2) 2002 Passenge		nassis .	Ī	Electronic Brake Control Module		•	•	•
(2) 2002 Passenge		nassis	-	(HZ) Bonneville SSEi	•	•	•	
(2) 2002 Passenge		nassis	1	(HY) Bonneville SLE	•	•	•	
(2) 2002 Passenge		nassis		(HX) Bonneville SE		•	•	
(2) 2002 Passenge		nassis		(HR) LeSabre Limited		•	•	
(2) 2002 Passenge		nassis I		(HP) LeSabre Custom		•		•
(2) 2002 Passenge				Rear Integration Module		•		•
(2) 2002 Passenge		nassis		DRP/ABS/TIM		•		
(2) 2002 Passenge		nassis l		Electronic Brake Control Module		•		•
(2) 2002 Passenge		nassis lassis		Magna Steer	•	•		
(2) 2002 Passenge		nassis l		Delco/Bosch ABS/TCS	•	•		
(2) 2002 Passenge		assis (DRP/ABS/TIM				
(2) 2002 Passenge		ody		(3) Two-Door Convertible				
(2) 2002 Passenge		-		(2) Two-Door Hatchback/Liftback				
(2) 2002 Passenge		-		(1) Two-Door Coupe/Sedan				
(2) 2002 Passenge		ody I		(4) Buick	•	•	•	
		ody I						
(2) 2002 Passenge		-		(3) Oldsmobile				
(2) 2002 Passenge		-		(2) Pontiac			•	
(2) 2002 Passenge		ody V		(1) Chevrolet	•	•	•	•
(2) 2002 Passenge		ody S		(1) Chevrolet	•	•	•	•
(2) 2002 Passenge		-		(3) Oldsmobile	•	•	•	•
(2) 2002 Passenge		ody		(2) Pontiac	•	•	•	•
(2) 2002 Passenge		ody		(1) Chevrolet	•	•	•	•
(2) 2002 Passenge				(2) Pontiac	•	•	•	•
(2) 2002 Passenge				(1) Chevrolet	•	•	•	•
(2) 2002 Passenge	er Car Bo	ody 1	Κ	(KY) Seville STS	lacksquare	lacksquare		

Year Menul	Menu2	Menu3	Menu4		Erase Codes		ECU Info.
(2) 2002 Passenger Car	Body	K	(KS) Seville SLS	•	•		
(2) 2002 Passenger Car	Body	K	(KF) DTS	•	•	•	
(2) 2002 Passenger Car	Body	K	(KE) DHS	•			
(2) 2002 Passenger Car	Body	K	(KD) Deville	•			
(2) 2002 Passenger Car	Body	J	Supplemental Inflatable Restraint	•			
(2) 2002 Passenger Car	Body	Ј	Radio	•	•	•	
(2) 2002 Passenger Car	Body	Ј	Instrument Panel Cluster	•	•	•	
(2) 2002 Passenger Car	Body	Ј	Body Control Module	•	•	•	
(2) 2002 Passenger Car	Body	H	(4) Buick	•	•	•	
(2) 2002 Passenger Car	Body	Н	(2) Pontiac	•			
(2) 2002 Passenger Car	Body	G	Vehicle Theft Deterrent	•			
(2) 2002 Passenger Car	Body	G	Supplemental Inflatable Restraint	•			
(2) 2002 Passenger Car	Body	G	Remote Function Actuation	•			
(2) 2002 Passenger Car	Body	G	Rear Integration Module	•			
(2) 2002 Passenger Car	Body	G	Radio	•	•	•	
(2) 2002 Passenger Car	Body	G	OnStar	•		•	
(2) 2002 Passenger Car	Body	G	Navigation Radio	•	•	•	
(2) 2002 Passenger Car	Body	G	Memory Seat Module	•	•	•	•
(2) 2002 Passenger Car	Body	G	Instrument Panel Module	•	•		
(2) 2002 Passenger Car	Body	G	Instrument Panel Cluster	•	•	•	•
(2) 2002 Passenger Car	Body	G	Driver Information Center	•	•	•	•
(2) 2002 Passenger Car	Body	G	Driver Door Module	•	•	•	
(2) 2002 Passenger Car	Body	G	Dash Integration Module	•	•	•	
(2) 2002 Passenger Car	Body	G	CD Changer	•	•	•	
(2) 2002 Passenger Car	Body	F	(2) Pontiac				
(2) 2002 Passenger Car	Body	F	(1) Chevrolet				
(2) 2002 Passenger Car	Body	Ē	Supplemental Inflatable Restraint		•	•	•
(2) 2002 Passenger Car	Body	E	Remote Function Actuation				
(2) 2002 Passenger Car	Body	E	Radio				
(2) 2002 Passenger Car	Body	E	OnStar		•	•	
(2) 2002 Passenger Car	Body	E	Memory Seat Module		•	•	•
(2) 2002 Passenger Car	Body	E	Memory Mirror Module		•	•	•
(2) 2002 Passenger Car	Body	E	Instrument Panel Cluster		•	•	
(2) 2002 Passenger Car	Body	E	Heating and Air Conditioning	•	•	•	
(2) 2002 Passenger Car	Body	F	Climate Control Panel	•	•	•	
(2) 2002 Passenger Car	Body	E	Cellular Telephone	•	•	•	
(2) 2002 Passenger Car	Body	F	Body Control Module	•	•	•	
(2) 2002 Passenger Car	Body	C	Vehicle Theft Deterrent	•	•	•	
(2) 2002 Passenger Car	Body	C	Supplemental Inflatable Restraint	•	•	•	
(2) 2002 Passenger Car	Body	C	Remote Function Actuation	•	•	•	
(2) 2002 Passenger Car	Body	C	OnStar				
(2) 2002 Passenger Car	Воду	C	Memory Seat Module				
(2) 2002 Passenger Car	Воду	C	Instrument Panel Cluster				
(2) 2002 Passenger Car	Воду	C	Heating and Air Conditioning				
(2) 2002 Passenger Car	Воду	C	Driver Door Module				
(4) 2002 rassenger car	ропу	<u>I</u> C	Intiver noor wounte				

Year Menu1	Menu2	Menu3	Menu4	Read Eras		ECU Info.
(2) 2002 Passenger Car	Body	С	Cellular Telephone	• •	•	•
(2) 2002 Passenger Car	Body	С	Body Control Module	• •	•	•
(2) 2002 Medium Duty True	ck Powertrain	Alternative Fuels	(E) 8.1L V8 L18 Dedicated LPG	• •	•	•
(2) 2002 Medium Duty True	ck Powertrain	(Z) 6.5L V8 L65	Powertrain Control Module	• •	•	
(2) 2002 Medium Duty True	ck Powertrain	(R) 5.7L V8 L31	4 Speed Automatic	• •	•	
(2) 2002 Medium Duty True	ck Powertrain	(F) 6.5L V8 L65	Powertrain Control Module	• •	•	
(2) 2002 Medium Duty True	ck Powertrain	(E) 8.1L V8 L18	Manual	• •	•	
(2) 2002 Medium Duty True	ck Powertrain	(E) 8.1L V8 L18	5 Speed Automatic	• •	•	
(2) 2002 Medium Duty True	ck Powertrain	(E) 8.1L V8 L18	4 Speed Automatic	• •	•	
(2) 2002 Medium Duty True	ck Powertrain	(C) 7. 2L L6 LG5	Powertrain Control Module	• •	•	
(2) 2002 Medium Duty True	ck Powertrain	(4) 4.8L L4 Diesel	Manual Transmission	• •	•	
(2) 2002 Medium Duty True	ck Powertrain	(4) 4.8L L4 Diesel	Automatic Transmission	• •	•	•
(2) 2002 Medium Duty True	ck Powertrain	(3) 7.8L L6 LG4	Manual Transmission	• •	•	
(2) 2002 Medium Duty True		(3) 7.8L L6 LG4	Automatic Transmission	• •	•	•
(2) 2002 Medium Duty True		T - B7 Chassis	Hydraulic 4WAL 4 Sensor	• •	•	•
(2) 2002 Medium Duty True		D - C Series	Hydraulic 4WAL 4 Sensor	• •	•	•
(2) 2002 Medium Duty True		C - T Series	Hydraulic 4WAL 4 Sensor	• •	•	
(2) 2002 Medium Duty True		B - W4 Series	Electronic Brake Control Module	• •	•	•
(2) 2002 Medium Duty True		A - W5 Series	Electronic Brake Control Module	• •	•	•
(2) 2002 Medium Duty True		7 - W52 Series	Hydraulic 4WAL 4 Sensor	• •	•	•
(2) 2002 Medium Duty True		6 - W22 Series	Hydraulic 4WAL 4 Sensor	• •	•	•
(2) 2002 LD Trk, MPV, Inc		Alternative Fuels	(U) 6.0L V8 LQ4 Dedicated CNG	• •	•	
(2) 2002 LD Trk, MPV, Inc		Alternative Fuels	(U) 6.0L V8 LQ4 Bi-Fuel	• •	•	
(2) 2002 LD Trk, MPV, Inc		Alternative Fuels	(R) 5.7L V8 L31 Dedicated LPG	• •	•	
(2) 2002 LD Trk, MPV, Inc		Alternative Fuels	(R) 5.7L V8 L31 Bi-Fuel	• •	•	
(2) 2002 LD Trk, MPV, Inc		(Z) 5.3L V8 L59	Without Throttle-actuated Control	• •	•	
(2) 2002 LD Trk, MPV, Inc		(Z) 5.3L V8 L59	With Throttle-actuated Control	• •	•	•
(2) 2002 LD Trk, MPV, Inc		(Y) 6.5L V8 L57	P	• •	•	•
(2) 2002 LD Trk, MPV, Inc		(X) 4.3L V6 LU3 (C/K, G only)	Under 8600 GVW	• •	•	•
(2) 2002 LD Trk, MPV, Inc		(X) 4.3L V6 LU3 (C/K, G only)	Equal to or Over 8600 GVW	• •	•	•
(2) 2002 LD Trk, MPV, Inc		(X) 4.3L V6 LU3	Under 8600 GVW	• •	•	•
(2) 2002 LD Trk, MPV, Inc		(X) 4. 3L V6 LU3	Equal to or Over 8600 GVW	• •	•	•
(2) 2002 LD Trk, MPV, Inc		(W) 4.3L V6 L35 (C/K, G only)	Under 8600 GVW	• •	•	•
(2) 2002 LD Trk, MPV, Inc	complete Powertrain	(W) 4.3L V6 L35 (C/K, G only)	Equal to or Over 8600 GVW	• •	•	•
(2) 2002 LD Trk, MPV, Inc		(W) 4.3L V6 L35	Under 8600 GVW	• •	•	•
(2) 2002 LD Trk, MPV, Inc		(W) 4.3L V6 L35	Equal to or Over 8600 GVW	• •	•	
(2) 2002 LD Trk, MPV, Inc		(V) 4.8L V8 LR4	Manua1	• •	•	
(2) 2002 LD Trk, MPV, Inc		(V) 4.8L V8 LR4	4 Speed Automatic	• •	•	•
(2) 2002 LD Trk, MPV, Inc		(U) 6. OL V8 LQ4	Manual	• •	•	•
(2) 2002 LD Trk, MPV, Inc		(U) 6. OL V8 LQ4	4 Speed Automatic	• •	•	•
(2) 2002 LD Trk, MPV, Inc		(T) 5. 3L V8 LM7	Without Throttle-actuated Control	• •	•	•
(2) 2002 LD Trk, MPV, Inc		(T) 5. 3L V8 LM7	With Throttle-actuated Control	• •	•	•
(2) 2002 LD Trk, MPV, Inc		(S) 4. 2L L6 LL8	4 Speed Automatic	• •	•	•
(2) 2002 LD Trk, MPV, Inc		(R) 5.7L V8 L31	Under 8600 GVW	• •	•	•
(2) 2002 LD Trk, MPV, Inc	complete Powertrain	(R) 5.7L V8 L31	Equal to or Over 8600 GVW	• •	•	

Year	Menu1	Menu2	Menu3	Menu4	Read Er		Live Data	ECU Info.
(2) 2002	LD Trk, MPV, Incomplete	Powertrain	(N) 6. 0L V8 LQ9	Powertrain Control Module	•	•	•	•
		Powertrain	(M) 5. OL V8 L30	Powertrain Control Module	•	•	•	•
		Powertrain	(G) 8.1L V8 L18 3500 HD Only	Manual	•	•	•	•
		Powertrain	(G) 8.1L V8 L18 3500 HD Only	4 Speed Automatic	•	•	•	•
(2) 2002	LD Trk, MPV, Incomplete	Powertrain	(G) 8.1L V8 L18	Manual	•	•	•	•
(2) 2002	LD Trk, MPV, Incomplete	Powertrain	(G) 8.1L V8 L18	5 Speed Automatic	•	•	•	•
(2) 2002	LD Trk, MPV, Incomplete	Powertrain	(G) 8.1L V8 L18	4 Speed Automatic	•	•	•	•
(2) 2002	LD Trk, MPV, Incomplete	Powertrain	(F) 6.5L V8 L65	P	•	•		
(2) 2002	LD Trk, MPV, Incomplete	Powertrain	(F) 6.5L V8 L65	K	•	•		
(2) 2002	LD Trk, MPV, Incomplete	Powertrain	(F) 6.5L V8 L65	G	•	•		
(2) 2002	LD Trk, MPV, Incomplete	Powertrain	(F) 6.5L V8 L65	C	•	•		
(2) 2002	LD Trk, MPV, Incomplete	Powertrain	(E) 3.4L V6 LA1	Without Air Pump	•	•	•	
(2) 2002	LD Trk, MPV, Incomplete	Powertrain	(E) 3.4L V6 LA1	With Air Pump	•	•	•	
(2) 2002	LD Trk, MPV, Incomplete	Powertrain	(C) 2. OL L4 L34	Without TZ2		•	•	
(2) 2002	LD Trk, MPV, Incomplete	Powertrain	(C) 2. OL L4 L34	With TZ2	•	•		
(2) 2002	LD Trk, MPV, Incomplete	Powertrain	(6) 1.6L L4 L01	Powertrain Control Module	•	•	•	•
(2) 2002	LD Trk, MPV, Incomplete	Powertrain	(5) 2. 2L L4 L43	S	•	•		
(2) 2002	LD Trk, MPV, Incomplete	Powertrain	(4) 2.5L V6 LE8	Powertrain Control Module	•	•		
(2) 2002	LD Trk, MPV, Incomplete	Powertrain	(1) 6.6L V8 LB7 Diesel	Federal Emissions	•	•		
(2) 2002	LD Trk, MPV, Incomplete	Powertrain	(1) 6.6L V8 LB7 Diesel	California Emissions	•	•	•	•
(2) 2002	LD Trk, MPV, Incomplete	Chassis	X	Electronic Brake Control Module	•	•	•	•
(2) 2002	LD Trk, MPV, Incomplete	Chassis	V	Electronic Brake Control Module	•	•	•	•
(2) 2002	LD Trk, MPV, Incomplete	Chassis	U	Electronic Brake Control Module	•	•	•	•
(2) 2002	LD Trk, MPV, Incomplete	Chassis	T	4WAL 3 Sensor	•	•	•	•
(2) 2002	LD Trk, MPV, Incomplete	Chassis	S	Traction Assist (If Equipped)	•	•	•	•
(2) 2002	LD Trk, MPV, Incomplete	Chassis	S	4WAL 3 Sensor	•	•	•	•
(2) 2002	LD Trk, MPV, Incomplete	Chassis	P	4WAL 3 Sensor	•	•	•	•
(2) 2002	LD Trk, MPV, Incomplete	Chassis	M	4WAL 3 Sensor	•	•		
(2) 2002	LD Trk, MPV, Incomplete	Chassis	L	4WAL 3 Sensor		•	•	
(2) 2002	LD Trk, MPV, Incomplete	Chassis	K	VSES (If Equipped)	•	•	•	•
(2) 2002	LD Trk, MPV, Incomplete	Chassis	K	RTD (Autoride) / EVO	•	•		
(2) 2002	LD Trk, MPV, Incomplete	Chassis	K	4WAL 3 Sensor	•	•		
(2) 2002	LD Trk, MPV, Incomplete	Chassis	Ј	Electronic Brake Control Module	•	•		
		Chassis	H	Rear Integration Module	•	•		
(2) 2002	LD Trk, MPV, Incomplete	Chassis	H	Magna Steer	•	•	•	•
	LD Trk, MPV, Incomplete		H	DRP/ABS/TCS	•	•	•	•
(2) 2002	LD Trk, MPV, Incomplete	Chassis	G	4WAL 3 Sensor	•	•	•	•
$(2) \ \overline{2002}$	LD Trk, MPV, Incomplete	Chassis	Е	Electronic Brake Control Module	•	•	•	•
		Chassis	С	Under 15000 GVW	•	•	•	•
		Chassis	С	Equal to or Over 15000 GVW	•	•	•	•
	LD Trk, MPV, Incomplete		В	Electronic Brake Control Module	•	•	•	•
	LD Trk, MPV, Incomplete		A	Electronic Brake Control Module	•	•	•	•
	LD Trk, MPV, Incomplete		X	(N) Chevrolet MPV	•	•	•	•
(2) 2002	LD Trk, MPV, Incomplete	Body	X	(M) Pontiac APV	•	lacksquare		•
	LD Trk, MPV, Incomplete		X	(H) Oldsmobile APV	•	lacksquare		•

Year Menu1	Menu2	Menu3	Menu4		Erase Codes		ECU Info.
(2) 2002 LD Trk, MPV, Incomplete	Body	V	(N) Chevrolet MPV	•	•	•	•
(2) 2002 LD Trk, MPV, Incomplete		V	(M) Pontiac APV		•	•	•
(2) 2002 LD Trk, MPV, Incomplete		V	(H) Oldsmobile APV		•	•	•
(2) 2002 LD Trk, MPV, Incomplete		U	(N) Chevrolet MPV		•	•	•
(2) 2002 LD Trk, MPV, Incomplete		II	(M) Pontiac APV		•	•	•
(2) 2002 LD Trk, MPV, Incomplete	Body	Τ	TrailBlazer EXT		•	•	•
(2) 2002 LD Trk, MPV, Incomplete	Body	T	TrailBlazer		•	•	
(2) 2002 LD Trk, MPV, Incomplete		T	S/T Classic	•	•		•
(2) 2002 LD Trk, MPV, Incomplete		T	Envoy XL	•	•	•	•
(2) 2002 LD Trk, MPV, Incomplete		Т	Envoy	•	•		
(2) 2002 LD Trk, MPV, Incomplete		Т	Bravada	•	•		
(2) 2002 LD Trk, MPV, Incomplete		S	TrailBlazer EXT	•	•		
(2) 2002 LD Trk, MPV, Incomplete		S	TrailBlazer	•	•	•	
(2) 2002 LD Trk, MPV, Incomplete		S	S/T Classic	•	•	•	
(2) 2002 LD Trk, MPV, Incomplete		ς	Envoy XL	•	•	•	
(2) 2002 LD Trk, MPV, Incomplete		ς	Envoy	•	•	•	•
(2) 2002 LD Trk, MPV, Incomplete		ς	Bravada	•	•	•	
(2) 2002 LD Trk, MPV, Incomplete		M	Supplemental Inflatable Restraint	•	•	•	
(2) 2002 LD Trk, MPV, Incomplete		M	Instrument Panel Cluster	•	•		
(2) 2002 LD Trk, MPV, Incomplete		M	Body Control Module	•	•		
(2) 2002 LD Trk, MPV, Incomplete		I I	Supplemental Inflatable Restraint	•	•		
(2) 2002 LD Trk, MPV, Incomplete		I	Instrument Panel Cluster				
(2) 2002 LD Trk, MPV, Incomplete		I	Body Control Module				
(2) 2002 LD Trk, MPV, Incomplete		K.	(T) GMC Truck				
(2) 2002 LD Trk, MPV, Incomplete		K	(C) Chevrolet Truck				
(2) 2002 LD Trk, MPV, Incomplete		K	(6) Cadillac				
(2) 2002 LD Trk, MPV, Incomplete		Т	Supplemental Inflatable Restraint		•		
(2) 2002 LD Trk, MPV, Incomplete		IJ Ги	(E) Cadillac Incomplete		•		
(2) 2002 LD Trk, MPV, Incomplete		[n	Supplemental Inflatable Restraint				
(2) 2002 LD Trk, MPV, Incomplete		[C	Radio		•		
(2) 2002 LD Trk, MPV, Incomplete		[C	Passlock		•		
(2) 2002 LD Trk, MPV, Incomplete		[C	Immobilizer		•		
(2) 2002 LD Trk, MPV, Incomplete			Supplemental Inflatable Restraint		•		
(2) 2002 LD Trk, MPV, Incomplete		C	(T) GMC Truck		•		
(2) 2002 LD Trk, MPV, Incomplete (2) 2002 LD Trk, MPV, Incomplete		[C	(C) Chevrolet Truck	•	•		
		C					
(2) 2002 LD Trk, MPV, Incomplete		В	(6) Cadillac				
(2) 2002 LD Trk, MPV, Incomplete			(7) Pontiac				
(2) 2002 LD Trk, MPV, Incomplete		В	(5) Buick	•	•	•	
(2) 2002 LD Trk, MPV, Incomplete		Λ	(7) Pontiac	•	•	•	•
(2) 2002 LD Trk, MPV, Incomplete		(D) 2 01 UC 101	(5) Buick	•	•	•	•
(1) 2001 Saturn	Powertrain	(R) 3. OL V6 L81	Powertrain Control Module	•	•	•	•
(1) 2001 Saturn	Powertrain	(F) 2. 2L L4 L61	Manual	•	•	•	•
(1) 2001 Saturn	Powertrain	(F) 2. 2L L4 L61	4 Speed Automatic	•	•	•	•
(1) 2001 Saturn	Powertrain	(8) 1.9L L4 L24	Powertrain Control Module	•	•	•	•
(1) 2001 Saturn	Powertrain	(7) 1.9L L4 LL0	Powertrain Control Module		•		

Year	Menu1	Menu2	Menu3	Menu4	Read E		Live Data	ECU Info.
(1) 2001	Saturn	Chassis	Z	Electronic Brake Control Module	•	•	•	
(1) 2001	Saturn	Chassis	J	Electronic Brake Control Module				
(1) 2001	Saturn	Body	Z	Supplemental Inflatable Restraint				
(1) 2001	Saturn	Body	Z	Instrument Panel Cluster				
(1) 2001	Saturn	Body	Z	Body Control Module				
(1) 2001	Saturn	Body	J	Supplemental Inflatable Restraint				
(1) 2001	Saturn	Body	J	Instrument Panel Cluster				
(1) 2001	Saturn	Body	J	Body Control Module				
(1) 2001	Passenger Car	Powertrain	(Y) 4.6L V8 LD8	Powertrain Control Module				
(1) 2001	Passenger Car	Powertrain	(T) 2.4L L4 LD9 Supercharged	N			•	
(1) 2001	Passenger Car	Powertrain	(T) 2.4L L4 LD9 Supercharged	J			•	
(1) 2001	Passenger Car	Powertrain	(T) 2.4L L4 LD9	N		•	•	
(1) 2001	Passenger Car	Powertrain	(T) 2.4L L4 LD9	Ј		•	•	
(1) 2001	Passenger Car	Powertrain	(S) 5.7L V8 LS6	Y		•	•	
(1) 2001	Passenger Car	Powertrain	(R) 3. 0L V6 L81	Powertrain Control Module	•	•	•	•
(1) 2001	Passenger Car	Powertrain	(K) 3.8L V6 L36	W	•	•	•	•
	Passenger Car	Powertrain	(K) 3.8L V6 L36	Н	•	•	•	•
	Passenger Car	Powertrain	(K) 3.8L V6 L36	F	•	•	•	•
	Passenger Car	Powertrain	(K) 3.8L V6 L36	C		•	•	•
	Passenger Car	Powertrain	(J) 3. 1L V6 LG8	W				
	Passenger Car	Powertrain	(J) 3. 1L V6 LG8	N			•	
	Passenger Car	Powertrain	(H) 3.5L V6 LX5	W		•		
	Passenger Car	Powertrain	(H) 3.5L V6 LX5	G				
	Passenger Car	Powertrain	(G) 5. 7L V8 LS1	γ				
	Passenger Car	Powertrain	(G) 5.7L V8 LS1	F				
	Passenger Car	Powertrain	(E) 3. 4L V6 LA1	W		•		•
	Passenger Car	Powertrain	(E) 3. 4L V6 LA1	N				
	Passenger Car	Powertrain	(C) 4. 0L V8 L47	Powertrain Control Module				
	Passenger Car	Powertrain	(9) 4. 6L V8 L37	Powertrain Control Module				
	Passenger Car	Powertrain	(8) 1. 8L L4 LV6	Manual				
	Passenger Car	Powertrain	(8) 1. 8L L4 LV6	4 Speed Automatic				
	Passenger Car	Powertrain	(8) 1. 8L L4 LV6	3 Speed Automatic				
	Passenger Car		(6) 1. 6L L4 L01	Manual Transmission				
	Passenger Car	Powertrain Powertrain	(6) 1.6L L4 L01 (6) 1.6L L4 L01			•		
		Powertrain		Automatic Transmission		•		
	Passenger Car	Powertrain	(4) 2.2L L4 LN2 Alternative Fuel	Powertrain Control Module	•			
	Passenger Car	Powertrain	(4) 2. 2L L4 LN2	J · · ·	•	•	•	•
	Passenger Car	Powertrain	(3) 1.6L L4 L73	Manual Transmission		•	•	•
	Passenger Car	Powertrain	(3) 1.6L L4 L73	Automatic Transmission		•	•	•
	Passenger Car	Powertrain	(2) 1. 4L L4 LC0	Powertrain Control Module	•	•	•	•
	Passenger Car	Powertrain	(2) 1. 3L L4 LY8	Powertrain Control Module	•	•	•	•
	Passenger Car	Powertrain	(1) 3.8L V6 L67	W 1		•	•	•
	Passenger Car	Powertrain	(1) 3.8L V6 L67	<u>H</u>		•	•	•
	Passenger Car	Powertrain	(1) 3.8L V6 L67	C	•	•	•	
	Passenger Car	Chassis	Y	RTD		•	•	
(1) 2001	Passenger Car	Chassis	Y	ABS/TCS		lacktriangle		

Year Menu	u1	Menu2	Menu3	Menu4		Erase Codes		ECU Info.
(1) 2001 Pass	senger Car	Chassis	W	(4) Buick	•	•	•	•
(1) 2001 Pass	senger Car	Chassis	W	(3) Oldsmobile	•	•	•	•
(1) 2001 Pass	senger Car	Chassis	W	(2) Pontiac		•	•	
(1) 2001 Pass	senger Car	Chassis	W	(1) Chevrolet		•	•	
(1) 2001 Pass	senger Car	Chassis	V	Variable Effort Steering		•	•	
(1) 2001 Pass	senger Car	Chassis	V	ABS		•	•	
(1) 2001 Pass	senger Car	Chassis	S	Electronic Brake Control Module		•	•	
(1) 2001 Pass	senger Car	Chassis	N	Electronic Brake Control Module		•	•	
(1) 2001 Pass	senger Car	Chassis	M	Electronic Brake Control Module			•	
(1) 2001 Pass	senger Car	Chassis	K	(KY) Seville STS	•	•	•	
(1) 2001 Pass	senger Car	Chassis	K	(KS) Seville SLS	•	•	•	
(1) 2001 Pass	senger Car	Chassis	K	(KF) DTS	•	•	•	
(1) 2001 Pass	senger Car	Chassis	K	(KE) DHS	•	•	•	
(1) 2001 Pass	senger Car	Chassis	K	(KD) Deville	•	•	•	
(1) 2001 Pass	senger Car	Chassis	J	Electronic Brake Control Module	•	•	•	
(1) 2001 Pass	senger Car	Chassis	Н	(HZ) Bonneville SSEi	•	•	•	
(1) 2001 Pass	senger Car	Chassis	Н	(HY) Bonneville SLE	•	•	•	
	senger Car	Chassis	Н	(HX) Bonneville SE	•	•	•	•
(1) 2001 Pass	senger Car	Chassis	Н	(HR) LeSabre Limited	•	•	•	•
(1) 2001 Pass	senger Car	Chassis	Н	(HP) LeSabre Custom	•	•	•	•
	senger Car	Chassis	G	Rear Integration Module	•	•	•	
	senger Car	Chassis	C1	DRP/ABS/TIM	•	•	•	
	senger Car	Chassis	F	Electronic Brake Control Module	•	•	•	
		Chassis	E	Magna Steer	•	•	•	
		Chassis	E	Delco/Bosch ABS/TCS	•	•	•	
		Chassis	C	DRP/ABS/TIM	•	•	•	•
		Body	Y	(3) Two-Door Convertible	•	•	•	•
		Body	Y	(2) Two-Door Hatchback/Liftback	•	•	•	•
		Body	Y	(1) Two-Door Coupe/Sedan	•	•	•	•
		Body	W	(4) Buick	•	•	•	•
		Body	W	(3) Oldsmobile	•	•	•	•
		Body	W	(2) Pontiac		•	•	•
		Body	W	(1) Chevrolet	•	•	•	
		Body	V	Supplemental Inflatable Restraint	•	•	•	•
(1) 2001 Pass		Body	V	Radio	•	•	•	
(1) 2001 Pass		Body	V	Power Roof	•	•	•	•
(1) 2001 Pass		Body	V	OnStar	•	•	•	•
(1) 2001 Pass		Body	V	Memory Seat Module	•	•	•	
(1) 2001 Pass		Body	V	Leveling Sensor	•	•	•	•
(1) 2001 Pass		Body	V	Instrument Panel Cluster	•	•	•	
(1) 2001 Pass		Body	V	Immobilizer	•	•		
(1) 2001 Pass (1) 2001 Pass		Body	V	Heating And Air Conditioning		•		
(1) 2001 Pass (1) 2001 Pass		Body		Body Control Module		•		
(1) 2001 Pass (1) 2001 Pass		Body	S	(1) Chevrolet	•	•		
(1) 2001 Pass (1) 2001 Pass		Body	N N	(3) Oldsmobile				
(1) 2001 Pass	senger car	Douy	IV.	(9) O1021100116	•	•	•	

Year Menu1		Menu2	Menu3	Menu4		Erase Codes		ECU Info.
(1) 2001 Passe:	nger Car	Body	N	(2) Pontiac	•	•		•
(1) 2001 Passe:	nger Car	Body	N	(1) Chevrolet	•	•		•
(1) 2001 Passes	nger Car	Body	M	Supplemental Inflatable Restraint				
(1) 2001 Passes	nger Car	Body	K	(KY) Seville STS				
(1) 2001 Passes	nger Car	Body	K	(KS) Seville SLS				
(1) 2001 Passes	nger Car	Body	K	(KF) DTS				
(1) 2001 Passes	nger Car	Body	K	(KE) DHS				
(1) 2001 Passes	nger Car	Body	K	(KD) Deville				
(1) 2001 Passes	nger Car	Body	J	Supplemental Inflatable Restraint				
(1) 2001 Passes	nger Car	Body	J	Radio	•	•		
(1) 2001 Passes	nger Car	Body	J	Instrument Panel Cluster	•	•		
(1) 2001 Passes	nger Car	Body	Ј	Body Control Module	•	•	•	
(1) 2001 Passes	nger Car	Body	Н	(4) Buick	•	•		
(1) 2001 Passes	nger Car	Body	Н	(2) Pontiac	•	•	•	
(1) 2001 Passes	nger Car	Body	G	Vehicle Theft Deterrent	•	•		
(1) 2001 Passes	nger Car	Body	G	Supplemental Inflatable Restraint	•	•		
(1) 2001 Passes	nger Car	Body	G	Remote Function Actuation	•	•	•	•
(1) 2001 Passes		Body	G	Rear Integration Module	•	•	•	•
(1) 2001 Passes	nger Car	Body	G	Radio	•	•	•	•
(1) 2001 Passes	nger Car	Body	G	OnStar OnStar	•	•	•	•
(1) 2001 Passe:		Body	G	Memory Seat Module	•	•		
(1) 2001 Passe:		Body	G	Instrument Panel Module	•	•		
(1) 2001 Passe:		Body	G	Instrument Panel Cluster	•	•		
(1) 2001 Passe:		Body	G	Driver Information Center	•	•		
(1) 2001 Passe:		Body	C _T	Driver Door Module	•	•		
(1) 2001 Passe:		Body	C _r	Dash Integration Module	•	•		
(1) 2001 Passe:		Body	C	CD Changer	•	•		•
(1) 2001 Passe:		Body	F	(2) Pontiac	•	•		•
(1) 2001 Passe:		Body	F	(1) Chevrolet	•	•		•
(1) 2001 Passe:		Body	E	Supplemental Inflatable Restraint	•	•		•
(1) 2001 Passe:		Body	E	Remote Function Actuation	•	•	•	•
(1) 2001 Passes		Body	F	Radio	•	•		•
(1) 2001 Passe:		Body	E	OnStar	•	•		•
(1) 2001 Passes		Body	F	Memory Seat Module	•	•	•	•
(1) 2001 Passe:		Body	F	Memory Mirror Module	•	•	•	
(1) 2001 Passe:		Body	E	Instrument Panel Cluster	•	•	•	•
(1) 2001 Passe:		Body		Heating and Air Conditioning	•	•	•	•
(1) 2001 Passe:		Body	E	Climate Control Panel	•	•	•	•
(1) 2001 Passes		Body	F	Cellular Telephone	•	•	•	
(1) 2001 Passe:		Body		Body Control Module	•	•		•
(1) 2001 Passe:		Body	C	Vehicle Theft Deterrent	•	•		
(1) 2001 Passe:		Body	C	Supplemental Inflatable Restraint	•			
(1) 2001 Passe:		Body	C	Remote Function Actuation	•			
(1) 2001 Passe: (1) 2001 Passe:		Body	C	OnStar				
(1) 2001 Passe:		Body	C	Memory Seat Module				
(1) ZUUI Passe	nger car	Douy	U	Imemory Seat Module	•			

Year	Menu1	Menu2	Menu3	Menu4	Read Eras		ECU Info.
(1) 2001	Passenger Car	Body	С	Instrument Panel Cluster	• •	•	•
	Passenger Car	Body	С	Heating and Air Conditioning	• •	•	•
(1) 2001	Passenger Car	Body	C	Driver Door Module	• •	•	•
(1) 2001	Passenger Car	Body	C	Cellular Telephone	• •	•	•
(1) 2001	Passenger Car	Body	C	Body Control Module	• •	•	•
(1) 2001	Medium Duty Truck	Powertrain	Alternative Fuels	(E) 8.1L V8 L18 Dedicated LPG	• •	•	
(1) 2001	Medium Duty Truck	Powertrain	(Z) 6.5L V8 L65	Powertrain Control Module	• •	•	
(1) 2001	Medium Duty Truck	Powertrain	(R) 5.7L V8 L31	4 Speed Automatic	• •	•	
(1) 2001	Medium Duty Truck	Powertrain	(E) 8.1L V8 L18	Manual	• •	•	
(1) 2001	Medium Duty Truck	Powertrain	(E) 8.1L V8 L18	5 Speed Automatic	• •	•	
(1) 2001	Medium Duty Truck	Powertrain	(E) 8.1L V8 L18	4 Speed Automatic	• •	•	
(1) 2001	Medium Duty Truck	Powertrain	(C) 7.2L L6 LG5	Powertrain Control Module	• •	•	
(1) 2001	Medium Duty Truck	Powertrain	(4) 4.8L L4 Diesel	Manual Transmission	• •	•	
(1) 2001	Medium Duty Truck	Powertrain	(4) 4.8L L4 Diesel	Automatic Transmission	• •	•	
(1) 2001	Medium Duty Truck	Powertrain	(3) 7.8L L6 LG4	Manual Transmission	• •	•	
(1) 2001	Medium Duty Truck	Powertrain	(3) 7.8L L6 LG4	Automatic Transmission	• •	•	
(1) 2001	Medium Duty Truck	Chassis	T - B7 Chassis	Hydraulic 4WAL 4 Sensor	• •	•	
(1) 2001	Medium Duty Truck	Chassis	D - C Series	Hydraulic 4WAL 4 Sensor	• •	•	
(1) 2001	Medium Duty Truck	Chassis	C - T Series	Hydraulic 4WAL 4 Sensor	• •	•	
(1) 2001	Medium Duty Truck	Chassis	B - W4 Series	Electronic Brake Control Module	• •	•	
(1) 2001	Medium Duty Truck	Chassis	A - W5 Series	Electronic Brake Control Module	• •	•	
(1) 2001	Medium Duty Truck	Chassis	6 - W22 Series	Hydraulic 4WAL 4 Sensor	• •	•	
(1) 2001	LD Trk, MPV, Incomplete	Powertrain	Alternative Fuels	(R) 5.7L V8 L31 Bi-Fuel	• •	•	
(1) 2001	LD Trk, MPV, Incomplete	Powertrain	(Y) 6.5L V8 L57	P	• •	•	
(1) 2001	LD Trk, MPV, Incomplete	Powertrain	(W) 4.3L V6 L35 (C/K pickup only)	Manual	• •	•	
(1) 2001	LD Trk, MPV, Incomplete	Powertrain	(W) 4.3L V6 L35 (C/K pickup only)	4 Speed Automatic	• •	•	
(1) 2001	LD Trk, MPV, Incomplete	Powertrain	(W) 4.3L V6 L35	Under 8600 GVW	• •	•	
(1) 2001	LD Trk, MPV, Incomplete	Powertrain	(W) 4.3L V6 L35	Equal to or Over 8600 GVW	• •	•	
(1) 2001	LD Trk, MPV, Incomplete	Powertrain	(V) 4.8L V8 LR4	Manual	• •	•	
(1) 2001	LD Trk, MPV, Incomplete	Powertrain	(V) 4.8L V8 LR4	4 Speed Automatic	• •	•	
	LD Trk, MPV, Incomplete		(U) 6.0L V8 LQ4	Under 8600 GVW	• •		
	LD Trk, MPV, Incomplete		(U) 6. OL V8 LQ4	Equal to or Over 8600 GVW	• •	•	
	LD Trk, MPV, Incomplete		(T) 5.3L V8 LM7	Without Throttle-actuated Control	• •	•	
(1) 2001	LD Trk, MPV, Incomplete	Powertrain	(T) 5.3L V8 LM7	With Throttle-actuated Control	• •	•	•
(1) 2001	LD Trk, MPV, Incomplete	Powertrain	(R) 5.7L V8 L31	Under 8600 GVW	• •	•	•
(1) 2001	LD Trk, MPV, Incomplete	Powertrain	(R) 5.7L V8 L31	Equal to or Over 8600 GVW	• •	•	
(1) 2001	LD Trk, MPV, Incomplete	Powertrain	(M) 5. OL V8 L30	Powertrain Control Module	• •	•	
(1) 2001	LD Trk, MPV, Incomplete	Powertrain	(G) 8.1L V8 L18 3500 HD Only	Manual	• •	•	
(1) 2001	LD Trk, MPV, Incomplete	Powertrain	(G) 8.1L V8 L18 3500 HD Only	4 Speed Automatic	• •	•	
(1) 2001	LD Trk, MPV, Incomplete	Powertrain	(G) 8.1L V8 L18	Manual	• •	•	
	LD Trk, MPV, Incomplete		(G) 8.1L V8 L18	5 Speed Automatic	• •	•	
	LD Trk, MPV, Incomplete		(G) 8.1L V8 L18	4 Speed Automatic	• •	•	
	LD Trk, MPV, Incomplete		(F) 6.5L V8 L65	P	• •	•	
	LD Trk, MPV, Incomplete		(F) 6.5L V8 L65	K	• •	•	
	LD Trk, MPV, Incomplete		(F) 6.5L V8 L65	G	• •		•

Year Menul	Menu2	Menu3	Menu4	Read I	Erase Codes	Live Data	ECU Info.
(1) 2001 LD Trk, MPV, Incompl	ete Powertrain	(F) 6.5L V8 L65	С	•	•	•	•
(1) 2001 LD Trk, MPV, Incompl		(E) 3.4L V6 LA1	Without Air Pump	•	•	•	•
(1) 2001 LD Trk, MPV, Incompl		(E) 3.4L V6 LA1	With Air Pump		•	•	
(1) 2001 LD Trk, MPV, Incompl		(C) 2. OL L4 L34	Without TZ2	•	•	•	•
(1) 2001 LD Trk, MPV, Incompl	ete Powertrain	(C) 2. OL L4 L34	With TZ2				
(1) 2001 LD Trk, MPV, Incompl	ete Powertrain	(6) 1.6L L4 L01	Without TZ2				
(1) 2001 LD Trk, MPV, Incompl		(5) 2. 2L L4 L43	S				
(1) 2001 LD Trk, MPV, Incompl		(4) 2.5L V6 LE8	Powertrain Control Module				
(1) 2001 LD Trk, MPV, Incompl		(1) 6.6L V8 LB7 Diesel	Manual	•			
(1) 2001 LD Trk, MPV, Incompl		(1) 6.6L V8 LB7 Diesel	5 Speed Automatic	•	•	•	
(1) 2001 LD Trk, MPV, Incompl		X	Electronic Brake Control Module	•			
(1) 2001 LD Trk, MPV, Incompl		U	Electronic Brake Control Module	•	•	•	
(1) 2001 LD Trk, MPV, Incompl		T	4WAL 3 Sensor	•	•	•	•
(1) 2001 LD Trk, MPV, Incompl		S	4WAL 3 Sensor	•	•	•	•
(1) 2001 LD Trk, MPV, Incompl		P	4WAL 3 Sensor	•	•	•	
(1) 2001 LD Trk, MPV, Incompl		M	4WAL 3 Sensor	•	•	•	
(1) 2001 LD Trk, MPV, Incompl		L	4WAL 3 Sensor	•	•	•	
(1) 2001 LD Trk, MPV, Incompl		K	RTD (Autoride) / EVO	•	•	•	
(1) 2001 LD Trk, MPV, Incompl		K	4WAL 3 Sensor	•	•	•	
(1) 2001 LD Trk, MPV, Incompl		J	Electronic Brake Control Module	•	•	•	
(1) 2001 LD Trk, MPV, Incompl		Н	Rear Integration Module	•	•	•	
(1) 2001 LD Trk, MPV, Incompl		Н	Magna Steer	•	•	•	
(1) 2001 LD Trk, MPV, Incompl		Н	DRP/ABS/TCS	•	•	•	•
(1) 2001 LD Trk, MPV, Incompl		G	4WAL 3 Sensor	•	•	•	•
(1) 2001 LD Trk, MPV, Incompl		Е	Electronic Brake Control Module	•	•	•	•
(1) 2001 LD Trk, MPV, Incompl		C	Under 15000 GVW	•	•	•	lacksquare
(1) 2001 LD Trk, MPV, Incompl		C	Equal to or Over 15000 GVW	•	•	•	lacktriangle
(1) 2001 LD Trk, MPV, Incompl		В	Electronic Brake Control Module	•	•	•	lacksquare
(1) 2001 LD Trk, MPV, Incompl		A	Electronic Brake Control Module	•	•	•	•
(1) 2001 LD Trk, MPV, Incompl		X	(N) Chevrolet MPV	•	•	•	•
(1) 2001 LD Trk, MPV, Incompl		X	(M) Pontiac APV	•	•	•	•
(1) 2001 LD Trk, MPV, Incompl		X	(H) Oldsmobile APV	•	•	•	•
(1) 2001 LD Trk, MPV, Incompl		U	(N) Chevrolet MPV	•	•	•	•
(1) 2001 LD Trk, MPV, Incompl		U	(M) Pontiac APV	•	•	•	•
(1) 2001 LD Trk, MPV, Incompl		T	Supplemental Inflatable Restraint	•	•	•	
(1) 2001 LD Trk, MPV, Incompl		T	OnStar	•	•	•	•
(1) 2001 LD Trk, MPV, Incompl		T	Memory Seat Module	•	•	•	•
(1) 2001 LD Trk, MPV, Incompl		T	Instrument Panel Cluster	•	•	•	•
(1) 2001 LD Trk, MPV, Incompl		T	Heating and Air Conditioning	•	•	•	•
(1) 2001 LD Trk, MPV, Incompl		T	Body Control Module	•	•	•	•
(1) 2001 LD Trk, MPV, Incompl		S	Supplemental Inflatable Restraint	•	•	•	•
(1) 2001 LD Trk, MPV, Incompl		S	OnStar	•	•	•	•
(1) 2001 LD Trk, MPV, Incompl		S	Memory Seat Module	•	•	•	•
(1) 2001 LD Trk, MPV, Incompl		S	Instrument Panel Cluster	•	•	•	•
(1) 2001 LD Trk, MPV, Incompl	ete Body	S	Heating and Air Conditioning				

Year Menu1	Menu2	Menu3	Menu4	Read Eras		ECU Info.
(1) 2001 LD Trk, MPV, Incomplet		S	Body Control Module	• •	•	
(1) 2001 LD Trk, MPV, Incomplet		N	Supplemental Inflatable Restraint	• •	•	•
(1) 2001 LD Trk, MPV, Incomplet		M	Supplemental Inflatable Restraint	• •	•	•
(1) 2001 LD Trk, MPV, Incomplet		M	Instrument Panel Cluster	• •	•	•
(1) 2001 LD Trk, MPV, Incomplet		M	Body Control Module	• •	•	
(1) 2001 LD Trk, MPV, Incomplet		L	Supplemental Inflatable Restraint	• •	•	
(1) 2001 LD Trk, MPV, Incomplet		L	Instrument Panel Cluster	• •	•	•
(1) 2001 LD Trk, MPV, Incomplet		L	Body Control Module		•	
(1) 2001 LD Trk, MPV, Incomplet		K	Supplemental Inflatable Restraint		•	
(1) 2001 LD Trk, MPV, Incomplet		K	OnStar		•	
(1) 2001 LD Trk, MPV, Incomplet		K	Memory Seat Module		•	
(1) 2001 LD Trk, MPV, Incomplet		K	Instrument Panel Cluster	• •		
(1) 2001 LD Trk, MPV, Incomplet	e Body	K	Heating and Air Conditioning	•		
(1) 2001 LD Trk, MPV, Incomplet	e Body	K	Driver Information Center	• •	•	
(1) 2001 LD Trk, MPV, Incomplet	e Body	K	Body Control Module	• •	•	
(1) 2001 LD Trk, MPV, Incomplet		Ј	Supplemental Inflatable Restraint	• •	•	•
(1) 2001 LD Trk, MPV, Incomplet		Н	(E) Cadillac Incomplete	• •	•	•
(1) 2001 LD Trk, MPV, Incomplet		G	Supplemental Inflatable Restraint	• •	•	
(1) 2001 LD Trk, MPV, Incomplet		G	Radio	• •	•	•
(1) 2001 LD Trk, MPV, Incomplet		G	Passlock	• •		
(1) 2001 LD Trk, MPV, Incomplet		G	Immobilizer	• •		
(1) 2001 LD Trk, MPV, Incomplet		E.	Supplemental Inflatable Restraint	• •	•	•
(1) 2001 LD Trk, MPV, Incomplet		C.	Supplemental Inflatable Restraint	0 0		•
(1) 2001 LD Trk, MPV, Incomplet		C	OnStar	0 0		•
(1) 2001 LD Trk, MPV, Incomplet		C	Memory Seat Module			
(1) 2001 LD Trk, MPV, Incomplet		C	Instrument Panel Cluster			
(1) 2001 LD Trk, MPV, Incomplet		C	Heating and Air Conditioning			
(1) 2001 LD Trk, MPV, Incomplet		C	Driver Information Center			
(1) 2001 LD Trk, MPV, Incomplet		C	Body Control Module			
(1) 2001 LD Trk, MPV, Incomplet		B	(7) Pontiac		+ -	
(1) 2001 LD Trk, MPV, Incomplet	 	Λ	(7) Pontiac	0 0	+ -	
(Y) 2000 Saturn	Powertrain	(R) 3. 0L V6 L81	Powertrain Control Module		+ -	
(Y) 2000 Saturn	Powertrain	(F) 2. 2L L4 L61	Manual			
(Y) 2000 Saturn (Y) 2000 Saturn	Powertrain	(F) 2.2L L4 L61	4 Speed Automatic		+ -	
(Y) 2000 Saturn (Y) 2000 Saturn	Powertrain	(8) 1. 9L L4 L24	Powertrain Control Module			
					+ -	
(Y) 2000 Saturn	Powertrain	(7) 1.9L L4 LL0	Powertrain Control Module			
(Y) 2000 Saturn	Chassis	L T	Electronic Brake Control Module	• •	•	
(Y) 2000 Saturn	Chassis	J 7	Electronic Brake Control Module	• •	•	
(Y) 2000 Saturn	Body	<i>L</i>	Supplemental Inflatable Restraint	• •	•	•
(Y) 2000 Saturn	Body	L Z	Instrument Panel Cluster	• •	•	•
(Y) 2000 Saturn	Body	L T	Body Control Module	• •	•	•
(Y) 2000 Saturn	Body	<u> </u>	Supplemental Inflatable Restraint	• •	•	•
(Y) 2000 Saturn	Body	1-	Instrument Panel Cluster	• •	•	•
(Y) 2000 Saturn	Body		Body Control Module	• •	•	•
(Y) 2000 Passenger Car	Powertrain	(Y) 4.6L V8 LD8	Powertrain Control Module			

Year Me	enu1	Menu2	Menu3	Menu4	Read I		Live Data	ECU Info.
(Y) 2000 Pa	assenger Car	Powertrain	(T) 2.4L L4 LD9 Supercharged	N	•	•	•	
	assenger Car	Powertrain	(T) 2.4L L4 LD9 Supercharged	J	•	•	•	
	assenger Car	Powertrain	(T) 2.4L L4 LD9	N	•	•	•	
		Powertrain	(T) 2.4L L4 LD9	J	•	•	•	
	assenger Car	Powertrain	(R) 3. OL V6 L81	Powertrain Control Module	•	•	•	
	assenger Car	Powertrain	(K) 3.8L V6 L36	W	•	•	•	
(Y) 2000 Pa	assenger Car	Powertrain	(K) 3.8L V6 L36	Н				
(Y) 2000 Pa	assenger Car	Powertrain	(K) 3.8L V6 L36	F				
(Y) 2000 Pa	assenger Car	Powertrain	(K) 3.8L V6 L36	C	•	•		
(Y) 2000 Pa	assenger Car	Powertrain	(J) 3.1L V6 LG8	W	•	•		
(Y) 2000 Pa	assenger Car	Powertrain	(J) 3.1L V6 LG8	N				
(Y) 2000 Pa	assenger Car	Powertrain	(H) 3.5L V6 LX5	Powertrain Control Module				
(Y) 2000 Pa	assenger Car	Powertrain	(G) 5.7L V8 LS1	Y				
(Y) 2000 Pa	assenger Car	Powertrain	(G) 5.7L V8 LS1	F		•	•	
(Y) 2000 Pa	assenger Car	Powertrain	(E) 3.4L V6 LA1	W	•	•	•	•
		Powertrain	(E) 3.4L V6 LA1	N	•	•	•	•
		Powertrain	(9) 4.6L V8 L37	Powertrain Control Module	•	•	•	•
	assenger Car	Powertrain	(8) 1.8L L4 LV6	Manual	•	•	•	•
	assenger Car	Powertrain	(8) 1.8L L4 LV6	4 Speed Automatic		•	•	•
	assenger Car	Powertrain	(8) 1. 8L L4 LV6	3 Speed Automatic			•	
		Powertrain	(6) 1. 6L L4 L01	Manual Transmission	•		•	•
	assenger Car	Powertrain	(6) 1. 6L L4 L01	Automatic Transmission				•
	assenger Car	Powertrain	(6) 1. 0L L3 LP2	Powertrain Control Module		•	•	•
	assenger Car	Powertrain	(4) 2.2L L4 LN2 Alternative Fuel	Powertrain Control Module		•		
	assenger Car	Powertrain	(4) 2. 2L L4 LN2	T				
	assenger Car	Powertrain	(3) 1. 6L L4 L73	Manual Transmission				•
	assenger Car	Powertrain	(3) 1. 6L L4 L73	Automatic Transmission				•
	assenger Car	Powertrain	(2) 1. 4L L4 LC0	Powertrain Control Module				
	assenger Car	Powertrain	(2) 1. 3L L4 LY8	Manual				
	assenger Car	Powertrain	(2) 1. 3L L4 LY8	3 Speed Automatic				
	assenger Car	Powertrain	(1) 3. 8L V6 L67	w		•		
		Powertrain	(1) 3. 8L V6 L67	Н		•		
		Powertrain	(1) 3.8L V6 L67	n C				
		Chassis	V V L01	RTD				
		Chassis	V	ABS/TCS/Magna Steer		•		
		Chassis	W	(4) Buick				
			W W	(3) Oldsmobile				
		Chassis	W W					
		Chassis	W W	(2) Pontiac				
		Chassis	W 77	(1) Chevrolet	•	•	•	•
		Chassis	V	Variable Effort Steering	•	•	•	•
		Chassis	V	ABS	•	•	•	•
		Chassis	5	Electronic Brake Control Module	•	•	•	•
		Chassis	N	Electronic Brake Control Module	•	•	•	•
		Chassis	M	Electronic Brake Control Module	•	•	•	•
(Y) 2000 Pa	assenger Car	Chassis	K	(KY) Seville STS	•			

Year	Menu1	Menu2	Menu3	Menu4		Erase Codes		ECU Info.
(Y) 2000	Passenger Car	Chassis	K	(KS) Seville SLS	•	•	•	•
(Y) 2000	Passenger Car	Chassis	K	(KF) DTS	•	•	•	
(Y) 2000	Passenger Car	Chassis	K	(KE) DHS		•		
(Y) 2000	Passenger Car	Chassis	K	(KD) Deville		•	•	
(Y) 2000	Passenger Car	Chassis	J	Electronic Brake Control Module	•	•		
(Y) 2000	Passenger Car	Chassis	Н	Rear Integration Module		•	•	
(Y) 2000	Passenger Car	Chassis	Н	DRP/ABS/TIM		•	•	
(Y) 2000	Passenger Car	Chassis	F	Electronic Brake Control Module		•	•	
(Y) 2000	Passenger Car	Chassis	E	Magna Steer		•	•	
(Y) 2000	Passenger Car	Chassis	Е	Delco/Bosch ABS/TCS		•	•	
(Y) 2000	Passenger Car	Chassis	C	DRP/ABS/TIM		•	•	
(Y) 2000	Passenger Car	Body	Y	(3) Two-Door Convertible	•	•	•	
(Y) 2000	Passenger Car	Body	Y	(2) Two-Door Hatchback/Liftback		•	•	
(Y) 2000	Passenger Car	Body	Y	(1) Two-Door Coupe/Sedan	•	•	•	
(Y) 2000	Passenger Car	Body	W	(4) Buick	•	•	•	
(Y) 2000	Passenger Car	Body	W	(3) Oldsmobile	•	•	•	•
(Y) 2000	Passenger Car	Body	W	(2) Pontiac	•	•	•	•
(Y) 2000	Passenger Car	Body	W	(1) Chevrolet	•	•	•	•
	Passenger Car	Body	V	Supplemental Inflatable Restraint	•	•	•	•
	Passenger Car	Body	V	Radio	•	•	•	
	Passenger Car	Body	V	Power Roof		•		
	Passenger Car	Body	V	OnStar	•	•	•	
	Passenger Car	Body	V	Memory Seat Module	•	•	•	
	Passenger Car	Body	V	Leveling Sensor	•	•	•	•
	Passenger Car	Body	V	Instrument Panel Cluster	•	•		•
	Passenger Car	Body	V	Immobilizer	•	•	•	•
	Passenger Car	Body	V	Heating And Air Conditioning	•	•	•	•
	Passenger Car	Body	V	Body Control Module	•	•	•	•
	Passenger Car	Body	S	(1) Chevrolet	•	•		•
	Passenger Car	Body	N	(3) Oldsmobile	•	•	•	
	Passenger Car	Body	N	(2) Pontiac	•	•	•	•
	Passenger Car	Body	N	(1) Chevrolet	•	•	•	
	Passenger Car	Body	M	Supplemental Inflatable Restraint	•	•		
	Passenger Car	Body	K	(KY) Seville STS	•	•	•	
	Passenger Car	Body	K K	(KS) Seville SLS	•	•	•	
	Passenger Car	Body	K	(KF) DTS	•	•	•	
	Passenger Car	Body	K	(KE) DHS		•	•	
	Passenger Car	Body	IV	(KD) Deville		•		
		Body	T T	Supplemental Inflatable Restraint		•		•
	Passenger Car	Body	J T	Radio		•		
	Passenger Car		J T					
	Passenger Car	Body	I.I	Instrument Panel Cluster	•	•	•	•
	Passenger Car	Body	J	Body Control Module	•	•	•	•
	Passenger Car	Body	Н	(4) Buick	•	•	•	•
	Passenger Car	Body	H	(2) Pontiac	•	•	•	•
(Y) 2000	Passenger Car	Body	F	(2) Pontiac		•	•	

Year	Menu1	Menu2	Menu3	Menu4		Erase Codes		ECU Info.
(Y) 2000	Passenger Car	Body	F	(1) Chevrolet	•	•	•	•
	Passenger Car	Body	Е	Supplemental Inflatable Restraint	•	•	•	•
(Y) 2000	Passenger Car	Body	Е	Remote Function Actuation	•	•	•	
(Y) 2000	Passenger Car	Body	E	Radio	•	•	•	
(Y) 2000	Passenger Car	Body	E	OnStar		•	•	
(Y) 2000	Passenger Car	Body	E	Memory Seat Module		•	•	
(Y) 2000	Passenger Car	Body	E	Memory Mirror Module				
(Y) 2000	Passenger Car	Body	E	Instrument Panel Cluster				
(Y) 2000	Passenger Car	Body	E	Heating and Air Conditioning				
(Y) 2000	Passenger Car	Body	E	Climate Control Panel				
(Y) 2000	Passenger Car	Body	E	Cellular Telephone				
(Y) 2000	Passenger Car	Body	E	Body Control Module				
(Y) 2000	Passenger Car	Body	C	Vehicle Theft Deterrent	•	•	•	
(Y) 2000	Passenger Car	Body	C	Supplemental Inflatable Restraint	•	•	•	
(Y) 2000	Passenger Car	Body	C	Remote Function Actuation	•	•	•	
(Y) 2000	Passenger Car	Body	C	OnStar	•	•	•	
(Y) 2000	Passenger Car	Body	C	Memory Seat Module	•	•	•	
(Y) 2000	Passenger Car	Body	C	Instrument Panel Cluster	•	•	•	
(Y) 2000	Passenger Car	Body	C	Heating and Air Conditioning	•	•	•	
(Y) 2000	Passenger Car	Body	C	Driver Door Module	•	•	•	
(Y) 2000	Passenger Car	Body	C	Cellular Telephone	•	•	•	•
(Y) 2000	Passenger Car	Body	C	Body Control Module	•	•	•	•
	Medium Duty Truck	Powertrain	(Z) 6.5L V8 L65	Powertrain Control Module	•	•	•	•
	Medium Duty Truck	Powertrain	(R) 5.7L V8 L31	Manual	•	•	•	•
(Y) 2000	Medium Duty Truck	Powertrain	(R) 5.7L V8 L31	4 Speed Automatic	•	•	•	•
(Y) 2000	Medium Duty Truck	Powertrain	(D) 7.4L V8 LP4	Manual Transmission	•	•	•	
	Medium Duty Truck	Powertrain	(D) 7.4L V8 LP4	Automatic Transmission	•	•	•	
	Medium Duty Truck	Powertrain	(C) 7.2L L6 LG5	Powertrain Control Module	•	•	•	
	Medium Duty Truck	Powertrain	(B) 7.4L V8 L21	Manual Transmission	•		•	•
	Medium Duty Truck	Powertrain	(B) 7.4L V8 L21	Automatic Transmission	•	•	•	
	Medium Duty Truck	Powertrain	(4) 4.8L L4 Diesel	Manual Transmission	•		•	•
	Medium Duty Truck	Powertrain	(4) 4.8L L4 Diesel	Automatic Transmission	•		•	•
	Medium Duty Truck	Powertrain	(3) 7.8L L6 LG4	Manual Transmission	•		•	
		Powertrain	(3) 7.8L L6 LG4	Automatic Transmission	•		•	
		Chassis	T - B7 Chassis	Hydraulic 4WAL 4 Sensor	•	•	•	•
	Medium Duty Truck	Chassis	D - C Series	Hydraulic 4WAL 4 Sensor	•	•	•	•
	Medium Duty Truck	Chassis	C - T Series	Hydraulic 4WAL 4 Sensor	•	•	•	•
	Medium Duty Truck	Chassis	B - W4 Series	Electronic Brake Control Module	•	•	•	•
		Chassis	A - W5 Series	Electronic Brake Control Module	•	•	•	•
	LD Trk, MPV, Incomplete		(Y) 6.5L V8 L57	P	•	•	•	•
	LD Trk, MPV, Incomplete		(X) 4.3L V6 LF6	T	•	•	•	•
	LD Trk, MPV, Incomplete		(X) 4.3L V6 LF6	S	•	•	•	•
	LD Trk, MPV, Incomplete		(W) 4.3L V6 L35	Т	•	•	•	•
	LD Trk, MPV, Incomplete		(W) 4.3L V6 L35	S	•	•	•	•
(Y) 2000	LD Trk, MPV, Incomplete	Powertrain	(W) 4.3L V6 L35	P				

Year Menu1	Menu2	Menu3	Menu4	Read Erase codes Codes	
(Y) 2000 LD Trk, MPV, Incomplete	Powertrain	(W) 4.3L V6 L35	М	• •	• •
(Y) 2000 LD Trk, MPV, Incomplete		(W) 4.3L V6 L35	L	• •	• •
(Y) 2000 LD Trk, MPV, Incomplete	Powertrain	(W) 4.3L V6 L35	K	• •	• •
(Y) 2000 LD Trk, MPV, Incomplete	Powertrain	(W) 4.3L V6 L35	G	• •	• •
(Y) 2000 LD Trk, MPV, Incomplete	Powertrain	(W) 4.3L V6 L35	С	• •	• •
(Y) 2000 LD Trk, MPV, Incomplete	Powertrain	(V) 4.8L V8 LR4	K	• •	• •
(Y) 2000 LD Trk, MPV, Incomplete		(V) 4.8L V8 LR4	C	• •	• •
(Y) 2000 LD Trk, MPV, Incomplete		(U) 6. OL V8 LQ4	K	• •	• •
(Y) 2000 LD Trk, MPV, Incomplete		(U) 6. OL V8 LQ4	C	• •	• •
(Y) 2000 LD Trk, MPV, Incomplete		(T) 5.3L V8 LM7	K	• •	• •
(Y) 2000 LD Trk, MPV, Incomplete		(T) 5.3L V8 LM7	C	• •	• •
(Y) 2000 LD Trk, MPV, Incomplete		(R) 5.7L V8 L31 Alternative Fuel	Powertrain Control Module	• •	• •
(Y) 2000 LD Trk, MPV, Incomplete		(R) 5.7L V8 L31	P	• •	• •
(Y) 2000 LD Trk, MPV, Incomplete		(R) 5.7L V8 L31	K	• •	• •
(Y) 2000 LD Trk, MPV, Incomplete		(R) 5.7L V8 L31	G	• •	• •
(Y) 2000 LD Trk, MPV, Incomplete		(R) 5.7L V8 L31	C	• •	• •
(Y) 2000 LD Trk, MPV, Incomplete		(M) 5. OL V8 L30	Powertrain Control Module	• •	• •
(Y) 2000 LD Trk, MPV, Incomplete		(L) 4.1L L6 LH3	Powertrain Control Module	• •	• •
(Y) 2000 LD Trk, MPV, Incomplete		(J) 7.4L V8 L29	P	• •	• •
(Y) 2000 LD Trk, MPV, Incomplete		(J) 7.4L V8 L29	K	• •	• •
(Y) 2000 LD Trk, MPV, Incomplete		(J) 7.4L V8 L29	G	• •	• •
(Y) 2000 LD Trk, MPV, Incomplete		(J) 7.4L V8 L29	C	• •	• •
(Y) 2000 LD Trk, MPV, Incomplete		(H) Electric Motor LN1	Powertrain Control Module	• •	• •
(Y) 2000 LD Trk, MPV, Incomplete		(F) 6.5L V8 L65	P	• •	• •
(Y) 2000 LD Trk, MPV, Incomplete		(F) 6.5L V8 L65	K	• •	• •
(Y) 2000 LD Trk, MPV, Incomplete		(F) 6.5L V8 L65	G	• •	• •
(Y) 2000 LD Trk, MPV, Incomplete		(F) 6.5L V8 L65	C	• •	• •
(Y) 2000 LD Trk, MPV, Incomplete		(E) 3. 4L V6 LA1	Without Air Pump	• •	• •
(Y) 2000 LD Trk, MPV, Incomplete		(E) 3. 4L V6 LA1	With Air Pump	• •	• •
(Y) 2000 LD Trk, MPV, Incomplete		(C) 2. OL L4 L34	Manual	• •	• •
(Y) 2000 LD Trk, MPV, Incomplete		(C) 2. 0L L4 L34	4 Speed Automatic	• •	• •
(Y) 2000 LD Trk, MPV, Incomplete		(B) 7. 4L V8 L21	Powertrain Control Module	• •	• •
(Y) 2000 LD Trk, MPV, Incomplete		(6) 1. 6L L4 L01	Powertrain Control Module	• •	• •
(Y) 2000 LD Trk, MPV, Incomplete	Powertrain	(5) 2. 2L L4 L43	S	• •	
(Y) 2000 LD Trk, MPV, Incomplete		(4) 2. 2L L4 LN2	S	• •	
(Y) 2000 LD Trk, MPV, Incomplete		X	Electronic Brake Control Module	• •	• •
(Y) 2000 LD Trk, MPV, Incomplete		U	Electronic Brake Control Module	• •	• •
(Y) 2000 LD Trk, MPV, Incomplete		[] C	4WAL 3 Sensor	• •	• •
(Y) 2000 LD Trk, MPV, Incomplete		ე ი	4WAL 3 Sensor	• •	• •
(Y) 2000 LD Trk, MPV, Incomplete		r v	4WAL 3 Sensor	• •	• •
(Y) 2000 LD Trk, MPV, Incomplete		M T	4WAL 3 Sensor	• •	• •
(Y) 2000 LD Trk, MPV, Incomplete		L v	4WAL 3 Sensor	• •	• •
(Y) 2000 LD Trk, MPV, Incomplete		K 77	RTD (Autoride) / EVO	• •	• •
(Y) 2000 LD Trk, MPV, Incomplete		Λ Τ	4WAL 3 Sensor	• •	• •
(Y) 2000 LD Trk, MPV, Incomplete	Unass1s	<u>[J</u>	Electronic Brake Control Module		

Year Menu	11	Menu2	Menu3	Menu4	Read codes	Erase Codes		ECU Info.
(Y) 2000 LD T	Crk, MPV, Incomplete	Chassis	Н	Rear Integration Module	•	•	•	•
	rk, MPV, Incomplete		Н	Magna Steer		•	•	•
(Y) 2000 LD T	rk, MPV, Incomplete	Chassis	Н	DRP/ABS/TCS		•	•	•
(Y) 2000 LD T	rk, MPV, Incomplete	Chassis	G	4WAL 3 Sensor		•	•	
(Y) 2000 LD T	rk, MPV, Incomplete	Chassis	E	Gasoline		•	•	
(Y) 2000 LD T	Crk, MPV, Incomplete	Chassis	E	Electric		•	•	
(Y) 2000 LD T	Crk, MPV, Incomplete	Chassis	C	Under 15000 GVW		•	•	
(Y) 2000 LD T	Crk, MPV, Incomplete	Chassis	C	Equal to or Over 15000 GVW			•	
	rk, MPV, Incomplete		X	(N) Chevrolet MPV			•	
	rk, MPV, Incomplete		X	(M) Pontiac APV			•	
	rk, MPV, Incomplete		X	(H) Oldsmobile APV			•	
	rk, MPV, Incomplete		V	(N) Chevrolet MPV			•	
	Crk, MPV, Incomplete		V	(M) Pontiac APV			•	
(Y) 2000 LD T	Crk, MPV, Incomplete	Body	V	(H) Oldsmobile APV			•	
	Crk, MPV, Incomplete		U	(N) Chevrolet MPV			•	
(Y) 2000 LD T	Crk, MPV, Incomplete	Body	U	(M) Pontiac APV		•	•	
(Y) 2000 LD T	rk, MPV, Incomplete	Body	U	(H) Oldsmobile APV		•	•	
(Y) 2000 LD T	Crk, MPV, Incomplete	Body	T	Supplemental Inflatable Restraint			•	
	Crk, MPV, Incomplete		T	OnStar			•	
(Y) 2000 LD T	Crk, MPV, Incomplete	Body	T	Memory Seat Module		•	•	
(Y) 2000 LD T	Crk, MPV, Incomplete	Body	T	Instrument Panel Cluster		•	•	
(Y) 2000 LD T	Crk, MPV, Incomplete	Body	T	Heating and Air Conditioning		•	•	
(Y) 2000 LD T	rk, MPV, Incomplete	Body	T	Body Control Module		•	•	
(Y) 2000 LD T	Crk, MPV, Incomplete	Body	S	Supplemental Inflatable Restraint		•	•	
(Y) 2000 LD T	rk, MPV, Incomplete	Body	S	OnStar OnStar		•	•	
(Y) 2000 LD T	Crk, MPV, Incomplete	Body	S	Memory Seat Module		•	•	
(Y) 2000 LD T	Crk, MPV, Incomplete	Body	S	Instrument Panel Cluster		•	•	
(Y) 2000 LD T	Crk, MPV, Incomplete	Body	S	Heating and Air Conditioning	•	•	•	
(Y) 2000 LD T	Crk, MPV, Incomplete	Body	S	Body Control Module		•	•	
(Y) 2000 LD T	Crk, MPV, Incomplete	Body	M	Supplemental Inflatable Restraint		•	•	
(Y) 2000 LD T	rk, MPV, Incomplete	Body	M	Instrument Panel Cluster		•	•	
(Y) 2000 LD T	rk, MPV, Incomplete	Body	M	Body Control Module		•	•	
(Y) 2000 LD T	rk, MPV, Incomplete	Body	L	Supplemental Inflatable Restraint		•	•	
(Y) 2000 LD T	rk, MPV, Incomplete	Body	L	Instrument Panel Cluster	•	•	•	•
(Y) 2000 LD T	rk, MPV, Incomplete	Body	L	Body Control Module	•	•	•	•
	rk, MPV, Incomplete		K	Supplemental Inflatable Restraint	•	•	•	•
	rk, MPV, Incomplete		K	Passlock	•	•	•	•
	rk, MPV, Incomplete		K	OnStar (VS-3B)	•	•	•	•
	rk, MPV, Incomplete		K	OnStar OnStar	•	•	•	•
	rk, MPV, Incomplete		K	Memory Seat Module	•	•	•	•
	Crk, MPV, Incomplete		K	Body Control Module	•	•	•	•
	Crk, MPV, Incomplete		Ј	Supplemental Inflatable Restraint	•	•	•	•
	Crk, MPV, Incomplete		Н	(E) Cadillac Incomplete	•	•	•	•
	Crk, MPV, Incomplete		G	Supplemental Inflatable Restraint	•	•	•	•
	Crk, MPV, Incomplete			Passlock	•	•	•	•

Year	Menu1	Menu2	Menu3	Menu4			Live Data	ECU Info.
(Y) 2000	LD Trk, MPV, Incomplete	Body	G	Immobilizer	•	•	•	•
		Body	E	Gasoline	•	•	•	•
(Y) 2000	LD Trk, MPV, Incomplete	Body	E	Electric	•	•	•	•
(Y) 2000	LD Trk, MPV, Incomplete	Body	C	No Systems Present	•	•	•	
(Y) 2000	LD Trk, MPV, Incomplete	Body	C	BCM, IPC, and Driver Seat Present	•			•
(Y) 2000	LD Trk, MPV, Incomplete	Body	C	BCM and IPC Present	•		•	
(X) 1999	Saturn	Powertrain	Powertrain Control Module		•		•	
	Saturn	Chassis	Electronic Brake Control Module		•	•	•	
(X) 1999	Saturn	Body	Supplemental Inflatable Restraint		•	•	•	
	Passenger Car	Powertrain	(Y) 4.6L V8 LD8	Powertrain Control Module	•	•	•	
	Passenger Car	Powertrain	(T) 2.4L L4 LD9	N	•	•	•	
	Passenger Car	Powertrain	(T) 2.4L L4 LD9	Ј	•	•	•	•
	Passenger Car	Powertrain	(R) 3. OL V6 L81	Powertrain Control Module	•	•	•	•
	Passenger Car	Powertrain	(M) 3.1L V6 L82	W	•	•	•	•
	Passenger Car	Powertrain	(M) 3.1L V6 L82	N	•	•	•	•
	Passenger Car	Powertrain	(K) 3.8L V6 L36	W	•	•	•	
	Passenger Car	Powertrain	(K) 3.8L V6 L36	Н	•	•	•	
	Passenger Car	Powertrain	(K) 3.8L V6 L36	F	•	•	•	•
	Passenger Car	Powertrain	(K) 3.8L V6 L36	C	•	•	•	•
	Passenger Car	Powertrain	(J) 3.1L V6 LG8	Powertrain Control Module	•	•	•	•
	Passenger Car	Powertrain	(H) 3.5L V6 LX5	Powertrain Control Module	•	•	•	
	Passenger Car	Powertrain	(G) 5.7L V8 LS1	Y	•	•	•	•
	Passenger Car	Powertrain	(G) 5.7L V8 LS1	F	•	•	•	•
	Passenger Car	Powertrain	(E) 3.4L V6 LA1	Powertrain Control Module	•	•	•	•
	Passenger Car	Powertrain	(C) 4. OL V8 L47	Powertrain Control Module	•		•	•
	Passenger Car	Powertrain	(9) 4.6L V8 L37	Powertrain Control Module	•	•	•	•
	Passenger Car	Powertrain	(8) 4.0L V8 - Shelby	Powertrain Control Module		•	•	•
	Passenger Car	Powertrain	(8) 1.8L L4 LV6	Manual		•	•	•
	Passenger Car	Powertrain	(8) 1.8L L4 LV6	4 Speed Automatic		•	•	•
	Passenger Car	Powertrain	(8) 1.8L L4 LV6	3 Speed Automatic		•	•	•
	Passenger Car	Powertrain	(6) 1.6L L4 L01	Manual Transmission	•	•	•	•
	Passenger Car	Powertrain	(6) 1.6L L4 L01	Automatic Transmission	•	•	•	•
	Passenger Car	Powertrain	(6) 1. 0L L3 LP2	Powertrain Control Module	•	•	•	•
	Passenger Car	Powertrain	(5) Electric Motor LN1	Powertrain Control Module		•	•	•
	Passenger Car	Powertrain	(4) 2.2L L4 LN2 Alternative Fuel	Powertrain Control Module	•	•	•	•
	Passenger Car	Powertrain	(4) 2. 2L L4 LN2	J	•	•	•	
	Passenger Car	Powertrain	(3) 1.6L L4 L73	Manual Transmission	•	•	•	•
	Passenger Car	Powertrain	(3) 1.6L L4 L73	Automatic Transmission	•	•	•	•
	Passenger Car	Powertrain	(2) 1.4L L4 LC0	Powertrain Control Module	•	•	•	•
	Passenger Car	Powertrain	(2) 1.3L L4 LY8	Manual	•	•	•	•
	Passenger Car	Powertrain	(2) 1.3L L4 LY8	3 Speed Automatic	•	•	•	•
	Passenger Car	Powertrain	(1) 3.8L V6 L67	W	•	•	•	•
	Passenger Car	Powertrain	(1) 3.8L V6 L67	Н		•	•	•
	Passenger Car	Powertrain	(1) 3.8L V6 L67	G		•	•	•
(X) 1999	Passenger Car	Powertrain	(1) 3.8L V6 L67	<u>C</u>				lacksquare

Year	Menu1	Menu2	Menu3	Menu4		Erase Codes		ECU Info.
(X) 1999	Passenger Car	Chassis	Y	CVRTD		•	•	•
(X) 1999	Passenger Car	Chassis	Y	ABS/TCS/Magna Steer		•	•	
(X) 1999	Passenger Car	Chassis	W	(4) Buick				
(X) 1999	Passenger Car	Chassis	W	(3) Oldsmobile				
(X) 1999	Passenger Car	Chassis	W	(2) Pontiac				
(X) 1999	Passenger Car	Chassis	W	(1) Chevrolet				
(X) 1999	Passenger Car	Chassis	V	Variable Effort Steering				
(X) 1999	Passenger Car	Chassis	V	ABS				
(X) 1999	Passenger Car	Chassis	S	Electronic Brake Control Module				
(X) 1999	Passenger Car	Chassis	P	BTCM		•	•	
(X) 1999	Passenger Car	Chassis	P	Auto Disconnect		•	•	
(X) 1999	Passenger Car	Chassis	N	Electronic Brake Control Module		•	•	
(X) 1999	Passenger Car	Chassis	M	Electronic Brake Control Module		•	•	
(X) 1999	Passenger Car	Chassis	K	ABS/TCS BLW ICCS2		•	•	
(X) 1999	Passenger Car	Chassis	Ј	Electronic Brake Control Module		•	•	
(X) 1999	Passenger Car	Chassis	Н	Delco/Bosch ABS	•	•	•	•
	Passenger Car	Chassis	F	Electronic Brake Control Module	•	•	•	•
	Passenger Car	Chassis	Е	Magna Steer	•	•	•	•
	Passenger Car	Chassis	Е	Delco/Bosch ABS/TCS		•	•	•
	Passenger Car	Chassis	С	ABS		•	•	
	Passenger Car	Body	Y	(3) Two-Door Convertible				
	Passenger Car	Body	Ÿ	(2) Two-Door Hatchback/Liftback			•	•
	Passenger Car	Body	Ÿ	(1) Two-Door Coupe/Sedan			•	
	Passenger Car	Body	W	(4) Buick		•	•	•
	Passenger Car	Body	W	(3) Oldsmobile		•	•	•
	Passenger Car	Body	W	(2) Pontiac				•
	Passenger Car	Body	W	(1) Chevrolet				•
	Passenger Car	Body	V	Supplemental Inflatable Restraint				•
	Passenger Car	Body	V	Remote Function Actuator				•
	Passenger Car	Body	V	Radio		•	•	
	Passenger Car	Body	V	Power Roof		•	•	•
	Passenger Car	Body	V	OnStar (VS-3B)		•	•	•
	Passenger Car	Body	V	OnStar		•		
	Passenger Car	Body	V	Memory Seat Module	•	•	•	
	Passenger Car	Body	V	Leveling Sensor	•	•	•	
	Passenger Car	Body	V	Instrument Panel Cluster	•	•	•	
	Passenger Car	Body	V	Immobilizer		•	•	
	Passenger Car	Body	V	Heating And Air Conditioning		•	•	
	Passenger Car	Body	V	Cellular Telephone		•	•	
	Passenger Car	Body	V	Body Control Module		•		•
	Passenger Car	Body	V	BCM/RFA		•		
		Body	V C	Shelby		•		
	Passenger Car Passenger Car		o c			•		
		Body	<u>S</u>	(1) Chevrolet	— 			
	Passenger Car	Body	P	Supplemental Inflatable Restraint	•	•	•	•
(X) 1999	Passenger Car	Body	<u>I</u> r	RSA				

Year	Menu1	Menu2	Menu3	Menu4	Read Era	ECU Info.
(X) 1999	Passenger Car	Body	Р	IPC	•	•
(X) 1999	Passenger Car	Body	P	HTCM		•
(X) 1999	Passenger Car	Body	N	(3) Oldsmobile		
(X) 1999	Passenger Car	Body	N	(2) Pontiac		
(X) 1999	Passenger Car	Body	N	(1) Chevrolet		
(X) 1999	Passenger Car	Body	M	Supplemental Inflatable Restraint	•	•
(X) 1999	Passenger Car	Body	K	(KY) Seville STS	•	
(X) 1999	Passenger Car	Body	K	(KS) Seville SLS	•	
(X) 1999	Passenger Car	Body	K	(KF) Deville Concours	•	
(X) 1999	Passenger Car	Body	K	(KE) Deville D'Elegance	•	•
(X) 1999	Passenger Car	Body	K	(KD) Deville	•	•
(X) 1999	Passenger Car	Body	J	(2) Pontiac	•	
	Passenger Car	Body	J	(1) Chevrolet	•	•
(X) 1999	Passenger Car	Body	Н	(4) Buick	•	•
	Passenger Car	Body	Н	(3) Oldsmobile	•	
	Passenger Car	Body	Н	(2) Pontiac	•	•
(X) 1999	Passenger Car	Body	G	(4) Buick	•	•
(X) 1999	Passenger Car	Body	G	(3) Oldsmobile	•	•
	Passenger Car	Body	F	(2) Pontiac	•	•
(X) 1999	Passenger Car	Body	F	(1) Chevrolet	•	•
(X) 1999	Passenger Car	Body	Е	Supplemental Inflatable Restraint		
(X) 1999	Passenger Car	Body	E	Remote Function Actuation		
(X) 1999	Passenger Car	Body	Е	Radio		
(X) 1999	Passenger Car	Body	Е	OnStar (VS-3B)		
(X) 1999	Passenger Car	Body	Е	OnStar		
(X) 1999	Passenger Car	Body	Е	Memory Seat Module		
(X) 1999	Passenger Car	Body	Е	Memory Mirror Module		
(X) 1999	Passenger Car	Body	Е	Instrument Panel Cluster		
(X) 1999	Passenger Car	Body	Е	Heating and Air Conditioning		
(X) 1999	Passenger Car	Body	Е	Climate Control Panel		
(X) 1999	Passenger Car	Body	Е	Cellular Telephone		
(X) 1999	Passenger Car	Body	Е	Body Control Module		
(X) 1999	Passenger Car	Body	С	Vehicle Theft Deterrent		
(X) 1999	Passenger Car	Body	С	Supplemental Inflatable Restraint		
(X) 1999	Passenger Car	Body	С	Remote Function Actuation		
	Passenger Car	Body	С	OnStar (VS-3B)		
(X) 1999	Passenger Car	Body	C	OnStar		
(X) 1999	Passenger Car	Body	С	Memory Seat Module		
(X) 1999	Passenger Car	Body	C	Instrument Panel Cluster	•	•
(X) 1999	Passenger Car	Body	С	Heating and Air Conditioning		
	Passenger Car	Body	С	Driver Door Module	•	
(X) 1999	Passenger Car	Body	С	Cellular Telephone	•	
	Passenger Car	Body	С	Body Control Module	•	
(X) 1999	Medium Duty Truck	Powertrain	(Z) 6.5L V8 L65	Powertrain Control Module	•	
(X) 1999	Medium Duty Truck	Powertrain	(R) 5.7L V8 L31	Manual	•	

Year	Menu1	Menu2	Menu3	Menu4	Read codes	Erase Codes	Live Data	ECU Info.
(X) 1999	Medium Duty Truck	Powertrain	(R) 5.7L V8 L31	4 Speed Automatic	•		•	
(X) 1999	Medium Duty Truck	Powertrain	(F) 6.5L V8 L65	Manual Transmission	•		•	
(X) 1999	Medium Duty Truck	Powertrain	(F) 6.5L V8 L65	Automatic Transmission	•		•	
(X) 1999	Medium Duty Truck	Powertrain	(D) 7.4L V8 LP4	Manual Transmission	•		•	
(X) 1999	Medium Duty Truck	Powertrain	(D) 7.4L V8 LP4	Automatic Transmission	•		•	
(X) 1999	Medium Duty Truck	Powertrain	(B) 7.4L V8 L21	Manual Transmission				
(X) 1999	Medium Duty Truck	Powertrain	(B) 7.4L V8 L21	Automatic Transmission				
(X) 1999	Medium Duty Truck	Powertrain	(4) 4.8L L4 Diesel	Manual Transmission				
(X) 1999	Medium Duty Truck	Powertrain	(4) 4.8L L4 Diesel	Automatic Transmission				
(X) 1999	Medium Duty Truck	Powertrain	(3) 7.8L L6 LG4	Manual Transmission				
(X) 1999	Medium Duty Truck	Powertrain	(3) 7.8L L6 LG4	Automatic Transmission				
(X) 1999	Medium Duty Truck	Chassis	T - B7 Chassis	Hydraulic 4WAL 4 Sensor				
(X) 1999	Medium Duty Truck	Chassis	D - C Series	Hydraulic 4WAL 4 Sensor				
(X) 1999	Medium Duty Truck	Chassis	C - T Series	Hydraulic 4WAL 4 Sensor	•	•	•	•
(X) 1999	LD Trk, MPV, Incomplete	Powertrain	(Y) 6.5L V8 L57	P				
(X) 1999	LD Trk, MPV, Incomplete	Powertrain	(X) 4.3L V6 LF6	T				
(X) 1999	LD Trk, MPV, Incomplete	Powertrain	(X) 4.3L V6 LF6	S				
(X) 1999	LD Trk, MPV, Incomplete	Powertrain	(W) 4.3L V6 L35	T				
(X) 1999	LD Trk, MPV, Incomplete	Powertrain	(W) 4.3L V6 L35	S				
(X) 1999	LD Trk, MPV, Incomplete	Powertrain	(W) 4.3L V6 L35	P				
(X) 1999	LD Trk, MPV, Incomplete	Powertrain	(W) 4.3L V6 L35	M				
(X) 1999	LD Trk, MPV, Incomplete	Powertrain	(W) 4.3L V6 L35	L	•			
(X) 1999	LD Trk, MPV, Incomplete	Powertrain	(W) 4.3L V6 L35	K				
(X) 1999	LD Trk, MPV, Incomplete	Powertrain	(W) 4.3L V6 L35	G	•			
(X) 1999	LD Trk, MPV, Incomplete	Powertrain	(W) 4.3L V6 L35	C	•			
(X) 1999	LD Trk, MPV, Incomplete	Powertrain	(V) 4.8L V8 LR4	K	•			
(X) 1999	LD Trk, MPV, Incomplete	Powertrain	(V) 4.8L V8 LR4	C				
(X) 1999	LD Trk, MPV, Incomplete	Powertrain	(U) 6.0L V8 LQ4	K				
(X) 1999	LD Trk, MPV, Incomplete	Powertrain	(U) 6.0L V8 LQ4	C				
(X) 1999	LD Trk, MPV, Incomplete	Powertrain	(T) 5.3L V8 LM7	K				
	LD Trk, MPV, Incomplete		(T) 5.3L V8 LM7	C				
	LD Trk, MPV, Incomplete		(S) 6.5L V8 L56	K				
	LD Trk, MPV, Incomplete		(S) 6.5L V8 L56	C				
	LD Trk, MPV, Incomplete		(R) 5.7L V8 L31 Alternative Fuel	Powertrain Control Module				
	LD Trk, MPV, Incomplete		(R) 5.7L V8 L31	P	•	•		•
	LD Trk, MPV, Incomplete		(R) 5.7L V8 L31	K	•	•	•	•
	LD Trk, MPV, Incomplete		(R) 5.7L V8 L31	G	•	•	•	•
	LD Trk, MPV, Incomplete		(R) 5.7L V8 L31	C	•	•	•	
	LD Trk, MPV, Incomplete		(M) 5. OL V8 L30	K	•	•	•	•
	LD Trk, MPV, Incomplete		(M) 5. OL V8 L30	G	•	•	•	•
(X) 1999	LD Trk, MPV, Incomplete	Powertrain	(M) 5. OL V8 L30	C	•	•	•	
(X) 1999	LD Trk, MPV, Incomplete	Powertrain	(L) 4.1L L6 LH3	Powertrain Control Module	•	•	•	•
(X) 1999	LD Trk, MPV, Incomplete	Powertrain	(K) 5.7L V8 L05	Manual Transmission	•	•	•	•
(X) 1999	LD Trk, MPV, Incomplete	Powertrain	(K) 5.7L V8 L05	Automatic Transmission	•	•	•	•
(X) 1999	LD Trk, MPV, Incomplete	Powertrain	(J) 7.4L V8 L29	P	•		•	•

Year Menu1	Menu2	Menu3	Menu4	Read Erase		ECU Info.
(X) 1999 LD Trk, MPV, Incomplete	Powertrain	(J) 7.4L V8 L29	K	• •		•
(X) 1999 LD Trk, MPV, Incomplete		(J) 7. 4L V8 L29	G	• •	•	•
(X) 1999 LD Trk, MPV, Incomplete		(J) 7.4L V8 L29	С	• •	•	•
(X) 1999 LD Trk, MPV, Incomplete		(F) 6.5L V8 L65	P	• •	•	•
(X) 1999 LD Trk, MPV, Incomplete		(F) 6.5L V8 L65	K	• •	•	•
(X) 1999 LD Trk, MPV, Incomplete	Powertrain	(F) 6.5L V8 L65	G	• •		•
(X) 1999 LD Trk, MPV, Incomplete	Powertrain	(F) 6.5L V8 L65	C	• •	•	•
(X) 1999 LD Trk, MPV, Incomplete	Powertrain	(E) 3.4L V6 LA1	Powertrain Control Module	• •		
(X) 1999 LD Trk, MPV, Incomplete	Powertrain	(C) 2. OL L4 L34	Manual	• •		
(X) 1999 LD Trk, MPV, Incomplete		(C) 2. OL L4 L34	4 Speed Automatic	• •	•	•
(X) 1999 LD Trk, MPV, Incomplete		(B) 7.4L V8 L21	Powertrain Control Module	• •	•	•
(X) 1999 LD Trk, MPV, Incomplete		(6) 1.6L L4 L01	Manual	• •	•	•
(X) 1999 LD Trk, MPV, Incomplete		(4) 2. 2L L4 LN2	S	• •	•	•
(X) 1999 LD Trk, MPV, Incomplete	Chassis	X	Electronic Brake Control Module	• •	•	•
(X) 1999 LD Trk, MPV, Incomplete	Chassis	U	Electronic Brake Control Module	• •	•	•
(X) 1999 LD Trk, MPV, Incomplete	Chassis	Т	4WAL 3 Sensor	• •	•	•
(X) 1999 LD Trk, MPV, Incomplete	Chassis	S	4WAL 3 Sensor	• •	•	•
(X) 1999 LD Trk, MPV, Incomplete	Chassis	P	4WAL 3 Sensor	• •		
(X) 1999 LD Trk, MPV, Incomplete	Chassis	M	4WAL 3 Sensor	• •	•	•
(X) 1999 LD Trk, MPV, Incomplete	Chassis	L	4WAL 3 Sensor	• •	•	•
(X) 1999 LD Trk, MPV, Incomplete	Chassis	K	Electronic Variable Orifice	• •	•	•
(X) 1999 LD Trk, MPV, Incomplete	Chassis	K	4WAL 3 Sensor	• •	•	•
(X) 1999 LD Trk, MPV, Incomplete	Chassis	Ј	Electronic Brake Control Module	• •	•	•
(X) 1999 LD Trk, MPV, Incomplete	Chassis	Н	Magna Steer	• •	•	•
(X) 1999 LD Trk, MPV, Incomplete	Chassis	H	Delco/Bosch ABS/TCS	• •	•	•
(X) 1999 LD Trk, MPV, Incomplete	Chassis	G	4WAL 3 Sensor	• •	•	•
(X) 1999 LD Trk, MPV, Incomplete	Chassis	E	Electronic Brake Control Module	• •	•	•
(X) 1999 LD Trk, MPV, Incomplete	Chassis	C	Under 15000 GVW	• •	•	•
(X) 1999 LD Trk, MPV, Incomplete	Chassis	C 	Equal to or Over 15000 GVW	• •	•	•
(X) 1999 LD Trk, MPV, Incomplete	Body	X	Vehicle Theft Deterrent	• •	•	•
(X) 1999 LD Trk, MPV, Incomplete	Body	X Y	Supplemental Inflatable Restraint	• •	•	•
(X) 1999 LD Trk, MPV, Incomplete	Body	X V	OnStar (VS-3B)	• •	•	•
(X) 1999 LD Trk, MPV, Incomplete	Body	X	OnStar	• •	•	•
(X) 1999 LD Trk, MPV, Incomplete		U	Vehicle Theft Deterrent	• •	•	•
(X) 1999 LD Trk, MPV, Incomplete			Supplemental Inflatable Restraint	• •	•	-
		U	OnStar (VS-3B)	• •		-
(X) 1999 LD Trk, MPV, Incomplete		U T	OnStar			
(X) 1999 LD Trk, MPV, Incomplete		T	Utility Dial Un			
(X) 1999 LD Trk, MPV, Incomplete			Pick Up			
(X) 1999 LD Trk, MPV, Incomplete (X) 1999 LD Trk, MPV, Incomplete		C	Envoy Utility			
(X) 1999 LD Trk, MPV, Incomplete (X) 1999 LD Trk, MPV, Incomplete		c	Pick Up			
(X) 1999 LD Trk, MPV, Incomplete (X) 1999 LD Trk, MPV, Incomplete		s c	Envoy			
(X) 1999 LD Trk, MPV, Incomplete		м	Supplemental Inflatable Restraint			
(X) 1999 LD Trk, MPV, Incomplete		M	Passlock			
(A) 1999 LD IIK, MEV, INCOMPLETE	pouy	IVI	rassiuck			

Year	Menu1	Menu2	Menu3	Menu4		Erase Codes		ECU Info.
(X) 1999	LD Trk, MPV, Incomplete	Body	L	Supplemental Inflatable Restraint	•	•	•	
(X) 1999	LD Trk, MPV, Incomplete	Body	L	Passlock	•		•	
(X) 1999	LD Trk, MPV, Incomplete	Body	K	Supplemental Inflatable Restraint	•		•	
(X) 1999	LD Trk, MPV, Incomplete	Body	K	OnStar (VS-3B)	•		•	
(X) 1999	LD Trk, MPV, Incomplete	Body	K	OnStar			•	
(X) 1999	LD Trk, MPV, Incomplete	Body	K	Instrument Panel Cluster	•	•		
	LD Trk, MPV, Incomplete		K	Body Control Module	•	•		
(X) 1999	LD Trk, MPV, Incomplete	Body	J	Supplemental Inflatable Restraint	•	•		
	LD Trk, MPV, Incomplete		Н	Radio	•	•	•	
	LD Trk, MPV, Incomplete		G	Supplemental Inflatable Restraint	•			
	LD Trk, MPV, Incomplete		G	Passlock	•			
	LD Trk, MPV, Incomplete		G	Immobilizer	•			
(X) 1999	LD Trk, MPV, Incomplete	Body	E	Supplemental Inflatable Restraint	•	•		
	LD Trk, MPV, Incomplete		C	Supplemental Inflatable Restraint	•			
(X) 1999	LD Trk, MPV, Incomplete	Body	C	OnStar (VS-3B)	•	•		
(X) 1999	LD Trk, MPV, Incomplete	Body	C	OnStar	•	•		
(X) 1999	LD Trk, MPV, Incomplete	Body	C	Instrument Panel Cluster	•	•		
(X) 1999	LD Trk, MPV, Incomplete	Body	C	Body Control Module	•	•		
(W) 1998	Saturn	Powertrain	Powertrain Control Module		•	•		
(W) 1998	Saturn	Chassis	Electronic Brake Control Module		•	•		
(W) 1998	Saturn	Body	Supplemental Inflatable Restraint		•	•		
(W) 1998	Passenger Car	Powertrain	(Y) 4.6L V8 LD8	Powertrain Control Module	•	•		
(W) 1998	Passenger Car	Powertrain	(T) 2.4L L4 LD9	N	•	•		
(W) 1998	Passenger Car	Powertrain	(T) 2.4L L4 LD9	Ј	•	•		
(W) 1998	Passenger Car	Powertrain	(R) 3. 0L V6 L81	Powertrain Control Module	•		•	
(W) 1998	Passenger Car	Powertrain	(M) 3.1L V6 L82	W	•		•	
(W) 1998	Passenger Car	Powertrain	(M) 3.1L V6 L82	N	•		•	
(W) 1998	Passenger Car	Powertrain	(K) 3.8L V6 L36	W	•		•	
(W) 1998	Passenger Car	Powertrain	(K) 3.8L V6 L36	Н	•		•	
(W) 1998	Passenger Car	Powertrain	(K) 3.8L V6 L36	F	•		•	
(W) 1998	Passenger Car	Powertrain	(K) 3.8L V6 L36	C			•	
(W) 1998	Passenger Car	Powertrain	(G) 5.7L V8 LS1	Y			•	
(W) 1998	Passenger Car	Powertrain	(G) 5.7L V8 LS1	F			•	
(W) 1998	Passenger Car	Powertrain	(C) 4.0L V8 L47	Powertrain Control Module	•		•	
(W) 1998	Passenger Car	Powertrain	(9) 4.6L V8 L37	Powertrain Control Module	•		•	
		Powertrain	(8) 4.0L V8 - Shelby	Powertrain Control Module	•	•	•	
(W) 1998	Passenger Car	Powertrain	(8) 1.8L L4 LV6	Manual	•	•	•	
(W) 1998	Passenger Car	Powertrain	(8) 1.8L L4 LV6	4 Speed Automatic	•	•	•	
(W) 1998	Passenger Car	Powertrain	(8) 1.8L L4 LV6	3 Speed Automatic	•	•	•	
	Passenger Car	Powertrain	(6) 1. OL L3 LP2	Powertrain Control Module	•	•	•	
(W) 1998	Passenger Car	Powertrain	(4) 2.2L L4 LN2 Bi-Fuel	Powertrain Control Module	•	•	•	•
	Passenger Car	Powertrain	(4) 2. 2L L4 LN2	J	•	•	•	•
(W) 1998	Passenger Car	Powertrain	(3) 1.6L L4 L73	Manual Transmission	•	•	•	•
(W) 1998	Passenger Car	Powertrain	(3) 1.6L L4 L73	Automatic Transmission	•	•	•	•
		Powertrain	(2) 1.4L L4 LC0	Powertrain Control Module	•	•	•	•

Year	Menu1	Menu2	Menu3	Menu4		Erase Codes		ECU Info.
(W) 1998	Passenger Car	Powertrain	(2) 1.3L L4 LY8	Manual	•	•	•	
	Passenger Car	Powertrain	(2) 1.3L L4 LY8	3 Speed Automatic	•	•		
(W) 1998	Passenger Car	Powertrain	(1) 3.8L V6 L67	W	•	•	•	
	Passenger Car	Powertrain	(1) 3.8L V6 L67	Н	•	•	•	
	Passenger Car	Powertrain	(1) 3.8L V6 L67	G	•	•		
	Passenger Car	Powertrain	(1) 3.8L V6 L67	C	•	•		
(W) 1998	Passenger Car	Chassis	Y	CVRTD				
(W) 1998	Passenger Car	Chassis	Y	ABS/TCS/Magna Steer				
(W) 1998	Passenger Car	Chassis	W	(4) Buick				
(W) 1998	Passenger Car	Chassis	W	(3) Oldsmobile				
(W) 1998	Passenger Car	Chassis	W	(2) Pontiac				
(W) 1998	Passenger Car	Chassis	W	(1) Chevrolet		•	•	
(W) 1998	Passenger Car	Chassis	V	Variable Effort Steering	•	•		
(W) 1998	Passenger Car	Chassis	V	ABS	•	•	•	
(W) 1998	Passenger Car	Chassis	S	Electronic Brake Control Module		•	•	
(W) 1998	Passenger Car	Chassis	N	Electronic Brake Control Module	•	•	•	•
(W) 1998	Passenger Car	Chassis	М	Electronic Brake Control Module	•	•	•	•
	Passenger Car	Chassis	К	ABS/TCS BLW ICCS2	•	•		
	Passenger Car	Chassis	T	Electronic Brake Control Module		•	•	
	Passenger Car	Chassis	H	Delco/Bosch ABS	•	•		
	Passenger Car	Chassis	F	Electronic Brake Control Module	•	•		
	Passenger Car	Chassis	F	Magna Steer	•	•	•	•
	Passenger Car	Chassis	F.	Delco/Bosch ABS/TCS		•	•	•
	Passenger Car	Chassis	C	ABS		•		
	Passenger Car	Body	γ	(3) Two-Door Convertible		•		
	Passenger Car	Body	V	(2) Two-Door Hatchback/Liftback	•	•		
	Passenger Car	Body	W	(4) Buick	•	•	•	
	Passenger Car	Body	W	(3) Oldsmobile		•		
	Passenger Car	Body	W	(2) Pontiac		•		
	Passenger Car	Body	W	(1) Chevrolet		•		
	Passenger Car	Body	V	Supplemental Inflatable Restraint		•		•
	Passenger Car	Body	V	Remote Function Actuator		•		
	Passenger Car	Body	V	Radio				
	Passenger Car	Body	V V	Power Roof		•		
	Passenger Car	Body	V V		_	•		
			V V	OnStar	•			
	Passenger Car	Body	V	Memory Seat Module	•	•	•	•
	Passenger Car	Body	V	Leveling Sensor	•	•	•	•
	Passenger Car	Body	V	Instrument Panel Cluster	•	•	•	•
	Passenger Car	Body	V	Immobilizer	•	•	•	•
	Passenger Car	Body	V 	Heating And Air Conditioning	•	•	•	•
	Passenger Car	Body	V 	Cruise Control	•	•	•	•
	Passenger Car	Body	V L	Cellular Telephone	•	•	•	•
	Passenger Car	Body	V	Body Control Module	•	•	•	•
	Passenger Car	Body	S	Shelby	•	•	•	•
(W) 1998	Passenger Car	Body	S	(1) Chevrolet				

Year Menu1	Menu2	Menu3	Menu4		Erase Codes		ECU Info.
(W) 1998 Passenger Car	Body	N	(4) Buick	•	•	•	
(W) 1998 Passenger Car	Body	N	(3) Oldsmobile	•	•	•	
(W) 1998 Passenger Car	Body	N	(2) Pontiac	•	•	•	
(W) 1998 Passenger Car	Body	N	(1) Chevrolet	•	•		
(W) 1998 Passenger Car	Body	M	Supplemental Inflatable Restraint	•	•		
(W) 1998 Passenger Car	Body	K	(KY) Seville STS	•	•		
(W) 1998 Passenger Car	Body	K	(KS) Seville SLS	•	•		
(W) 1998 Passenger Car	Body	K	(KF) Deville Concours	•	•		
(W) 1998 Passenger Car	Body	K	(KE) Deville D'Elegance	•	•		
(W) 1998 Passenger Car	Body	K	(KD) Deville		•	•	
(W) 1998 Passenger Car	Body	Ј	(2) Pontiac		•	•	
(W) 1998 Passenger Car	Body	Ј	(1) Chevrolet	•	•	•	
(W) 1998 Passenger Car	Body	Н	(4) Buick		•	•	
(W) 1998 Passenger Car	Body	Н	(3) Oldsmobile	•	•	•	
(W) 1998 Passenger Car	Body	Н	(2) Pontiac	•	•	•	
(W) 1998 Passenger Car	Body	G	(4) Buick	•	•	•	
(W) 1998 Passenger Car	Body	G	(3) Oldsmobile	•	•	•	•
(W) 1998 Passenger Car	Body	F	(2) Pontiac	•	•	•	•
(W) 1998 Passenger Car	Body	F	(1) Chevrolet	•	•	•	•
(W) 1998 Passenger Car	Body	Е	Supplemental Inflatable Restraint	•	•	•	
(W) 1998 Passenger Car	Body	Е	Remote Function Actuation	•	•	•	
(W) 1998 Passenger Car	Body	E	Radio		•	•	
(W) 1998 Passenger Car	Body	E	OnStar		•	•	
(W) 1998 Passenger Car	Body	E	Memory Seat Module		•	•	
(W) 1998 Passenger Car	Body	E	Memory Mirror Module		•	•	
(W) 1998 Passenger Car	Body	E	Instrument Panel Cluster		•	•	•
(W) 1998 Passenger Car	Body	F.	Heating and Air Conditioning		•	•	•
(W) 1998 Passenger Car	Body	F.	Climate Control Panel		•	•	•
(W) 1998 Passenger Car	Body	F.	Cellular Telephone		•	•	
(W) 1998 Passenger Car	Body	F.	Body Control Module		•	•	•
(W) 1998 Passenger Car	Body	C	Vehicle Theft Deterrent		•	•	•
(W) 1998 Passenger Car	Body	C	Supplemental Inflatable Restraint		•	•	•
(W) 1998 Passenger Car	Body	C	Remote Function Actuation		•	•	
(W) 1998 Passenger Car	Body	C	OnStar	•	•	•	
(W) 1998 Passenger Car	Body	C	Memory Seat Module	•	•	•	
(W) 1998 Passenger Car	Body	C	Instrument Panel Cluster	•	•	•	
(W) 1998 Passenger Car	Body	C	Heating and Air Conditioning	•	•	•	
(W) 1998 Passenger Car	Body	C	Driver Door Module	•	•	•	
(W) 1998 Passenger Car	Body	C	Cellular Telephone	•	•	•	
(W) 1998 Passenger Car	Body	C	Body Control Module	•	•	•	
(W) 1998 Medium Duty True		(Z) 6.5L V8 L65	Powertrain Control Module	•	•		
(W) 1998 Medium Duty True		(R) 5.7L V8 L31	Manual	•	•		
(W) 1998 Medium Duty True		(R) 5.7L V8 L31	4 Speed Automatic	•	•		
(W) 1998 Medium Duty True		(P) 6. OL V8 LS0	Powertrain Control Module				
(W) 1998 Medium Duty True		(M) 7. OL V8 LRO	Powertrain Control Module				
(w) 1990 Medium Duty Iru	Zw Lowertrain	(M) 1. UL YO LAU	Lower frain courtor wounte				

Year Menul	Menu2	Menu3	Menu4	Read	Erase	Live	ECU
rear menur	MelluZ	Menus	Melia.	codes	Codes	Data	Info.
(W) 1998 Medium Duty Truck	Powertrain	(F) 6.5L V8 L65	Manual Transmission	•	•	•	•
(W) 1998 Medium Duty Truck	Powertrain	(F) 6.5L V8 L65	Automatic Transmission	•	•	•	•
(W) 1998 Medium Duty Truck	Chassis	T - B7 Chassis	Hydraulic 4WAL 4 Sensor	•	•	•	•
(W) 1998 Medium Duty Truck	Chassis	D - C Series	Hydraulic 4WAL 4 Sensor	•	•	•	•
(W) 1998 Medium Duty Truck	Chassis	C - T Series	Hydraulic 4WAL 4 Sensor	•	•	•	•
(W) 1998 LD Trk, MPV, Incomplete	Powertrain	(Y) 6.5L V8 L57	P	•	•	•	•
(W) 1998 LD Trk, MPV, Incomplete	Powertrain	(X) 4.3L V6 LF6	Т	•	•	•	•
(W) 1998 LD Trk, MPV, Incomplete	Powertrain	(X) 4.3L V6 LF6	S	•	•	•	•
(W) 1998 LD Trk, MPV, Incomplete	Powertrain	(W) 4.3L V6 L35	Т	•	•	•	•
(W) 1998 LD Trk, MPV, Incomplete	Powertrain	(W) 4.3L V6 L35	S	•	•	•	•
(W) 1998 LD Trk, MPV, Incomplete	Powertrain	(W) 4.3L V6 L35	P	•	•	•	•
(W) 1998 LD Trk, MPV, Incomplete	Powertrain	(W) 4.3L V6 L35	M	•	•	•	•
(W) 1998 LD Trk, MPV, Incomplete	Powertrain	(W) 4.3L V6 L35	L	•	•	•	•
(W) 1998 LD Trk, MPV, Incomplete	Powertrain	(W) 4.3L V6 L35	K	•	•	•	•
(W) 1998 LD Trk, MPV, Incomplete	Powertrain	(W) 4.3L V6 L35	G	•	•	•	•
(W) 1998 LD Trk, MPV, Incomplete	Powertrain	(W) 4.3L V6 L35	С	•	•	•	•
(W) 1998 LD Trk, MPV, Incomplete	Powertrain	(S) 6.5L V8 L56	K	•	•	•	•
(W) 1998 LD Trk, MPV, Incomplete	Powertrain	(S) 6.5L V8 L56	С	•	•	•	•
(W) 1998 LD Trk, MPV, Incomplete	Powertrain	(R) 5.7L V8 L31 Bi-Fuel	Powertrain Control Module	•	•	•	•
(W) 1998 LD Trk, MPV, Incomplete	Powertrain	(R) 5.7L V8 L31	P	•	•	•	•
(W) 1998 LD Trk, MPV, Incomplete	Powertrain	(R) 5.7L V8 L31	K	•	•	•	•
(W) 1998 LD Trk, MPV, Incomplete	Powertrain	(R) 5.7L V8 L31	G	•	•	•	•
(W) 1998 LD Trk, MPV, Incomplete	Powertrain	(R) 5.7L V8 L31	C	•	•	•	•
(W) 1998 LD Trk, MPV, Incomplete	Powertrain	(M) 5. OL V8 L30	K	•	•	•	•
(W) 1998 LD Trk, MPV, Incomplete	Powertrain	(M) 5. OL V8 L30	G	•	•	•	•
(W) 1998 LD Trk, MPV, Incomplete	Powertrain	(M) 5. OL V8 L30	C	•	•	•	•
(W) 1998 LD Trk, MPV, Incomplete	Powertrain	(K) 5.7L V8 L05	Manual Transmission	•	•	•	•
(W) 1998 LD Trk, MPV, Incomplete	Powertrain	(K) 5.7L V8 L05	Automatic Transmission	•	•	•	•
(W) 1998 LD Trk, MPV, Incomplete	Powertrain	(J) 7.4L V8 L29	P 	•	•	•	•
(W) 1998 LD Trk, MPV, Incomplete	Powertrain	(J) 7.4L V8 L29	K	•	•	•	•
(W) 1998 LD Trk, MPV, Incomplete	Powertrain	(J) 7. 4L V8 L29	G	•	•	•	•
(W) 1998 LD Trk, MPV, Incomplete	Powertrain	(J) 7. 4L V8 L29		•	•	•	•
(W) 1998 LD Trk, MPV, Incomplete	Powertrain	(H) Electric Motor LN1	Powertrain Control Module		•	•	
(W) 1998 LD Trk, MPV, Incomplete		(F) 6.5L V8 L65	 	•	•	•	•
(W) 1998 LD Trk, MPV, Incomplete		(F) 6.5L V8 L65	K	•	•	•	
(W) 1998 LD Trk, MPV, Incomplete		(F) 6.5L V8 L65	<u></u>	•	•	•	•
(W) 1998 LD Trk, MPV, Incomplete		(F) 6.5L V8 L65		•	-	•	
(W) 1998 LD Trk, MPV, Incomplete		(E) 3. 4L V6 LA1	Powertrain Control Module	•	•	•	
(W) 1998 LD Trk, MPV, Incomplete		(B) 7. 4L V8 L21	Powertrain Control Module	•	•	•	
(W) 1998 LD Trk, MPV, Incomplete	Powertrain	(7) 4. 1L L6 LH9	Powertrain Control Module	•	•	•	
(W) 1998 LD Trk, MPV, Incomplete	Powertrain	(6) 1. 6L L4 L01	Manual	•	•	•	
(W) 1998 LD Trk, MPV, Incomplete		(6) 1. 6L L4 L01	4 Speed Automatic	•	•	•	_
(W) 1998 LD Trk, MPV, Incomplete		(6) 1. 6L L4 L01	3 Speed Automatic	•	•	•	
(W) 1998 LD Trk, MPV, Incomplete		(4) 2. 2L L4 LN2	S	•	•	•	
(W) 1998 LD Trk, MPV, Incomplete	Chassis	X	Electronic Brake Control Module				

Year	Menu1	Menu2	Menu3	Menu4		Erase Codes		ECU Info.
(W) 1998	LD Trk, MPV, Incomplete	Chassis	U	Electronic Brake Control Module	•	•	•	
(W) 1998	LD Trk, MPV, Incomplete	Chassis	T	4WAL 3 Sensor	•	•	•	
(W) 1998	LD Trk, MPV, Incomplete	Chassis	S	4WAL 3 Sensor	•	•	•	
	LD Trk, MPV, Incomplete		P	Electronic Variable Orifice	•	•	•	
(W) 1998	LD Trk, MPV, Incomplete	Chassis	P	4WAL 3 Sensor	•	•	•	
	LD Trk, MPV, Incomplete		M	Electronic Variable Orifice		•	•	
	LD Trk, MPV, Incomplete		M	4WAL 3 Sensor		•	•	
(W) 1998	LD Trk, MPV, Incomplete	Chassis	L	Electronic Variable Orifice		•	•	
	LD Trk, MPV, Incomplete		L	4WAL 3 Sensor		•		
	LD Trk, MPV, Incomplete		K	Electronic Variable Orifice		•		
	LD Trk, MPV, Incomplete		K	4WAL 3 Sensor		•		
	LD Trk, MPV, Incomplete		J	Electronic Brake Control Module		•		
	LD Trk, MPV, Incomplete		Н	Magna Steer		•		
	LD Trk, MPV, Incomplete		Н	Delco/Bosch ABS/TCS		•		
	LD Trk, MPV, Incomplete		G	Electronic Variable Orifice		•	•	
	LD Trk, MPV, Incomplete		G	4WAL 3 Sensor		•	•	
(W) 1998	LD Trk, MPV, Incomplete	Chassis	E	Gasoline		•	•	
	LD Trk, MPV, Incomplete		E	Electric		•	•	
	LD Trk, MPV, Incomplete		C	Under 15000 GVW		•		
	LD Trk, MPV, Incomplete		C	Equal to or Over 15000 GVW		•		
(W) 1998	LD Trk, MPV, Incomplete	Body	X	Supplemental Inflatable Restraint			•	
(W) 1998	LD Trk, MPV, Incomplete	Body	X	OnStar		•	•	
(W) 1998	LD Trk, MPV, Incomplete	Body	U	Supplemental Inflatable Restraint	•	•	•	
(W) 1998	LD Trk, MPV, Incomplete	Body	U	OnStar		•	•	
(W) 1998	LD Trk, MPV, Incomplete	Body	T	ZN4	•	•	•	
(W) 1998	LD Trk, MPV, Incomplete	Body	T	Utility	•	•	•	
(W) 1998	LD Trk, MPV, Incomplete	Body	T	Pick Up	•	•	•	
(W) 1998	LD Trk, MPV, Incomplete	Body	T	Envoy	•	•	•	
(W) 1998	LD Trk, MPV, Incomplete	Body	S	ZN4	•	•	•	
(W) 1998	LD Trk, MPV, Incomplete	Body	S	Utility	•	•	•	
(W) 1998	LD Trk, MPV, Incomplete	Body	S	Pick Up	•	•	•	
(W) 1998	LD Trk, MPV, Incomplete	Body	S	Envoy	•	•	•	
(W) 1998	LD Trk, MPV, Incomplete	Body	M	Supplemental Inflatable Restraint	•	•	•	
(W) 1998	LD Trk, MPV, Incomplete	Body	M	Passlock	•	•	•	
(W) 1998	LD Trk, MPV, Incomplete	Body	L	Supplemental Inflatable Restraint	•	•	•	
	LD Trk, MPV, Incomplete		L	Passlock	•	•	•	
	LD Trk, MPV, Incomplete		K	Supplemental Inflatable Restraint	•	•	•	
	LD Trk, MPV, Incomplete		K	Passlock	•	•	•	
	LD Trk, MPV, Incomplete		K	OnStar	•	•	•	
	LD Trk, MPV, Incomplete		J	Supplemental Inflatable Restraint	•	•	•	•
	LD Trk, MPV, Incomplete		Н	Radio	•	•	•	•
	LD Trk, MPV, Incomplete		G	Supplemental Inflatable Restraint	•	•	•	•
	LD Trk, MPV, Incomplete		G	Passlock	•	•	•	•
	LD Trk, MPV, Incomplete		G	Immobilizer	•	•	•	•
	LD Trk, MPV, Incomplete		E	Gasoline	•	•	•	

Year M	lenu1	Menu2	Menu3	Menu4	Read E		Live Data	ECU Info.
(W) 1998 L	D Trk, MPV, Incomplete	Body	E	Electric	•	•	•	•
(W) 1998 L	D Trk, MPV, Incomplete	Body	C	Supplemental Inflatable Restraint	•	•		
(W) 1998 L	D Trk, MPV, Incomplete	Body	C	Passlock				
(W) 1998 L	D Trk, MPV, Incomplete	Body	C	OnStar				
(V) 1997 S	Saturn	Powertrain	(8) 1.9L L4 L24	Powertrain Control Module		•	•	
(V) 1997 S	Saturn	Powertrain	(7) 1.9L L4 LL0	Powertrain Control Module				
(V) 1997 S	Saturn	Chassis	Electronic Brake Control Module					
(V) 1997 S	Saturn	Body	Supplemental Inflatable Restraint					
(V) 1997 P	Passenger Car	Powertrain	(Y) 4.6L V8 LD8	Powertrain Control Module				
(V) 1997 P	Passenger Car	Powertrain	(X) 3.4L V6 LQ1	Powertrain Control Module				
(V) 1997 P	Passenger Car	Powertrain	(T) 2.4L L4 LD9	N				
(V) 1997 P	Passenger Car	Powertrain	(T) 2.4L L4 LD9	J				•
(V) 1997 P	Passenger Car	Powertrain	(R) 3. 0L V6 L81	Powertrain Control Module	•	•	•	•
(V) 1997 P	Passenger Car	Powertrain	(P) 5.7L V8 LT1	F	•	•	•	•
(V) 1997 P	Passenger Car	Powertrain	(M) 3.1L V6 L82	W	•	•	•	
		Powertrain	(M) 3.1L V6 L82	N	•	•	•	•
		Powertrain	(K) 3.8L V6 L36	W	•	•	•	•
		Powertrain	(K) 3.8L V6 L36	Н	•	•	•	•
	Passenger Car	Powertrain	(K) 3.8L V6 L36	G	•	•	•	•
	Passenger Car	Powertrain	(K) 3.8L V6 L36	F	•	•	•	•
		Powertrain	(K) 3.8L V6 L36	C		•		
		Powertrain	(G) 5.7L V8 LS1	Y		•	•	
	Passenger Car	Powertrain	(C) 4. OL V8 L47	Powertrain Control Module		•		
	Passenger Car	Powertrain	(9) 4. 6L V8 L37	Powertrain Control Module		•		
	Passenger Car	Powertrain	(9) 1. 3L L4 L72	(5) Four-Door Sedan		•	•	•
	Passenger Car	Powertrain	(9) 1. 3L L4 L72	(2) Two-Door Hatchback/Liftback		•	•	•
	Passenger Car	Powertrain	(8) 1. 8L L4 LV6	Manual		•	•	•
	Passenger Car	Powertrain	(8) 1. 8L L4 LV6	4 Speed Automatic	•	•	•	•
	Passenger Car	Powertrain	(6) 1. 6L L4 L01	Manual	•	•	•	•
		Powertrain	(6) 1. 6L L4 L01	3 Speed Automatic	•	•	•	•
		Powertrain	(6) 1. 0L L3 LP2	Powertrain Control Module	•	•	•	•
		Powertrain	(5) Electric Motor LN1	Powertrain Control Module		•	•	•
		Powertrain	(4) 2. 2L L4 LN2	T	•	•		•
		Powertrain	(1) 3. 8L V6 L67	W		•	•	•
		Powertrain	(1) 3. 8L V6 L67	Н	•	•	•	•
		Powertrain	(1) 3. 8L V6 L67	G		•	•	•
		Powertrain	(1) 3. 8L V6 L67	C		•	•	•
		Chassis	γ	CVRTD		•	•	
		Chassis	Y	ABS/TCS/Magna Steer	•	•	•	
		Chassis	W	Electronic Brake Control Module	•	•	•	•
		Chassis	V	Variable Effort Steering				•
		Chassis	V	ABS				•
		Chassis	ς	Electronic Brake Control Module				•
		Chassis	D	BTCM				
		Chassis	r N	Electronic Brake Control Module				
(v) 1991 P	assenger Car	Ullass15	IV	Triectionic prake control module	_			

Year	Menu1	Menu2	Menu3	Menu4		Erase Codes		ECU Info.
(V) 1997	Passenger Car	Chassis	M	Electronic Brake Control Module	•	•	•	
(V) 1997	Passenger Car	Chassis	K	ABS		•		
(V) 1997	Passenger Car	Chassis	Ј	Electronic Brake Control Module		•		
(V) 1997	Passenger Car	Chassis	Н	Delco/Bosch ABS		•		
(V) 1997	Passenger Car	Chassis	F	Electronic Brake Control Module		•		
(V) 1997	Passenger Car	Chassis	E	Magna Steer		•		
(V) 1997	Passenger Car	Chassis	C	ABS		•		
(V) 1997	Passenger Car	Body	Z	Supplemental Inflatable Restraint		•		
(V) 1997	Passenger Car	Body	Y	Supplemental Inflatable Restraint				
(V) 1997	Passenger Car	Body	Y	Seat Control Module				
(V) 1997	Passenger Car	Body	Y	Right Door Control Module	•	•	•	
(V) 1997	Passenger Car	Body	Y	Remote Function Actuation	•	•		
(V) 1997	Passenger Car	Body	Y	Radio	•	•		
(V) 1997	Passenger Car	Body	Υ	Left Door Control Module		•		
	Passenger Car	Body	Y	Instrument Panel Cluster	•	•	•	•
(V) 1997	Passenger Car	Body	У	Heating and Air Conditioning	•	•	•	•
	Passenger Car	Body	Y	Body Control Module		•	•	
	Passenger Car	Body	W	(4) Buick				
	Passenger Car	Body	W	(3) Oldsmobile	•		•	
	Passenger Car	Body	W	(2) Pontiac			•	
	Passenger Car	Body	W	(1) Chevrolet		•	•	
	Passenger Car	Body	V	Supplemental Inflatable Restraint	•	•	•	
	Passenger Car	Body	V	Remote Function Actuator		•	•	
	Passenger Car	Body	V	Radio		•	•	
	Passenger Car	Body	V	Power Roof				
	Passenger Car	Body	V	Memory Seat Module				
	Passenger Car	Body	V	Leveling Sensor				
	Passenger Car	Body	V	Instrument Panel Cluster				
	Passenger Car	Body	V	Immobilizer				
	Passenger Car	Body	77	Heating And Air Conditioning				
	Passenger Car	Body	77	Cruise Control				
		Body	V	Cellular Telephone				
	Passenger Car		V	Body Control Module				
	Passenger Car	Body	V D					
	Passenger Car	Body	P D	Supplemental Inflatable Restraint	•	•		•
	Passenger Car	Body	P D	RSA	•	•	•	
	Passenger Car	Body	P D	IPC	•	•	•	•
	Passenger Car	Body	IP	HTCM	•	•	•	•
	Passenger Car	Body	N	(4) Buick	•	•	•	•
	Passenger Car	Body	N N	(3) Oldsmobile	•	•	•	•
	Passenger Car	Body	N	(2) Pontiac	•	•	•	•
	Passenger Car	Body	N	(1) Chevrolet	•	•	•	•
	Passenger Car	Body	M	Supplemental Inflatable Restraint	•	•	•	
	Passenger Car	Body	K	Supplemental Inflatable Restraint	•	•	•	•
	Passenger Car	Body	K	Remote Function Actuation	•	•	•	•
(V) 1997	Passenger Car	Body	K	Radio				

Year	Menu1	Menu2	Menu3	Menu4	Read E		Live Data	ECU Info.
	Passenger Car	Body	K	Memory Seat Module	•	•	•	•
	Passenger Car	Body	K	Memory Mirror Module	•	•	•	
	Passenger Car	Body	K	Instrument Panel Cluster	•	•	•	•
(V) 1997	Passenger Car	Body	K	Heating and Air Conditioning				•
	Passenger Car	Body	K	Climate Control Panel	•	•	•	•
(V) 1997	Passenger Car	Body	K	Cellular Telephone				•
	Passenger Car	Body	K	Body Control Module				
(V) 1997	Passenger Car	Body	J	(2) Pontiac			•	
(V) 1997	Passenger Car	Body	J	(1) Chevrolet				•
(V) 1997	Passenger Car	Body	Н	(4) Buick				•
(V) 1997	Passenger Car	Body	Н	(3) Oldsmobile			•	•
(V) 1997	Passenger Car	Body	Н	(2) Pontiac			•	•
(V) 1997	Passenger Car	Body	G	(4) Buick		•	•	•
	Passenger Car	Body	G	(3) Oldsmobile	•	•	•	•
(V) 1997	Passenger Car	Body	F	(2) Pontiac	•	•	•	•
	Passenger Car	Body	F	(1) Chevrolet	•	•	•	•
	Passenger Car	Body	Е	Supplemental Inflatable Restraint		•	•	•
	Passenger Car	Body	Е	Remote Function Actuation		•	•	•
	Passenger Car	Body	E	Radio		•	•	
	Passenger Car	Body	E	Memory Seat Module			•	
	Passenger Car	Body	E	Memory Mirror Module			•	
	Passenger Car	Body	F.	Instrument Panel Cluster		•	•	•
	Passenger Car	Body	F.	Heating and Air Conditioning		•	•	•
	Passenger Car	Body	F	Climate Control Panel		•	•	
	Passenger Car	Body	E	Cellular Telephone				•
	Passenger Car	Body	E	Body Control Module		•		•
	Passenger Car	Body	C	Vehicle Theft Deterrent			•	•
	Passenger Car	Body	C	Supplemental Inflatable Restraint		•	-	•
	Passenger Car	Body	C	Remote Function Actuation			•	•
	Passenger Car	Body	C	Memory Seat Module				
	Passenger Car	Body	C	Instrument Panel Cluster				
	Passenger Car	Body	C	Heating and Air Conditioning				
	Passenger Car	Body	C	Driver Door Module				
	Passenger Car	Body	6	Cellular Telephone				
		Body				•	•	
	Passenger Car		(7) C. F.L. VO. I.C.F.	Body Control Module	•			
	Medium Duty Truck	Powertrain	(Z) 6.5L V8 L65	Powertrain Control Module	•	•	•	•
	Medium Duty Truck	Powertrain	(Y) 6.5L V8 L57	Powertrain Control Module		•	•	•
	Medium Duty Truck	Powertrain	(P) 6. 0L V8 LS0	Powertrain Control Module		•	•	•
	Medium Duty Truck	Powertrain	(M) 7. OL V8 LRO	Powertrain Control Module	•	•	•	•
	Medium Duty Truck	Powertrain	(F) 6.5L V8 L65	Manual Transmission	•	•	•	•
	Medium Duty Truck	Powertrain	(F) 6.5L V8 L65	Automatic Transmission	•	•	•	•
	Medium Duty Truck	Powertrain	(A) 5.7L V8 L31	Federal Emissions	•	•	•	•
	Medium Duty Truck	Powertrain	(A) 5.7L V8 L31	California Emissions	•	•	•	•
	Medium Duty Truck	Chassis	T - B7 Chassis	Hydraulic 4WAL 4 Sensor		•	•	•
(V) 1997	Medium Duty Truck	Chassis	D - C Series	Hydraulic 4WAL 4 Sensor				

Year Menul	Menu2	Menu3	Menu4	Read Er	rase L odes D		ECU Info.
(V) 1997 Medium Duty Truck	Chassis	C - T Series	Hydraulic 4WAL 4 Sensor		•	•	
(V) 1997 LD Trk, MPV, Incomplete		(Y) 6.5L V8 L57	Powertrain Control Module	•	•	•	•
(V) 1997 LD Trk, MPV, Incomplete	Powertrain	(X) 4.3L V6 LF6	T	•	•	•	•
(V) 1997 LD Trk, MPV, Incomplete		(X) 4.3L V6 LF6	S	•	•	•	
(V) 1997 LD Trk, MPV, Incomplete		(W) 4.3L V6 L35	Т	•	•	•	
(V) 1997 LD Trk, MPV, Incomplete		(W) 4.3L V6 L35	S	•	•	•	
(V) 1997 LD Trk, MPV, Incomplete		(W) 4.3L V6 L35	Р		•		
(V) 1997 LD Trk, MPV, Incomplete		(W) 4.3L V6 L35	M		•		
(V) 1997 LD Trk, MPV, Incomplete		(W) 4.3L V6 L35	L		•		
(V) 1997 LD Trk, MPV, Incomplete	Powertrain	(W) 4.3L V6 L35	K		•		
(V) 1997 LD Trk, MPV, Incomplete	Powertrain	(W) 4.3L V6 L35	G		•		
(V) 1997 LD Trk, MPV, Incomplete	Powertrain	(W) 4.3L V6 L35	C		•		
(V) 1997 LD Trk, MPV, Incomplete	Powertrain	(S) 6.5L V8 L56	K		•	•	
(V) 1997 LD Trk, MPV, Incomplete	Powertrain	(S) 6.5L V8 L56	C	•	•	•	•
(V) 1997 LD Trk, MPV, Incomplete		(R) 5.7L V8 L31 Bi-Fuel	Powertrain Control Module	•	•	•	
(V) 1997 LD Trk, MPV, Incomplete		(R) 5.7L V8 L31	Р	•	•	•	•
(V) 1997 LD Trk, MPV, Incomplete		(R) 5.7L V8 L31	K	•	•	•	•
(V) 1997 LD Trk, MPV, Incomplete		(R) 5.7L V8 L31	G	•	•	•	•
(V) 1997 LD Trk, MPV, Incomplete		(R) 5.7L V8 L31	С	•	•	•	•
(V) 1997 LD Trk, MPV, Incomplete		(N) 7. 4L V8 L19	P	•	•	•	•
(V) 1997 LD Trk, MPV, Incomplete		(M) 5. OL V8 L30	K		•		•
(V) 1997 LD Trk, MPV, Incomplete		(M) 5. OL V8 L30	G		•		•
(V) 1997 LD Trk, MPV, Incomplete		(M) 5. OL V8 L30	C		•	•	•
(V) 1997 LD Trk, MPV, Incomplete		(J) 7.4L V8 L29	P		•	•	
(V) 1997 LD Trk, MPV, Incomplete		(J) 7. 4L V8 L29	K		•		•
(V) 1997 LD Trk, MPV, Incomplete		(J) 7. 4L V8 L29	G		•		•
(V) 1997 LD Trk, MPV, Incomplete		(J) 7. 4L V8 L29	C		•		•
(V) 1997 LD Trk, MPV, Incomplete		(H) Electric Motor LN1	Powertrain Control Module		•		•
(V) 1997 LD Trk, MPV, Incomplete		(F) 6.5L V8 L65	P		•		•
(V) 1997 LD Trk, MPV, Incomplete		(F) 6.5L V8 L65	K		•		•
(V) 1997 LD Trk, MPV, Incomplete		(F) 6.5L V8 L65	C		•	•	•
(V) 1997 LD Trk, MPV, Incomplete		(F) 6.5L V8 L65	C		•	•	•
(V) 1997 LD Trk, MPV, Incomplete		(E) 3. 4L V6 LA1	Powertrain Control Module		•	•	
(V) 1997 LD Trk, MPV, Incomplete		(6) 1. 6L L4 L01	Manual		•	•	
(V) 1997 LD Trk, MPV, Incomplete		(6) 1.6L L4 L01	4 Speed Automatic		•	•	
(V) 1997 LD Trk, MPV, Incomplete		(6) 1.6L L4 L01	3 Speed Automatic				
(V) 1997 LD Trk, MPV, Incomplete		(4) 2. 2L L4 LN2	c speed nutomatic				
(V) 1997 LD Trk, MPV, Incomplete		V L. CL LT LNC	Electronic Brake Control Module				
(V) 1997 LD Trk, MPV, Incomplete (V) 1997 LD Trk, MPV, Incomplete		Λ II	Electronic Brake Control Module				
		U ጥ	4WAL 3 Sensor				
(V) 1997 LD Trk, MPV, Incomplete		<u>r</u>		1			
(V) 1997 LD Trk, MPV, Incomplete		<u>5</u>	4WAL 3 Sensor		•	•	
(V) 1997 LD Trk, MPV, Incomplete		P D	Electronic Variable Orifice		•	•	•
(V) 1997 LD Trk, MPV, Incomplete		<u>r</u>	4WAL 3 Sensor		•	•	•
(V) 1997 LD Trk, MPV, Incomplete		M	Electronic Variable Orifice		•	•	•
(V) 1997 LD Trk, MPV, Incomplete	Unassis	M	4WAL 3 Sensor	•	•		

Year Menu1	Menu2	Menu3	Menu4	Read Erase codes Codes		ECU Info.
(V) 1997 LD Trk, MPV, Incomplete	Chassis	L	Electronic Variable Orifice	• •	•	•
(V) 1997 LD Trk, MPV, Incomplete	Chassis	L	4WAL 3 Sensor	• •	•	•
(V) 1997 LD Trk, MPV, Incomplete	Chassis	K	Electronic Variable Orifice	• •	•	•
(V) 1997 LD Trk, MPV, Incomplete		K	4WAL 3 Sensor	• •	•	•
(V) 1997 LD Trk, MPV, Incomplete		J	Electronic Brake Control Module	• •	•	•
(V) 1997 LD Trk, MPV, Incomplete		Н	Magna Steer	• •	•	
(V) 1997 LD Trk, MPV, Incomplete		Н	Delco/Bosch ABS/TCS	• •	•	
(V) 1997 LD Trk, MPV, Incomplete		G	Electronic Variable Orifice	• •		
(V) 1997 LD Trk, MPV, Incomplete		G	4WAL 3 Sensor	• •	•	•
(V) 1997 LD Trk, MPV, Incomplete		E	Gasoline	• •	•	•
(V) 1997 LD Trk, MPV, Incomplete		E	Electric	• •	•	•
(V) 1997 LD Trk, MPV, Incomplete		C	Electronic Variable Orifice	• •	•	•
(V) 1997 LD Trk, MPV, Incomplete		C	4WAL 3 Sensor	• •	•	•
(V) 1997 LD Trk, MPV, Incomplete		X	Supplemental Inflatable Restraint	• •	•	•
(V) 1997 LD Trk, MPV, Incomplete		U	Supplemental Inflatable Restraint	• •	•	•
(V) 1997 LD Trk, MPV, Incomplete		Т	Supplemental Inflatable Restraint	• •	•	•
(V) 1997 LD Trk, MPV, Incomplete		S	Supplemental Inflatable Restraint	• •	•	•
(V) 1997 LD Trk, MPV, Incomplete		M	Supplemental Inflatable Restraint	• •	•	•
(V) 1997 LD Trk, MPV, Incomplete		L	Supplemental Inflatable Restraint	• •	•	•
(V) 1997 LD Trk, MPV, Incomplete		K	Supplemental Inflatable Restraint	• •	•	•
(V) 1997 LD Trk, MPV, Incomplete		J	Supplemental Inflatable Restraint	• •	•	•
(V) 1997 LD Trk, MPV, Incomplete		Н	Supplemental Inflatable Restraint	• •	•	•
(V) 1997 LD Trk, MPV, Incomplete		Н	Remote Function Actuation	• •	•	•
(V) 1997 LD Trk, MPV, Incomplete		Н	Radio	• •	•	•
(V) 1997 LD Trk, MPV, Incomplete		Н	Memory Seat Module	• •	•	•
(V) 1997 LD Trk, MPV, Incomplete		Н	Memory Mirror Module	• •	•	•
(V) 1997 LD Trk, MPV, Incomplete		Н	Instrument Panel Cluster	• •	•	•
(V) 1997 LD Trk, MPV, Incomplete		Н	Heating and Air Conditioning	• •	•	•
(V) 1997 LD Trk, MPV, Incomplete		H	Climate Control Panel	• •	•	•
(V) 1997 LD Trk, MPV, Incomplete		Н	Cellular Telephone	• •	•	•
(V) 1997 LD Trk, MPV, Incomplete		H	Body Control Module	• •	•	•
(V) 1997 LD Trk, MPV, Incomplete		G	Supplemental Inflatable Restraint	• •	•	•
(V) 1997 LD Trk, MPV, Incomplete		E .	Gasoline	• •	•	•
(V) 1997 LD Trk, MPV, Incomplete	Body	E .	Electric	• •	•	•
(V) 1997 LD Trk, MPV, Incomplete		(0) 1 01 14 104	Supplemental Inflatable Restraint	• •	•	•
(T) 1996 Saturn	Powertrain	(8) 1. 9L L4 L24	Powertrain Control Module	• •	•	•
(T) 1996 Saturn	Powertrain	(7) 1.9L L4 LL0	Powertrain Control Module	• •	•	•
(T) 1996 Saturn	Chassis	Electronic Brake Control Module		• •	•	•
(T) 1996 Saturn	Body	Supplemental Inflatable Restraint		• •	•	•
(T) 1996 Passenger Car	Powertrain	(Y) 4.6L V8 LD8	Powertrain Control Module	• •	•	•
(T) 1996 Passenger Car	Powertrain	(X) 3. 4L V6 LQ1	Powertrain Control Module	• •	•	•
(T) 1996 Passenger Car	Powertrain	(W) 4.3L V8 L99	В	• •	•	•
(T) 1996 Passenger Car	Powertrain	(T) 2.4L L4 LD9	N	• •	•	•
(T) 1996 Passenger Car	Powertrain	(T) 2. 4L L4 LD9	<u> </u>	• •	•	•
(T) 1996 Passenger Car	Powertrain	(P) 5.7L V8 LT1	<u>I</u> Y			

Year	Menu1	Menu2	Menu3	Menu4	Read :		Live Data	ECU Info.
	Passenger Car	Powertrain	(P) 5.7L V8 LT1	F	•	•	•	•
	Passenger Car	Powertrain	(P) 5.7L V8 LT1	D	•	•	•	•
	Passenger Car	Powertrain	(P) 5.7L V8 LT1	В	•	•	•	•
	Passenger Car	Powertrain	(M) 3.1L V6 L82	W	•	•	•	•
	Passenger Car	Powertrain	(M) 3.1L V6 L82	N	•	•	•	•
	Passenger Car	Powertrain	(M) 3.1L V6 L82	L	•	•	•	•
	Passenger Car	Powertrain	(M) 3.1L V6 L82	A	•	•	•	•
	Passenger Car	Powertrain	(K) 3.8L V6 L36	W	•	•	•	•
(T) 1996	Passenger Car	Powertrain	(K) 3.8L V6 L36	Н			•	
(T) 1996	Passenger Car	Powertrain	(K) 3.8L V6 L36	G			•	
(T) 1996	Passenger Car	Powertrain	(K) 3.8L V6 L36	F				•
(T) 1996	Passenger Car	Powertrain	(K) 3.8L V6 L36	C			•	•
(T) 1996	Passenger Car	Powertrain	(C) 4. 0L V8 L47	Powertrain Control Module		•	•	•
(T) 1996	Passenger Car	Powertrain	(9) 4.6L V8 L37	Powertrain Control Module	•	•	•	
(T) 1996	Passenger Car	Powertrain	(9) 1.3L L4 L72	(5) Four-Door Sedan	•	•	•	•
	Passenger Car	Powertrain	(9) 1. 3L L4 L72	(2) Two-Door Hatchback/Liftback	•	•	•	•
	Passenger Car	Powertrain	(8) 1.8L L4 LV6	Manual		•	•	•
	Passenger Car	Powertrain	(8) 1. 8L L4 LV6	4 Speed Automatic			•	
	Passenger Car	Powertrain	(6) 1. 6L L4 L01	Manual			•	
	Passenger Car	Powertrain		3 Speed Automatic			•	
	Passenger Car	Powertrain	(6) 1. 0L L3 LP2	Powertrain Control Module		•	•	•
	Passenger Car	Powertrain	(5) 5. 7L V8 LT4	V		•	•	•
	Passenger Car	Powertrain	(4) 2. 2L L4 LN2	I		•	•	
	Passenger Car	Powertrain	(4) 2. 2L L4 LN2	T		•	•	
	Passenger Car	Powertrain	(4) 2. 2L L4 LN2	Δ			•	•
	Passenger Car	Powertrain	(1) 3. 8L V6 L67	и				
	Passenger Car	Powertrain	(1) 3.8L V6 L67	11 C				
	Passenger Car	Powertrain	(1) 3. 8L V6 L67	C				
	Passenger Car	Chassis	` '	RTD				
			V	ABS/TCS				
	Passenger Car	Chassis	T W	,				
	Passenger Car	Chassis	W C	Electronic Brake Control Module	•		•	•
	Passenger Car	Chassis		Electronic Brake Control Module	•	•	•	•
	Passenger Car	Chassis		Electronic Brake Control Module	•	•	•	•
	Passenger Car	Chassis		Electronic Brake Control Module	•	•	•	•
		Chassis		Electronic Brake Control Module	•	•	•	
	Passenger Car	Chassis		ABS/TCS	•	•	•	•
	Passenger Car	Chassis		Electronic Brake Control Module	•	•	•	•
	Passenger Car	Chassis		Delco/Bosch ABS	•	•	•	•
	Passenger Car	Chassis		Electronic Brake Control Module	•	•	•	•
	Passenger Car	Chassis	E	CVRSS/ALC	•	•	•	•
	Passenger Car	Chassis	Е	ABS/TCS	•	•	•	•
	Passenger Car	Chassis	D	VES	•	•	•	•
	Passenger Car	Chassis		ABS/TCS	•	•	•	•
	Passenger Car	Chassis		Delco/Bosch ABS	•	•	•	•
(T) 1996	Passenger Car	Chassis	В	ABS				

Year	Menu1	Menu2	Menu3	Menu4		Erase Codes		ECU Info.
(T) 1996	Passenger Car	Chassis	A	Electronic Brake Control Module	•	•	•	
(T) 1996	Passenger Car	Body	Y	Supplemental Inflatable Restraint		•		
(T) 1996	Passenger Car	Body	Y	Central Control Module		•		
(T) 1996	Passenger Car	Body	W	(4) Buick		•		
(T) 1996	Passenger Car	Body	W	(3) Oldsmobile		•		
(T) 1996	Passenger Car	Body	W	(2) Pontiac		•		
(T) 1996	Passenger Car	Body	W	(1) Chevrolet		•		
(T) 1996	Passenger Car	Body	N	(4) Buick		•		
(T) 1996	Passenger Car	Body	N	(3) Oldsmobile		•		
(T) 1996	Passenger Car	Body	N	(2) Pontiac			•	
(T) 1996	Passenger Car	Body	M	Supplemental Inflatable Restraint			•	
(T) 1996	Passenger Car	Body	L	Supplemental Inflatable Restraint	•	•	•	
(T) 1996	Passenger Car	Body	K	Supplemental Inflatable Restraint	•	•	•	
(T) 1996	Passenger Car	Body	K	Remote Function Actuation		•	•	
(T) 1996	Passenger Car	Body	K	Radio		•	•	•
(T) 1996	Passenger Car	Body	K	Memory Seat Module	•	•	•	•
	Passenger Car	Body	K	Instrument Panel Cluster	•	•	•	
	Passenger Car	Body	K	Heating and Air Conditioning		•	•	
	Passenger Car	Body	K	Climate Control Panel			•	
	Passenger Car	Body	K	Cellular Telephone			•	
	Passenger Car	Body	K	Body Control Module		•	•	
	Passenger Car	Body	Ţ	(2) Pontiac	•	•	•	
	Passenger Car	Body	I	(1) Chevrolet		•	•	
	Passenger Car	Body	Н	(4) Buick		•		
	Passenger Car	Body	Н	(3) Oldsmobile				
	Passenger Car	Body	П	(2) Pontiac		•	•	
	Passenger Car	Body	C	(4) Buick			•	
	Passenger Car	Body	C	(3) Oldsmobile			•	
	Passenger Car	Body	E C	(2) Pontiac				
	Passenger Car	Body	Γ	(1) Chevrolet				
	Passenger Car	Body		Supplemental Inflatable Restraint				
	Passenger Car	Body	<u>г</u>	Remote Function Actuation				
	Passenger Car	Body	<u>г</u>	Radio				
	Passenger Car	Body	E F			•		
		Body	E E	Memory Seat Module		•		
	Passenger Car		E	Instrument Panel Cluster	•			
	Passenger Car	Body	E	Heating and Air Conditioning	•	•	•	•
	Passenger Car	Body	E D	Climate Control Panel	•	•	•	•
	Passenger Car	Body	E D	Cellular Telephone	•	•	•	•
	Passenger Car	Body	E D	Body Control Module	•	•	•	•
	Passenger Car	Body	ען	Supplemental Inflatable Restraint	•	•	•	•
	Passenger Car	Body	D	Heating and Air Conditioning	•	•	•	•
	Passenger Car	Body	D .	Central Control Module	•	•	•	•
	Passenger Car	Body	C	(4) Buick	•	•	•	•
	Passenger Car	Body	C	(3) Oldsmobile	•	•	•	
(T) 1996	Passenger Car	Body	В	(4) Buick				

Year Menu1	Menu2	Menu3	Menu4	Read I			CU fo.
(T) 1996 Passenger Car	Body	В	(1) Chevrolet				•
(T) 1996 Passenger Car	Body	Ā	Supplemental Inflatable Restraint	•	•	•	•
(T) 1996 Medium Duty Truck	Powertrain	(Z) 6.5L V8 L65	Powertrain Control Module	•	•	•	•
(T) 1996 Medium Duty Truck	Powertrain	(Y) 6.5L V8 L57	Powertrain Control Module	•	•	•	•
(T) 1996 Medium Duty Truck	Powertrain	(P) 6.0L V8 LS0	Powertrain Control Module	•	•	•	
(T) 1996 Medium Duty Truck	Powertrain	(M) 7.0L V8 LRO	Powertrain Control Module	•	•	•	
(T) 1996 Medium Duty Truck	Powertrain	(D) 5.7L V8 L05	Powertrain Control Module	•	•	•	
(T) 1996 Medium Duty Truck	Powertrain	(A) 5.7L V8 L31	Federal Emissions	•	•	• •	
(T) 1996 Medium Duty Truck	Powertrain	(A) 5.7L V8 L31	California Emissions	•	•	• •	
(T) 1996 LD Trk, MPV, Incomp		(Z) 4.3L V6 LB4	G	•	•		
(T) 1996 LD Trk, MPV, Incomp		(Y) 6.5L V8 L57	Powertrain Control Module	•	•	• •	
(T) 1996 LD Trk, MPV, Incomp		(X) 4.3L V6 LF6	T	•	•	• •	•
(T) 1996 LD Trk, MPV, Incomp		(X) 4.3L V6 LF6	S	•	•	• •	•
(T) 1996 LD Trk, MPV, Incomp		(W) 4.3L V6 L35	Т	•	•	• •	•
(T) 1996 LD Trk, MPV, Incomp		(W) 4.3L V6 L35	S	•		• •	•
(T) 1996 LD Trk, MPV, Incomp		(W) 4.3L V6 L35	Р	•	•	• •	•
(T) 1996 LD Trk, MPV, Incomp		(W) 4.3L V6 L35	M	•	•	• •	•
(T) 1996 LD Trk, MPV, Incomp		(W) 4.3L V6 L35	L	•		• •	•
(T) 1996 LD Trk, MPV, Incomp		(W) 4.3L V6 L35	K	•			•
(T) 1996 LD Trk, MPV, Incomp		(W) 4.3L V6 L35	G	•	•	• •	•
(T) 1996 LD Trk, MPV, Incomp		(W) 4.3L V6 L35	С	•			•
(T) 1996 LD Trk, MPV, Incomp		(S) 6.5L V8 L56	K	•			•
(T) 1996 LD Trk, MPV, Incomp		(S) 6.5L V8 L56	С	•			•
(T) 1996 LD Trk, MPV, Incomp		(R) 5.7L V8 L31	Р	•			
(T) 1996 LD Trk, MPV, Incomp		(R) 5.7L V8 L31	K	•			
(T) 1996 LD Trk, MPV, Incomp		(R) 5.7L V8 L31	G	•			•
(T) 1996 LD Trk, MPV, Incomp		(R) 5.7L V8 L31	C	•			•
(T) 1996 LD Trk, MPV, Incomp		(N) 7.4L V8 L19	Р	•			•
(T) 1996 LD Trk, MPV, Incomp		(N) 7.4L V8 L19	Н	•			•
(T) 1996 LD Trk, MPV, Incomp		(N) 7.4L V8 L19	G	•			•
(T) 1996 LD Trk, MPV, Incomp		(M) 5. OL V8 L30	K	•			•
(T) 1996 LD Trk, MPV, Incomp		(M) 5. OL V8 L30	G	•			•
(T) 1996 LD Trk, MPV, Incomp		(M) 5. OL V8 L30	C	•			•
(T) 1996 LD Trk, MPV, Incomp	olete Powertrain	(K) 5.7L V8 L05	H	•			•
(T) 1996 LD Trk, MPV, Incomp		(K) 5.7L V8 L05	G	•			•
(T) 1996 LD Trk, MPV, Incomp	olete Powertrain	(J) 7. 4L V8 L29	P	•			•
(T) 1996 LD Trk, MPV, Incomp	olete Powertrain	(J) 7. 4L V8 L29	K	•			•
(T) 1996 LD Trk, MPV, Incomp		(J) 7. 4L V8 L29	G	•			•
(T) 1996 LD Trk, MPV, Incomp		(J) 7. 4L V8 L29	C	•			•
(T) 1996 LD Trk, MPV, Incomp		(F) 6.5L V8 L65	P	•			•
(T) 1996 LD Trk, MPV, Incomp		(F) 6.5L V8 L65	K	•			•
(T) 1996 LD Trk, MPV, Incomp		(F) 6.5L V8 L65	G	•			•
(T) 1996 LD Trk, MPV, Incomp		(F) 6.5L V8 L65	C	•			•
(T) 1996 LD Trk, MPV, Incomp		(E) 3. 4L V6 LA1	Powertrain Control Module	•			•
(T) 1996 LD Trk, MPV, Incomp	olete Powertrain	(6) 1.6L L4 L01	(8) Two Door Utility		•		

Year	Menu1	Menu2	Menu3	Menu4		Erase Codes		ECU Info.
(T) 1996	LD Trk, MPV, Incomplete	Powertrain	(6) 1.6L L4 L01	(3) Four Door Cab		•	•	
(T) 1996	LD Trk, MPV, Incomplete	Powertrain	(4) 2.2L L4 LN2	S	•			
(T) 1996	LD Trk, MPV, Incomplete	Chassis	U	Electronic Brake Control Module	•			
(T) 1996	LD Trk, MPV, Incomplete	Chassis	T	VCM OBD2 4WAL	•			
(T) 1996	LD Trk, MPV, Incomplete	Chassis	T	VCM 4WAL	•			
(T) 1996	LD Trk, MPV, Incomplete	Chassis	S	VCM OBD2 4WAL	•			
(T) 1996	LD Trk, MPV, Incomplete	Chassis	S	VCM 4WAL	•			
(T) 1996	LD Trk, MPV, Incomplete	Chassis	S	4WAL 3 Sensor	•	•	•	
(T) 1996	LD Trk, MPV, Incomplete	Chassis	M	4WAL 3 Sensor	•	•	•	
(T) 1996	LD Trk, MPV, Incomplete	Chassis	L	4WAL 3 Sensor	•	•	•	
(T) 1996	LD Trk, MPV, Incomplete	Chassis	K	4WAL 3 Sensor	•			
(T) 1996	LD Trk, MPV, Incomplete	Chassis	Ј	Electronic Brake Control Module	•			
(T) 1996	LD Trk, MPV, Incomplete	Chassis	G	4WAL 3 Sensor	•			
(T) 1996	LD Trk, MPV, Incomplete	Chassis	E	Electronic Brake Control Module	•			
(T) 1996	LD Trk, MPV, Incomplete	Chassis	C	4WAL 3 Sensor	•			
(T) 1996	LD Trk, MPV, Incomplete	Body	U	Supplemental Inflatable Restraint	•			
(T) 1996	LD Trk, MPV, Incomplete	Body	T	Supplemental Inflatable Restraint				
(T) 1996	LD Trk, MPV, Incomplete	Body	S	Supplemental Inflatable Restraint	•	•	•	
(T) 1996	LD Trk, MPV, Incomplete	Body	M	Supplemental Inflatable Restraint	•			
(T) 1996	LD Trk, MPV, Incomplete	Body	L	Supplemental Inflatable Restraint	•			
(T) 1996	LD Trk, MPV, Incomplete	Body	K	Supplemental Inflatable Restraint	•			
(T) 1996	LD Trk, MPV, Incomplete	Body	J	Supplemental Inflatable Restraint	•	•	•	
(T) 1996	LD Trk, MPV, Incomplete	Body	G	Supplemental Inflatable Restraint	•	•	•	
(T) 1996	LD Trk, MPV, Incomplete	Body	E	Supplemental Inflatable Restraint	•	•	•	
(T) 1996	LD Trk, MPV, Incomplete	Body		Supplemental Inflatable Restraint	•	•	•	•