

MaxiSys_BMW_V9.80 Function List (Note:For reference only)

NOTES:

- This function is supported.
- * This function may be supported, which depends on the actual condition of the vehicle.
- O This function is not supported.
- ▲ This function is the new feature in this version.

As for special function please refer to the special function table.

Series	Model Series	Part	Systems	Ecu	Read	Freeze	Erase	Live	Component	Physical
Delles	Model Selles	lait	руз сеша	Info.	DTC	Frame	DTC	Data	activation	HW
1 Series	E81/E82/E87/E88	Body	MRS/AB Airbag/ACSM		•	•	•	•	0	•
1 Series	E81/E82/E87/E88	Body	AHM Trailer module		•	•	•	•	•	•
1 Series	E81/E82/E87/E88	Body	AMP Amplifier	•	•	•	•	•	•	•
1 Series	E81/E82/E87/E88	Body	CA Comfort access system	•	•	•	•	•	0	•
1 Series	E81/E82/E87/E88	Body	CAN communication analysis		•	•	0	0	0	0
1 Series	E81/E82/E87/E88	Body	CCC-A Applications		•	•	•	•	•	•
1 Series	E81/E82/E87/E88	Body	CCC-ANT Aerial tuner	•	•	•	•	•	•	•
1 Series	E81/E82/E87/E88	Body	CCC-ASK Audio system controller	•	•	•	•	•	•	•
1 Series	E81/E82/E87/E88	Body	CCC-BO User interface		•	•	•	•	•	•
1 Series	E81/E82/E87/E88	Body	CCC-GW Gateway	•	•	•	•	•	•	•
1 Series	E81/E82/E87/E88	Body	CDC CD Changer	•	•	•	•	0	•	•
1 Series	E81/E82/E87/E88	Body	CIC Car Information Computer	•	•	•	•	•	•	•
1 Series	E81/E82/E87/E88	Body	CIC-GW Gateway	•	•	•	•	0	•	•
1 Series	E81/E82/E87/E88	Body	CID Central information display	•	•	•	•	•	•	•
1 Series	E81/E82/E87/E88	Body	CON Controller	•	•	•	•	•	•	•
1 Series	E81/E82/E87/E88	Body	CVM/CVM2 Convertible top module	•	•	•	•	•	•	•
1 Series	E81/E82/E87/E88	Body	DWA anti-theft alarm system	•	•	•	•	•	•	•
1 Series	E81/E82/E87/E88	Body	FRM footwell module	•	•	•	•	•	•	•
1 Series	E81/E82/E87/E88	Body	FRM2 footwell module 2	•	•	•	•	•	•	•
1 Series	E81/E82/E87/E88	Body	FZD Function centre, roof	•	•	•	•	•	•	•
1 Series	E81/E82/E87/E88	Body	IHKA Heater/automatic A/C control	•	•	•	•	•	•	•
1 Series	E81/E82/E87/E88	Body	IHKR Heater and A/C control	•	•	•	•	•	•	•
1 Series	E81/E82/E87/E88	Body	IHR Integrated heater control	•	•	•	•	•	•	•
1 Series	E81/E82/E87/E88	Body	INSTR Instrument cluster	•	•	•	•	•	•	•
1 Series	E81/E82/E87/E88	Body	JBE Junction-box electronics	•	•	•	•	•	•	•
1 Series	E81/E82/E87/E88	Body	JBE2 Junction Box electronics	•	•	•	•	•	•	•
1 Series	E81/E82/E87/E88	Body	JNAV Navigation system, Japan	•	•	•	•	•	•	•
1 Series	E81/E82/E87/E88	Body	M-ASK-BO User interface	•	•	•	•	•	•	•
1 Series	E81/E82/E87/E88	Body	M-ASK-GW Gateway	•	•	•	•	•	•	•
1 Series	E81/E82/E87/E88	Body	M-ASK-NAV Navigation system	•	•	•	•	•	•	0
1 Series	E81/E82/E87/E88	Body	MOST system analysis	•	•	•	•	0	0	0
1 Series	E81/E82/E87/E88	Body	PDC Park distance control	•	•	•	•	•	•	•
1 Series	E81/E82/E87/E88	Body	RAD Radio	•	•	•	•	•	•	•
1 Series	E81/E82/E87/E88	Body	RAD2-BO User interface	•	•	•	•	•	•	•
1 Series	E81/E82/E87/E88	Body	RAD2-GW Gateway	•	•	•	•	•	•	•
1 Series	E81/E82/E87/E88	Body	RLSS Rain/Light Solar Sensor	•	•	•	•	•	0	0

Series	Model Series	Part	Systems	Ecu Info.	Read DTC	Freeze Frame	Erase DTC	Live Data	Component activation	Physical HW
1 Series	E81/E82/E87/E88	Body	SDARS Satellite tuner		•	•	•	•	•	•
1 Series	E81/E82/E87/E88	Body	SINE Siren and tilt sensor		•	•	•	•	0	0
1 Series	E81/E82/E87/E88	Body	SMBF Seat memory, front passenger							
1 Series	E81/E82/E87/E88	Body	SMFA Seat module, driver		•	•	•	•	•	•
1 Series	E81/E82/E87/E88	Body	TCU Telematic control unit	•	•	•	•	•	•	•
1 Series	E81/E82/E87/E88	Body	ULF Universal charging and hands-free facility	•	•	•	•	•	•	•
1 Series	E81/E82/E87/E88	Body	ULF-SBX Interface box	•	•	•	•	•	•	•
1 Series	E81/E82/E87/E88	Body	ULF-SBX-H Interface box High	•	•	•	•	•	•	•
1 Series	E81/E82/E87/E88	Chassis	ABS/ASC/DSC Dynamic Stability Control	•	•	•	•	•	•	•
1 Series	E81/E82/E87/E88	Chassis	AL active front steering(AFS70)	•	•	•	•	•	0	•
1 Series	E81/E82/E87/E88	Chassis	AL active steering	•	•	•	•	•	0	•
1 Series	E81/E82/E87/E88	Chassis	EPS Electronic Power Steering		•	•	•	•	•	•
1 Series	E81/E82/E87/E88	Chassis	RDC Tyre pressure control	•	•	•	•	•	•	•
1 Series	E81/E82/E87/E88	Drive	CAS Car Access System		•	•	•	•	•	•
1 Series	E81/E82/E87/E88	Drive	DME/DDE(Engine Electronics)		•	•	•	•	•	•
1 Series	E81/E82/E87/E88	Drive	EGS/AGS(Transmission Control)		•	•	•	•	•	•
1 Series	E81/E82/E87/E88	Drive	EKPS fuel-pump control		•	•	•	•	•	•
3 Series	E30	Drive	DME/DDE(Engine Electronics)	•	•	0	•	•	•	
3 Series	E30	Drive	EML (Engine-Power Control)		•	0	•	•	0	
3 Series	E30	Drive	EGS/AGS(Transmission Control)	•	•	0	•	•	•	
3 Series	E30	Body	KOM(Instrument cluster)	•	•	0	•			
3 Series	E30	Drive	EWS(Electronic car Immobilisation system)	•	•	0	•	•	0	
3 Series	E30	Drive	GSR(Cruise control)	•		0	•	•	0	
3 Series	E30	Body	AB(airbag)	•		0		•	0	
3 Series	E30	Body	SPM/SM(Seat/mirror memory)	•		0	•	•	0	
3 Series	E30	Body	IHK (Heater-A/C system)	•		0		•	0	
3 Series	E30	Chassis	ABS(Anti-lock braking system)\n ASC(Automatic stability control)\n ABD(Automatic brake differential(All-wheel drive))\n DSC(Dynamic stability control('94->))	•	•	0	•	•	•	
3 Series	E30	Chassis	DSC(Dynamic stability control)	•	•	0	•	•	0	
3 Series	E30	Body	ADS (Throttle-valve control)	•	•	0	•	•	0	
3 Series	E30	Chassis	ABS/ASC tester	•	•	0	•	•	0	
3 Series	E36[<9803]	Drive	DME/DDE(Engine Electronics)	•	•	0	•	•	•	
3 Series	E36[<9803]	Drive	EML(Engine-Power Control)	•	•	0	•	•	0	
3 Series	E36[<9803]	Drive	EGS/AGS(Transmission Control)	•	•	0	•	•	•	
3 Series	E36[<9803]	Body	KOM(Instrument cluster)	•	•	0	•		_	
3 Series	E36[<9803]	Drive	EWS(Electronic car Immobilisation system)	•	•	0	•	•	0	
3 Series	E36[<9803]	Drive	GSR(Cruise control)	•	•	0	•	•	0	
3 Series	E36[<9803]	Body	AB(airbag)	•	•	0	•	•	0	

Series	Model Series	Part	Systems	Ecu Info.	Read DTC	Freeze Frame	Erase DTC	Live Data	Component activation	Physical HW
3 Series	E36[<9803]	Body	SPM/SM(Seat/mirror memory)	•	•	0		•	0	
3 Series	E36[<9803]	Body	IHK(Heater-A/C system)	•	•	0	•	•	0	
3 Series	E36[<9803]	Chassis	ABS(Anti-lock braking system)\n ASC(Automatic stability control)\n ABD(Automatic brake differential(All-wheel drive))\n DSC(Dynamic stability control('94->))	•	•	0	•	•	•	
3 Series	E36[<9803]	Chassis	DSC(Dynamic stability control)	•	•	0	•	•	0	
3 Series	E36[<9803]	Body	ADS(Throttle-valve control)	•	•	0	•	•	0	
3 Series	E36[<9803]	Chassis	ABS/ASC tester	•	•	0	•	•	0	
3 Series	E36[>9803]	Body	MRS/AB Airbag/ACSM	•	•	0	•	•	0	•
3 Series	E36[>9803]	Body	BCO/MID On-board computer/MID			0				
3 Series	E36[>9803]	Body	CVM/CVM2 Convertible top module	•	•	0	•	•	•	•
3 Series	E36[>9803]	Body	IHKA Heater/automatic A/C control	•	•	0	•	•	•	•
3 Series	E36[>9803]	Body	IR Radio/infrared locking system							
3 Series	E36[>9803]	Body	KOM Instrument cluster	•	•	0	•	•	•	0
3 Series	E36[>9803]	Body	PDC Park distance control	•	•	0	•	•	•	•
3 Series	E36[>9803]	Body	URS Rollover sensor	•	•	0	•	•	•	0
3 Series	E36[>9803]	Body	ZKE Central body electronics	•	•	0	•	•	•	0
3 Series	E36[>9803]	Chassis	ABS/ASC/DSC Dynamic Stability Control	•	•	0	•	•	•	•
3 Series	E36[>9803]	Drive	DME/DDE(Engine Electronics)	•	•	0	•	•	•	•
3 Series	E36[>9803]	Drive	EGS/AGS(Transmission Control)	•	•	0	•	•	•	•
3 Series	E36[>9803]	Drive	EWS Vehicle immobilizer	•	•	0	•	•	•	0
3 Series	E36[>9803]	Drive	GR Cruise control	•	•	0	•	•	•	0
3 Series	E36[>9803]	Drive	TOENS Thermal oil-level sensor	•	•	0	•	•	•	0
3 Series	E46	Body	MRS/AB Airbag/ACSM	•	•	0	•	•	0	•
3 Series	E46	Body	AHL Adaptive directional headlights	•	•	0	•	•	•	•
3 Series	E46	Body	AIC Automatic Interval control	•	•	0	•	•	0	0
3 Series	E46	Body	BIT Basis Interface Telephone	•	•	0	•	•	0	0
3 Series	E46	Body	BM On-board monitor	•	•	0	•	•	•	0
3 Series	E46	Body	CVM/CVM2 Convertible top module	•	•	0	•	•	•	•
3 Series	E46	Body	IHKA Heater/automatic A/C control	•	•	0	•	•	•	•
3 Series	E46	Body	IHKR Heater and A/C control	•	•	0	•	•	•	•
3 Series	E46	Body	JBIT Japan Basis Interface Telephone	•	0	0	0	•	0	0
3 Series	E46	Body	KOM Instrument cluster	•	•	0	•	•	•	0
3 Series	E46	Body	LSZ Light switching centre	•	•	0	•	•	•	0
3 Series	E46	Body	MIR Multi-Information Radio	•	•	0	•	•	0	0
3 Series	E46	Body	NAJ Navigation computer, Japan	•	•	0	•	•	•	0
3 Series	E46	Body	NAR Navigation radio	•	•	0	•	0	•	0
3 Series	E46	Body	NAV Navigation computer	•	•	0	•	•	•	0
3 Series	E46	Body	NAV Navigation computer MKII	•	•	0	•	•	0	0
3 Series	E46	Body	PDC Park distance control	•	•	0	•	•	•	•
3 Series	E46	Body	RAD Radio	•	•	0	•	•	•	•
3 Series	E46	Body	RLS Rain/Light Sensor	•	•	0	•	•	0	•

	E46			Info.	DTC	Frame	DTC	Data	activation	Physical HW
3 Series	LTO	Body	SES Language-input system	•	•	0	•	0	•	0
	E46	Body	SHD Sliding/tilting sunroof	•	•	0	•	•	•	•
3 Series	E46	Body	SMB Entrance aid, passenger	•	•	0	•	•		0
3 Series	E46	Body	SMF Entrance aid, driver	•	•	0	•	•	•	0
3 Series	E46	Body	SMF Seat memory, driver	•	•	0	•	•	•	0
3 Series	E46	Body	SPMBT Mirror memory, passenger	•	•	0	•	•	•	0
3 Series	E46	Body	SPMFT Mirror memory, driver	•	•	0	•	•	•	0
3 Series	E46	Body	SZM Switching centre, centre console	•	•	0	•	•	•	•
3 Series	E46	Body	TCU Telematic control unit	•	•	0	•	•	•	•
3 Series	E46	Body	TEL Telephone interface	0	0	0	0	•	•	0
	E46	Body	ULF Universal charging and hands-free facility	•	•	0	•	•	•	•
3 Series	E46	Body	URS Rollover sensor	•	•	0	•	•	0	0
3 Series	E46	Body	VID Video module	•	•	0	•	0	0	0
3 Series	E46	Body	VID Video module III	•	•	0	•	0	0	0
3 Series	E46	Body	ZKE Central body electronics	•	•	0	•	•	•	0
	E46	Body	ZUH Auxiliary heater	•	•	0	•	•	•	0
	E46	Chassis	ABS/ASC/DSC Dynamic Stability Control	•	•	0	•	•	•	•
	E46	Chassis	DDS Deflation Detection System	•	•	0	•	•	0	0
	E46	Chassis	LWS Steering angle sensor	•	•	0	•	•	0	0
	E46	Chassis	MFL Multi-function steering wheel	•	•	0	•	•	0	0
	E46		RDC Tyre pressure control	•	•	0	•	•	•	•
	E46	Drive	DME/DDE(Engine Electronics)	•	•	0	•	•	•	•
	E46	Drive	EGS/AGS(Transmission Control)	•	•	0	•	•	•	•
	E46	Drive	EKP Fuel pump	•	•	0	•	•	•	0
	E46	Drive	EWS Vehicle immobilizer	•	•	0	•	•	•	0
	E46	Drive	GR Cruise control	•	•	0	•	•	•	0
	E90/E91/E92/E93	Body	MRS/AB Airbag/ACSM	•	•	•	•	•	0	•
	E90/E91/E92/E93	Body	AHM Trailer module	•	•	•	•	•	•	•
	E90/E91/E92/E93	Body	AMP Amplifier	•	•	•	•	•	•	•
	E90/E91/E92/E93	Body	CA Comfort access system	•	•	•	•	•	0	•
	E90/E91/E92/E93	Body	CAN communication analysis	•	•	•	0	0	0	0
3 Series	E90/E91/E92/E93	Body	CCC-A Applications	•	•	•	•	•	•	•
3 Series	E90/E91/E92/E93	Body	CCC-ANT Aerial tuner	•	•	•	•	•	•	•
		Body	CCC-ASK Audio system controller	•	•	•	•	•	•	•
3 Series	E90/E91/E92/E93	Body	CCC-BO User interface	•	•	•	•	•	•	•
3 Series	E90/E91/E92/E93	Body	CCC-GW Gateway	•	•	•	•	•	•	•
3 Series	E90/E91/E92/E93	Body	CDC CD Changer	•	•	•	•	0	•	•
3 Series	E90/E91/E92/E93	Body	CIC Car Information Computer	•	•	•	•	•	•	•
3 Series	E90/E91/E92/E93	Body	CIC-GW Gateway	•	•	•	•	0	•	•
3 Series	E90/E91/E92/E93	Body	CID Central information display	•	•	•		•	•	•
	E90/E91/E92/E93	Body	CNAV Navigation system, China	•	•	•	•	•	•	•
	E90/E91/E92/E93	Body	CON Controller	•	•	•	•	•	•	•
3 Series	E90/E91/E92/E93	Body	CTM Convertible-top module	•	•	•		•	•	•

Series	Model Series	Part	Systems	Ecu Info.	Read DTC	Freeze Frame	Erase DTC	Live Data	Component activation	Physical HW
3 Series	E90/E91/E92/E93	Body	DAB Digital tuner	•	•	•	•	•	•	•
3 Series	E90/E91/E92/E93	Body	DWA anti-theft alarm system	•	•	•	•	•	•	•
3 Series	E90/E91/E92/E93	Body	FLA High Beam Assist	•	•	•	•	•	•	•
3 Series	E90/E91/E92/E93	Body	FRM footwell module	•	•	•	•	•	•	•
3 Series	E90/E91/E92/E93	Body	FRM2 footwell module 2	•	•	•	•	•	•	•
3 Series	E90/E91/E92/E93	Body	FZD Function centre, roof	•	•	•	•	•	•	•
3 Series	E90/E91/E92/E93	Body	IBOC Digital tuner US	•	•	•	•	•	0	•
3 Series	E90/E91/E92/E93	Body	IHKA Heater/automatic A/C control	•	•	•	•	•	•	•
3 Series	E90/E91/E92/E93	Body	IHKR Heater and A/C control	•	•	•	•	•	•	•
3 Series	E90/E91/E92/E93	Body	IHR Integrated heater control	•	•	•	•	•	•	•
3 Series	E90/E91/E92/E93	Body	INSTR Instrument cluster	•	•	•	•	•	•	•
3 Series	E90/E91/E92/E93	Body	JBE Junction-box electronics	•	•	•	•	•	•	•
3 Series	E90/E91/E92/E93	Body	JBE2 Junction Box electronics	•	•	•	•	•	•	•
3 Series	E90/E91/E92/E93	Body	JNAV Navigation system, Japan	•	•	•	•	•	•	•
3 Series	E90/E91/E92/E93	Body	KNAV Navigation system, Korea	•	•	•	•	•	•	•
3 Series	E90/E91/E92/E93	Body	M-ASK-BO User interface	•	•	•	•	•	•	•
3 Series	E90/E91/E92/E93	Body	M-ASK-GW Gateway	•	•	•	•	•	•	•
3 Series	E90/E91/E92/E93	Body	M-ASK-NAV Navigation system	•	•	•	•	•	•	0
3 Series	E90/E91/E92/E93	Body	MOST system analysis	•	•	•	•	0	0	0
3 Series	E90/E91/E92/E93	Body	PDC Park distance control	•	•	•	•	•	•	•
3 Series	E90/E91/E92/E93	Body	RAD Radio	•	•	•	•	•	•	•
3 Series	E90/E91/E92/E93	Body	RAD2-BO User interface	•	•	•	•	•	•	•
3 Series	E90/E91/E92/E93	Body	RAD2-GW Gateway	•	•	•	•	•	•	•
3 Series	E90/E91/E92/E93	Body	RLSS Rain/Light Solar Sensor	•	•	•	•	•	0	0
3 Series	E90/E91/E92/E93	Body	SDARS Satellite tuner	•	0	0	0	0	0	0
3 Series	E90/E91/E92/E93	Body	SHD Panorama glass sunroof							
3 Series	E90/E91/E92/E93	Body	SINE Siren and tilt sensor	•	•	•	•	•	0	0
3 Series	E90/E91/E92/E93	Body	SMBF Seat module, passenger	•	•	•	•	•	•	•
3 Series	E90/E91/E92/E93	Body	SMFA Seat module, driver	•	•	•	•	•	•	•
3 Series	E90/E91/E92/E93	Body	TCU Telematic control unit	•	•	•	•	•	•	•
3 Series	E90/E91/E92/E93	Body	ULF Universal charging and hands-free facility	•	•	•	•	•	•	•
3 Series	E90/E91/E92/E93	Body	ULF-SBX Interface box	•	•	•	•	•	•	•
3 Series	E90/E91/E92/E93	Body	ULF-SBX-H Interface box High	•	•	•	•	•	•	•
3 Series	E90/E91/E92/E93		VM Video Module	•	•	•	•	•	•	•
3 Series	E90/E91/E92/E93	Chassis	ABS/ASC/DSC Dynamic Stability Control	•	•	•	•	•	•	•
3 Series	E90/E91/E92/E93		ACC Active Cruise Control	•	•	•	•	0	0	•
3 Series	E90/E91/E92/E93		AL active front steering(AFS70)	•	•	•	•	•	0	•
3 Series	E90/E91/E92/E93		AL active steering	•	•	•	•	•	0	•
3 Series	E90/E91/E92/E93		EDC Damper Control	•	•	•	•	•	•	•
3 Series	E90/E91/E92/E93		EPS Electronic Power Steering	•	•	•	•	•	•	•
3 Series	E90/E91/E92/E93	Chassis	LDM Longitudinal Dynamics Management	•	•	•	•	•	0	•
3 Series	E90/E91/E92/E93		RDC Tyre pressure control	•	•	•	•	•	•	•
3 Series	E90/E91/E92/E93	Drive	CAS Car Access System	•	•	•	•	•	•	•

Series	Model Series	Part	Systems	Ecu Info.	Read DTC	Freeze Frame	Erase DTC	Live Data	Component activation	Physical HW
3 Series	E90/E91/E92/E93	Drive	DME/DDE(Engine Electronics)	•	•	•	•	•	•	•
3 Series	E90/E91/E92/E93	Drive	DKG Twin-clutch gearbox		•	•	•	•	•	•
3 Series	E90/E91/E92/E93	Drive	EGS/AGS(Transmission Control)	•	•	•	•	•	•	•
3 Series	E90/E91/E92/E93	Drive	EKPS fuel-pump control	•	•	•	•	•	•	•
3 Series	E90/E91/E92/E93	Drive	GWS Gear selector switch	•	•	•	•	•	•	•
3 Series	E90/E91/E92/E93	Drive	VTG Transfer case	•	•	•	•	•	•	•
5 Series	E28	Drive	DME/DDE(Engine Electronics)	•	•	0	•	•	•	
5 Series	E28	Drive	EML(Engine-Power Control)	•	•	0	•	•	0	
5 Series	E28	Drive	EGS/AGS(Transmission Control)	•	•	0	•	•	•	
5 Series	E28	Body	KOM(Instrument cluster)	•	•	0	•			
5 Series	E28	Drive	EWS(Electronic car Immobilisation system)	•	•	0	•	•	0	
5 Series	E28	Drive	GSR(Cruise control)	•	•	0	•	•	0	
5 Series	E28	Body	AB(airbag)	•	•	0	•	•	0	
5 Series	E28	Body	SPM/SM(Seat/mirror memory)	•	•	0	•	•	0	
5 Series	E28	Body	IHK(Heater-A/C system)	•	•	0	•	•	0	
5 Series	E28	Chassis	ABS(Anti-lock braking system)\n ASC(Automatic stability control)\n ABD(Automatic brake differential(All-wheel drive))\n DSC(Dynamic stability control('94->))	•	•	0	•	•	•	
5 Series	E28	Chassis	DSC(Dynamic stability control)	•	•	0	•	•	0	
5 Series	E28	Body	ADS(Throttle-valve control)	•	•	0	•	•	0	
5 Series	E28	Chassis	ABS/ASC tester		•	0	•	•	0	
5 Series	E34	Drive	DME/DDE(Engine Electronics)	•	•	0	•	•	•	
5 Series	E34	Drive	EML(Engine-Power Control)		•	0	•	•	0	
5 Series	E34	Drive	EGS/AGS(Transmission Control)		•	0	•	•	•	
5 Series	E34	Body	KOM(Instrument cluster)	•	•	0	•	•	0	
5 Series	E34	Drive	EWS(Electronic car Immobilisation system)	•	•	0	•	•	0	
5 Series	E34	Drive	GSR(Cruise control)	•	•	0	•	•	0	
5 Series	E34	Body	AB(airbag)	•	•	0	•	•	0	
5 Series	E34	Body	SPM/SM(Seat/mirror memory)	•	•	0	•	•	0	
5 Series	E34	Body	IHK(Heater-A/C system)	•	•	0	•	•	0	
5 Series	E34	Chassis	ABS(Anti-lock braking system)\n ASC(Automatic stability control)\n ABD(Automatic brake differential(All-wheel drive))\n DSC(Dynamic stability control('94->))	•	•	0	•	•	•	
5 Series	E34	Chassis	DSC(Dynamic stability control)	•	•	0	•	•	0	
5 Series	E34	Body	ADS(Throttle-valve control)	•	•	0	•	•	0	
5 Series	E34	Chassis	ABS/ASC tester	•	•	0	•	•	0	
5 Series	E39	Body	MRS/AB Airbag/ACSM	•	•	0	•	•	0	•
5 Series	E39	Body	AIC Automatic Interval control		•	0	•	•	0	0

Series	Model Series	Part	Systems	Ecu Info.	Read DTC	Freeze Frame	Erase DTC	Live Data	Component activation	Physical HW
5 Series	E39	Body	BIT Basis Interface Telephone	•	0	0	0	•	0	0
5 Series	E39	Body	BM On-board monitor	•	•	0	•	•	•	0
5 Series	E39	Body	DSP Digital Sound Processor	•	•	0	•	•	0	0
5 Series	E39	Body	GM base module	•	•	0	•	•	•	0
5 Series	E39	Body	GSR Cruise control	•	•	0	•	•	0	0
5 Series	E39	Body	HKM Boot-lid module	•	•	0	•	0	0	0
5 Series	E39	Body	IHKA Heater/automatic A/C control	•	•	0	•	•	•	•
5 Series	E39	Body	IHKR Heater and A/C control	•	•	0	•	•	•	•
5 Series	E39	Body	IHR Integrated heater control	•	•	0	•	•	•	•
5 Series	E39	Body	IKE Instrument-cluster electronics	•	•	0	•	0	0	0
5 Series	E39	Body	IRIS Integrated Radio-Information System	•	0	0	0	0	0	0
5 Series	E39	Body	JBIT Japan Basis Interface Telephone	•	0	0	0	•	0	0
5 Series	E39	Body	KOM Instrument cluster	•	•	0	•	•	•	0
5 Series	E39	Body	LCM Light Check Module	•	•	0	•	•	•	0
5 Series	E39	Body	LCM Light Check Module IV	•	•	0	•	•	•	0
5 Series	E39	Body	LRA Automatic headlight vertical aim control	•	•	0	•	•	•	0
5 Series	E39	Body	MID Multi Information Display	•	•	0	•	0	0	0
5 Series	E39	Body	NAJ Navigation computer, Japan	•	•	0	•	•	•	0
5 Series	E39	Body	NAV Navigation computer	•	•	0	•	•	•	0
5 Series	E39	Body	PDC Park distance control	•	•	0	•	•	•	•
5 Series	E39	Body	RAD Radio	•	•	0	•	•	•	•
5 Series	E39	Body	RLS Rain/Light Sensor	•	•	0	•	•	0	•
5 Series	E39	Body	SES Language-input system	•	•	Ö	•	0	•	0
5 Series	E39	Body	SM/LSM Seat/steering-column memory	0	0	0	0	•	•	0
5 Series	E39	Body	STH park heating	•	•	0	•	•	•	0
5 Series	E39	Body	SZM Switching centre, centre console	•	•	0	•	•	•	•
5 Series	E39	Body	TCU Telematic control unit	•	•	0	•	•	•	•
5 Series	E39	Body	TEL Telephone interface	0	0	0	0	•	•	0
5 Series	E39	Body	ULF Universal charging and hands-free facility	•	•	0	•	•	•	•
5 Series	E39	Body	VID Video module	•	•	0	•	0	0	0
5 Series	E39	Body	ZKE Central body electronics	•	•	0	•	•	•	0
5 Series	E39		ABS/ASC/DSC Dynamic Stability Control	•	•	0	•	•	•	•
5 Series	E39	_	DDS Deflation Detection System	•	•	0	•	•	0	0
5 Series	E39	Chassis	EDC Damper Control	•	•	0	•	•	•	•
5 Series	E39	Chassis	EHC Electronic Ride-Height Control	•	•	0	•	•	•	•
5 Series	E39	Chassis	LEW Steering-angle sensor	•	•	0	•	•	0	0
5 Series	E39	Chassis	MFL Multi-function steering wheel	•	•	0	•	•	0	0
5 Series	E39	Chassis	RDC Tyre pressure control	•	•	0	•	•	•	•
5 Series	E39	Drive	DME/DDE (Engine Electronics)	•	•	0		•	•	•
5 Series	E39	Drive	EGS/AGS (Transmission Control)			0	•		•	•
5 Series	E39	Drive	EWS Vehicle immobilizer	•		0		•	•	0
5 Series	E39	Drive	GR Cruise control			0		•	•	0
0 001169	T00	DIIAC	or orarge control	• •		$\overline{}$		-	· •	$\overline{}$

Series	Model Series	Part	Systems	Ecu Info.	Read DTC	Freeze Frame	Erase DTC	Live Data	Component activation	Physical HW
5 Series	E60/E61	Body	MRS/AB Airbag/ACSM	•	•	•	•	•	0	•
5 Series	E60/E61	Body	AHL Adaptive directional headlights	•	•	•	•	•	•	•
5 Series	E60/E61	Body	AHM Trailer module	•	•	•	•	•	•	•
5 Series	E60/E61	Body	ALBBF active backrest width, front passenger	•	•	•	•	•	0	•
5 Series	E60/E61	Body	ALBFA active backrest width, driver	•	•	•	•	•	0	•
5 Series	E60/E61	Body	AMP Amplifier	•	•	•	•	•	•	•
5 Series	E60/E61	Body	CA Comfort access system		•	•	•	•	0	•
5 Series	E60/E61	Body	CAN communication analysis		•	•	0	0	0	0
5 Series	E60/E61	Body	CCC-A Applications	•	•	•	•	•	•	•
5 Series	E60/E61	Body	CCC-ANT Aerial tuner	•	•	•	•	•	•	•
5 Series	E60/E61	Body	CCC-ASK Audio system controller	•	•	•	•	•	•	•
5 Series	E60/E61	Body	CCC-BO User interface	•	•	•	•	•	•	•
5 Series	E60/E61	Body	CCC-GW Gateway	•	•	•	•	•	•	•
5 Series	E60/E61	Body	CDC CD Changer	•	•	•	•	0	•	•
5 Series	E60/E61	Body	CHAMP-BO User interface	•	•	•	•	•	•	•
5 Series	E60/E61	Body	CHAMP-GW Gateway	•	•	•	•	•	•	•
5 Series	E60/E61	Body	CIC Car Information Computer	•	•	•	•	•	•	•
5 Series	E60/E61	Body	CIC-GW Gateway		•	•	•	0	•	•
5 Series	E60/E61	Body	CID Central information display		•	•	•	•	•	•
5 Series	E60/E61	Body	CNAV Navigation system, China	•	•	•	•	•	•	•
5 Series	E60/E61	Body	CON Controller		•	•	•	•	•	•
5 Series	E60/E61	Body	DAB Digital tuner	•	•	•	•	•	•	•
5 Series	E60/E61	Body	DVDC DVD Changer		•	•	•	0	•	•
5 Series	E60/E61	Body	DWA anti-theft alarm system		•	•	•	•	•	•
5 Series	E60/E61	Body	FBI Flexible Bus Interface	•	•	•	•	•	0	•
5 Series	E60/E61	Body	FD Rear-compartment display	•	•	•	•	•	•	•
5 Series	E60/E61	Body	FD2 Rear-compartment display 2	•	•	•	•	•	•	•
5 Series	E60/E61	Body	FLA High Beam Assist	•	•	•	•	•	•	•
5 Series	E60/E61	Body	HKL Rear-lid lift	•	•	•	•	•	•	•
5 Series	E60/E61	Body	HUD Head-Up Display		•	•	•	•	•	•
5 Series	E60/E61	Body	IHKA Heater/automatic A/C control	•	•	•	•	•	•	•
5 Series	E60/E61	Body	INSTR Instrument cluster	•		•		•	•	
5 Series	E60/E61	Body	JNAV Navigation system, Japan			•	•		•	•
5 Series	E60/E61	Body	KBM Body basic module	•	•	•		•		
5 Series	E60/E61	Body	KGM Body Gateway Module	•				•	•	
5 Series	E60/E61	Body	KHI Headset interface	•				•	•	
5 Series	E60/E61	Body	KNAV Navigation system, Korea	•	•			•		
5 Series	E60/E61	Body	LM2 Light module 2	•		•		•		
5 Series	E60/E61	Body	LM2 Light module 2 with adaptive headlight	•	•		•	•		
o peries	E00/ E01	Dody							_	
5 Series	E60/E61	Body	LM2 AHL2 Light module 2 with adaptive headlight 2	•	•	•	•	•	•	•
5 Series	E60/E61	Body	M-ASK-BO User interface	•	•	•	•	•	•	•

Series	Model Series	Part	Systems	Ecu Info.	Read DTC	Freeze Frame	Erase DTC	Live Data	Component activation	Physical HW
5 Series	E60/E61	Body	M-ASK-GW Gateway	•	•	•	•	•	•	•
5 Series	E60/E61	Body	M-ASK-NAV Navigation system	•	•	•	•	•	•	0
5 Series	E60/E61	Body	MOST system analysis	•	•	•	•	0	0	0
5 Series	E60/E61	Body	MPM Micro-power module	•	•	•	•	•	•	•
5 Series	E60/E61	Body	NVE Night Vision Electronics	•	•	•	•	•	•	•
5 Series	E60/E61	Body	NVK Night Vision camera		•	•	•	•	•	•
5 Series	E60/E61	Body	PDC Park distance control	•	•	•	•	•	•	•
5 Series	E60/E61	Body	RLS Rain/Light Sensor	•	•	•	•	•	0	•
5 Series	E60/E61	Body	RLSS Rain/Light Solar Sensor	•	•	•	•	•	0	0
5 Series	E60/E61	Body	RSE Rear Seat Entertainment	•	•	•	•	•	•	•
5 Series	E60/E61	Body	SBSL Satellite, B-pillar, left	•	•	•	•	•	0	•
5 Series	E60/E61	Body	SBSR Satellite, B-pillar, right	•	•	•	•	•	•	•
5 Series	E60/E61	Body	SDARS Satellite tuner	•	•	•	•	•	•	•
5 Series	E60/E61	Body	SFZ Satellite vehicle centre	•	•	•	•	•	0	•
5 Series	E60/E61	Body	SGM-SIM Safety and Gateway Module(SIM)	•	•	•	•	•	•	•
5 Series	E60/E61	Body	SGM-ZGM Safety and Gateway Module (ZGM)	•	•	•	•	0	0	•
5 Series	E60/E61	Body	SHD Slide/tilt sunroof 2				 		Ü	
5 Series	E60/E61	Body	SHD Sliding/tilting sunroof	•		•	•	•	•	
5 Series	E60/E61	Body	SHZH Independent/auxiliary heater							
5 Series	E60/E61	Body	SINE Siren and tilt sensor					•	0	0
5 Series	E60/E61	Body	SMBF Seat module, passenger					•	•	•
5 Series	E60/E61	Body	SMFA Seat module, driver	•				•	•	•
5 Series	E60/E61	Body	SVS Language processing system	•				0	•	•
5 Series	E60/E61	Body	SZL Steering column switch centre 2					•	•	•
5 Series	E60/E61	Body	SZL Switch centre, steering column							•
5 Series	E60/E61	Body	SZM Switching centre, centre console						•	•
5 Series 5 Series	E60/E61	Body	TCU Telematic control unit						•	•
	E60/E61	Body	TLC Lane Departure Warning						•	0
5 Series	E60/E61	Body							•	•
5 Series			TMBF Door module, front passenger					•		•
5 Series	E60/E61	Body	TMFA Door module, driver	_	_		_		0	•
5 Series	E60/E61	Body	ULF Universal charging and hands-free facility	•	•	•	•	•	•	•
5 Series	E60/E61	Body	ULF-SBX Interface box	•	•	•	•	•	•	•
5 Series	E60/E61	Body	ULF-SBX-H Interface box High	•	•	•	•	•	•	•
5 Series	E60/E61	Body	VM Video Module	•	•	•	•	•	•	•
5 Series	E60/E61	Chassis	ABS/ASC/DSC Dynamic Stability Control	•	•	•	•	•	•	•
5 Series	E60/E61	Chassis	ACC Active Cruise Control	•	•	•	•	0	0	•
5 Series	E60/E61		ACC2 Active Cruise Control 2	•	•	•	•	0	0	•
5 Series	E60/E61		AL active front steering(AFS70)	•	•	•	•	•	0	•
5 Series	E60/E61		AL active steering	•	•	•	•	•	0	•
5 Series	E60/E61		ARS Dynamic Drive 2	•	•	•	•	•	•	•
5 Series	E60/E61	Chassis	EDC Damper Control	•	•	•	•	•	•	•
5 Series	E60/E61	Chassis	EHC Electronic Ride-Height Control	•	•	•	•	•	•	•
5 Series	E60/E61	Chassis	LDM Longitudinal Dynamics Management	•	•	•	•	•	0	•

Series	Model Series	Part	Systems	Ecu Info.	Read DTC	Freeze Frame	Erase DTC	Live Data	Component activation	Physical HW
5 Series	E60/E61	Chassis	LRR Long-range sensor	•	•	•	•	0	0	•
5 Series	E60/E61	Chassis	RDC Tyre pressure control	•	•	•	•	•	•	•
5 Series	E60/E61	Drive	CAS Car Access System	•	•	•	•	•	•	•
5 Series	E60/E61	Drive	DME/DDE(Engine Electronics)	•	•	•	•	•	•	•
5 Series	E60/E61	Drive	EGS/AGS(Transmission Control)	•	•	•	•	•	•	•
5 Series	E60/E61	Drive	EKPS fuel-pump control	•	•	•	•	•	•	•
5 Series	E60/E61	Drive	GWS Gear selector switch	•	•	•	•	•	•	•
5 Series	E60/E61	Drive	VTC Valvetronic	•	0	0	0	0	0	•
5 Series	E60/E61	Drive	VTC2 Valvetronic 2	•	0	0	0	0	0	•
5 Series	E60/E61	Drive	VTG Transfer case	•	•	•	•	•	•	•
6 Series	E24	Drive	DME/DDE(Engine Electronics)	•	•	0	•	•	•	
6 Series	E24	Drive	EML(Engine-Power Control)	•	•	0	•	•	0	
6 Series	E24	Drive	EGS/AGS(Transmission Control)	•	•	0	•	•	•	
6 Series	E24	Body	KOM(Instrument cluster)	•	•	0	•			
6 Series	E24	Drive	EWS(Electronic car Immobilisation system)	•	•	0	•	•	0	
6 Series	E24	Drive	GSR(Cruise control)	•	•	0	•	•	0	
6 Series	E24	Body	AB (airbag)	•	•	0	•	•	0	
6 Series	E24	Body	SPM/SM(Seat/mirror memory)	•	•	0	•	•	0	
6 Series	E24	Body	IHK(Heater-A/C system)	•	•	0	•	•	0	
6 Series	E24	Chassis	ABS(Anti-lock braking system)\n ASC(Automatic stability control)\n ABD(Automatic brake differential(All-wheel drive))\n DSC(Dynamic stability control('94->))	•	•	0	•	•	•	
6 Series	E24	Chassis	DSC(Dynamic stability control)	•	•	0	•	•	0	
6 Series	E24	Body	ADS(Throttle-valve control)	•	•	0	•	•	0	
6 Series	E24	Chassis	ABS/ASC tester	•	•	Ö	•	•	0	
6 Series	E63/E64	Body	MRS/AB Airbag/ACSM	•	•	•	•	•	0	•
6 Series	E63/E64	Body	AHL Adaptive directional headlights	•	•	•	•	•	•	•
6 Series	E63/E64	Body	AMP Amplifier	•	•	•	•	•	•	•
6 Series	E63/E64	Body	CA Comfort access system	•	•	•	•	•	0	•
6 Series	E63/E64	Body	CAN communication analysis	•	•	•	0	0	0	0
6 Series	E63/E64	Body	CCC-A Applications	•	•	•	•	•	•	•
6 Series	E63/E64	Body	CCC-ANT Aerial tuner	•	•	•	•	•	•	•
6 Series	E63/E64	Body	CCC-ASK Audio system controller	•	•	•	•	•	•	•
6 Series	E63/E64	Body	CCC-BO User interface	•	•	•	•	•	•	•
6 Series	E63/E64	Body	CCC-GW Gateway	•	•	•	•	•	•	•
6 Series	E63/E64	Body	CDC CD Changer	•	•	•	•	0	•	•
6 Series	E63/E64	Body	CHAMP-BO User interface	•	•	•	•	•	•	•
6 Series	E63/E64	Body	CHAMP-GW Gateway	•	•	•	•	•	•	•
6 Series	E63/E64	Body	CIC Car Information Computer	•	•	•	•	•	•	•
6 Series	E63/E64	Body	CIC-GW Gateway	•	•	•	•	0	•	•
6 Series	E63/E64	Body	CID Central information display	•	•	•		•	•	•

	D00 /D04		Systems	Info.	DTC	Frame	DTC	Data	activation	Physical HW
C Carrier	E63/E64	Body	CNAV Navigation system, China	•	•	•	•	•	•	•
6 Series	E63/E64	Body	CON Controller	•	•	•	•	•	•	•
6 Series	E63/E64	Body	CVM/CVM2 Convertible top module	•	•	•	•	•	•	•
6 Series	E63/E64	Body	DAB Digital tuner	•	•	•	•	•	•	•
6 Series	E63/E64	Body	DVDC DVD Changer	•	•	•	•	0	•	•
6 Series	E63/E64	Body	DWA anti-theft alarm system	•	•	•	•	•	•	•
6 Series	E63/E64	Body	FLA High Beam Assist	•	•	•	•	•	•	•
6 Series	E63/E64	Body	HUD Head-Up Display	•	•	•	•	•	•	•
6 Series	E63/E64	Body	IBOC Digital tuner US	•	•	•	•	•	0	•
6 Series	E63/E64	Body	IHKA Heater/automatic A/C control	•	•	•	•	•	•	•
	E63/E64	Body	INSTR Instrument cluster	•	•	•	•	•	•	•
	E63/E64	Body	JNAV Navigation system, Japan	•	•	•	•	•	•	•
	E63/E64	Body	KBM Body basic module	•	•	•	•	•	•	•
	E63/E64	Body	KGM Body Gateway Module	•	•	•	•	•	•	•
	E63/E64	Body	KNAV Navigation system, Korea	•	•	•	•	•	•	•
	E63/E64	Body	LM2 Light module 2	•	•	•	•	•	•	•
	E63/E64	Body	LM2 AHL light module 2 with adaptive headlight	•	•	•	•	•	•	•
6 Series	E63/E64	Body	LM2 AHL2 Light module 2 with adaptive headlight 2	•	•	•	•	•	•	•
6 Series	E63/E64	Body	M-ASK-BO User interface	•	•	•	•	•	•	•
	E63/E64	Body	M-ASK-GW Gateway	•	•	•	•	•	•	•
6 Series	E63/E64	Body	MOST system analysis	•	•	•	•	0	0	0
	E63/E64	Body	MPM Micro-power module	•	•	•	•	•	•	•
	E63/E64	Body	NVE Night Vision Electronics	•	•	•	•	•	•	•
	E63/E64	Body	NVK Night Vision camera	•	•	•	•	•	•	•
	E63/E64	Body	PDC Park distance control	•	•	•	•	•	•	•
	E63/E64	Body	RLS Rain/Light Sensor	•	•	•	•	•	0	•
	E63/E64	Body	RLSS Rain/Light Solar Sensor	•	•	•	•	•	0	0
	E63/E64	Body	SBSL Satellite, B-pillar, left	•	•	•	•	•	0	•
	E63/E64	Body	SBSR Satellite, B-pillar, right	•	•	•	•	•	•	•
	E63/E64	Body	SDARS Satellite tuner	•	•	•	•	•	•	•
	E63/E64	Body	SFZ Satellite vehicle centre	•	•	•	•	•	0	•
	E63/E64	Body	SGM-SIM Safety and Gateway Module(SIM)	•	•	•	•	•	•	•
	E63/E64	Body	SGM-ZGM Safety and Gateway Module(ZGM)	•	•	•	•	0	0	•
	E63/E64	Body	SHD Slide/tilt sunroof 2	-						
	E63/E64	Body	SHZH Independent/auxiliary heater	•	•	•	•	•	•	•
	E63/E64	Body	SMBF Seat memory, front passenger		_	_	_		_	
	E63/E64	Body	SMF Seat memory, driver	•	•	•	•	•	•	0
	E63/E64	Body	SVS Language processing system	•	•	•	•	0	•	•
	E63/E64	Body	SZL Steering column switch centre 2	•	•	•	•	•	•	•
	E63/E64	Body	SZL Switch centre, steering column	•	•	•	•	•	•	•
	E63/E64	Body	SZM Switching centre, centre console	•	•	•	•	•	•	•
	E63/E64	Body	TCU Telematic control unit	•	•	•	•	•	•	•

Series	Model Series	Part	Systems	Ecu Info.	Read DTC	Freeze Frame	Erase DTC	Live Data	Component activation	Physical HW
6 Series	E63/E64	Body	TLC Lane Departure Warning	•	•	•	•	•	•	0
6 Series	E63/E64	Body	TMBF Door module, front passenger	•	•	•	•	•	•	•
6 Series	E63/E64	Body	TMFA Door module, driver	•	•	•	•	•	0	•
6 Series	E63/E64	Body	ULF Universal charging and hands-free facility	•	•	•	•	•	•	•
6 Series	E63/E64	Body	ULF-SBX Interface box	•	•	•	•	•	•	•
6 Series	E63/E64	Body	ULF-SBX-H Interface box High	•	•	•	•	•	•	•
6 Series	E63/E64	Body	VM Video Module	•	•	•	•	•	•	•
6 Series	E63/E64	Chassis	ABS/ASC/DSC Dynamic Stability Control	•	•	•	•	•	•	•
6 Series	E63/E64	Chassis	ACC2 Active Cruise Control 2	•	•	•	•	0	0	•
6 Series	E63/E64	Chassis	AL active front steering (AFS70)	•		•	•	•	0	
6 Series	E63/E64	Chassis	AL active steering	•	•	•		•	0	•
6 Series	E63/E64	Chassis	ARS Dynamic Drive	•				•		
6 Series	E63/E64	Chassis	ARS Dynamic Drive 2					•	•	
6 Series	E63/E64	Chassis	EDC Damper Control						•	
6 Series	E63/E64	Chassis	LDM Longitudinal Dynamics Management						0	
6 Series	E63/E64	Chassis	LRR Long-range sensor					0	0	
6 Series	E63/E64	Chassis	RDC Tyre pressure control							
	E63/E64	Drive								
6 Series	E63/E64	-	CAS Car Access System							
6 Series		Drive	DME/DDE (Engine Electronics)		_			_		
6 Series	E63/E64	Drive	EGS/AGS(Transmission Control)				•		•	•
6 Series	E63/E64	Drive	EKPS fuel-pump control		•		•	•	•	•
6 Series	E63/E64	Drive	GWS Gear selector switch	•	•	0	•	•	•	•
6 Series	E63/E64	Drive	VTC Valvetronic	•	0	0	0	0	0	•
6 Series	E63/E64	Drive	VTC2 Valvetronic 2	•	0	0	0	0	0	•
7 Series	E23	Drive	DME/DDE (Engine Electronics)	•	•	0	•	•	•	
7 Series	E23	Drive	EML (Engine-Power Control)	•	•	0	•	•	0	
7 Series	E23	Drive	EGS/AGS(Transmission Control)	•	•	0	•	•	•	
7 Series	E23	Body	KOM(Instrument cluster)	•	•	0	•			
7 Series	E23	Drive	EWS(Electronic car Immobilisation system)	•	•	0	•	•	0	
7 Series	E23	Drive	GSR(Cruise control)	•	•	0	•	•	0	
7 Series	E23	Body	AB(airbag)	•	•	0	•	•	0	
7 Series	E23	Body	SPM/SM(Seat/mirror memory)	•	•	0	•	•	0	
7 Series	E23	Body	IHK(Heater-A/C system)	•	•	0	•	•	0	
7 Series	E23	Chassis	ABS(Anti-lock braking system)\n ASC(Automatic stability control)\n ABD(Automatic brake differential(All-wheel drive))\n DSC(Dynamic stability control('94->))	•	•	0	•	•	•	
7 Series	E23	Chassis	DSC(Dynamic stability control)			0			0	
	E23								0	
7 Series	E23	Body	ADS (Throttle-valve control)			0				
7 Series		Chassis	ABS/ASC tester		—	0			0	
7 Series	E32	Drive	DME/DDE(Engine Electronics)			0		•	•	

Series	Model Series	Part	Systems	Ecu Info.	Read DTC	Freeze Frame	Erase DTC	Live Data	Component activation	Physical HW
7 Series	E32	Drive	EML(Engine-Power Control)	•	•	0	•	•	0	
7 Series	E32	Drive	EGS/AGS(Transmission Control)		•	0	•	•	•	
7 Series	E32	Body	KOM(Instrument cluster)	•	•	0	•			
7 Series	E32	Drive	EWS(Electronic car Immobilisation system)	•	•	0	•	•	0	
7 Series	E32	Drive	GSR(Cruise control)	•	•	0	•	•	0	
7 Series	E32	Body	AB(airbag)	•	•	0	•	•	0	
7 Series	E32	Body	SPM/SM(Seat/mirror memory)	•	•	0	•	•	0	
7 Series	E32	Body	IHK(Heater-A/C system)	•	•	0	•	•	0	
7 Series	E32	Chassis	ABS (Anti-lock braking system) \n ASC (Automatic stability control) \n ABD (Automatic brake differential (All-wheel drive)) \n DSC (Dynamic stability control ('94->))	•	•	0	•	•	•	
7 Series	E32	Chassis	DSC(Dynamic stability control)	•	•	0	•	•	0	
7 Series	E32	Body	ADS(Throttle-valve control)	•	•	0	•	•	0	
7 Series	E32	Chassis	ABS/ASC tester	•	•	0	•	•	0	
7 Series	E38	Body	MRS/AB Airbag/ACSM	•	•	0	•	•	0	•
7 Series	E38	Body	AIC Automatic Interval control	•	•	0	•	•	0	0
7 Series	E38	Body	BIT Basis Interface Telephone	•	•	0	•	•	0	0
7 Series	E38	Body	BM On-board monitor	•	•	0	•	•	•	0
7 Series	E38	Body	BMBT On-board monitor, control panel	•	•	0	•	•	0	0
7 Series	E38	Body	CCM Check Control Module	•	•	0	•	0	0	0
7 Series	E38	Body	DSP Digital Sound Processor	•	•	0	•	•	0	0
7 Series	E38	Body	FBZV Radio-control system	•	•	0	•	0	0	0
7 Series	E38	Body	FGB rear compartment blower	•	•	0	•	0	0	0
7 Series	E38	Body	FHK rear-compartment heating/air conditioning	•	•	0	•	0	0	0
7 Series	E38	Body	FID Rear-compartment information display	•	•	0	•	0	0	0
7 Series	E38	Body	FMBT Rear-compartment monitor, control panel			0			-	-
7 Series	E38	Body	FMGT Rear-compartment monitor, graphics section			0				
7 Series	E38	Body	GR2 Cruise control	•	•	0	•	•	0	0
7 Series	E38	Body	HKM Boot-lid module	•	•	0	•	0	0	0
7 Series	E38	Body	IHKA Heater/automatic A/C control	•	•	0	•	•	•	•
7 Series	E38	Body	IHKR Heater and A/C control	•	•	0	•	•	•	•
7 Series	E38	Body	IKE Instrument-cluster electronics	•	•	0	•	0	0	0
7 Series	E38	Body	IR Infrared compact locking system			0				
7 Series	E38	Body	IR Radio/infrared locking system			0				
7 Series	E38	Body	JBIT Japan Basis Interface Telephone	•	0	0	0	•	0	0
7 Series	E38	Body	LCM Light Check Module	•	•	0	•	•	•	0
7 Series	E38	Body	LM Lights Module	•	•	0	•	•	•	•

Series	Model Series	Part	Systems	Ecu Info.	Read DTC	Freeze Frame	Erase DTC	Live Data	Component activation	Physical HW
7 Series	E38	Body	LRA Automatic headlight vertical aim control	•	•	0	•	•	•	0
7 Series	E38	Body	MID Multi Information Display	•	•	0	•	0	0	0
7 Series	E38	Body	NAJ Navigation computer, Japan	•	•	0	•	•	•	0
7 Series	E38	Body	NAV Navigation computer	•	•	0	•	•	•	0
7 Series	E38	Body	NAV Navigation computer MKIII	•	•	0	•	•	0	0
7 Series	E38	Body	PDC Park distance control	•	•	0	•	•	•	•
7 Series	E38	Body	RAD Radio	•	•	0	•	•	•	•
7 Series	E38	Body	RCC Radio-clock module	•	0	0	0	•	0	0
7 Series	E38	Body	SES Language-input system	•	•	0	•	0	•	0
7 Series	E38	Body	SHD Sliding/tilting sunroof	•	•	0	•	•	•	•
7 Series	E38	Body	SM/LSM Seat/steering-column memory	0	0	0	0	•	•	0
7 Series	E38	Body	SMB passenger seat memory	•	•	0	•	•		0
7 Series	E38	Body	STH park heating	•	•	0	•	•	•	0
7 Series	E38	Body	SZM Switching centre, centre console	•	•	0	•	•	•	•
7 Series	E38	Body	TEL Telephone interface	0	0	0	0	•	•	0
7 Series	E38	Body	URS Rollover sensor	•	•	0	•	•	0	0
7 Series	E38	Body	VID Video module	•	•	0	•	0	0	0
7 Series	E38	Body	VID Video module III	•	•	0	•	0	0	0
7 Series	E38	Body	ZKE Central body electronics	•	•	0	•	•	•	0
7 Series	E38	Chassis	ABS/ASC/DSC Dynamic Stability Control	•	•	0	•	•	•	•
7 Series	E38	Chassis	EDC Damper Control	•	•	0	•	•	•	•
7 Series	E38	Chassis	LEW Steering-angle sensor	•	•	0	•	•	0	0
7 Series	E38	Chassis	MFL Multi-function steering wheel	•	•	Ö	•	•	0	0
7 Series	E38	Chassis	RDC Tyre pressure control	•	•	0	•	•	•	•
7 Series	E38	Chassis	RDW tyre-blowout warning	•	•	0	•	•	0	0
7 Series	E38	Drive	DME/DDE (Engine Electronics)	•	•	0	•	•	•	•
7 Series	E38	Drive	EGS/AGS(Transmission Control)	•	•	0	•	•	•	•
7 Series	E38	Drive	EML Electronic engine-power control	•	•	0	•	0	0	0
7 Series	E38	Drive	EWS Vehicle immobilizer	•	•	0	•	•	•	0
7 Series	E38	Drive	TRS Electronic battery isolator switch	•	•	0	•	0	0	0
7 Series	E65	Body	AHL Adaptive directional headlights	•	•	•	•	•	•	•
7 Series	E65	Body	AHM Trailer module	•	•	•	•	•	•	•
7 Series	E65	Body	AMP Amplifier	•	•	•	•	•	•	•
7 Series	E65	Body	ANT Aerial/antenna tuner	•	•	•	•	•	•	•
7 Series	E65	Body	ASK Audio system controller	•	•	•	•	•	•	•
7 Series	E65	Body	BZM Control centre, centre console	•	•	•	•	•	•	•
7 Series	E65	Body	CA Comfort access system	•	•	•	•	•	0	•
7 Series	E65	Body	CAN communication analysis	•	•		0	0	0	0
7 Series	E65	Body	CD Control Display	•	•		Ĕ	0	<u> </u>	•
7 Series	E65	Body	CDC CD Changer	•	•			0	•	•
7 Series	E65	Body	CD-GW Control Display(Gateway)					•		•
7 Series	E65	Body	CEM Clean Energy Module					•	0	0
7 Series	E65	Body	CNAV Navigation system, China			•				
1 periez	003	роцу	TOTAL MANIGACION SYSTEM, ONINA							

Series	Model Series	Part	Systems	Ecu Info.	Read DTC	Freeze Frame	Erase DTC	Live Data	Component activation	Physical HW
7 Series	E65	Body	CON Controller	•	•	•	•	•	•	•
7 Series	E65	Body	DAB Digital tuner	•	•	•	•	•	•	•
7 Series	E65	Body	DVDC DVD Changer	•	•	•	•	0	•	•
7 Series	E65	Body	DWA anti-theft alarm system	•	•	•	•	•	•	•
7 Series	E65	Body	FBI Flexible Bus Interface	•	•	•	•	•	0	•
7 Series	E65	Body	FBZM Rear compartment, control centre, centre console	•	•	•	•	•	•	•
7 Series	E65	Body	FCON Rear compartment controller	•	•	•	•	•	•	•
7 Series	E65	Body	FD Rear-compartment display	•	•	•	•	•	•	•
7 Series	E65	Body	FKA Rear heater/air conditioning	•	•	•	•	•	•	•
7 Series	E65	Body	FLA High Beam Assist	•	•	•	•	•	•	•
7 Series	E65	Body	HKL Rear-lid lift	•	•	•	•	•	•	•
7 Series	E65	Body	IBOC Digital tuner US	•	•	•	•	•	0	•
7 Series	E65	Body	IHKA Heater/automatic A/C control	•				•	•	
7 Series	E65	Body	INSTR Instrument cluster	•				•	•	
7 Series	E65	Body	JBIT Japan Basis Interface Telephone	•	0	0	0	•	0	0
7 Series	E65	Body	JNAV Navigation system, Japan	-						
7 Series	E65	Body	KHI Headset interface							
7 Series	E65	Body	KNAV Navigation system, Korea							
	E65	Body	LM Lights Module	•						
7 Series	E65	Body		-						
7 Series 7 Series	E65	Body	LM2 Light module 2 LM2 Light module 2 with adaptive headlight	•						
7 Series	E65	Body	LM2 AHL2 Light module 2 with adaptive	•	•	•	•	•	•	•
7.0.	DCE	D 1	headlight 2							
7 Series	E65	Body	MOST system analysis	•	•	•	•	0	0	0
7 Series	E65	Body	NAJ Navigation computer, Japan	•	•	•	•	•	•	0
7 Series	E65	Body	NAV Navigation computer	•	•	•	•	•	•	0
7 Series	E65	Body	NVE Night Vision Electronics	•	•	•	•	•	•	•
7 Series	E65	Body	NVK Night Vision camera	•	•	•	•	•	•	•
7 Series	E65	Body	PDC Park distance control		•	•	•	•	•	•
7 Series	E65	Body	PM Power Module	•	•	•	•	•	•	•
7 Series	E65	Body	RLS Rain/Light Sensor	•	•	•	•	•	0	•
7 Series	E65	Body	SASL Satellite, A-pillar, left	•	•	•	•	•	0	•
7 Series	E65	Body	SASR Satellite, A-pillar, right	•	•	•	•	•	0	•
7 Series	E65	Body	SBSL Satellite, B-pillar, left	•	•	•	•	•	0	•
7 Series	E65	Body	SBSR Satellite, B-pillar, right	•	•	•	•	•	•	•
7 Series	E65	Body	SDARS Satellite tuner	•	•	•	•	•	•	•
7 Series	E65	Body	SEC2 Supplementary control unit 2	•	•	•	•	•	•	•
7 Series	E65	Body	SFZ Satellite vehicle centre	•	•	•	•	•	0	•
7 Series	E65	Body	SG-FD Control unit, rear-compartment display	•	•	•	•	0	•	•
7 Series	E65	Body	SG-FD-GW Control unit, rear-compartment display(gateway)	•	•	•	•	•	•	•

Series	Model Series	Part	Systems	Ecu Info.	Read DTC	Freeze Frame	Erase DTC	Live Data	Component activation	Physical HW
7 Series	E65	Body	SGM-SIM Safety and Gateway Module(SIM)		•	•	•	•	•	•
7 Series	E65	Body	SGM-ZGM Safety and Gateway Module(ZGM)		•	•	•	0	0	•
7 Series	E65	Body	SHD Slide/tilt sunroof 2							
7 Series	E65	Body	SHD Sliding/tilting sunroof	•	•	•	•	•	•	•
7 Series	E65	Body	SHZH Independent/auxiliary heater	•	•	•	•	•	•	•
7 Series	E65	Body	SIM Safety and Information Module	•	•	•	•	•	•	0
7 Series	E65	Body	SINE Siren and tilt sensor	•	•	•	•	•	0	0
7 Series	E65	Body	SMBF Seat module, passenger	•	•	•	•	•	•	•
7 Series	E65	Body	SMBFH Seat module, passenger's side, rear	•	•	•	•	•	•	•
7 Series	E65	Body	SMFA Seat module, driver	•	•	•	•	•	•	•
7 Series	E65	Body	SMFAH Seat module, driver's side, rear	•	•	•	•	•	•	•
7 Series	E65	Body	SSBF Satellite, seat, passenger	•	•	•	•	•	0	•
7 Series	E65	Body	SSFA Satellite, seat, driver	•	•	•	•	•	0	•
7 Series	E65	Body	SSH Satellite, seat, rear	•	•	•	•	•	•	•
7 Series	E65	Body	STVL Satellite, door, front left	•	•	•	•	•	0	•
7 Series	E65	Body	STVR Satellite, door, front right	•	•	•	•	•	0	•
7 Series	E65	Body	SVS Language processing system				•	0	•	•
7 Series	E65	Body	SZL Switch centre, steering column	•				•	•	
7 Series	E65	Body	TCU Telematic control unit							
7 Series	E65	Body	TEL Telephone interface	0	0	0	0	•		0
7 Series	E65	Body	TEL Telephone (USA)					0	•	
7 Series	E65	Body	TMBFH Door module, passenger's side, rear	•				•	0	
7 Series	E65	Body	TMBFT Door module, passenger door	•				•	0	
7 Series	E65	Body	TMFAH Door module, driver's side, rear	•				•	0	
7 Series	E65	Body	TMFAT Door module, driver's door					•	0	
7 Series	E65	Body	VM Video Module					•		
7 Series	E65	Body	WIM Wiper module	•				•		
7 Series	E65	Body	ZBM Two-battery management							
7 Series	E65	Body	ZGM Central Gateway Module					0	0	
7 Series	E65	Chassis	ABS/ASC/DSC Dynamic Stability Control							
7 Series	E65	Chassis	ACC Active Cruise Control					0	0	
7 Series	E65	Chassis	ACC2 Active Cruise Control 2					0	0	
	E65									
7 Series	E65	Chassis	ARS Dynamic Drive							
7 Series			ARS Dynamic Drive 2			—				
7 Series	E65 E65		CIM Chassis Integration Module	•	•	•	•	•	•	•
7 Series	E65	Chassis	CIM2 Chassis Integration Module 2		•				•	•
7 Series		Chassis	EDC Damper Control	_						
7 Series	E65	Chassis	EHC Electronic Ride-Height Control	•	•			•	•	•
7 Series	E65	Chassis	EMF Parking brake	•	•			•	•	•
7 Series	E65	Chassis	RDC Tyre pressure control	•	•	—	•	•	•	•
7 Series	E65	Drive	CAS Car Access System	•	•	•	•	•	•	•
7 Series	E65	Drive	DME/DDE(Engine Electronics)	•	•	•	•	•	•	•
7 Series	E65	Drive	EGS/AGS(Transmission Control)	•	•	•	•	•	•	•
7 Series	E65	Drive	EKPS fuel-pump control			•				

Series	Model Series	Part	Systems	Ecu Info.	Read DTC	Freeze Frame	Erase DTC	Live Data	Component activation	Physical HW
7 Series	E65	Drive	HPFI control unit							
7 Series	E65	Drive	VTC Valvetronic		0	0	0	0	0	•
7 Series	E65	Drive	VTC2 Valvetronic 2	•	0	0	0	0	0	•
8 Series	E31	Drive	DME/DDE(Engine Electronics)	•	•	0	•	•	•	
8 Series	E31	Drive	EML(Engine-Power Control)	•	•	0	•	•	0	
8 Series	E31	Drive	EGS/AGS(Transmission Control)	•	•	0	•	•	•	
8 Series	E31	Body	KOM(Instrument cluster)	•	•	0	•			
8 Series	E31	Drive	EWS(Electronic car Immobilisation system)	•	•	0	•	•	0	
8 Series	E31	Drive	GSR(Cruise control)	•	•	0	•	•	0	
8 Series	E31	Body	AB(airbag)	•	•	0	•	•	0	
8 Series	E31	Body	SPM/SM(Seat/mirror memory)	•	•	0	•	•	0	
8 Series	E31	Body	IHK (Heater-A/C system)	•	•	0	•	•	0	
8 Series	E31	Chassis	ABS (Anti-lock braking system) \n ASC (Automatic stability control) \n ABD (Automatic brake differential (All-wheel drive)) \n DSC (Dynamic stability control ('94->))	•	•	0	•	•	•	
8 Series	E31	Chassis	DSC(Dynamic stability control)	•	•	0	•	•	0	
8 Series	E31	Body	ADS(Throttle-valve control)	•	•	0	•	•	0	
8 Series	E31	Chassis	ABS/ASC tester	•	•	0	•	•	0	
X3 Series	E83	Body	MRS/AB Airbag/ACSM	•	•	0	•	•	0	•
X3 Series	E83	Body	AHL Adaptive directional headlights	•	•	0	•	•	•	•
X3 Series	E83	Body	CDC CD Changer	•	•	0	•	0	•	•
X3 Series	E83	Body	CID Central information display	•	•	0	•	•	•	•
X3 Series	E83	Body	DSP Digital Sound Processor		•	0	•	•	0	0
X3 Series	E83	Body	GM base module	•	•	0	•	•	•	0
X3 Series	E83	Body	IHKA Heater/automatic A/C control	•	•	0	•	•	•	•
X3 Series	E83	Body	IHKR Heater and A/C control		•	0	•	•	•	•
X3 Series	E83	Body	INSTR Instrument cluster		•	0	•	•	•	•
X3 Series	E83	Body	JBIT Japan Basis Interface Telephone		0	0	0	•	0	0
X3 Series	E83	Body	LM Lights Module		•	0	•	•	•	•
X3 Series	E83	Body	LSZ Light switch centre II	•	•	0	•	•	•	0
X3 Series	E83	Body	MIR Multi-Information Radio		•	0	•	•	0	0
X3 Series	E83	Body	NAJ Navigation computer, Japan		•	0	•	•	•	0
X3 Series	E83	Body	NAV Navigation computer		•	0	•	•	•	0
X3 Series	E83	Body	PDC Park distance control		•	0	•	•	•	•
X3 Series	E83	Body	RAD Radio	•	•	0	•	•	•	•
X3 Series	E83	Body	RLS Rain/Light Sensor	•	•	0	•	•	0	•
X3 Series	E83	Body	SBBF Seat occupancy, passenger	•	•	0	•		0	0
X3 Series	E83	Body	SES Language-input system	•	•	0	•	0	•	0
X3 Series	E83	Body	SHD Sliding/tilting sunroof	•	•	0	•	•	•	•
X3 Series	E83	Body	SMF Seat memory, driver		•	0	•	•	•	0
X3 Series	E83	Body	SZM Switching centre, centre console	•	•	0	•	•	•	•

	E83			Info.	DTC	Frame	DTC	Data	activation	Physical HW
X3 Series		Body	TCU Telematic control unit	•	•	0	•	•	•	•
	E83	Body	ULF Universal charging and hands-free facility	•	•	0	•	•	•	•
X3 Series	E83	Body	VID Video module	•	•	0	•	0	0	0
X3 Series	E83	Chassis	ABS/ASC/DSC Dynamic Stability Control	•	•	0	•	•	•	•
X3 Series	E83	Chassis	LWS Steering angle sensor	•	•	0	•	•	0	0
X3 Series	E83	Chassis	MFL Multi-function steering wheel	•	•	0	•	•	0	0
	E83	Chassis	RDC Tyre pressure control	•	•	0	•	•	•	•
X3 Series	E83	Chassis	SVT Servotronic	•	•	0	•	•	0	0
	E83	Drive	DME/DDE(Engine Electronics)	•	•	0	•	•	•	•
X3 Series	E83	Drive	EGS/AGS(Transmission Control)	•	•	0	•	•	•	•
	E83	Drive	EKPS fuel-pump control	•	•	0	•	•	•	•
	E83	Drive	EWS Vehicle immobilizer	•	•	0	•	•	•	0
	E83	Drive	VTG Transfer case	•	•	0	•	•	•	•
	E53	Body	MRS/AB Airbag/ACSM	•	•	0	•	•	0	•
	E53	Body	AHL Adaptive directional headlights	•	•	0	•	•	•	•
	E53	Body	AIC Automatic Interval control	•	•	0	•	•	0	0
X5 Series	E53	Body	BIT Basis Interface Telephone	•	•	0	•	•	0	0
	E53	Body	BM On-board monitor	•	•	0	•	•	•	0
	E53	Body	DSP Digital Sound Processor	•	•	0	•	•	0	0
	E53	Body	IHKA Heater/automatic A/C control	•	•	0	•	•	•	•
	E53	Body	IHKR Heater and A/C control	•	•	0	•	•	•	•
	E53	Body	IKE Instrument-cluster electronics	•	•	0	•	0	0	0
	E53	Body	JBIT Japan Basis Interface Telephone	•	0	0	0	•	0	0
	E53	Body	KOM Instrument cluster	•	•	0	•	•	•	0
	E53	Body	LCM Light Check Module	•	•	0	•	•	•	0
	E53	Body	LCM Light Check Module IV	•	•	0	•	•	•	0
	E53	Body	LRA Automatic headlight vertical aim control	•	•	0	•	•	•	0
X5 Series	E53	Body	MID Multi Information Display	•	•	0	•	0	0	0
	E53	Body	NAJ Navigation computer, Japan	•	•	0	•	•	•	0
	E53	Body	NAV Navigation computer	•	•	0	•	•	•	0
	E53	Body	NAV Navigation computer MKII	•	•	0	•	•	0	0
	E53	Body	PDC Park distance control	•	•	0	•	•	•	•
	E53	Body	PDC2 Park Distance Control 2	•	•	0	•	•	•	0
	E53	Body	RAD Radio	•	•	0	•	•	•	•
	E53	Body	RLS Rain/Light Sensor	•	•	0	•	•	0	•
	E53	Body	SBBF Seat occupancy, passenger	•	•	0	•		0	0
	E53	Body	SES Language-input system	•	•	0	•	0	•	0
	E53	Body	SHD Sliding/tilting sunroof	•	•	0	•	•	•	•
	E53	Body	SM/SLM Seat/steering-column memory	•	•	0	•	•	•	0
	E53	Body	STH park heating	•	•	0	•	•	•	0
	E53	Body	SZM Switching centre, centre console	•	•	0	•	•	•	•
	E53	Body	TCU Telematic control unit	•	•	0	•	•	•	•

Series	Model Series	Part	Systems	Ecu Info.	Read DTC	Freeze Frame	Erase DTC	Live Data	Component activation	Physical HW
X5 Series	E53	Body	TEL Telephone interface	0	0	0	0	•	•	0
X5 Series	E53	Body	ULF Universal charging and hands-free facility	•	•	0	•	•	•	•
X5 Series	E53	Body	VID Video module	•	•	0	•	0	0	0
X5 Series	E53	Body	ZKE Central body electronics	•	•	0	•	•	•	0
X5 Series	E53	Chassis	ABS/ASC/DSC Dynamic Stability Control	•	•	0	•	•	•	•
X5 Series	E53	Chassis	EHC Electronic Ride-Height Control	•	•	0	•	•	•	•
X5 Series	E53	Chassis	EHC2 Electronic ride-level control							
X5 Series	E53	Chassis	LEW Steering-angle sensor	•	•	0	•	•	0	0
X5 Series	E53	Chassis	MFL Multi-function steering wheel	•	•	0	•	•	0	0
X5 Series	E53	Chassis	RDC Tyre pressure control	•	•	0	•	•	•	•
X5 Series	E53	Drive	DME/DDE (Engine Electronics)	•	•	0	•	•	•	•
X5 Series	E53	Drive	EGS/AGS (Transmission Control)	•	•	Ö	•	•	•	•
X5 Series	E53	Drive	EWS Vehicle immobilizer	•	•	0	•	•	•	0
X5 Series	E53	Drive	VTG Transfer case	•		0		•	•	•
X5 Series	E70	Body	MRS/AB Airbag/ACSM	•		•	•	•	0	
X5 Series	E70	Body	AHM Trailer module					•		
X5 Series	E70	Body	AMPH Hi-Fi amplifier	 						
X5 Series	E70	Body	AMPT Top Hi-Fi amplifier	+ -						
X5 Series	E70	Body	CA Comfort access system						0	
X5 Series	E70	Body	CAN communication analysis	•			0	0	0	0
X5 Series	E70	Body	CCC-A Applications							
X5 Series	E70	Body	CCC-ANT Aerial tuner						•	•
X5 Series	E70	Body	CCC-ASK Audio system controller							
X5 Series	E70	Body	CCC-BO User interface							•
	E70							<u> </u>	•	•
X5 Series		Body	CCC-GW Gateway	•		•	_	•		
X5 Series	E70	Body	CDC CD Changer	•		•	•	0	•	•
X5 Series	E70	Body	CHAMP-BO User interface	•	•	•	•	•	•	•
X5 Series	E70	Body	CHAMP-GW Gateway	•	•	•	•	•	•	•
X5 Series	E70	Body	CID Central information display	•	•	•	•	•	•	•
X5 Series	E70	Body	CNAV Navigation system, China	•	•	•	•	•	•	•
X5 Series	E70	Body	CON Controller	•	•	•	•	•	•	•
X5 Series	E70	Body	DAB Digital tuner	•	•	•	•	•	•	•
X5 Series	E70	Body	DVDC DVD Changer	•		•		0	-	•
X5 Series	E70	Body	FD Rear-compartment display	•	•	•	•	•	•	•
X5 Series	E70	Body	FKA Rear heater/air conditioning	•	•	•	•	•	•	•
X5 Series	E70	Body	FLA High Beam Assist	•	•	•	•	•	•	•
X5 Series	E70	Body	FRM2 footwell module 2	•	•	•	•	•	•	•
X5 Series	E70	Body	FZD Function centre, roof	•	•	•	•	•	•	•
X5 Series	E70	Body	HKL Rear-lid lift	•	•	•	•	•	•	•
X5 Series	E70	Body	HUD Head-Up Display	•	•	•	•	•	•	•
X5 Series	E70	Body	IBOC Digital tuner US	•	•	•	•	•	0	•
X5 Series	E70	Body	IHKA Heater/automatic A/C control	•	•	•	•	•	•	•
X5 Series	E70	Body	INSTR Instrument cluster	•	•	•	•	•	•	•

Series	Model Series	Part	Systems	Ecu Info.	Read DTC	Freeze Frame	Erase DTC	Live Data	Component activation	Physical HW
X5 Series	E70	Body	JBE2 Junction Box electronics	•	•	•	•	•	•	•
X5 Series	E70	Body	JNAV Navigation system, Japan	•	•	•	•	•	•	•
X5 Series	E70	Body	KHM Headphones module							
X5 Series	E70	Body	KNAV Navigation system, Korea	•	•	•	•	•	•	•
X5 Series	E70	Body	M-ASK-BO User interface	•	•	•	•	•	•	•
X5 Series	E70	Body	M-ASK-GW Gateway	•	•	•	•	•	•	•
X5 Series	E70	Body	MOST system analysis	•	•	•	•	0	0	0
X5 Series	E70	Body	PDC Park distance control	•	•	•	•	•	•	•
X5 Series	E70	Body	RFK Reversing camera	•	•	•	•	•	•	•
X5 Series	E70	Body	RLSS Rain/Light Solar Sensor	•	•	•	•	•	0	0
X5 Series	E70	Body	RSE Rear Seat Entertainment	•	•	•	•	•	•	•
X5 Series	E70	Body	SDARS Satellite tuner	•	•	•	•	•	•	•
X5 Series	E70	Body	SINE Siren and tilt sensor	•	•	•	•	•	0	0
X5 Series	E70	Body	SMBF Seat module, passenger	•	•	•	•	•	•	•
X5 Series	E70	Body	SMFA Seat module, driver	•	•	•	•	•	•	•
X5 Series	E70	Body	TCU Telematic control unit	•	•	•	•	•	•	•
X5 Series	E70	Body	ULF-SBX Interface box	•	•	•	•	•	•	•
X5 Series	E70	Body	ULF-SBX-H Interface box High	•	•	•	•	•	•	•
X5 Series	E70	Body	VM Video Module	•	•	•	•	•	•	•
X5 Series	E70	Body	VSW video switch	•	•	•	•	•	•	0
X5 Series	E70	Chassis	ABS/ASC/DSC Dynamic Stability Control	•	•	•	•	•	•	•
X5 Series	E70	Chassis	AL active front steering(AFS70)	•	•	•	•	•	0	•
X5 Series	E70	Chassis	ARS Dynamic Drive	•	•	•	•	•	•	•
X5 Series	E70	Chassis	EDCSHL Damper satellite, rear left	•	•	•	•	•	•	•
X5 Series	E70	Chassis	EDCSHR Damper satellite, rear right	•	•	•	•	•	•	•
X5 Series	E70	Chassis	EDCSVL Damper satellite, front left	•	•	•	•	•	•	•
X5 Series	E70	Chassis	EDCSVR Damper satellite, front right	•	•	•	•	•	•	•
X5 Series	E70	Chassis	EHC Electronic Ride-Height Control	•	•	•	•	•	•	•
X5 Series	E70	Chassis	EMF Parking brake	•	•	•	•	•	•	•
X5 Series	E70	Chassis	RDC Tyre pressure control	•	•	•	•	•	•	•
X5 Series	E70	Chassis	VDM Vertical Dynamics Management	•	•	•	•	•	•	•
X5 Series	E70	Drive	CAS Car Access System	•	•	•	•	•	•	•
X5 Series	E70	Drive	DME/DDE(Engine Electronics)	•	•	•	•	•	•	•
X5 Series	E70	Drive	EGS/AGS(Transmission Control)	•	•	•	•	•	•	•
X5 Series	E70	Drive	EKPS fuel-pump control	•	•	•	•	•	•	•
X5 Series	E70	Drive	GWS Gear selector switch	•	•	•	•	•	•	•
X5 Series	E70	Drive	VTC Valvetronic	•	0	0	0	0	0	•
X5 Series	E70	Drive	VTC2 Valvetronic 2	•	0	Ö	0	0	0	•
X5 Series	E70	Drive	VTG Transfer case	•	•	•	•	•	•	•
X6 Series	E71	Body	MRS/AB Airbag/ACSM	•	•	•	•	•	0	•
X6 Series	E71	Body	AHM Trailer module	•	•	•	•	•	•	•
X6 Series	E71	Body	AMPH Hi-Fi amplifier	•	•	•	•	•	•	•
X6 Series	E71	Body	AMPT Top Hi-Fi amplifier	•	•	•	•	•	•	•
X6 Series	E71	Body	CA Comfort access system	•	•	•	•	•	0	•
VO DELLES	гіт	роцу	on comport access system							

Series	Model Series	Part	Systems	Ecu Info.	Read DTC	Freeze Frame	Erase DTC	Live Data	Component activation	Physical HW
X6 Series	E71	Body	CAN communication analysis	•	•	•	0	0	0	0
X6 Series	E71	Body	CCC-A Applications	•	•	•	•	•	•	•
X6 Series	E71	Body	CCC-ANT Aerial tuner	•	•	•	•	•	•	•
X6 Series	E71	Body	CCC-ASK Audio system controller	•	•	•	•	•	•	•
X6 Series	E71	Body	CCC-BO User interface	•	•	•	•	•	•	•
X6 Series	E71	Body	CCC-GW Gateway	•	•	•	•	•	•	•
X6 Series	E71	Body	CDC CD Changer	•	•	•	•	0	•	•
X6 Series	E71	Body	CHAMP-BO User interface	•	•	•	•	•	•	•
X6 Series	E71	Body	CHAMP-GW Gateway	•	•	•	•	•	•	•
X6 Series	E71	Body	CID Central information display	•	•	•	•	•	•	•
X6 Series	E71	Body	CNAV Navigation system, China	•	•	•	•	•	•	•
X6 Series	E71	Body	CON Controller	•	•	•	•	•	•	•
X6 Series	E71	Body	DAB Digital tuner	•	•	•	•	•	•	•
X6 Series	E71	Body	DVDC DVD Changer	•	•	•	•	0	•	•
X6 Series	E71	Body	FD Rear-compartment display	•	•	•	•	•	•	•
X6 Series	E71	Body	FKA Rear heater/air conditioning	•	•	•	•	•	•	•
X6 Series	E71	Body	FLA High Beam Assist	•	•	•	•	•	•	•
X6 Series	E71	Body	FRM2 footwell module 2	•	•	•	•	•	•	•
X6 Series	E71	Body	FZD Function centre, roof	•	•	•	•	•	•	•
X6 Series	E71	Body	HKL Rear-lid lift	•	•	•	•	•	•	•
X6 Series	E71	Body	HUD Head-Up Display	•	•	•	•	•	•	•
X6 Series	E71	Body	IBOC Digital tuner US	•	•	•	•	•	0	•
X6 Series	E71	Body	IHKA Heater/automatic A/C control	•	•	•	•	•	•	•
X6 Series	E71	Body	INSTR Instrument cluster	•	•	•	•	•	•	•
X6 Series	E71	Body	JBE2 Junction Box electronics	•	•	•	•	•	•	•
X6 Series	E71	Body	JNAV Navigation system, Japan	•	•	•	•	•	•	•
X6 Series	E71	Body	KHM Headphones module							
X6 Series	E71	Body	KNAV Navigation system, Korea	•	•	•	•	•	•	•
X6 Series	E71	Body	M-ASK-BO User interface	•	•	•	•	•	•	•
X6 Series	E71	Body	M-ASK-GW Gateway	•	•	•	•	•	•	•
X6 Series	E71	Body	MOST system analysis	•	•	•	•	0	0	0
X6 Series	E71	Body	PDC Park distance control	•	•	•	•	•	•	•
X6 Series	E71	Body	RFK Reversing camera	•	•	•	•	•	•	•
X6 Series	E71	Body	RLSS Rain/Light Solar Sensor	•	•	•	•	•	0	0
X6 Series	E71	Body	RSE Rear Seat Entertainment	•	•	•	•	•	•	•
X6 Series	E71	Body	SDARS Satellite tuner	•	•	•	•	•	•	•
X6 Series	E71	Body	SINE Siren and tilt sensor	•	•	•	•	•	0	0
X6 Series	E71	Body	SMBF Seat module, passenger	•	•	•	•	•	•	•
X6 Series	E71	Body	SMFA Seat module, driver	•	•	•	•	•	•	•
X6 Series	E71	Body	TCU Telematic control unit	•	•	•	•	•	•	•
X6 Series	E71	Body	ULF-SBX Interface box	•	•	•	•	•	•	•
X6 Series	E71	Body	ULF-SBX-H Interface box High	•	•	•	•	•	•	•
X6 Series	E71	Body	VM Video Module	•	•	•	•	•	•	•
X6 Series	E71	Body	VSW video switch	•	•	•	•	•	•	0

R6 Series E71 Chassis ARS/ASC/DSC Dynamic Stability Control	0	•
X6 Series E71	•	•
R6 Series E71	•	
K6 Series E71 Chassis EDCSUR Damper satellite, rear right K6 Series E71 Chassis EDCSVL Damper satellite, front left K6 Series E71 Chassis EDCSVR Damper satellite, front right K6 Series E71 Chassis EMC Series Left (Chassis EMC Farking brake) K6 Series E71 Chassis EMF Parking brake K6 Series E71 Chassis RDC Tyre pressure control K6 Series E71 Chassis VDM Vertical Dynamics Management K6 Series E71 Chassis VDM Vertical Dynamics Management K6 Series E71 Drive CAS Car Access System K6 Series E71 Drive Drive EGS/AGS(Transmission Control) K6 Series E71 Drive EMS Gear selector switch K6 Series E71 Drive GWS Gear selector switch K6 Series E71 Drive WG Gear selector switch K6 Series E71 Drive WG Gear selector switch K6 Series E71 Drive WG Gear selector switch K7 Series E30 Drive Drive<		
X6 Series E71 Chassis EDCSVR Damper satellite, front left X6 Series E71 Chassis EDCSVR Damper satellite, front right X6 Series E71 Chassis EME Electronic Ride-Height Control X6 Series E71 Chassis EMF Parking brake X6 Series E71 Chassis ICM Integrated Chassis Management X6 Series E71 Chassis ICM Integrated Chassis Management X6 Series E71 Chassis VDM Vertical Dynamics Management X6 Series E71 Drive CAS Car Access System X6 Series E71 Drive CAS Car Access System X6 Series E71 Drive EKPS fuel-pump control X6 Series E71 Drive EKPS fuel-pump control X6 Series E71 Drive EKPS fuel-pump control X6 Series E71 Drive UTG Transfer case X7 Series E30 Drive DME/DDE(Engine Electronics) X7 Series E30 Drive EML(Engine Electronics) X8 Series E30 Drive EML(Engine Electronics) X8 Series E30 Body KOM(Instrument cluster) X8 Series E30 Body SPM/SM(Seat/mirror memory) X8 Series E30 Body SPM/SM(Seat/mirror memory) X8 Series E30 Body SPM/SM(Seat/mirror memory) X8 Series E30 Body IIIK(Illeater-A/C system) ABS(Anti-lock braking system)\n		•
X6 Series E71		•
X6 Series E71 Chassis EMC Electronic Ride-Height Control X6 Series E71 Chassis EMF Parking brake X6 Series E71 Chassis ICM Integrated Chassis Management X6 Series E71 Chassis RDC Tyre pressure control X6 Series E71 Chassis Wertical Dynamics Management X6 Series E71 Drive CAS Car Access System X6 Series E71 Drive Drive DME/DDE (Engine Electronics) X6 Series E71 Drive EGS/AGS (Transmission Control) X6 Series E71 Drive EKPS fuel-pump control X6 Series E71 Drive EKPS fuel-pump control X6 Series E71 Drive GWS Gear selector switch X6 Series E71 Drive GWS Gear selector switch X6 Series E71 Drive WTG Transfer case Z Series E30 Drive VTG Transfer case Z Series E30 Drive EMC(Engine Electronics) O Z Series E30 Drive EMS/ASS (Transmission Control) O	•	•
K6 Series E71 Chassis EHC Electronic Ride-Height Control Image: Chassis EMF Parking brake Image: Chassis EMF Parking brake Parking brake Image: Chassis EMF Parking brake Image: Chassis EMF Parking brake Image: Chassis EMF Parking brake </td <td>•</td> <td>•</td>	•	•
X6 Series E71	•	•
X6 Series	•	•
X6 Series E71 Chassis VDM Vertical Dynamics Management ●	0	0
X6 Series E71 Chassis VDM Vertical Dynamics Management ●	•	•
X6 Series E71 Drive CAS Car Access System ●	•	•
X6 Series E71 Drive DME/DDE (Engine Electronics) ● <td>•</td> <td>•</td>	•	•
X6 Series E71 Drive EGS/AGS(Transmission Control) ●	•	•
X6 Series E71 Drive EKPS fuel-pump control • • • • • • • • • • • • • • • • • • •	•	•
X6 Series E71 Drive GWS Gear selector switch • • • • • • • • • • • • • • • • • • •	•	•
X6 Series E71 Drive QMVH Lateral-moment distribution, rear axle X6 Series E71 Drive VTG Transfer case Z Series E30 Drive DME/DDE(Engine Electronics) Z Series E30 Drive EML(Engine-Power Control) Z Series E30 Drive EGS/AGS(Transmission Control) Z Series E30 Body KOM(Instrument cluster) Z Series E30 Drive EWS(Electronic car Immobilisation system) Z Series E30 Body AB(airbag) Z Series E30 Body SPM/SM(Seat/mirror memory) Z Series E30 Body IHK(Heater-A/C system) ABS(Anti-lock braking system)\n ABS(Anti-lock braking system)\n ABS(Automatic stability control)\n	•	
Z Series E30 Drive DME/DDE (Engine Electronics) ●<	•	•
Z Series E30 Drive DME/DDE(Engine Electronics) ● </td <td>•</td> <td>•</td>	•	•
Z Series E30 Drive EML(Engine-Power Control) ●	•	
Z Series E30 Drive EGS/AGS (Transmission Control) ● <td>0</td> <td></td>	0	
Z Series E30 Body KOM(Instrument cluster) ● ● ● ● ● ■	•	
Z Series E30 Drive EWS(Electronic car Immobilisation system) ●		
Z Series E30 Body AB(airbag) ● ● ● ● ● ■	0	
Z Series E30 Body AB(airbag) ●	0	
Z Series E30 Body SPM/SM(Seat/mirror memory) ●	0	
Z Series E30 Body IHK(Heater-A/C system) • • • • • • • • • • • • • • • • • • •	0	
ABS (Anti-lock braking system) \n ASC (Automatic stability control) \n	0	
drive))\n DSC(Dynamic stability control('94->))	•	
Z Series E30 Chassis DSC(Dynamic stability control) • O • O	0	
Z Series E30 Body ADS(Throttle-valve control) • • O •	0	
Z Series E30 Chassis ABS/ASC tester • O •	0	
Z3 Series E36 Body MRS/AB Airbag/ACSM • O •	0	•
Z3 Series E36 Body IR Radio/infrared locking system	1	
Z3 Series E36 Body KOM Instrument cluster • O •	•	0
Z3 Series E36 Body ZKE Central body electronics • O •	•	0
Z3 Series E36 Chassis ABS/ASC/DSC Dynamic Stability Control • O •	•	•
Z3 Series E36 Chassis LEW Steering-angle sensor • O •	0	0

Series	Model Series	Part	Systems	Ecu Info.	Read DTC	Freeze Frame	Erase DTC	Live Data	Component activation	Physical HW
Z3 Series	E36	Drive	DME/DDE(Engine Electronics)		•	0	•	•	•	•
Z3 Series	E36	Drive	EGS/AGS(Transmission Control)	•	•	0	•	•	•	•
Z3 Series	E36	Drive	EWS Vehicle immobilizer	•	•	0	•	•	•	0
Z3 Series	E36	Drive	GR Cruise control	•	•	0	•	•	•	0
Z3 Series	E36	Drive	TOENS Thermal oil-level sensor	•	•	0	•	•	•	0
Z4 Series	E85/E86	Body	MRS/AB Airbag/ACSM	•	•	0	•	•	0	•
Z4 Series	E85/E86	Body	CDC CD Changer	•	•	0	•	0	•	•
Z4 Series	E85/E86	Body	CID Central information display	•	•	0	•	•	•	•
Z4 Series	E85/E86	Body	CVM/CVM2 Convertible top module	•	•	0	•	•	•	•
Z4 Series	E85/E86	Body	DSP Digital Sound Processor	•	•	0	•	•	0	0
Z4 Series	E85/E86	Body	GM5 General module 5	•	•	0	•	•	•	0
Z4 Series	E85/E86	Body	IHKA Heater/automatic A/C control	•	•	0	•	•	•	•
Z4 Series	E85/E86	Body	IHKS Integrated heating/air-conditioning control	•	•	0	•	•	•	•
Z4 Series	E85/E86	Body	INSTR Instrument cluster	•	•	0	•	•	•	•
Z4 Series	E85/E86	Body	LSZ Light switch centre II	•	•	0	•	•	•	0
Z4 Series	E85/E86	Body	MIR Multi-Information Radio	•	•	0	•	•	0	0
Z4 Series	E85/E86	Body	NAJ Navigation computer, Japan	•	•	0	•	•	•	0
Z4 Series	E85/E86	Body	NAV Navigation computer	•	•	0	•	•	•	0
Z4 Series	E85/E86	Body	PDC Park distance control	•	•	0	•	•	•	•
Z4 Series	E85/E86	Body	RAD Radio	•		0	•	•	•	•
Z4 Series	E85/E86	Body	RLS Rain/Light Sensor	•		0	•	•	0	•
Z4 Series	E85/E86	Body	SBBF Seat occupancy, passenger	•		0	•	 	0	0
Z4 Series	E85/E86	Body	SBSL Satellite, B-pillar, left	•		0		•	0	•
Z4 Series	E85/E86	Body	SBSR Satellite, B-pillar, right	•		0		•	•	•
Z4 Series	E85/E86	Body	SES Language-input system	•	•	0	•	0	•	0
Z4 Series	E85/E86	Body	SIM Safety and Information Module	•		0		•	•	0
Z4 Series	E85/E86	Body	SMF Seat memory, driver	•		0		•	•	0
Z4 Series	E85/E86	Body	STVL Satellite, door, front left	•		0	•	•	0	•
Z4 Series	E85/E86	Body	STVR Satellite, door, front right	•		0	•	•	0	•
Z4 Series	E85/E86	Body	SZM Switching centre, centre console	•		0	•	•	•	•
Z4 Series	E85/E86	Body	TCU Telematic control unit	•	•	0	•	•	•	•
Z4 Series	E85/E86	Body	ULF Universal charging and hands-free facility	•	•	0	•	•	•	•
Z4 Series	E85/E86	Body	VID Video module	•	•	0		0	0	0
Z4 Series	E85/E86	Chassis	ABS/ASC/DSC Dynamic Stability Control	•		0		•	•	•
Z4 Series	E85/E86	Chassis	EPS Electronic Power Steering	•	•	0		•	•	•
Z4 Series	E85/E86	Chassis	LWS Steering angle sensor	•		0			0	0
Z4 Series	E85/E86	Chassis	MFL Multi-function steering wheel	•		0		•	0	0
Z4 Series	E85/E86	Chassis	RDC Tyre pressure control	•	•	0		•		•
Z4 Series	E85/E86	Drive	DME/DDE(Engine Electronics)	•		0		•		
Z4 Series	E85/E86	Drive	EGS/AGS(Transmission Control)	•		0				•
Z4 Series	E85/E86	Drive	EKPS fuel-pump control			0				
Z4 Series	E85/E86	Drive	EWS Vehicle immobilizer			0			•	0
71 DELLES	E00/ E00	חדדוה	Trun tentere immonitivei						· •	J

D=0		Systems	Info.	DTC	Frame	DTC	Data	Component activation	Physical HW
E52	Body	MRS/AB Airbag/ACSM	•	•	0	•	•	0	•
E52	Body	BIT Basis Interface Telephone	•	•	0	•	•	0	0
E52	Body	CVM/CVM2 Convertible top module	•	•	0	•	•	•	•
E52	Body	DSP Digital Sound Processor	•	•	0	•	•	0	0
E52	Body	GM base module	•	•	0	•	•	•	0
E52	Body	IHKS Integrated heating/air-conditioning control	•	•	0	•	•	•	•
E52	Body	KOM Instrument cluster	•	•	0	•	•	•	0
E52	Body	LCM Light Check Module	•	•	0	•	•	•	0
E52	Body	LCM Light Check Module IV	•	•	0	•	•	•	0
E52	Body	LRA Automatic headlight vertical aim control	•	•	0	•	•	•	0
E52	Body	MIR Multi-Information Radio	•	•	0	•	•	0	0
E52	Body	NAV Navigation computer MKII	•	•	0	•	•	0	0
E52	Body		•	•	0	•	•	0	0
E52	Body	RAD Radio	•	•	0	•	•	•	•
E52	Body	TEL Telephone interface	0	0	0	0	•	•	0
E52	Chassis		•	•	0	•	•	•	•
			•	•	0	•	•	0	0
			•	•	0	•	•		0
			•	•	0	•	•	0	0
E52			•	•	0	•	•	•	•
E52	Drive	EGS/AGS (Transmission Control)	•	•	0	•	•	•	•
E52	Drive	EWS Vehicle immobilizer	•	•	0	•	•	•	0
			•	•	•	•	•	•	•
	Drive		•	•	•	•	•	•	•
Z4 E89	Drive	DME/DDE(Engine Electronics)	•	•	•	•	•	•	•
			•	•	•	•	•	•	•
Z4 E89	Drive		•	•	•	•	•	•	•
	Drive	GWS Gear selector switch	•	•	•	•	•	•	•
			•	•	•	•	•	•	•
			•	•	•	•	•	•	•
			•	•	•	•	•	•	•
			•	•	•	•	•	•	•
			•	•	•	•	•	•	•
Z4 E89	Body		•	•	•	•	•	•	•
			•	•	•	•	•	0	•
			•	•	•	0	0		0
	_		•	•	•	•		•	•
			•	•	•	•	•	•	•
			•	•	•	•		•	•
	_			•	•	•		•	•
	_		•	•	•	•	•	•	•
				•		•		•	•
	E52	E52 Body E52 Chassis E52 Chassis E52 Chassis E52 Chassis E52 Drive E52 Drive E52 Drive E52 Drive E4 E89 Drive E4 E89 Drive E4 E89 Drive E4 E89 Chassis E4 E89 Chassis E54 E89 Chassis E52 Drive Chassis E52 Drive Chassi	E52 Body CVM/CVM2 Convertible top module E52 Body GM base module E52 Body GM base module E52 Body INTESTINGENIES E52 Body KOM Instrument cluster E52 Body LCM Light Check Module IV E52 Body MIR Multi-Information Radio E52 Body NAV Navigation computer MKII E52 Body NAV Navigation computer MKII E52 Body RAD Radio E52 Body RAD Radio E52 Body TEL Telephone interface E52 Body TEL Telephone interface E52 Chassis DDS Deflation Detection System E52 Chassis LEW Steering-angle sensor E52 Chassis LEW Steering-angle sensor E52 Drive EGS/AGS (Transmission Control) E52 Drive EGS/AGS (Transmission Control) E52 Drive EWS Vehicle immobilizer E4 E89 Drive DME (Transmission Control) E54 E89 Drive EGS/AGS (Transmission Control) E55 Drive EMS Telluth gearbox E4 E89 Drive EGS/AGS (Transmission Control) E4 E89 Drive EGS/AGS (Transmission Control) E4 E89 Drive EGS/AGS (Transmission Control) E4 E89 Drive EMS Fuel-pump control E4 E89 Drive EMS Fuel-pump control E4 E89 Drive EMS Gear selector switch EA E89 Chassis EDC Damper Control E4 E89 Chassis EDC Damper Control E52 EDC Damper Control E53 EDC Damper Control E54 E89 Chassis EDC Damper Control E55 EDC Damper Control E56 EDC Damper Control E57 EDC CDC CDC CDC CDC CDC CDC CDC CDC CDC	E52 Body CVM/CVM2 Convertible top module E52 Body DSP Digital Sound Processor ■ E52 Body GM base module E52 Body HKKS Integrated heating/air-conditioning control E52 Body KOM Instrument cluster E52 Body LCM Light Check Module E52 Body LCM Light Check Module IV E52 Body LCM Light Check Module IV E52 Body LCM Light Check Module IV E52 Body MIR Multi-Information Radio E52 Body NAV Navigation computer MKII ■ E52 Body NAV Navigation computer MKII ■ E52 Body NAV Navigation computer MKII ■ E52 Body RAD Radio E52 Body RAD Radio ■ E52 Chassis BDS Deflation Detection System ■ E52 Chassis ELV Electronic steering-column locking ■ E52 Chassis ELV Electronic steering-column locking ■ E52 Chassis ELV Electronic steering-column locking ■ E52 Drive BGS/AGS (Transmission Control) ■ E52 Drive BGS/AGS (Transmission Control) ■ E52 Drive BGS/AGS (Transmission Control) ■ E52 Drive BKS Vehicle immobilizer ■ E489 Drive DKG Twin-clutch gearbox ■ A4 E89 Drive DKG Twin-clutch gearbox ■ A4 E89 Drive BGS/AGS (Transmission Control) ■ E64 E89 Drive BGS/AGS (Transmission Control) ■ E65 A4 E89 Drive BGS/AGS (Transmission Control) ■ E44 E89 Chassis BMF Parking brake ■ E489 Body CNAV Navigation analysis ■ E489 Body CN	E52 Body DSP Digital Sound Processor E52 Body GM base module E52 Body GM base module E52 Body Control E52 Body KM Instrument cluster E52 Body LCM Light Check Module E52 Body LCM Light Check Module E52 Body LCM Light Check Module IV E52 Body LCM Light Check Module IV E52 Body MR Multi-Information Radio E52 Body NAV Navigation computer MKIII E52 Body NAV Navigation computer MKIII E52 Body NAV Navigation computer MKIII E52 Body TEL Telephone interface E52 Body TEL Telephone interface E52 Chassis ABS/ASC/DSC Dynamic Stability Control E52 Chassis LEW Steering-angle sensor E52 Chassis LEW Steering-angle sensor E52 Brive ES/AGS (Transmission Control) E52 Brive ES/AGS (Transmission Control) E52 Brive DKG Twin-clutch gearbox Z4 E89 Drive DMG DPDE Gengine Electronics) E4 E89 Chassis ABS/ASC/DSC Dynamic Stability Control EAS Sear Access System DF DF DF CMS Vehicle immobilizer E54 Bes Drive DMG Sear Selector switch EAS Drive EWS Vehicle immobilizer E55 Brive DNG Twin-clutch gearbox EAT E89 Drive DMG Sear selector switch EAS Chassis BDC Damper Control EAS Chassis BDC Damper Control EAS Chassis BDC Damper Control EAS Chassis BDC Chassis SED Damper Control EAS Chassis BDC Chassis SED Damper Control EAS Chassis BDC CAC Confort access system EAS BDC CAC CONFORT CONTROL CAC CONTROL CAC CONTROL CAC CAC CONTROL CAC CONTROL CAC CONTROL CAC CONTROL CAC CONTROL CAC CONTROL CAC CAC CONTROL CAC CONTROL CAC CAC CONTROL CAC CONTROL CAC CAC	E52	Bedy	Body	E82

Series	Model Series	Part	Systems	Ecu Info.	Read DTC	Freeze Frame	Erase DTC	Live Data	Component activation	Physical HW
Z Reihe	Z4_E89	Body	CTM Convertible-top module	•	•	•	•	•	•	•
Z Reihe	Z4_E89	Body	DAB Digital tuner	•	•	•	•	•	•	•
Z Reihe	Z4_E89	Body	DVDC DVD Changer	•	•	•	•	0	•	•
Z Reihe	Z4_E89	Body	DWA anti-theft alarm system	•	•	•	•	•	•	•
Z Reihe	Z4_E89	Body	FLA High Beam Assist	•	•	•	•	•	•	•
Z Reihe	Z4_E89	Body	FRM2 Footwell module 2	•	•	•	•	•	•	•
Z Reihe	Z4_E89	Body	FZD Function centre, roof	•	•	•	•	•	•	•
Z Reihe	Z4_E89	Body	IHKA Heater/automatic A/C control	•	•	•	•	•	•	•
Z Reihe	Z4_E89	Body	IHKR Heater and A/C control	•	•	•	•	•	•	•
Z Reihe	Z4_E89	Body	IHR Integrated heater control	•	•	•	•	•	•	•
Z Reihe	Z4 E89	Body	INSTR Instrument cluster	•	•	•	•	•	•	•
Z Reihe	Z4 E89	Body	JBE2 Junction Box electronics	•	•	•	•	•	•	•
Z Reihe	Z4 E89	Body	JNAV Navigation system, Japan	•	•	•	•	•	•	•
Z Reihe	Z4 E89	Body	KNAV Navigation system, Korea	•	•	•	•	•	•	•
Z Reihe	Z4_E89	Body	M-ASK-BO User interface	•	•	•	•	•	•	•
Z Reihe	Z4 E89	Body	M-ASK-BO User interface	•	•	•	•	•	•	•
Z Reihe	Z4_E89	Body	MOST system analysis	•	•	•	•	0	0	0
Z Reihe	Z4_E89	Body	MRS/AB Airbag/ACSM	•	•	•	•	•	0	•
Z Reihe	Z4 E89	Body	PDC Park Distance Control	•	•	•	•	•	•	•
Z Reihe	Z4_E89	Body	RAD Radio	•	•	•	•	•	•	•
Z Reihe	Z4 E89	Body	RAD2-BO User interface	•	•	•	•	•	•	•
Z Reihe	Z4 E89	Body	RAD2-GW Gateway	•	•	•	•	•	•	•
Z Reihe	Z4 E89	Body	RLSS Rain/light solar sensor	•	•	•	•	•	0	0
Z Reihe	Z4 E89	Body	SDARS Satellite tuner	•	•	•	•	•	•	•
Z Reihe	Z4 E89	Body	SINE Siren and tilt sensor	•	•	•	•	•	0	0
Z Reihe	Z4 E89	Body	SMFA Seat module, driver	•	•	•	•	•	•	•
Z Reihe	Z4_E89	Body	TCU Telematic Control Unit	•	•	•	•	•	•	•
Z Reihe	Z4_E89	Body	ULF Universal charging and hands-free facility	•	•	•	•	•	•	•
Z Reihe	Z4 E89	Body	ULF-SBX Interface box	•	•	•	•	•	•	•
Z Reihe	Z4_E89	Body	ULF-SBX-H Interface box High	•	•	•	•	•	•	•
Z Reihe	Z4 E89	Body	VM Video Module	•	•	•	•	•	•	•
1 Series	F20	Drive	DDE Diesel Electronics	•	•	•	•	•	•	0
1 Series	F20	Drive	DME Digital Motor Electronics	•	•	•	•	•	•	0
1 Series	F20	Drive	EGS transmission management	•	•	•	•	•	•	0
1 Series	F20	Drive	EKPS Fuel-pump control	•	•	•	•	•	•	0
1 Series	F20	Drive	GWS Gear selector switch	•	•	•	•	•	•	0
1 Series	F20	Chassis	DSC Dynamic Stability Control	•	•	•	•	•	•	0
1 Series	F20	Chassis	EPS Electronic Power Steering	•	•		•	•	•	0
1 Series	F20	Chassis	VDM Vertical Dynamics Management	•	•	•	•	•	•	0
1 Series	F20	Body	ACC Active Cruise Control	•	•		•	•	•	0
1 Series	F20	Body	ACSM Crash Safety Module	•	•	•	•	•	•	0
1 Series	F20	Body	AHM Trailer module						•	0
1 Series	F20	Body	AMPH Hi-Fi amplifier							0
1 DOLLES	1 40	Doug	TEMPTE TE CHIPTETTOE							\cup

Series	Model Series	Part	Systems	Ecu Info.	Read DTC	Freeze Frame	Erase DTC	Live Data	Component activation	Physical HW
1 Series	F20	Body	CBX-ECALL Combox emergency call	•	•	•	•	•	•	0
1 Series	F20	Body	CBX-MEDIA Combox Multimedia	•	•	•	•	•	•	0
1 Series	F20	Body	CIC Car Information Computer	•	•	•	•	•	•	0
1 Series	F20	Body	CID Central information display	•	•	•	•	•	•	0
1 Series	F20	Body	CON Controller	•	•	•	•	•	•	0
1 Series	F20	Body	DVDC DVD Changer	•	•	•	•	•	•	0
1 Series	F20	Body	FCON Rear compartment controller	•	•	•	•	•	•	0
1 Series	F20	Body	FEM Front electronic module	•	•	•	•	•	•	0
1 Series	F20	Body	FLA High Beam Assist	•	•	•	•	•	•	0
1 Series	F20	Body	FZD Function centre, roof	•	•	•	•	•	•	0
1 Series	F20	Body	ICM Integrated Chassis Management	•	•	•	•	•	•	0
1 Series	F20	Body	IHKA Integrated automatic heating/air conditioning	•	•	•	•	•	•	0
1 Series	F20	Body	INSTR Instrument cluster	•	•	•	•	•	•	0
1 Series	F20	Body	KAFAS Camera-based driver-assistance systems	•	•	•	•	•	•	0
1 Series	F20	Body	PDC Park distance control		•	•	•	•	•	0
1 Series	F20	Body	PMA Parking assistant						•	0
1 Series	F20	Body	RAD Radio						•	0
1 Series	F20	Body	REM Rear electronic module					•	•	0
1 Series	F20	Body	SMBF Seat module, passenger	•				•	•	0
1 Series	F20	Body	SMBFH Seat module, passenger's side, rear						•	0
1 Series	F20	Body	SMFA Seat module, driver							0
1 Series	F20	Body	SMFAH Seat module, driver's side, rear	•					•	0
1 Series	F20	Body	SWW Lane change warning						•	0
1 Series	F20	Body	TRSVC allround-view camera	•				•	•	0
1 Series	F20	Body	ZGM Central Gateway Control Module	•				•	•	0
3 Series	F30	Drive	DDE Diesel Electronics					•	•	0
3 Series	F30	Drive	DME Digital Motor Electronics	•				•		0
3 Series	F30	Drive	EGS transmission management					•	•	0
3 Series	F30	Drive	EKPS Fuel-pump control						•	0
3 Series	F30	Drive	GWS Gear selector switch					•	•	0
3 Series	F30	Chassis	DSC Dynamic Stability Control	•				•		0
3 Series	F30		EPS Electronic Power Steering							0
3 Series	F30		VDM Vertical Dynamics Management	•	•	•		•		0
3 Series	F30	Body	ACC Active Cruise Control							0
3 Series	F30	Body	ACSM Crash Safety Module	•	•			•	•	0
3 Series	F30	Body	AHM Trailer module	•				•		0
3 Series	F30	Body	AMPH Hi-Fi amplifier	•	•			•		0
3 Series	F30	Body	CBX-ECALL Combox emergency call	•	•			•		0
3 Series	F30	Body	CBX-MEDIA Combox Multimedia	•	•			•		0
3 Series	F30	Body	CID Central information display	•				•		0
3 Series	F30	Body	CON Controller					•		0
3 Series	F30	Body	DVDC DVD Changer			•			•	0
n periez	ī. οΛ	ьоцу	עוע סעוע וומוואָפו עייע סעוע	' 						\cup

Series	Model Series	Part	Systems	Ecu Info.	Read DTC	Freeze Frame	Erase DTC	Live Data	Component activation	Physical HW
3 Series	F30	Body	EMALI Electric-motor reel, left	•	•	•	•	•	•	0
3 Series	F30	Body	EMARE Electric-motor reel, right	•	•	•	•	•	•	0
3 Series	F30	Body	EME Electric machine electronics	•	•	•	•	•	•	0
3 Series	F30	Body	FCON Rear compartment controller	•	•	•	•	•	•	0
3 Series	F30	Body	FEM Front electronic module	•	•	•	•	•	•	0
3 Series	F30	Body	FLA High Beam Assist	•	•	•	•	•	•	0
3 Series	F30	Body	FZD Function centre, roof	•	•	•	•	•	•	0
3 Series	F30	Body	ICM Integrated Chassis Management	•	•	•	•	•	•	0
3 Series	F30	Body	IHKA Integrated automatic heating/air conditioning	•	•	•	•	•	•	0
3 Series	F30	Body	INSTR Instrument cluster	•	•	•	•	•	•	0
3 Series	F30	Body	KAFAS Camera-based driver-assistance systems	•	•	•	•	•	•	0
3 Series	F30	Body	PDC Park distance control	•	•	•	•	•	•	0
3 Series	F30	Body	PMA Parking assistant	•	•	•	•	•	•	0
3 Series	F30	Body	RAD Radio	•	•	•	•	•	•	0
3 Series	F30	Body	RDC Tyre pressure control	•	•	•	•	•	•	0
3 Series	F30	Body	REM Rear electronic module	•	•	•	•	•	•	0
3 Series	F30	Body	SMBF Seat module, passenger	•	•	•	•	•	•	0
3 Series	F30	Body	SMBFH Seat module, passenger's side, rear	•	•	•	•	•	•	0
3 Series	F30	Body	SME Accumulator-management electronics	•	•	•	•	•	•	0
3 Series	F30	Body	SMFA Seat module, driver	•	•	•	•	•	•	0
3 Series	F30	Body	SMFAH Seat module, driver's side, rear	•	•	•	•	•	•	0
3 Series	F30	Body	SWW Lane change warning	•	•	•	•	•	•	0
3 Series	F30	Body	SCR Selective Catalytic Reduction	•	•	•	•	•	•	0
3 Series	F30	Body	TRSVC allround-view camera	•	•	•	•	•	•	0
3 Series	F30	Body	VM Video Module	•	•	•	•	•	•	0
3 Series	F30	Body	ZGM Central Gateway Control Module	•	•	•	•	•	•	0
5 Series	F07	Drive	CAS Car Access System	•	•	•	•	•	•	0
5 Series	F07	Drive	DDE Diesel Electronics	•	•	•	•	•	•	0
5 Series	F07	Drive	DME Digital Motor Electronics	•	•	•	•	•	•	0
5 Series	F07	Drive	EGS transmission management	•	•	•	•	•	•	0
5 Series	F07	Drive	EKPS Fuel-pump control	•	•	•	•	•	•	0
5 Series	F07	Drive	GWS Gear selector switch	•	•	•	•	•	•	0
5 Series	F07		DSC Dynamic Stability Control	•	•	•	•	•	•	0
5 Series	F07	Chassis	EHC Electronic Ride-Height Control	•	•	•	•	•	•	0
5 Series	F07	Chassis	EMF Parking brake	•	•	•	•	•	•	0
5 Series	F07	Chassis	EPS Electronic Power Steering	•	•	•	•	•	•	0
5 Series	F07	Chassis	VDM Vertical Dynamics Management	•	•	•	•	•	•	0
5 Series	F07	Chassis	EDCSHL Damper satellite, rear left	•	•	•	•	•	•	0
5 Series	F07	Chassis	EDCSHR Damper satellite, rear right	•	•	•	•	•	•	0
5 Series	F07	Chassis	EDCSVL Damper satellite, front left	•	•	•	•	•	•	0
5 Series	F07	Chassis	EDCSVR Damper satellite, front right	•	•	•	•	•	•	0
5 Series	F07	Body	ACC Active Cruise Control	•	•	•	•	•	•	0

Series	Model Series	Part	Systems	Ecu Info.	Read DTC	Freeze Frame	Erase DTC	Live Data	Component activation	Physical HW
5 Series	F07	Body	ACSM Crash Safety Module	•	•	•	•	•	•	0
5 Series	F07	Body	AHM Trailer module	•	•	•	•	•	•	0
5 Series	F07	Body	AL active steering	•	•	•	•	•	•	0
5 Series	F07	Body	AMPT Top Hi-Fi amplifier	•	•	•	•	•	•	0
5 Series	F07	Body	CBX-ECALL Combox emergency call	•	•	•	•	•	•	0
5 Series	F07	Body	CID Central information display	•	•	•	•	•	•	0
5 Series	F07	Body	CON Controller	•	•	•	•	•	•	0
5 Series	F07	Body	DVDC DVD Changer	•	•	•	•	•	•	0
5 Series	F07	Body	EMALI Electric-motor reel, left	•	•	•	•	•	•	0
5 Series	F07	Body	EMARE Electric-motor reel, right	•	•	•	•	•	•	0
5 Series	F07	Body	FD Rear-compartment display	•	•	•	•	•	•	0
5 Series	F07	Body	FD2 Rear-compartment display 2	•	•	•	•	•	•	0
5 Series	F07	Body	FKA Rear heater/air conditioning	•	•	•	•	•	•	0
5 Series	F07	Body	FLA High Beam Assist	•	•	•	•	•	•	0
5 Series	F07	Body	FRM Footwell module	•	•	•	•	•	•	0
5 Series	F07	Body	FZD Function centre, roof	•	•	•	•	•	•	0
5 Series	F07	Body	HKL Rear-lid lift	•	•	•	•	•	•	0
5 Series	F07	Body	HSR Rear-axle slip-angle control	•	•	•	•	•	•	0
5 Series	F07	Body	HUD Head-Up Display	•	•	•	•	•	•	0
5 Series	F07	Body	ICM Integrated Chassis Management	•	•	•	•	•	•	0
5 Series	F07	Body	IHKA Integrated automatic heating/air conditioning	•	•	•	•	•	•	0
5 Series	F07	Body	JBE Junction-box electronics	•	•	•	•	•	•	0
5 Series	F07	Body	KAFAS Camera-based driver-assistance systems	•	•	•	•	•	•	0
5 Series	F07	Body	INSTR Instrument cluster	•	•	•	•	•	•	0
5 Series	F07	Body	NVE Night Vision Electronics	•	•	•	•	•	•	0
5 Series	F07	Body	PDC Park Distance Control	•	•	•	•	•	•	0
5 Series	F07	Body	RAD Radio	•	•	•	•	•	•	0
5 Series	F07	Body	RDC Tyre pressure control	•	•	•	•	•	•	0
5 Series	F07	Body	RSE Rear Seat Entertainment	•	•	•	•	•	•	0
5 Series	F07	Body	SMBF Seat module, passenger	•	•	•	•	•	•	0
5 Series	F07	Body	SMBFH Seat module, passenger's side, rear	•	•	•	•	•	•	0
5 Series	F07	Body	SMFA Seat module, driver	•	•	•	•	•	•	0
5 Series	F07	Body	SMFAH Seat module, driver's side, rear	•	•	•	•	•	•	0
5 Series	F07	Body	SVT Servotronic	•	•	•	•	•	•	0
5 Series	F07	Body	SWW Lane change warning	•	•	•	•	•	•	0
5 Series	F07	Body	SZL Switch centre, steering column	•	•	•	•	•	•	0
5 Series	F07	Body	TRSVC allround-view camera	•	•	•	•	•	•	0
5 Series	F07	Body	ULF-SBX Interface box	•	•	•	•	•	•	0
5 Series	F07	Body	ULF-SBX-H Interface box high	•	•	•	•	•	•	0
5 Series	F07	Body	VM Video Module	•	•	•	•	•	•	0
5 Series	F07	Body	VSW video switch	•	•	•	•	•	•	0
5 Series	F07	Body	VTG Transfer case	•	•	•	•	•	•	0

Series	Model Series	Part	Systems	Ecu Info.	Read DTC	Freeze Frame	Erase DTC	Live Data	Component activation	Physical HW
5 Series	F07	Body	ZGM Central Gateway Control Module	•	•	•	•	•	•	0
5 Series	F07	Body	SDARS Satellite tuner	•	•	•	•	•	•	0
5 Series	F10/F11	Drive	CAS Car Access System	•	•	•	•	•	•	0
5 Series	F10/F11	Drive	DDE Diesel Electronics	•	•	•	•	•	•	0
5 Series	F10/F11	Drive	DME Digital Motor Electronics	•	•	•	•	•	•	0
5 Series	F10/F11	Drive	DME Digital Motor Electronics 2	•	•	•	•	•	•	0
5 Series	F10/F11	Drive	EGS transmission management	•	•	•	•	•	•	0
5 Series	F10/F11	Drive	EKPS Fuel-pump control	•	•	•	•	•	•	0
5 Series	F10/F11	Drive	GWS Gear selector switch	•	•	•	•	•	•	0
5 Series	F10/F11	Chassis	AL active steering	•	•	•	•	•	•	0
5 Series	F10/F11	Chassis	DSC Dynamic Stability Control	•	•	•	•	•	•	0
5 Series	F10/F11	Chassis	EDCSHL Damper satellite, rear left	•	•	•	•	•	•	0
5 Series	F10/F11	Chassis	EDCSHR Damper satellite, rear right	•	•	•	•	•	•	0
5 Series	F10/F11	Chassis	EDCSVL Damper satellite, front left	•	•	•	•	•	•	0
5 Series	F10/F11	Chassis	EDCSVR Damper satellite, front right	•	•	•	•	•	•	0
5 Series	F10/F11	Chassis	EHC Electronic Ride-Height Control	•	•	•	•	•	•	0
5 Series	F10/F11	Chassis	EMF Parking brake	•	•	•	•	•	•	0
5 Series	F10/F11	Chassis	EPS Electronic Power Steering	•	•	•	•	•	•	0
5 Series	F10/F11	Chassis	ICM Integrated Chassis Management	•	•	•	•	•	•	0
5 Series	F10/F11	Chassis	VDM Vertical Dynamics Management	•	•	•	•	•	•	0
5 Series	F10/F11	Body	ACC Active Cruise Control	•	•	•	•	•	•	0
5 Series	F10/F11	Body	ACSM Crash Safety Module	•	•	•	•	•	•	0
5 Series	F10/F11	Body	AHM Trailer module	•	•	•	•	•	•	0
5 Series	F10/F11	Body	AMPT Top Hi-Fi amplifier	•	•	•	•	•	•	0
5 Series	F10/F11	Body	ASD Active Sound Design	•	•	•	•	•	•	0
5 Series	F10/F11	Body	CBX-ECALL Combox emergency call	•	•	•	•	•	•	0
5 Series	F10/F11	Body	CBX-MEDIA Combox Multimedia	•	•	•	•	•	•	0
5 Series	F10/F11	Body	CIC Car Information Computer	•	•	•	•	•	•	0
5 Series	F10/F11	Body	CID Central Information Display	•	•	•	•	•	•	0
5 Series	F10/F11	Body	CON Controller	•	•	•	•	•	•	0
5 Series	F10/F11	Body	DVDC DVD Changer	•	•	•	•	•	•	0
5 Series	F10/F11	Body	EMALI Electric-motor reel, left	•	•	•	•	•	•	0
5 Series	F10/F11	Body	EMARE Electric-motor reel, right	•	•	•	•	•	•	0
5 Series	F10/F11	Body	EME Electric machine electronics	•	•	•	•	•	•	0
5 Series	F10/F11	Body	FCON Rear compartment controller	•	•	•	•	•	•	0
5 Series	F10/F11	Body	FD Rear-compartment display	•	•	•	•	•	•	0
5 Series	F10/F11	Body	FD2 Rear-compartment display 2	•	•	•	•	•	•	0
5 Series	F10/F11	Body	FKA Rear heater/air conditioning	•	•	•	•	•	•	0
5 Series	F10/F11	Body	FLA High Beam Assist	•	•	•	•	•	•	0
5 Series	F10/F11	Body	FRM Footwell module	•	•	•	•	•	•	0
5 Series	F10/F11	Body	FZD Function centre, roof	•	•	•	•	•	•	0
5 Series	F10/F11	Body	GHAS Regulated differential lock	•	•	•	•	•	•	0
5 Series	F10/F11	Body	HKL Rear-lid lift	•	•	•	•	•	•	0

Series	Model Series	Part	Systems	Ecu Info.	Read DTC	Freeze Frame	Erase DTC	Live Data	Component activation	Physical HW
5 Series	F10/F11	Body	HKL Automatic luggage compartment lid actuation	•	•	•	•	•	•	0
5 Series	F10/F11	Body	HSR Rear-axle slip-angle control	•	•	•	•	•	•	0
5 Series	F10/F11	Body	HUD Head-Up Display	•	•	•	•	•	•	0
5 Series	F10/F11	Body	IHKA Integrated automatic heating/air conditioning	•	•	•	•	•	•	0
5 Series	F10/F11	Body	JBE Junction-box electronics	•	•	•	•	•	•	0
5 Series	F10/F11	Body	KAFAS Camera-based driver-assistance systems	•	•	•	•	•	•	0
5 Series	F10/F11	Body	INSTR Instrument cluster	•	•	•	•	•	•	0
5 Series	F10/F11	Body	NVE Night Vision Electronics	•	•	•	•	•	•	0
5 Series	F10/F11	Body	PDC Park Distance Control	•	•	•	•	•	•	0
5 Series	F10/F11	Body	PMA Parking assistant	•	•	•	•	•	•	0
5 Series	F10/F11	Body	RAD Radio	•	•	•	•	•	•	0
5 Series	F10/F11	Body	RDC Tyre pressure control	•	•	•	•	•	•	0
5 Series	F10/F11	Body	RSE Rear Seat Entertainment	•	•	•	•	•	•	0
5 Series	F10/F11	Body	SEC Supplementary control unit	•	•	•	•	•	•	0
5 Series	F10/F11	Body	SEC2 Supplementary control unit 2	•	•	•	•	•	•	0
5 Series	F10/F11	Body	SMBF Seat module, passenger	•	•	•	•	•	•	0
5 Series	F10/F11	Body	SMBFH Seat module, passenger's side, rear	•	•	•	•	•	•	0
5 Series	F10/F11	Body	SME Accumulator-management electronics	•	•	•	•	•	•	0
5 Series	F10/F11	Body	SMFA Seat module, driver	•	•	•	•	•	•	0
5 Series	F10/F11	Body	SMFAH Seat module, driver's side, rear	•	•	•	•	•	•	0
5 Series	F10/F11	Body	SVT Servotronic	•	•	•	•	•	•	0
5 Series	F10/F11	Body	SWW Lane change warning	•	•	•	•	•	•	0
5 Series	F10/F11	Body	SZL Switch centre, steering column	•	•	•	•	•	•	0
5 Series	F10/F11	Body	SCR Selective Catalytic Reduction	•	•	•	•	•	•	0
5 Series	F10/F11	Body	TRSVC allround-view camera	•	•	•	•	•	•	0
5 Series	F10/F11	Body	ULF-SBX Interface box	•	•	•	•	•	•	0
5 Series	F10/F11	Body	ULF-SBX-H Interface box high	•	•	•	•	•	•	0
5 Series	F10/F11	Body	VM Video Module	•	•	•	•	•	•	0
5 Series	F10/F11	Body	VSW video switch	•	•	•	•	•	•	0
5 Series	F10/F11	Body	VTG Transfer case	•	•	•	•	•	•	0
5 Series	F10/F11	Body	ZGM Central Gateway Control Module	•	•	•	•	•	•	0
5 Series	F10/F11	Body	SDARS Satellite tuner	•	•	•	•	•	•	0
5 Series	F18	Drive	CAS Car Access System	•	•	•	•	•	•	0
5 Series	F18	Drive	DME Digital Motor Electronics	•	•	•	•	•	•	0
5 Series	F18	Drive	EGS transmission management	•	•	•	•	•	•	0
5 Series	F18	Drive	EKPS Fuel-pump control	•	•	•	•	•	•	0
5 Series	F18	Drive	GWS Gear selector switch	•	•	•	•	•	•	0
5 Series	F18	Chassis	AL active steering	•	•	•	•	•	•	0
5 Series	F18	Chassis	DSC Dynamic Stability Control	•	•	•	•	•	•	0
5 Series	F18	Chassis	EDCSHL Damper satellite, rear left	•	•	•	•	•	•	0
5 Series	F18	Chassis	EDCSHR Damper satellite, rear right	•	•	•	•	•	•	0

Series	Model Series	Part	Systems	Ecu Info.	Read DTC	Freeze Frame	Erase DTC	Live Data	Component activation	Physical HW
5 Series	F18	Chassis	EDCSVL Damper satellite, front left	•	•	•	•	•	•	0
5 Series	F18	Chassis	EDCSVR Damper satellite, front right	•	•	•	•	•	•	0
5 Series	F18	Chassis	EHC Electronic Ride-Height Control	•	•	•	•	•	•	0
5 Series	F18	Chassis	EMF Parking brake	•	•	•	•	•	•	0
5 Series	F18	Chassis	EPS Electronic Power Steering	•	•	•	•	•	•	0
5 Series	F18	Chassis	ICM Integrated Chassis Management	•	•	•	•	•	•	0
5 Series	F18	Chassis	VDM Vertical Dynamics Management	•	•	•	•	•	•	0
5 Series	F18	Body	ACC Active Cruise Control	•	•	•	•	•	•	0
5 Series	F18	Body	ACSM Crash Safety Module	•	•	•	•	•	•	0
5 Series	F18	Body	AHM Trailer module	•	•	•	•	•	•	0
5 Series	F18	Body	AMPT Top Hi-Fi amplifier	•	•	•	•	•	•	0
5 Series	F18	Body	CBX-ECALL Combox emergency call	•	•	•	•	•	•	0
5 Series	F18	Body	CBX-MEDIA Combox Multimedia	•	•	•	•	•	•	0
5 Series	F18	Body	CID Central Information Display	•	•	•	•	•	•	0
5 Series	F18	Body	CON Controller	•	•	•	•	•	•	0
5 Series	F18	Body	DVDC DVD Changer	•	•	•	•	•	•	0
5 Series	F18	Body	EMALI Electric-motor reel, left	•	•	•	•	•	•	0
5 Series	F18	Body	EMARE Electric-motor reel, right	•	•	•	•	•	•	0
5 Series	F18	Body	FCON Rear compartment controller	•	•	•	•	•	•	0
5 Series	F18	Body	FD Rear-compartment display	•	•	•	•	•	•	0
5 Series	F18	Body	FD2 Rear-compartment display 2	•	•	•	•	•	•	0
5 Series	F18	Body	FKA Rear heater/air conditioning	•	•	•	•	•	•	0
5 Series	F18	Body	FLA High Beam Assist	•	•	•	•	•	•	0
5 Series	F18	Body	FRM Footwell module	•	•	•	•	•	•	0
5 Series	F18	Body	FZD Function centre, roof	•	•	•	•	•	•	0
5 Series	F18	Body	HKL Rear-lid lift	•	•	•	•	•	•	0
5 Series	F18	Body	HSR Rear-axle slip-angle control	•	•	•	•	•	•	0
5 Series	F18	Body	HUD Head-Up Display	•	•	•	•	•	•	0
5 Series	F18	Body	IHKA Integrated automatic heating/air conditioning	•	•	•	•	•	•	0
5 Series	F18	Body	JBE Junction-box electronics	•	•	•	•	•	•	0
5 Series	F18	Body	KAFAS Camera-based driver-assistance	•	•	•	•	•	•	0
5 Series	F18	Body	INSTR Instrument cluster	•	•		•	•	•	Ο
5 Series	F18	Body	NVE Night Vision Electronics	•	•	•		•	•	0
5 Series	F18	Body	PDC Park Distance Control	•	•	•	•	•	•	0
5 Series	F18	Body	PMA Parking assistant	•	•	•	•	•	•	0
5 Series	F18	Body	RAD Radio	•	•	•		•	•	0
5 Series	F18	Body	RDC Tyre pressure control	•	•			•	•	0
5 Series	F18	Body	RSE Rear Seat Entertainment	•	•	•		•	•	0
5 Series	F18	Body	SMBF Seat module, passenger	•	•		•	•	•	0
5 Series	F18	Body	SMBFH Seat module, passenger's side, rear					•	•	0
5 Series	F18	Body	SMFA Seat module, driver	•		•			•	0
5 Series	F18	Body	SMFAH Seat module, driver's side, rear					•	•	0
O DOLLES	1 10	Dody	Dan in bear module, alliver a stat, real						-	\cup

Series	Model Series	Part	Systems	Ecu Info.	Read DTC	Freeze Frame	Erase DTC	Live Data	Component activation	Physical HW
5 Series	F18	Body	SWW Lane change warning	•	•	•	•	•	•	0
5 Series	F18	Body	SZL Switch centre, steering column	•	•	•	•	•	•	0
5 Series	F18	Body	TRSVC allround-view camera	•	•	•	•	•	•	0
5 Series	F18	Body	ULF-SBX Interface box	•	•	•	•	•	•	0
5 Series	F18	Body	ULF-SBX-H Interface box high	•	•	•	•	•	•	0
5 Series	F18	Body	VM Video Module	•	•	•	•	•	•	0
5 Series	F18	Body	VSW video switch	•	•	•	•	•	•	0
5 Series	F18	Body	VTG Transfer case	•	•	•	•	•	•	0
5 Series	F18	Body	ZGM Central Gateway Control Module	•	•	•	•	•	•	0
5 Series	F18	Body	SDARS Satellite tuner	•	•	•	•	•	•	0
6 Series	F12/F13	Drive	CAS Car Access System	•	•	•	•	•	•	0
6 Series	F12/F13	Drive	DDE Diesel Electronics	•	•	•	•	•	•	0
6 Series	F12/F13	Drive	DME Digital Motor Electronics	•	•	•	•	•	•	0
6 Series	F12/F13	Drive	EGS transmission management	•	•	•	•	•	•	0
6 Series	F12/F13	Drive	EKPS Fuel-pump control	•	•	•	•	•	•	0
6 Series	F12/F13	Drive	GWS Gear selector switch	•	•	•	•	•	•	0
6 Series	F12/F13	Chassis	AL active steering	•	•	•	•	•	•	0
6 Series	F12/F13	Chassis	DSC Dynamic Stability Control	•	•	•	•	•	•	0
6 Series	F12/F13	Chassis	EDCSHL Damper satellite, rear left	•	•	•		•	•	Ö
6 Series	F12/F13	Chassis	EDCSHR Damper satellite, rear right	•	•	•	•	•	•	0
6 Series	F12/F13	Chassis	EDCSVL Damper satellite, front left	•	•	•		•	•	Ö
6 Series	F12/F13	Chassis	EDCSVR Damper satellite, front right	•	•	•	•	•	•	0
6 Series	F12/F13	Chassis	EMF Parking brake	•	•	•	•	•	•	0
6 Series	F12/F13	Chassis	EPS Electronic Power Steering	•	•	•		•	•	0
6 Series	F12/F13	Chassis	ICM Integrated Chassis Management	•	•	•	•	•	•	0
6 Series	F12/F13	Chassis	VDM Vertical Dynamics Management	•	•	•	•	•	•	0
6 Series	F12/F13	Body	ACC Active Cruise Control	•	•	•	•	•	•	0
6 Series	F12/F13	Body	ACSM Crash Safety Module	•	•	•	•	•	•	0
6 Series	F12/F13	Body	AHM Trailer module	•	•	•	•	•	•	0
6 Series	F12/F13	Body	AMPT Top Hi-Fi amplifier	•	•	•	•	•	•	0
6 Series	F12/F13	Body	ASD Active Sound Design	•	•	•	•	•	•	0
6 Series	F12/F13	Body	CBX-ECALL Combox emergency call	•	•	•	•	•	•	0
6 Series	F12/F13	Body	CBX-MEDIA Combox Multimedia	•	•	•	•	•	•	0
6 Series	F12/F13	Body	CID Central Information Display	•	•	•	•	•	•	0
6 Series	F12/F13	Body	CON Controller	•	•	•	•	•	•	0
6 Series	F12/F13	Body	CVM Convertible top module	•	•	•	•	•	•	0
6 Series	F12/F13	Body	DVDC DVD Changer	•	•	•		•	•	0
6 Series	F12/F13	Body	EMALI Electric-motor reel, left	•	•	•		•	•	0
6 Series	F12/F13	Body	EMARE Electric-motor reel, right	•	•			•		0
6 Series	F12/F13	Body	FD Rear-compartment display	•	•			•		0
6 Series	F12/F13	Body	FD2 Rear-compartment display 2	•	•			•		0
6 Series	F12/F13	Body	FKA Rear heater/air conditioning	•	•			•		0
6 Series	F12/F13	Body	FLA High Beam Assist	•				•		0
6 Series	F12/F13	Body	FRM Footwell module			•				0
O DCITES	1 14/110	Dody	I I'm I OOCWCII MOUUIC							\cup

Series	Model Series	Part	Systems	Ecu Info.	Read DTC	Freeze Frame	Erase DTC	Live Data	Component activation	Physical HW
6 Series	F12/F13	Body	FZD Function centre, roof	•	•	•	•	•	•	0
6 Series	F12/F13	Body	HSR Rear-axle slip-angle control	•	•	•	•	•	•	0
6 Series	F12/F13	Body	HUD Head-Up Display	•	•	•	•	•	•	0
6 Series	F12/F13	Body	IHKA Integrated automatic heating/air conditioning	•	•	•	•	•	•	0
6 Series	F12/F13	Body	JBE Junction-box electronics	•	•	•	•	•	•	0
6 Series	F12/F13	Body	KAFAS Camera-based driver-assistance systems	•	•	•	•	•	•	0
6 Series	F12/F13	Body	INSTR Instrument cluster	•	•	•	•	•	•	0
6 Series	F12/F13	Body	NVE Night Vision Electronics	•	•	•	•	•	•	0
6 Series	F12/F13	Body	PDC Park Distance Control	•	•	•	•	•	•	0
6 Series	F12/F13	Body	PMA Parking assistant	•	•	•	•	•	•	0
6 Series	F12/F13	Body	RAD Radio	•	•	•	•	•	•	0
6 Series	F12/F13	Body	RDC Tyre pressure control	•	•	•	•	•	•	0
6 Series	F12/F13	Body	SINE Siren and tilt sensor	•	•	•	•	•	•	0
6 Series	F12/F13	Body	SMBF Seat module, passenger		•	•	•	•	•	0
6 Series	F12/F13	Body	SMBFH Seat module, passenger's side, rear			•		•	•	0
6 Series	F12/F13	Body	SMFA Seat module, driver		•	•	•	•	•	0
6 Series	F12/F13	Body	SMFAH Seat module, driver's side, rear			•		•	•	0
6 Series	F12/F13	Body	SVT Servotronic			•	•	•	•	0
6 Series	F12/F13	Body	SWW Lane change warning	•		•	•	•	•	0
6 Series	F12/F13	Body	SZL Switch centre, steering column					•	•	0
6 Series	F12/F13	Body	TRSVC allround-view camera					•	•	0
6 Series	F12/F13	Body	VM Video Module		•	•	•	•	•	0
6 Series	F12/F13	Body	VSW video switch			•		•	•	0
6 Series	F12/F13	Body	VTG Transfer case	•				•	•	0
6 Series	F12/F13	Body	ZGM Central Gateway Control Module	•				•	•	0
6 Series	F12/F13	Body	SDARS Satellite tuner					•	•	0
7 Series	F01/F02/F04	Drive	CAS Car Access System			•	•	•	·	0
7 Series	F01/F02/F04	Drive	DME Digital Motor Electronics					•	•	0
7 Series	F01/F02/F04	Drive	DDE Diesel Electronics					•	•	0
7 Series	F01/F02/F04	Drive	DME Digital Motor Electronics 2		•	•	•	•	•	0
7 Series	F01/F02/F04	Drive	EGS transmission management	•		•	•	•	•	0
7 Series	F01/F02/F04	Drive	GWS Gear selector switch			•				0
7 Series	F01/F02/F04	Drive	EKPS Fuel-pump control	•	•	•		•	•	0
7 Series	F01/F02/F04	Chassis	DSC Dynamic Stability Control	•	•			•	•	0
7 Series	F01/F02/F04	Chassis	ICM Integrated Chassis Management	•	•			•		0
7 Series	F01/F02/F04	Chassis	VDM Vertical Dynamics Management	•						0
7 Series	F01/F02/F04	Chassis	EDCSHL Damper satellite, rear left	•						0
7 Series	F01/F02/F04	Chassis	EDCSHR Damper satellite, rear right	•				•		0
7 Series	F01/F02/F04	Chassis	EDCSVL Damper satellite, front left					•		0
7 Series	F01/F02/F04	Chassis	EDCSVR Damper satellite, front right							0
7 Series	F01/F02/F04	Chassis	EMF Parking brake			•				0
7 Series	F01/F02/F04	Chassis	EHC Electronic Ride-Height Control						•	0
1 DELIES	101/104/104	CHassis	THE PIECTIONIC WINE HEISHE COUNTED		· •	•		. •	· •	\cup

Series	Model Series	Part	Systems	Ecu Info.	Read DTC	Freeze Frame	Erase DTC	Live Data	Component activation	Physical HW
7 Series	F01/F02/F04	Chassis	AL active steering	•	•	•	•	•	•	0
7 Series	F01/F02/F04	Body	INSTR Instrument cluster	•	•	•	•	•	•	0
7 Series	F01/F02/F04	Body	IHKA Integrated automatic heating/air conditioning	•	•	•	•	•	•	0
7 Series	F01/F02/F04	Body	ACSM Crash Safety Module	•	•	•	•	•	•	0
7 Series	F01/F02/F04	Body	CIC Car Information Computer	•	•	•	•	•	•	0
7 Series	F01/F02/F04	Body	FZD Function centre, roof	•	•	•	•	•	•	0
7 Series	F01/F02/F04	Body	PDC Park Distance Control	•	•	•	•	•	•	0
7 Series	F01/F02/F04	Body	FRM Footwell module	•	•	•	•	•	•	0
7 Series	F01/F02/F04	Body	JBE Junction-box electronics	•	•	•	•	•	•	0
7 Series	F01/F02/F04	Body	ZGM Central Gateway Control Module	•	•	•	•	•	0	0
7 Series	F01/F02/F04	Body	SZL Switch centre, steering column	•	•	•	•	•	•	0
7 Series	F01/F02/F04	Body	CON Controller	•	•	•	•	•	•	0
7 Series	F01/F02/F04	Body	CID Central Information Display	•	•	•	•	•	•	0
7 Series	F01/F02/F04	Body	SMFA Seat module, driver	•	•	•	•	•	•	0
7 Series	F01/F02/F04	Body	SMBF Seat module, passenger	•	•	•	•	•	•	0
7 Series	F01/F02/F04	Body	AMPH Hi-Fi amplifier	•	•	•	•	•	•	0
7 Series	F01/F02/F04	Body	HUD Head-Up Display	•	•	•	•	•	•	0
7 Series	F01/F02/F04	Body	ULF-SBX-H Interface box high	•	•	•	•	•	•	•
7 Series	F01/F02/F04	Body	FLA High Beam Assist	•	•	•	•	•	•	0
7 Series	F01/F02/F04	Body	RSE Rear Seat Entertainment	•	•	•	•	•	•	0
7 Series	F01/F02/F04	Body	DVDC DVD Changer	•	•	•	•	•	•	0
7 Series	F01/F02/F04	Body	VSW video switch	•	•	•	•	•	•	0
7 Series	F01/F02/F04	Body	HKL Rear-lid lift	•	•	•	•	•	•	0
7 Series	F01/F02/F04	Body	FD Rear-compartment display	•	•	•	•	•	•	0
7 Series	F01/F02/F04	Body	FD2 Rear-compartment display 2	•	•	•	•	•	•	0
7 Series	F01/F02/F04	Body	ACC Active Cruise Control	•	•	•	•	•	•	0
7 Series	F01/F02/F04	Body	AHM Trailer module	•	•	•	•	•	•	0
7 Series	F01/F02/F04	Body	CBX-ECALL Combox emergency call	•	•	•	•	•	•	0
7 Series	F01/F02/F04	Body	CBX-MEDIA Combox Multimedia	•	•	•	•	•	•	0
7 Series	F01/F02/F04	Body	EMALI Electric-motor reel, left	•	•	•	•	•	•	0
7 Series	F01/F02/F04	Body	EMARE Electric-motor reel, right	•	•	•	•	•	•	0
7 Series	F01/F02/F04	Body	EME Electric machine electronics	•	•	•	•	•	•	0
7 Series	F01/F02/F04	Body	FCON Rear compartment controller	•	•	•	•	•	•	0
7 Series	F01/F02/F04	Body	FKA Rear heater/air conditioning	•	•	•	•	•	•	0
7 Series	F01/F02/F04	Body	GZAL Targeted illumination, left	•	•	•	•	•	•	0
7 Series	F01/F02/F04	Body	GZAR Targeted illumination, right	•	•	•	•	•	•	0
7 Series	F01/F02/F04	Body	HKA Rear-cabin automatic A/C	•	•	•	•	•	•	0
7 Series	F01/F02/F04	Body	HSR Rear-axle slip-angle control	•	•	•	•	•	•	0
7 Series	F01/F02/F04	Body	KAFAS Camera-based driver-assistance systems	•	•	•	•	•	•	0
7 Series	F01/F02/F04	Body	LHML LED main light module, left	•	•	•	•	•	•	0
7 Series	F01/F02/F04	Body	LHMR LED main light module, right	•	•	•	•	•	•	0
7 Series	F01/F02/F04	Body	NVE Night Vision Electronics	•	•	•	•	•	•	0

Forcise	ries M	odel Series	Part	Systems	Ecu Info.	Read DTC	Freeze Frame	Erase DTC	Live Data	Component activation	Physical HW
Series	Series F	01/F02/F04	Body	RAD Radio	•	•	•	•	•	•	0
Series	Series F	01/F02/F04	Body	RDC Tyre pressure control	•	•	•	•	•	•	0
Series	Series F	01/F02/F04	Body	SDARS Satellite tuner	•	•	•	•	•	•	0
Terries	Series F	01/F02/F04	Body	SMBFH Seat module, passenger's side, rear	•	•	•	•	•	•	0
Series	Series F	01/F02/F04	Body	SME Accumulator-management electronics	•	•	•	•	•	•	0
Series	Series F	01/F02/F04	Body	SMFAH Seat module, driver's side, rear	•	•	•	•	•	•	0
Series	Series F	01/F02/F04	Body	SVT Servotronic	•	•	•	•	•	•	0
T Series	Series F	01/F02/F04	Body	SWW Lane change warning	•	•	•	•	•	•	0
Series	Series F	01/F02/F04	Body	STML Headlight driver module, left	•	•	•	•	•	•	0
TScries	Series F	01/F02/F04	Body	STMR Headlight driver module, right	•	•	•	•	•	•	0
T Series	Series F	01/F02/F04	Body	TRSVC allround-view camera	•	•	•	•	•	•	0
T Series	Series F	01/F02/F04	Body	TBX Touchbox	•	•	•	•	•	•	0
T Series	Series F	01/F02/F04	Body	ULF-SBX Interface box	•	•	•	•	•	•	0
X3 Series F25	Series F	01/F02/F04	Body	VM Video Module	•	•	•	•	•	•	0
\$\frac{\capacitage}{\capacitage} \$\capac	Series F	01/F02/F04	Body	VTG Transfer case	•	•	•	•	•	•	0
X3 Series F25 Drive DME Digital Motor Electronics X3 Series F25 Drive EGS transmission management X3 Series F25 Drive ERPS Fuel-pump control X3 Series F25 Drive GWS Gear selector switch X3 Series F25 Chassis DSC Dynamic Stability Control X3 Series F25 Chassis DSC Dynamic Stability Control X3 Series F25 Chassis EMF Parking brake X3 Series F25 Chassis EPS Electronic Power Steering X3 Series F25 Chassis ICM Integrated Chassis Management X3 Series F25 Chassis ICM Integrated Chassis Management X3 Series F25 Chassis YOM Vertical Dynamics Management X3 Series F25 Body ACC Active Cruise Control X3 Series F25 Body ACSM Crash Safety Module X3 Series F25 Body AMPT Trailer module X3 Series F25 Body AMPT Trop Hi-Fi amplifier X3 Series F25 Body CBX-ECALL Combox energency call X3 Series F25 Body CBX-ECALL Combox Multimedia X3 Series F25 Body CDX Central Information Display X3 Series F25 Body CDX Central Information Display X3 Series F25 Body FM Footwell module X3 Series F25 Body FM Footwell module X3 Series F25 Body GHAS	Series F	25	Drive	CAS Car Access System	•	•	•	•	•	•	0
X3 Series F25	Series F	25	Drive	DDE Diesel Electronics	•	•	•	•	•	•	0
Name	Series F	25	Drive	DME Digital Motor Electronics	•	•	•	•	•	•	0
X3 Series F25 Drive GWS Gear selector switch		25	Drive	EGS transmission management	•	•	•	•	•	•	0
X3 Series F25 Chassis EMF Parking brake		25	Drive	EKPS Fuel-pump control	•	•	•	•	•	•	0
X3 Series F25 Chassis EMF Parking brake X3 Series F25 Chassis EPS Electronic Power Steering X3 Series F25 Chassis ICM Integrated Chassis Management X3 Series F25 Chassis VDM Vertical Dynamics Management X3 Series F25 Body ACC Active Cruise Control X3 Series F25 Body ACSM Crash Safety Module X3 Series F25 Body AMPT Top Hi-Fi amplifier X3 Series F25 Body AMPT Top Hi-Fi amplifier X3 Series F25 Body CBX-ECALL Combox emergency call X3 Series F25 Body CID Central Information Display X3 Series F25 Body CON Controller X3 Series F25 Body FLA High Beam Assist X3 Series F25 Body FLA Bigh Beam Assist X3 Series F25 Body CHAS Regulated differential lock	Series F	25	Drive	GWS Gear selector switch	•	•	•	•	•	•	0
X3 Series F25 Chassis EPS Electronic Power Steering ● <t< td=""><td>Series F</td><td>25</td><td>Chassis</td><td>DSC Dynamic Stability Control</td><td>•</td><td>•</td><td>•</td><td>•</td><td>•</td><td>•</td><td>0</td></t<>	Series F	25	Chassis	DSC Dynamic Stability Control	•	•	•	•	•	•	0
X3 Series F25 Chassis ICM Integrated Chassis Management ●	Series F	25	Chassis	EMF Parking brake	•	•	•	•	•	•	0
X3 Series F25 Chassis VDM Vertical Dynamics Management • • • • • • • • • • • • • • • • • • •	Series F	25	Chassis	EPS Electronic Power Steering	•	•	•	•	•	•	0
X3 Series F25 Body ACC Active Cruise Control • • • • • • • • • • • • • • • • • • •		25			•	•	•	•	•	•	0
X3 Series F25 Body ACC Active Cruise Control • • • • • • • • • • • • • • • • • • •	Series F	25	Chassis	VDM Vertical Dynamics Management	•	•	•	•	•	•	0
X3 Series F25 Body ACSM Crash Safety Module • • • • • • • • • • X3 Series F25 Body AHM Trailer module • • • • • • • • • • X3 Series F25 Body AMPT Top Hi-Fi amplifier • • • • • • • • • • • X3 Series F25 Body CBX-ECALL Combox emergency call • • • • • • • • • • • • X3 Series F25 Body CBX-MEDIA Combox Multimedia • • • • • • • • • • • • • • • • • • •					•	•	•	•	•	•	0
X3 Series F25 Body AHM Trailer module ●		25	Body	ACSM Crash Safety Module	•	•	•	•	•	•	0
X3 Series F25 Body AMPT Top Hi-Fi amplifier • • • • • • X3 Series F25 Body CBX-ECALL Combox emergency call • <t< td=""><td></td><td>25</td><td>Body</td><td></td><td>•</td><td>•</td><td>•</td><td>•</td><td>•</td><td>•</td><td>0</td></t<>		25	Body		•	•	•	•	•	•	0
X3 Series F25 Body CBX-ECALL Combox emergency call ● ● ● ● X3 Series F25 Body CBX-MEDIA Combox Multimedia ● ● ● ● X3 Series F25 Body CID Central Information Display ● ● ● ● X3 Series F25 Body CON Controller ● ● ● ● X3 Series F25 Body DVDC DVD Changer ● ● ● ● X3 Series F25 Body FLA High Beam Assist ● ● ● ● X3 Series F25 Body FRM Footwell module ● ● ● ● X3 Series F25 Body FZD Function centre, roof ● ● ● ● X3 Series F25 Body GHAS Regulated differential lock ● ● ● ●		25	Body	AMPT Top Hi-Fi amplifier	•	•	•	•	•	•	0
X3 Series F25 Body CBX-MEDIA Combox Multimedia ● ● ● ● X3 Series F25 Body CID Central Information Display ● ● ● ● ● X3 Series F25 Body CON Controller ● ● ● ● ● ● X3 Series F25 Body DVDC DVD Changer ● ● ● ● ● ● X3 Series F25 Body FLA High Beam Assist ● ● ● ● ● ● X3 Series F25 Body FRM Footwell module ● ● ● ● ● ● X3 Series F25 Body FZD Function centre, roof ● ● ● ● ● ● X3 Series F25 Body GHAS Regulated differential lock ● ● ● ● ● ●		25	Body	CBX-ECALL Combox emergency call	•	•	•	•	•	•	0
X3 Series F25 Body CID Central Information Display ● ● ● ● ● X3 Series F25 Body DVDC DVD Changer ● ● ● ● ● X3 Series F25 Body FLA High Beam Assist ● ● ● ● ● X3 Series F25 Body FRM Footwell module ● ● ● ● ● X3 Series F25 Body FZD Function centre, roof ● ● ● ● ● X3 Series F25 Body GHAS Regulated differential lock ● ● ● ● ●		25	Body	CBX-MEDIA Combox Multimedia	•	•	•	•	•	•	0
X3 Series F25 Body CON Controller ● ● ● ● ● X3 Series F25 Body FLA High Beam Assist ● ● ● ● ● X3 Series F25 Body FRM Footwell module ● ● ● ● ● X3 Series F25 Body FZD Function centre, roof ● ● ● ● ● X3 Series F25 Body GHAS Regulated differential lock ● ● ● ●		25	Body	CID Central Information Display	•	•	•	•	•	•	0
X3 Series F25 Body DVDC DVD Changer ● ● ● ● ● X3 Series F25 Body FLA High Beam Assist ● ● ● ● ● X3 Series F25 Body FRM Footwell module ● ● ● ● ● X3 Series F25 Body FZD Function centre, roof ● ● ● ● ● X3 Series F25 Body GHAS Regulated differential lock ● ● ● ● ●		25	Body		•	•	•	•	•	•	0
X3 Series F25 Body FLA High Beam Assist •		25	Body	DVDC DVD Changer	•	•	•	•	•	•	0
X3 Series F25 Body FRM Footwell module •						•	•	•		•	0
X3 Series F25 Body FZD Function centre, roof					•	•	•	•	•	•	0
X3 Series F25 Body GHAS Regulated differential lock $lacktriangle$ $lacktriangle$ $lacktriangle$						•	•	•	•	•	0
						•	•	•		•	0
						•	•	•		•	0
X3 Series F25 Body HKL Automatic luggage compartment lid actuation				HKL Automatic luggage compartment lid	•	•	•	•		•	0
X3 Series F25 Body HUD Head-Up Display • • • •	Series F	25	Body				•	•	•	•	0

Series	Model Series	Part	Systems	Ecu Info.	Read DTC	Freeze Frame	Erase DTC	Live Data	Component activation	Physical HW
X3 Series	F25	Body	IHKA Integrated automatic heating/air conditioning	•	•	•	•	•	•	0
X3 Series	F25	Body	JBE Junction-box electronics	•	•	•	•	•	•	0
X3 Series	F25	Body	KAFAS Camera-based driver-assistance systems	•	•	•	•	•	•	0
X3 Series	F25	Body	INSTR Instrument cluster	•	•	•	•	•	•	0
X3 Series	F25	Body	PDC Park Distance Control	•	•	•	•	•	•	0
X3 Series	F25	Body	RAD Radio	•	•	•	•	•	•	0
X3 Series	F25	Body	RDC Tyre pressure control	•	•	•	•	•	•	0
X3 Series	F25	Body	SMBF Seat module, passenger	•	•	•	•	•	•	0
X3 Series	F25	Body	SMBFH Seat module, passenger's side, rear	•	•	•	•	•	•	0
X3 Series	F25	Body	SMFA Seat module, driver	•	•	•	•	•	•	0
X3 Series	F25	Body	SMFAH Seat module, driver's side, rear	•	•	•	•	•	•	0
X3 Series	F25	Body	SWW Lane change warning	•	•	•	•	•	•	0
X3 Series	F25	Body	SZL Switch centre, steering column	•	•	•	•	•	•	0
X3 Series	F25	Body	TRSVC allround-view camera	•	•	•	•	•	•	0
X3 Series	F25	Body	VM Video Module	•	•	•	•	•	•	0
X3 Series	F25	Body	VTG Transfer case	•	•	•	•	•	•	0
X3 Series	F25	Body	ZGM Central Gateway Control Module	•	•	•	•	•	•	0
X6 Series	E72	Drive	CAS Car Access System	•	•	•	•	•	•	0
X6 Series	E72	Drive	DME Digital Motor Electronics	•	•	•	•	•	•	0
X6 Series	E72	Drive	EKPS Fuel-pump control	•	•	•	•	•	•	0
X6 Series	E72	Drive	EMPI Hybrid oil-pump activation	•	•	•	•	•	•	0
X6 Series	E72	Drive	GWS Gear selector switch	•	•	•	•	•	•	0
X6 Series	E72	Drive	TCM Hybrid-transmission control	•	•	•	•	•	•	0
X6 Series	E72	Drive	VTG Transfer case	•	•	•	•	•	•	0
X6 Series	E72	Chassis	DSC Dynamic Stability Control	•	•	•	•	•	•	0
X6 Series	E72	Chassis	DSM Hybrid parking lock	•	•	•	•	•	•	0
X6 Series	E72	Chassis	EHC Electronic Ride-Height Control	•	•	•	•	•	•	0
X6 Series	E72	Chassis	EMF Parking brake	•	•	•	•	•	•	0
X6 Series	E72	Chassis	EPS Electronic Power Steering	•	•	•	•	•	•	0
X6 Series	E72	Chassis	RDC Tyre pressure control	•	•	•	•	•	•	0
X6 Series	E72	Chassis	SBA Hybrid brake-actuation changeover	•	•		•	•	•	0
X6 Series	E72	Body	ACSM Crash Safety Module	•	•	•	•		•	0
X6 Series	E72	Body	AHM Trailer module	•	•	•	•	•	•	0
X6 Series	E72	Body	AMPT Top Hi-Fi amplifier		•	•	•	•	•	0
X6 Series	E72	Body	APM Hybrid DC/DC converter		•		•	•		0
X6 Series	E72	Body	BCM Battery check module		•	•	•	•	•	0
X6 Series	E72	Body	CA Comfort access system	•				•		0
X6 Series	E72	Body	CBX-ECALL Combox emergency call	•				•	•	0
X6 Series	E72	Body	CDC CD Changer							0
X6 Series	E72	Body	CCC-GW Gateway	•				•		0
X6 Series	E72	Body	CID Central Information Display	•				•		0
X6 Series	E72	Body	CON Controller			•				0
VO DELLES	D14	роцу	CON CONTINUED							$\overline{}$

Series	Model Series	Part	Systems	Ecu Info.	Read DTC	Freeze Frame	Erase DTC	Live Data	Component activation	Physical HW
X6 Series	E72	Body	DVDC DVD Changer	•	•	•	•	•	•	0
X6 Series	E72	Body	EKK Electric A/C compressor	•	•	•	•	•	•	0
X6 Series	E72	Body	FD Rear-compartment display	•	•	•	•	•	•	0
X6 Series	E72	Body	FKA Rear heater/air conditioning	•	•	•	•	•	•	0
X6 Series	E72	Body	FLA High Beam Assist	•	•	•	•	•	•	0
X6 Series	E72	Body	FRM2 Footwell module 2	•	•	•	•	•	•	0
X6 Series	E72	Body	FZD Function centre, roof	•	•	•	•	•	•	0
X6 Series	E72	Body	HCP Hybrid master control unit	•	•	•	•	•	•	0
X6 Series	E72	Body	HIM Hybrid Interface Module	•	•	•	•	•	•	0
X6 Series	E72	Body	HKL Rear-lid lift	•	•	•	•	•	•	0
X6 Series	E72	Body	HUD Head-Up Display	•	•	•	•	•	•	0
X6 Series	E72	Body	IHKA Integrated automatic heating/air conditioning	•	•	•	•	•	•	0
X6 Series	E72	Body	JBE2 Junction Box electronics	•	•	•	•	•	•	0
X6 Series	E72	Body	INSTR Instrument cluster	•	•			•	•	0
X6 Series	E72	Body	M-ASK-BO User interface	•	•	•	•	•	•	0
X6 Series	E72	Body	MCPA Hybrid electric-motor control 1	•	•	•	•		•	0
X6 Series	E72	Body	MCPB Hybrid electric-motor control 2				•		•	0
X6 Series	E72	Body	PDC Park Distance Control						•	0
X6 Series	E72	Body	RLSS Rain/light solar sensor							0
X6 Series	E72	Body	RSE Rear Seat Entertainment					•		0
X6 Series	E72	Body	SINE Siren and tilt sensor					•		0
X6 Series	E72	Body	SMFA Seat module, driver					•		0
X6 Series	E72	Body	SMBF Seat module, passenger							0
X6 Series	E72	Body	TFE Hybrid pressure-tank electronics							0
X6 Series	E72	Body	TRSVC allround-view camera							0
X6 Series	E72	Body	ULF-SBX Interface box							0
X6 Series	E72	Body	ULF-SBX Interface box ULF-SBX-H Interface box high							0
X6 Series	E72	Body	VM Video Module							0
X1 Series	E84	Drive	CAS Car Access System							0
X1 Series	E84	Drive								0
	E84		DDE Diesel Electronics							0
X1 Series	E84	Drive	DME Digital Motor Electronics							
X1 Series		Drive	EGS transmission management							0
X1 Series	E84	Drive	EKPS Fuel-pump control							
X1 Series	E84		DSC Dynamic Stability Control	•	•	•	•	•	•	0
X1 Series	E84	Chassis	EPS Electronic Power Steering						•	0
X1 Series	E84	Body	ACSM Crash Safety Module	•	•	•		•		0
X1 Series	E84	Body	AHM Trailer module	•	•			•	•	0
X1 Series	E84	Body	AMPT Top Hi-Fi amplifier	•	•			•		0
X1 Series	E84	Body	CBX-ECALL Combox emergency call	•	•			•		0
X1 Series	E84	Body	CID Central Information Display	•	•			•	•	0
X1 Series	E84	Body	CON Controller	•	•	_		•	•	0
X1 Series	E84	Body	FLA High Beam Assist	+ •	•	•		•	•	0
X1 Series	E84	Body	FRM Footwell module		•	•		•	•	0

Series	Model Series	Part	Systems	Ecu Info.	Read DTC	Freeze Frame	Erase DTC	Live Data	Component activation	Physical HW
X1 Series	E84	Body	FZD Function centre, roof	•	•	•	•	•	•	0
X1 Series	E84	Body	IHKA Integrated automatic heating/air conditioning	•	•	•	•	•	•	0
X1 Series	E84	Body	JBE Junction-box electronics	•	•	•	•	•	•	0
X1 Series	E84	Body	INSTR Instrument cluster	•	•	•	•	•	•	0
X1 Series	E84	Body	PDC Park Distance Control	•	•	•	•	•	•	0
X1 Series	E84	Body	RDC Tyre pressure control	•	•	•	•	•	•	0
X1 Series	E84	Body	SMBF Seat module, passenger	•	•	•	•	•	•	0
X1 Series	E84	Body	SMFA Seat module, driver	•	•	•	•	•	•	0
X1 Series	E84	Body	TRSVC allround-view camera	•	•	•	•	•	•	0
X1 Series	E84	Body	VM Video Module	•	•	•	•	•	•	0
X1 Series	E84	Body	VTG Transfer case	•	•	•	•	•	•	0
X1 Series	E84	Body	CA Comfort access system	•	•	•	•	•	•	0
X1 Series	E84	Body	CDC CD Changer	•	•	•	•	•	•	0
X1 Series	E84	Body	CHAMP-BO User interface	•	•	•	•	•	•	0
X1 Series	E84	Body	CCC-GW Gateway	•	•	•	•	•	•	0
X1 Series	E84	Body	DAB Digital tuner	•	•	•	•	•	•	0
X1 Series	E84	Body	DWA anti-theft alarm system	•	•	•	•	•	•	0
X1 Series	E84	Body	RLSS Rain/light solar sensor	•	•	•	•	•	•	0
X1 Series	E84	Body	SHD Sliding/tilting sunroof	•	•	•	•	•	•	0
X1 Series	E84	Body	SINE Siren and tilt sensor	•	•	•	•	•	•	0
X1 Series	E84	Body	ULF-SBX Interface box	•	•	•	•	•	•	0
X1 Series	E84	Body	ULF-SBX-H Interface box High	•	•	•	•	•	•	0
2 Series	F22	Drive	CAS Car Access System	•	•	•	•	•	•	0
2 Series	F22	Drive	DDE Diesel Electronics	•	•	•	•	•	•	0
2 Series	F22	Drive	DME Digital Motor Electronics	•	•	•	•	•	•	0
2 Series	F22	Drive	DME Digital Motor Electronics 2	•	•	•	•	•	•	0
2 Series	F22	Drive	EGS transmission management	•	•	•	•	•	•	0
2 Series	F22	Drive	EKPS Fuel-pump control	•	•	•	•	•	•	0
2 Series	F22	Drive	GWS Gear selector switch	•	•	•	•	•	•	0
2 Series	F22	Chassis	AL active steering	•	•	•	•	•	•	0
2 Series	F22	Chassis	DSC Dynamic Stability Control	•	•	•	•	•	•	0
2 Series	F22	Chassis	EHC Electronic Ride-Height Control	•	•	•	•	•	•	0
2 Series	F22		EMF Parking brake	•	•	•	•	•	•	0
2 Series	F22		EPS Electronic Power Steering	•	•	•	•	•	•	0
2 Series	F22	Chassis	ICM Integrated Chassis Management	•	•	•	•	•	•	0
2 Series	F22	Chassis	VDM Vertical Dynamics Management	•	•	•	•	•	•	0
2 Series	F22	Chassis	VDM2 Vertical dynamics management	•	•	•	•	•	•	0
2 Series	F22	Body	ACC Active Cruise Control	•	•	•	•	•	•	0
2 Series	F22	Body	ACSM Crash Safety Module	•	•	•	•	•	•	0
2 Series	F22	Body	AHM Trailer module	•	•	•	•	•	•	0
2 Series	F22	Body	AMPH Hi-Fi amplifier	•	•	•	•	•	•	0
2 Series	F22	Body	ASD Active Sound Design	•	•	•	•	•	•	0
2 Series	F22	Body	CBX-ECALL Combox emergency call	•	•	•	•	•	•	0

Series	Model Series	Part	Systems	Ecu Info.	Read DTC	Freeze Frame	Erase DTC	Live Data	Component activation	Physical HW
2 Series	F22	Body	CBX-MEDIA Combox Multimedia	•	•	•	•	•	•	0
2 Series	F22	Body	CIC Car Information Computer	•	•	•	•	•	•	0
2 Series	F22	Body	CON Controller	•	•	•	•	•	•	0
2 Series	F22	Body	CVM Convertible top module	•	•	•	•	•	•	0
2 Series	F22	Body	DVDC DVD Changer	•	•	•	•	•	•	0
2 Series	F22	Body	EMALI Electric-motor reel, left	•	•	•	•	•	•	0
2 Series	F22	Body	EMARE Electric-motor reel, right	•	•	•	•	•	•	0
2 Series	F22	Body	EME Electric machine electronics	•	•	•	•	•	•	0
2 Series	F22	Body	EME2 Electrical machine electronics	•	•	•	•	•	•	0
2 Series	F22	Body	FLA High Beam Assist	•	•	•	•	•	•	0
2 Series	F22	Body	FRM Footwell module	•	•	•	•	•	•	0
2 Series	F22	Body	FZD Function centre, roof	•	•	•	•	•	•	0
2 Series	F22	Body	GHAS Regulated differential lock	•	•	•	•	•	•	0
2 Series	F22	Body	HKL Automatic luggage compartment lid actuation	•	•	•	•	•	•	0
2 Series	F22	Body	IHKA Integrated automatic heating/air conditioning	•	•	•	•	•	•	0
2 Series	F22	Body	INSTR Instrument cluster	•	•	•	•	•	•	0
2 Series	F22	Body	KAFAS Camera-based driver-assistance systems	•	•	•	•	•	•	0
2 Series	F22	Body	PDC Park distance control	•	•	•	•	•	•	0
2 Series	F22	Body	PMA Parking assistant	•	•	•	•	•	•	0
2 Series	F22	Body	RAD Radio	•	•	•	•	•	•	0
2 Series	F22	Body	RDC Tyre pressure control	•	•	•	•	•	•	0
2 Series	F22	Body	SEC Supplementary control unit	•	•	•	•	•	•	0
2 Series	F22	Body	SEC2 Supplementary control unit 2	•	•	•	•	•	•	0
2 Series	F22	Body	SINE Siren and tilt sensor	•	•	•	•	•	•	0
2 Series	F22	Body	SMBF Seat module, passenger	•	•	•	•	•	•	0
2 Series	F22	Body	SMBFH Seat module, passenger's side, rear	•	•	•	•	•	•	0
2 Series	F22	Body	SME Accumulator-management electronics	•	•	•	•	•	•	0
2 Series	F22	Body	SMFA Seat module, driver	•	•	•	•	•	•	0
2 Series	F22	Body	SMFAH Seat module, driver's side, rear	•	•	•	•	•	•	0
2 Series	F22	Body	SVT Servotronic	•	•	•	•	•	•	0
2 Series	F22	Body	SWW Lane change warning	•	•	•	•	•	•	0
2 Series	F22	Body	SZL Switch centre, steering column	•	•	•	•	•	•	0
2 Series	F22	Body	TRSVC allround-view camera	•	•	•	•	•	•	0
2 Series	F22	Body	VM Video Module	•	•	•	•	•	•	0
2 Series	F22	Body	VTG Transfer case	•	•	•	•	•	•	0
2 Series	F22	Body	ZGM Central Gateway Control Module	•	•	•	•	•	•	0
3 Series	F34	Drive	CAS Car Access System	•	•	•	•	•	•	0
3 Series	F34	Drive	DDE Diesel Electronics	•	•	•	•	•	•	0
3 Series	F34	Drive	DME Digital Motor Electronics	•	•	•	•	•	•	0
3 Series	F34	Drive	DME Digital Motor Electronics 2	•	•	•	•	•	•	0
3 Series	F34	Drive	EGS transmission management	•	•	•	•	•	•	0

Series	Model Series	Part	Systems	Ecu Info.	Read DTC	Freeze Frame	Erase DTC	Live Data	Component activation	Physical HW
3 Series	F34	Drive	EKPS Fuel-pump control	•	•	•	•	•	•	0
3 Series	F34	Drive	GWS Gear selector switch	•	•	•	•	•	•	0
3 Series	F34	Chassis	AL active steering	•	•	•	•	•	•	0
3 Series	F34	Chassis	DSC Dynamic Stability Control	•	•	•	•	•	•	0
3 Series	F34	Chassis	EHC Electronic Ride-Height Control	•	•	•	•	•	•	0
3 Series	F34	Chassis	EMF Parking brake	•	•	•	•	•	•	0
3 Series	F34	Chassis	EPS Electronic Power Steering	•	•	•	•	•	•	0
3 Series	F34	Chassis	ICM Integrated Chassis Management	•	•	•	•	•	•	0
3 Series	F34	Chassis	VDM Vertical Dynamics Management	•	•	•	•	•	•	0
3 Series	F34	Chassis	VDM2 Vertical dynamics management	•	•	•	•	•	•	0
3 Series	F34	Body	ACC Active Cruise Control	•	•	•	•	•	•	0
3 Series	F34	Body	ACSM Crash Safety Module	•	•	•	•	•	•	0
3 Series	F34	Body	AHM Trailer module	•	•	•	•	•	•	0
3 Series	F34	Body	AMPH Hi-Fi amplifier	•	•	•	•	•	•	0
3 Series	F34	Body	ASD Active Sound Design	•	•	•	•	•	•	0
3 Series	F34	Body	CBX-ECALL Combox emergency call	•	•	•	•	•	•	0
3 Series	F34	Body	CBX-MEDIA Combox Multimedia	•	•	•	•	•	•	0
3 Series	F34	Body	CIC Car Information Computer	•	•	•	•	•	•	0
3 Series	F34	Body	CON Controller	•	•	•	•	•	•	0
3 Series	F34	Body	CVM Convertible top module	•	•	•	•	•	•	0
3 Series	F34	Body	DVDC DVD Changer	•	•	•	•	•	•	0
3 Series	F34	Body	EMALI Electric-motor reel, left	•	•	•	•	•	•	0
3 Series	F34	Body	EMARE Electric-motor reel, right	•	•	•	•	•	•	0
3 Series	F34	Body	EME Electric machine electronics	•	•	•	•	•	•	0
3 Series	F34	Body	EME2 Electrical machine electronics	•	•	•	•	•	•	0
3 Series	F34	Body	FLA High Beam Assist	•	•	•	•	•	•	0
3 Series	F34	Body	FRM Footwell module	•	•	•	•	•	•	0
3 Series	F34	Body	FZD Function centre, roof	•	•	•	•	•	•	0
3 Series	F34	Body	GHAS Regulated differential lock	•	•	•	•	•	•	0
3 Series	F34	Body	HKL Automatic luggage compartment lid actuation	•	•	•	•	•	•	0
3 Series	F34	Body	IHKA Integrated automatic heating/air conditioning	•	•	•	•	•	•	0
3 Series	F34	Body	INSTR Instrument cluster	•	•	•	•	•	•	0
3 Series	F34	Body	KAFAS Camera-based driver-assistance systems	•	•	•	•	•	•	0
3 Series	F34	Body	PDC Park distance control	•	•	•	•	•	•	0
3 Series	F34	Body	PMA Parking assistant	•	•	•	•	•	•	0
3 Series	F34	Body	RAD Radio	•	•	•	•	•	•	0
3 Series	F34	Body	RDC Tyre pressure control	•	•	•	•	•	•	0
3 Series	F34	Body	SEC Supplementary control unit	•	•	•	•	•	•	0
3 Series	F34	Body	SEC2 Supplementary control unit 2	•	•	•	•	•	•	0
3 Series	F34	Body	SINE Siren and tilt sensor	•	•	•	•	•	•	0
3 Series	F34	Body	SMBF Seat module, passenger	•	•	•	•	•	•	0

Series	Model Series	Part	Systems	Ecu Info.	Read DTC	Freeze Frame	Erase DTC	Live Data	Component activation	Physical HW
3 Series	F34	Body	SMBFH Seat module, passenger's side, rear	•	•	•	•	•	•	0
3 Series	F34	Body	SME Accumulator-management electronics		•	•	•	•	•	0
3 Series	F34	Body	SMFA Seat module, driver		•	•	•	•	•	0
3 Series	F34	Body	SMFAH Seat module, driver's side, rear		•	•	•	•	•	0
3 Series	F34	Body	SVT Servotronic		•	•	•	•	•	0
3 Series	F34	Body	SWW Lane change warning		•	•	•	•	•	0
3 Series	F34	Body	SZL Switch centre, steering column		•	•	•	•	•	0
3 Series	F34	Body	TRSVC allround-view camera	•	•	•	•	•	•	0
3 Series	F34	Body	VM Video Module	•	•	•	•	•	•	0
3 Series	F34	Body	VTG Transfer case	•	•	•	•	•	•	0
3 Series	F34	Body	ZGM Central Gateway Control Module	•	•	•	•	•	•	0
4 Series	F32/F33	Drive	CAS Car Access System	•	•	•	•	•	•	0
4 Series	F32/F33	Drive	DDE Diesel Electronics	•	•	•	•	•	•	0
4 Series	F32/F33	Drive	DME Digital Motor Electronics	•	•	•	•	•	•	0
4 Series	F32/F33	Drive	DME Digital Motor Electronics 2	•	•	•	•	•	•	0
4 Series	F32/F33	Drive	EGS transmission management	•	•	•	•	•	•	0
4 Series	F32/F33	Drive	EKPS Fuel-pump control	•	•	•	•	•	•	0
4 Series	F32/F33	Drive	GWS Gear selector switch	•	•	•	•	•	•	0
4 Series	F32/F33	Chassis	AL active steering	•	•	•	•	•	•	0
4 Series	F32/F33	Chassis	DSC Dynamic Stability Control	•	•	•	•	•	•	0
4 Series	F32/F33	Chassis	EHC Electronic Ride-Height Control	•	•	•	•	•	•	0
4 Series	F32/F33	Chassis	EMF Parking brake	•	•	•	•	•	•	0
4 Series	F32/F33	Chassis	EPS Electronic Power Steering	•	•	•	•	•	•	0
4 Series	F32/F33	Chassis	ICM Integrated Chassis Management	•	•	•	•	•	•	0
4 Series	F32/F33	Chassis	VDM Vertical Dynamics Management	•	•	•	•	•	•	0
4 Series	F32/F33	Chassis	VDM2 Vertical dynamics management	•	•	•	•	•	•	0
4 Series	F32/F33	Body	ACC Active Cruise Control	•	•	•	•	•	•	0
4 Series	F32/F33	Body	ACSM Crash Safety Module	•	•	•	•	•	•	0
4 Series	F32/F33	Body	AHM Trailer module	•	•	•	•	•	•	0
4 Series	F32/F33	Body	AMPH Hi-Fi amplifier	•	•	•	•	•	•	0
4 Series	F32/F33	Body	ASD Active Sound Design	•	•	•	•	•	•	0
4 Series	F32/F33	Body	CBX-ECALL Combox emergency call	•	•	•	•	•	•	0
4 Series	F32/F33	Body	CBX-MEDIA Combox Multimedia	•	•	•	•	•	•	0
4 Series	F32/F33	Body	CIC Car Information Computer	•	•	•	•	•	•	0
4 Series	F32/F33	Body	CON Controller	•	•	•	•	•	•	0
4 Series	F32/F33	Body	CVM Convertible top module	•	•	•	•	•	•	0
4 Series	F32/F33	Body	DVDC DVD Changer	•	•	•	•	•	•	0
4 Series	F32/F33	Body	EMALI Electric-motor reel, left	•	•	•	•	•	•	0
4 Series	F32/F33	Body	EMARE Electric-motor reel, right	•	•	•	•	•	•	0
4 Series	F32/F33	Body	EME Electric machine electronics	•	•	•	•	•	•	0
4 Series	F32/F33	Body	EME2 Electrical machine electronics	•	•	•	•	•	•	0
4 Series	F32/F33	Body	FLA High Beam Assist	•	•	•	•	•	•	0
4 Series	F32/F33	Body	FRM Footwell module	•	•	•	•	•	•	0
4 Series	F32/F33	Body	FZD Function centre, roof	•	•	•	•	•	•	0
1 001103	1 04/1 00	Doug	I DD I GHO CIOH COHOLO, 1001			_				$\overline{}$

Series	Model Series	Part	Systems	Ecu Info.	Read DTC	Freeze Frame	Erase DTC	Live Data	Component activation	Physical HW
4 Series	F32/F33	Body	GHAS Regulated differential lock	•	•	•	•	•	•	0
4 Series	F32/F33	Body	HKL Automatic luggage compartment lid actuation	•	•	•	•	•	•	0
4 Series	F32/F33	Body	IHKA Integrated automatic heating/air conditioning	•	•	•	•	•	•	0
4 Series	F32/F33	Body	INSTR Instrument cluster	•	•	•	•	•	•	0
4 Series	F32/F33	Body	KAFAS Camera-based driver-assistance systems	•	•	•	•	•	•	0
4 Series	F32/F33	Body	PDC Park distance control	•	•	•	•	•	•	0
4 Series	F32/F33	Body	PMA Parking assistant	•	•	•	•	•	•	0
4 Series	F32/F33	Body	RAD Radio	•	•	•	•	•	•	0
4 Series	F32/F33	Body	RDC Tyre pressure control	•	•	•	•	•	•	0
4 Series	F32/F33	Body	SEC Supplementary control unit	•	•	•	•	•	•	0
4 Series	F32/F33	Body	SEC2 Supplementary control unit 2	•	•	•	•	•	•	0
4 Series	F32/F33	Body	SINE Siren and tilt sensor	•	•	•	•	•	•	0
4 Series	F32/F33	Body	SMBF Seat module, passenger		•	•	•	•	•	0
4 Series	F32/F33	Body	SMBFH Seat module, passenger's side, rear		•	•		•	•	0
4 Series	F32/F33	Body	SME Accumulator-management electronics					•	•	0
4 Series	F32/F33	Body	SMFA Seat module, driver					•		0
4 Series	F32/F33	Body	SMFAH Seat module, driver's side, rear	•				•		0
4 Series	F32/F33	Body	SVT Servotronic							0
4 Series	F32/F33	Body	SWW Lane change warning							0
4 Series	F32/F33	Body	SZL Switch centre, steering column							0
4 Series	F32/F33	Body	TRSVC allround-view camera							0
4 Series	F32/F33	Body	VM Video Module							0
4 Series	F32/F33	Body	VTG Transfer case					•		0
4 Series 4 Series	F32/F33	Body	ZGM Central Gateway Control Module							0
6 Series	F06	Drive	CAS Car Access System							0
	F06	Drive	DDE Diesel Electronics							0
6 Series	F06	Drive								0
6 Series	F06		DME Digital Motor Electronics DME Digital Motor Electronics 2						•	0
6 Series	F06	Drive								0
6 Series	F06	Drive	EGS transmission management							0
6 Series	F06	Drive	EKPS Fuel-pump control							0
6 Series		Drive	GWS Gear selector switch		•	_				
6 Series	F06 F06		AL active steering	•	•	•		•	•	0
6 Series	F06	Chassis	DSC Dynamic Stability Control						•	
6 Series		Chassis	EDCSHL Damper satellite, rear left	•						0
6 Series	F06	Chassis	EDCSHR Damper satellite, rear right	•				•		0
6 Series	F06	Chassis	EDCSVL Damper satellite, front left	•	•			•		0
6 Series	F06	Chassis	EDCSVR Damper satellite, front right	•				•		0
6 Series	F06	Chassis	EHC Electronic Ride-Height Control	•				•		0
6 Series	F06	Chassis	EMF Parking brake		•	•		-	•	0
6 Series	F06	Chassis	EPS Electronic Power Steering	—	•	-		-	•	0
6 Series	F06	Chassis	ICM Integrated Chassis Management		•	•	•			0

Series	Model Series	Part	Systems	Ecu Info.	Read DTC	Freeze Frame	Erase DTC	Live Data	Component activation	Physical HW
6 Series	F06	Chassis	VDM Vertical Dynamics Management	•	•	•	•	•	•	0
6 Series	F06	Chassis	VDM2 Vertical dynamics management		•	•	•	•	•	0
6 Series	F06	Body	ACC Active Cruise Control	•	•	•	•	•	•	0
6 Series	F06	Body	ACSM Crash Safety Module	•	•	•	•	•	•	0
6 Series	F06	Body	AHM Trailer module	•	•	•	•	•	•	0
6 Series	F06	Body	AMPH Hi-Fi amplifier	•	•	•	•	•	•	0
6 Series	F06	Body	AMPT Top Hi-Fi amplifier	•	•	•	•	•	•	0
6 Series	F06	Body	ASD Active Sound Design	•	•	•	•	•	•	0
6 Series	F06	Body	CBX-ECALL Combox emergency call	•	•	•	•	•	•	0
6 Series	F06	Body	CBX-MEDIA Combox Multimedia	•	•	•	•	•	•	0
6 Series	F06	Body	CIC Car Information Computer	•	•	•	•	•	•	0
6 Series	F06	Body	CID Central information display	•	•	•	•	•	•	0
6 Series	F06	Body	CON Controller	•	•	•	•	•	•	0
6 Series	F06	Body	CVM Convertible top module	•	•	•	•	•	•	0
6 Series	F06	Body	DVDC DVD Changer	•	•	•	•	•	•	0
6 Series	F06	Body	EMALI Electric-motor reel, left	•	•	•	•	•	•	0
6 Series	F06	Body	EMARE Electric-motor reel, right	•	•	•	•	•	•	0
6 Series	F06	Body	EME Electric machine electronics	•	•	•	•	•	•	0
6 Series	F06	Body	EME2 Electrical machine electronics	•	•	•	•	•	•	0
6 Series	F06	Body	FCON Rear compartment controller	•	•	•	•	•	•	0
6 Series	F06	Body	FD Rear-compartment display	•	•	•	•	•	•	0
6 Series	F06	Body	FD2 Rear-compartment display 2		•	•	•	•	•	0
6 Series	F06	Body	FKA Rear heater/air conditioning	•	•	•	•	•	•	0
6 Series	F06	Body	FLA High Beam Assist		•	•	•	•	•	0
6 Series	F06	Body	FRM Footwell module	•	•	•	•	•	•	0
6 Series	F06	Body	FZD Function centre, roof	•	•	•	•	•	•	0
6 Series	F06	Body	GHAS Regulated differential lock	•	•	•	•	•	•	0
6 Series	F06	Body	HKA Rear-cabin automatic A/C		•	•	•	•	•	0
6 Series	F06	Body	HKL Automatic luggage compartment lid actuation	•	•	•	•	•	•	0
6 Series	F06	Body	HKL Rear-lid lift	•	•	•	•	•	•	0
6 Series	F06	Body	HSR Rear-axle slip-angle control	•	•	•	•	•	•	0
6 Series	F06	Body	HUD Head-Up Display	•	•	•	•	•	•	0
6 Series	F06	Body	IHKA Integrated automatic heating/air conditioning	•	•	•	•	•	•	0
6 Series	F06	Body	INSTR Instrument cluster	•	•	•		•	•	0
6 Series	F06	Body	JBE Junction-box electronics		•	•		•	•	0
6 Series	F06	Body	KAFAS Camera-based driver-assistance systems	•	•	•	•	•	•	0
6 Series	F06	Body	NVE Night Vision Electronics	•	•	•	•	•	•	0
6 Series	F06	Body	PDC Park distance control	•	•	•		•	•	0
6 Series	F06	Body	PMA Parking assistant	•	•	•	•	•	•	0
6 Series	F06	Body	RAD Radio	•	•	•		•	•	0
6 Series	F06	Body	RDC Tyre pressure control	•		•		•	•	0
0 001109	1. 00	Doug	INDO 1310 PIOSBUIC COULTOI	_			_			

Series	Model Series	Part	Systems	Ecu Info.	Read DTC	Freeze Frame	Erase DTC	Live Data	Component activation	Physical HW
6 Series	F06	Body	REM Rear electronic module	•	•	•	•	•	•	0
6 Series	F06	Body	RSE Rear Seat Entertainment	•	•	•	•	•	•	0
6 Series	F06	Body	SDARS Satellite tuner	•	•	•	•	•	•	0
6 Series	F06	Body	SEC Supplementary control unit	•	•	•	•	•	•	0
6 Series	F06	Body	SEC2 Supplementary control unit 2	•	•	•	•	•	•	0
6 Series	F06	Body	SINE Siren and tilt sensor	•	•	•	•	•	•	0
6 Series	F06	Body	SMBF Seat module, passenger	•	•	•	•	•	•	0
6 Series	F06	Body	SMBFH Seat module, passenger's side, rear	•	•	•	•	•	•	0
6 Series	F06	Body	SME Accumulator-management electronics	•	•	•	•	•	•	0
6 Series	F06	Body	SMFA Seat module, driver	•	•	•	•	•	•	0
6 Series	F06	Body	SMFAH Seat module, driver's side, rear	•	•	•	•	•	•	0
6 Series	F06	Body	SVT Servotronic	•	•	•	•	•	•	0
6 Series	F06	Body	SWW Lane change warning	•	•	•	•	•	•	0
6 Series	F06	Body	SZL Switch centre, steering column	•	•	•	•	•	•	0
6 Series	F06	Body	SDARS Satellite tuner	•	•	•	•	•	•	0
6 Series	F06	Body	TRSVC_allround-view camera	•	•	•	•	•	•	0
6 Series	F06	Body	TCU Telematic Control Unit	•	•	•	•	•	•	0
6 Series	F06	Body	ULF-SBX Interface box	•	•	•	•	•	•	0
6 Series	F06	Body	ULF-SBX-H Interface box high	•	•	•	•	•	•	0
6 Series	F06	Body	VM Video Module	•	•	•	•	•	•	0
6 Series	F06	Body	VSW video switch	•	•	•	•	•	•	0
6 Series	F06	Body	VTG Transfer case	•	•	•	•	•	•	0
6 Series	F06	Body	ZGM Central Gateway Control Module	•	•	•	•	•	•	0
I Series	I00/I12	Drive	CAS Car Access System	•	•	•	•	•	•	0
I Series	I00/I12	Drive	DDE Diesel Electronics	•	•	•	•	•	•	0
I Series	I00/I12	Drive	DME Digital Motor Electronics	•	•	•	•	•	•	0
I Series	I00/I12	Drive	DME Digital Motor Electronics 2	•	•	•	•	•	•	0
I Series	I00/I12	Drive	EGS transmission management	•	•	•	•	•	•	0
I Series	I00/I12	Drive	GWS Gear selector switch	•	•	•	•	•	•	0
I Series	I00/I12	Chassis	DSC Dynamic Stability Control	•	•	•	•	•	•	0
I Series	I00/I12	Chassis	EMF Parking brake	•	•	•	•	•	•	0
I Series	100/112	Chassis	EPS Electronic Power Steering	•	•	•	•	•	•	0
I Series	I00/I12	Body	ACSM Crash Safety Module	•	•	•	•	•	•	0
I Series	I00/I12	Body	AMPH Hi-Fi amplifier	•	•	•	•	•	•	0
I Series	I00/I12	Body	AMPT Top Hi-Fi amplifier	•	•	•	•	•	•	0
I Series	I00/I12	Body	ASD Active Sound Design	•	•	•	•	•	•	0
I Series	I00/I12	Body	CBX-ECALL Combox emergency call	•	•	•	•	•	•	0
I Series	I00/I12	Body	CBX-ECALL Combox emergency call	•	•	•	•	•	•	0
I Series	I00/I12	Body	CIC Car Information Computer	•	•	•	•	•	•	0
I Series	I00/I12	Body	CON Controller	•	•	•	•	•	•	0
I Series	I00/I12	Body	EME Electric machine electronics	•	•	•	•	•	•	0
I Series	I00/I12	Body	EME2 Electrical machine electronics	•	•	•	•	•	•	0
I Series	100/112	Body	FZD Function centre, roof	•	•	•	•	•	•	0

	100/112			Info.	DTC	Frame	DTC	Data	activation	HW
I Series		Body	IHKA Integrated automatic heating/air conditioning	•	•	•	•	•	•	0
I DOLLOD	I00/I12	Body	INSTR Instrument cluster	•	•	•	•	•	•	0
I Series	100/112	Body	KAFAS Camera-based driver-assistance systems	•	•	•	•	•	•	0
I Series	I00/I12	Body	PMA Parking assistant	•	•	•	•	•	•	0
I Series	I00/I12	Body	RAD Radio	•	•	•	•	•	•	0
I Series	I00/I12	Body	SME Accumulator-management electronics	•	•	•	•	•	•	0
I Series	I00/I12	Body	ZGM Central Gateway Control Module	•	•	•	•	•	•	0
X Series	X5_F15	Drive	CAS Car Access System	•	•	•	•	•	•	0
X Series	X5_F15	Drive	DDE Diesel Electronics	•	•	•	•	•	•	0
X Series	X5_F15	Drive	DME Digital Motor Electronics	•	•	•	•	•	•	0
X Series	X5_F15	Drive	DME Digital Motor Electronics 2	•	•	•	•	•	•	0
	X5 F15	Drive	EGS transmission management	•	•	•	•	•	•	0
	X5 F15	Drive	EKPS Fuel-pump control	•	•	•	•	•	•	0
	X5 F15	Drive	GWS Gear selector switch	•	•	•	•	•	•	0
	X5_F15	Drive	QMVH Lateral-moment distribution, rear axle	•	•	•	•	•	•	0
X Series	X5 F15	Chassis	AL active steering	•	•	•	•	•	•	0
	X5 F15	Chassis	DSC Dynamic Stability Control	•	•	•	•	•	•	0
	X5 F15	Chassis	EHC Electronic Ride-Height Control	•	•	•	•	•	•	0
X Series	X5 F15	Chassis	EMF Parking brake	•	•	•	•	•	•	0
	X5 F15		EPS Electronic Power Steering	•	•	•	•	•	•	0
	X5 F15	Chassis	ICM Integrated Chassis Management	•	•	•	•	•	•	0
	X5 F15	Chassis	VDM Vertical Dynamics Management	•	•	•	•	•	•	0
	X5 F15		VDM2 Vertical dynamics management	•	•	•	•	•	•	0
	X5 F15	Body	ACC Active Cruise Control	•	•	•	•	•	•	0
	X5 F15	Body	ACSM Crash Safety Module	•	•	•	•	•	•	0
	X5 F15	Body	AHM Trailer module	•	•	•	•	•	•	0
	X5 F15	Body	AMPH Hi-Fi amplifier	•	•	•	•	•	•	0
	X5 F15	Body	ASD Active Sound Design	•	•	•	•	•	•	0
	X5 F15	Body	CBX-ECALL Combox emergency call	•	•	•	•	•	•	0
	X5 F15	Body	CBX-MEDIA Combox Multimedia	•	•	•	•	•	•	0
	X5 F15	Body	CIC Car Information Computer	•	•	•	•	•	•	0
	X5 F15		CID Central information display	•	•	•	•	•	•	0
	X5 F15	Body	CON Controller	•	•	•	•	•	•	0
	X5 F15	Body	DVDC DVD Changer	•	•	•	•	•	•	0
	X5 F15	Body	EMALI Electric-motor reel, left	•	•	•	•	•	•	0
	X5 F15	Body	EMARE Electric-motor reel, right	•	•	•	•	•	•	0
	X5 F15	Body	EME Electric machine electronics	•	•	•	•	•	•	0
	X5 F15	Body	EME2 Electrical machine electronics	•	•	•	•	•	•	0
	X5 F15	Body	FKA Rear heater/air conditioning	•	•	•	•	•	•	0
	X5 F15	Body	FLA High Beam Assist	•	•	•	•	•	•	0
	X5_F15	Body	FRM Footwell module	•	•	•	•	•	•	0

Series	Model Series	Part	Systems	Ecu Info.	Read DTC	Freeze Frame	Erase DTC	Live Data	Component activation	Physical HW
X Series	X5_F15	Body	FZD Function centre, roof	•	•	•	•	•	•	0
X Series	X5_F15	Body	HKL Automatic luggage compartment lid actuation	•	•	•	•	•	•	0
X Series	X5 F15	Body	HKL Rear-lid lift	•	•	•	•	•	•	0
X Series	X5_F15	Body	HUD Head-Up Display	•	•	•	•	•	•	0
X Series	X5_F15	Body	IHKA Integrated automatic heating/air conditioning	•	•	•	•	•	•	0
X Series	X5 F15	Body	INSTR Instrument cluster	•	•	•	•	•	•	0
X Series	X5 F15	Body	JBE Junction-box electronics	•	•	•	•	•	•	0
X Series	X5_F15	Body	KAFAS Camera-based driver-assistance systems	•	•	•	•	•	•	0
X Series	X5 F15	Body	NVE Night Vision Electronics	•	•	•	•	•	•	0
X Series	X5_F15	Body	PDC Park distance control	•	•	•	•	•	•	0
X Series	X5 F15	Body	PMA Parking assistant	•	•	•	•	•	•	0
X Series	X5 F15	Body	PCU Power Control Unit	•	•	•	•	•	•	0
X Series	X5 F15	Body	RDC Tyre pressure control	•	•	•	•	•	•	0
X Series	X5 F15	Body	RSE Rear Seat Entertainment	•	•	•	•	•	•	0
X Series	X5 F15	Body	SEC Supplementary control unit	•	•	•	•	•	•	0
X Series	X5 F15	Body	SEC2 Supplementary control unit 2	•	•	•	•	•	•	0
X Series	X5 F15	Body	SMBF Seat module, passenger	•	•	•	•	•	•	0
X Series	X5_F15	Body	SME Accumulator-management electronics	•	•	•	•	•	•	0
X Series	X5_F15	Body	SMFA Seat module, driver	•	•	•	•	•	•	0
X Series	X5_F15	Body	SVT Servotronic	•	•	•	•	•	•	0
X Series	X5_F15	Body	SWW Lane change warning	•	•	•	•	•	•	0
X Series	X5_F15	Body	STML Headlight driver module, left	•	•	•	•	•	•	0
X Series	X5_F15	Body	STMR Headlight driver module, right	•	•	•	•	•	•	0
X Series	X5_F15	Body	TRSVC allround-view camera	•	•	•	•	•	•	0
X Series	X5_F15	Body	TBX Touchbox	•	•	•	•	•	•	0
X Series	X5 F15	Body	VM Video Module	•	•	•	•	•	•	0
X Series	X5_F15	Body	VTG Transfer case	•	•	•	•	•	•	0
X Series	X5 F15	Body	ZGM Central Gateway Control Module	•	•	•	•	•	•	0
3 Series	F80	Drive	CAS Car Access System	•	•	•	•	•	•	0
3 Series	F80	Drive	DDE Diesel Electronics	•	•	•	•	•	•	0
3 Series	F80	Drive	DME Digital Motor Electronics	•	•	•	•	•	•	0
3 Series	F80	Drive	DME Digital Motor Electronics 2	•	•	•	•	•	•	0
3 Series	F80	Drive	EGS transmission management	•	•	•	•	•	•	0
3 Series	F80	Drive	EKPS Fuel-pump control	•	•	•	•	•	•	0
3 Series	F80	Drive	GWS Gear selector switch	•	•	•	•	•	•	0
3 Series	F80		AL active steering	•	•	•	•	•	•	0
3 Series	F80	Chassis	DSC Dynamic Stability Control	•	•	•	•	•	•	0
3 Series	F80	Chassis	EHC Electronic Ride-Height Control	•	•	•	•	•	•	0
3 Series	F80	Chassis	EMF Parking brake	•	•	•	•	•	•	0
3 Series	F80	Chassis	EPS Electronic Power Steering	•	•	•	•	•	•	0
3 Series	F80	Chassis	ICM Integrated Chassis Management	•	•	•		•	•	0

3 Series F80 3 Series F80	0 0 0 10 0 0 10 0 0 10 0 0 10 0 0 10 0 0 10 0 0 10	Chassis Body Body Body Body	VDM Vertical Dynamics Management VDM2 Vertical dynamics management ACC Active Cruise Control ACSM Crash Safety Module	•	•	•	•	•	•	0
3 Series F80	0 1 0 1 0 1 0 1 0 1 0 1	Body Body Body Body	ACC Active Cruise Control ACSM Crash Safety Module	•		•		_		
3 Series F80	0] 0] 0] 0]	Body Body Body	ACSM Crash Safety Module							0
3 Series F80	10 1 10 1 10 1	Body Body				•	•	•	•	0
3 Series F80 3 Series F80 3 Series F80	30 30	Body	AIM T	•	•	•	•	•	•	0
3 Series F80 3 Series F80	30		AHM Trailer module	•	•	•	•	•	•	0
3 Series F80			AMPH Hi-Fi amplifier	•	•	•	•	•	•	0
	10	Body	ASD Active Sound Design	•	•	•	•	•	•	0
3 Series F80		Body	CBX-ECALL Combox emergency call	•	•	•	•	•	•	0
O DOLLOS LOO	0 1	Body	CBX-MEDIA Combox Multimedia	•	•	•	•	•	•	0
3 Series F80	0	Body	CIC Car Information Computer	•	•	•	•	•	•	0
3 Series F80	10	Body	CON Controller	•	•	•	•	•	•	0
3 Series F80	10	Body	CVM Convertible top module	•	•	•	•	•	•	0
3 Series F80	30		DVDC DVD Changer	•	•	•	•	•	•	0
3 Series F80			EMALI Electric-motor reel, left	•	•	•	•	•	•	0
3 Series F80			EMARE Electric-motor reel, right	•	•	•	•	•	•	0
3 Series F80			EME Electric machine electronics	•	•	•	•	•	•	0
3 Series F80			EME2 Electrical machine electronics	•	•	•	•	•	•	0
3 Series F80			FLA High Beam Assist	•	•	•	•	•	•	0
3 Series F80		_	FRM Footwell module	•	•	•	•	•	•	0
3 Series F80			FZD Function centre, roof	•	•	•	•	•	•	0
3 Series F80			GHAS Regulated differential lock	•	•	•	•	•	•	0
3 Series F80		Body	HKL Automatic luggage compartment lid actuation	•	•	•	•	•	•	0
3 Series F80	30	DOUV	IHKA Integrated automatic heating/air conditioning	•	•	•	•	•	•	0
3 Series F80	30		INSTR Instrument cluster	•	•	•	•	•	•	0
3 Series F80		Body	KAFAS Camera-based driver-assistance systems	•	•	•	•	•	•	0
3 Series F80	30		PDC Park distance control	•	•	•	•	•	•	0
3 Series F80			PMA Parking assistant	•	•	•	•	•	•	0
3 Series F80		_	RAD Radio	•	•	•	•	•	•	0
3 Series F80			RDC Tyre pressure control	•	•	•	•	•	•	0
3 Series F80			SEC Supplementary control unit	•	•	•	•	•	•	0
3 Series F80			SEC2 Supplementary control unit 2	•	•	•	•	•	•	0
3 Series F80		·	SINE Siren and tilt sensor	•	•	•	•	•	•	0
3 Series F80			SMBF Seat module, passenger	•	•	•	•	•	•	0
3 Series F80		_	SMBFH Seat module, passenger's side, rear	•	•	•	•	•	•	0
3 Series F80			SME Accumulator-management electronics	•	•	•	•	•	•	0
3 Series F80			SMFA Seat module, driver	•	•	•	•	•	•	0
3 Series F80			SMFAH Seat module, driver's side, rear	•	•	•	•	•	•	0
3 Series F80			SVT Servotronic	•	•	•	•	•	•	0
3 Series F80			SWW Lane change warning	•	•	•	•	•	•	0
3 Series F80			SZL Switch centre, steering column	•	•	•	•	•	•	0
3 Series F80			TRSVC_allround-view camera	•	•	•	•	•	•	0

Series	Model Series	Part	Systems	Ecu Info.	Read DTC	Freeze Frame	Erase DTC	Live Data	Component activation	Physical HW
3 Series	F80	Body	VM Video Module	•	•	•	•	•	•	0
3 Series	F80	Body	VTG Transfer case	•	•	•	•	•	•	0
3 Series	F80	Body	ZGM Central Gateway Control Module	•	•	•	•	•	•	0
4 Series	F82/F83	Drive	CAS Car Access System	•	•	•	•	•	•	0
4 Series	F82/F83	Drive	DDE Diesel Electronics	•	•	•	•	•	•	0
4 Series	F82/F83	Drive	DME Digital Motor Electronics	•	•	•	•	•	•	0
4 Series	F82/F83	Drive	DME Digital Motor Electronics 2	•	•	•	•	•	•	0
4 Series	F82/F83	Drive	EGS transmission management	•	•	•	•	•	•	0
4 Series	F82/F83	Drive	EKPS Fuel-pump control	•	•	•	•	•	•	0
4 Series	F82/F83	Drive	GWS Gear selector switch	•	•	•	•	•	•	0
4 Series	F82/F83	Chassis	AL active steering	•	•	•	•	•	•	0
4 Series	F82/F83	Chassis	DSC Dynamic Stability Control	•	•	•	•	•	•	0
4 Series	F82/F83	Chassis	EHC Electronic Ride-Height Control	•	•	•	•	•	•	0
4 Series	F82/F83	Chassis	EMF Parking brake	•	•	•	•	•	•	0
4 Series	F82/F83	Chassis	EPS Electronic Power Steering	•	•	•	•	•	•	0
4 Series	F82/F83	Chassis	ICM Integrated Chassis Management	•	•	•	•	•	•	0
4 Series	F82/F83	Chassis	VDM Vertical Dynamics Management	•	•		•	•	•	0
4 Series	F82/F83	Chassis	VDM2 Vertical dynamics management	•	•	•	•	•	•	Ō
4 Series	F82/F83	Body	ACC Active Cruise Control	•	•	•	•	•	•	Ō
4 Series	F82/F83	Body	ACSM Crash Safety Module	•	•	•	•	•	•	0
4 Series	F82/F83	Body	AHM Trailer module	•	•	•	•	•	•	0
4 Series	F82/F83	Body	AMPH Hi-Fi amplifier	•	•	•	•	•	•	0
4 Series	F82/F83	Body	ASD Active Sound Design	•	•	•	•	•	•	0
4 Series	F82/F83	Body	CBX-ECALL Combox emergency call	•	•	•	•	•	•	0
4 Series	F82/F83	Body	CBX-MEDIA Combox Multimedia	•	•	•	•	•	•	0
4 Series	F82/F83	Body	CIC Car Information Computer	•	•	•	•	•	•	0
4 Series	F82/F83	Body	CON Controller	•	•	•	•	•	•	0
4 Series	F82/F83	Body	CVM Convertible top module	•	•		•	•	•	0
4 Series	F82/F83	Body	DVDC DVD Changer	•	•	•	•	•	•	0
4 Series	F82/F83	Body	EMALI Electric-motor reel, left	•	•	•	•	•	•	0
4 Series	F82/F83	Body	EMARE Electric-motor reel, right	•	•		•	•	•	0
4 Series	F82/F83	Body	EME Electric machine electronics	•	•	•	•	•	•	0
4 Series	F82/F83	Body	EME2 Electrical machine electronics	•	•	•	•	•	•	0
4 Series	F82/F83	Body	FLA High Beam Assist	-	•	•		•		0
4 Series	F82/F83	Body	FRM Footwell module	•	•			•		0
4 Series	F82/F83	Body	FZD Function centre, roof	•				•	•	0
4 Series	F82/F83	Body	GHAS Regulated differential lock	•	•	•	•	•	•	0
4 Series	F82/F83	Body	HKL Automatic luggage compartment lid actuation	•	•	•	•	•	•	0
4 Series	F82/F83	Body	IHKA Integrated automatic heating/air conditioning	•	•	•	•	•	•	0
4 Series	F82/F83	Body	INSTR Instrument cluster	•	•	•	•	•	•	0
4 Series	F82/F83	Body	KAFAS Camera-based driver-assistance systems	•	•	•	•	•	•	0

Series	Model Series	Part	Systems	Ecu Info.	Read DTC	Freeze Frame	Erase DTC	Live Data	Component activation	Physical HW
4 Series	F82/F83	Body	PDC Park distance control	•	•	•	•	•	•	0
4 Series	F82/F83	Body	PMA Parking assistant	•	•	•	•	•	•	0
4 Series	F82/F83	Body	RAD Radio	•	•	•	•	•	•	0
4 Series	F82/F83	Body	RDC Tyre pressure control	•	•	•	•	•	•	0
4 Series	F82/F83	Body	SEC Supplementary control unit	•	•	•	•	•	•	0
4 Series	F82/F83	Body	SEC2 Supplementary control unit 2	•	•	•	•	•	•	0
4 Series	F82/F83	Body	SINE Siren and tilt sensor	•	•	•	•	•	•	0
4 Series	F82/F83	Body	SMBF Seat module, passenger	•	•	•	•	•	•	0
4 Series	F82/F83	Body	SMBFH Seat module, passenger's side, rear	•	•	•	•	•	•	0
4 Series	F82/F83	Body	SME Accumulator-management electronics	•	•	•	•	•	•	0
4 Series	F82/F83	Body	SMFA Seat module, driver	•	•	•	•	•	•	0
4 Series	F82/F83	Body	SMFAH Seat module, driver's side, rear	•	•	•	•	•	•	0
4 Series	F82/F83	Body	SVT Servotronic	•	•	•	•	•	•	0
4 Series	F82/F83	Body	SWW Lane change warning	•	•	•	•	•	•	0
4 Series	F82/F83	Body	SZL Switch centre, steering column	•	•	•	•	•	•	0
4 Series	F82/F83	Body	TRSVC_allround-view camera	•	•	•	•	•	•	0
4 Series	F82/F83	Body	VM Video Module	•	•	•	•	•	•	0
4 Series	F82/F83	Body	VTG Transfer case	•	•	•	•	•	•	0
4 Series	F82/F83	Body	ZGM Central Gateway Control Module	•	•	•	•	•	•	0
X Series	X4 F26	Drive	CAS Car Access System	•	•	•	•	•	•	0
X Series	X4 F26	Drive	DDE Diesel Electronics	•	•	•	•	•	•	0
X Series	X4 F26	Drive	DME Digital Motor Electronics	•	•	•	•	•	•	0
X Series	X4 F26	Drive	EGS transmission management	•	•	•	•	•	•	0
X Series	X4 F26	Drive	EKPS Fuel-pump control	•	•	•	•	•	•	0
X Series	X4 F26	Drive	GWS Gear selector switch	•	•	•	•	•	•	0
X Series	X4 F26	Chassis	DSC Dynamic Stability Control	•	•	•	•	•	•	0
X Series	X4 F26	Chassis	EMF Parking brake	•	•	•	•	•	•	0
X Series	X4 F26	Chassis	EPS Electronic Power Steering	•	•	•	•	•	•	0
X Series	X4 F26	Chassis	ICM Integrated Chassis Management	•	•	•	•	•	•	0
X Series	X4 F26	Chassis	VDM Vertical Dynamics Management	•	•	•	•	•	•	0
X Series	X4 F26	Body	ACC Active Cruise Control	•	•		•	•	•	0
X Series	X4 F26	Body	ACSM Crash Safety Module	•	•	•	•	•	•	0
X Series	X4 F26	Body	AHM Trailer module	•	•	•	•	•	•	0
X Series	X4 F26	Body	AMPT Top Hi-Fi amplifier	•	•	•	•	•	•	0
X Series	X4 F26	Body	CBX-ECALL Combox emergency call	•	•	•	•	•	•	0
X Series	X4 F26	Body	CBX-MEDIA Combox Multimedia	•	•	•	•	•	•	0
X Series	X4 F26	Body	CID Central Information Display	•	•	•	•	•	•	0
X Series	X4 F26	Body	CON Controller	•	•	•	•	•	•	0
X Series	X4_F26	Body	DVDC DVD Changer	•	•		•	•	•	0
X Series	X4 F26	Body	FLA High Beam Assist	•	•	•	•	•	•	0
X Series	X4_F26	Body	FRM Footwell module	•	•		•	•	•	0
X Series	X4_F26	Body	FZD Function centre, roof	•	•	•	•	•	•	0
X Series	X4 F26	Body	GHAS Regulated differential lock		•	•		•	•	0
X Series	X4_F26	Body	HKL Rear-lid lift			•		•		0
v DOLLOR	A 1_1 20	Doug	IIID ROOF THE THE							$\overline{}$

Series	Model Series	Part	Systems	Ecu Info.	Read DTC	Freeze Frame	Erase DTC	Live Data	Component activation	Physical HW
X Series	X4_F26	Body	HKL Automatic luggage compartment lid actuation	•	•	•	•	•	•	0
X Series	X4_F26	Body	HUD Head-Up Display	•	•	•	•	•	•	0
X Series	X4_F26	Body	IHKA Integrated automatic heating/air conditioning	•	•	•	•	•	•	0
X Series	X4 F26	Body	JBE Junction-box electronics	•	•	•	•	•	•	0
X Series	X4_F26	Body	KAFAS Camera-based driver-assistance systems	•	•	•	•	•	•	0
X Series	X4 F26	Body	INSTR Instrument cluster	•	•	•	•	•	•	0
X Series	X4_F26	Body	PDC Park Distance Control	•	•	•	•	•	•	0
X Series	X4_F26	Body	RAD Radio	•	•	•	•	•	•	0
X Series	X4_F26	Body	RDC Tyre pressure control	•	•	•	•	•	•	0
X Series	X4_F26	Body	SMBF Seat module, passenger	•	•	•	•	•	•	0
X Series	X4 F26	Body	SMBFH Seat module, passenger's side, rear	•	•	•	•	•	•	0
X Series	X4_F26	Body	SMFA Seat module, driver	•	•	•	•	•	•	0
X Series	X4_F26	Body	SMFAH Seat module, driver's side, rear	•	•	•	•	•	•	0
X Series	X4_F26	Body	SWW Lane change warning	•	•	•	•	•	•	0
X Series	X4_F26	Body	SZL Switch centre, steering column	•	•	•	•	•	•	0
X Series	X4_F26	Body	TRSVC allround-view camera	•	•	•	•	•	•	0
X Series	X4 F26	Body	VM Video Module	•	•	•	•	•	•	0
X Series	X4_F26	Body	VTG Transfer case	•	•	•	•	•	•	0
X Series	X4_F26	Body	ZGM Central Gateway Control Module	•	•	•	•	•	•	0
X Series	X5_F85	Drive	CAS Car Access System	•	•	•	•	•	•	0
X Series	X5_F85	Drive	DDE Diesel Electronics	•	•	•	•	•	•	0
X Series	X5_F85	Drive	DME Digital Motor Electronics	•	•	•	•	•	•	0
X Series	X5_F85	Drive	DME Digital Motor Electronics 2	•	•	•	•	•	•	0
X Series	X5_F85	Drive	EGS transmission management	•	•	•	•	•	•	0
X Series	X5_F85	Drive	EKPS Fuel-pump control	•	•	•	•	•	•	0
X Series	X5_F85	Drive	GWS Gear selector switch	•	•	•	•	•	•	0
X Series	X5_F85	Drive	QMVH Lateral-moment distribution, rear axle	•	•	•	•	•	•	0
X Series	X5_F85	Chassis	AL active steering	•	•	•	•	•	•	0
X Series	X5_F85	Chassis	DSC Dynamic Stability Control	•	•	•	•	•	•	0
X Series	X5_F85		EHC Electronic Ride-Height Control	•	•	•	•	•	•	0
X Series	X5_F85		EMF Parking brake	•	•	•	•	•	•	0
X Series	X5_F85	Chassis	EPS Electronic Power Steering	•	•	•	•	•	•	0
X Series	X5_F85	Chassis	ICM Integrated Chassis Management	•	•	•	•	•	•	0
X Series	X5_F85	Chassis	VDM Vertical Dynamics Management	•	•	•	•	•	•	0
X Series	X5_F85	Chassis	VDM2 Vertical dynamics management	•	•	•	•	•	•	0
X Series	X5_F85	Body	ACC Active Cruise Control	•	•	•	•	•	•	0
X Series	X5_F85	Body	ACSM Crash Safety Module	•	•	•	•	•	•	0
X Series	X5 F85	Body	AHM Trailer module	•	•	•	•	•	•	0
X Series	X5_F85	Body	AMPH Hi-Fi amplifier	•	•	•	•	•	•	0
X Series	X5 F85	Body	ASD Active Sound Design	•	•	•	•	•	•	0

Series	Model Series	Part	Systems	Ecu Info.	Read DTC	Freeze Frame	Erase DTC	Live Data	Component activation	Physical HW
X Series	X5_F85	Body	CBX-ECALL Combox emergency call	•	•	•	•	•	•	0
X Series	X5_F85	Body	CBX-MEDIA Combox Multimedia	•	•	•	•	•	•	0
X Series	X5 F85	Body	CIC Car Information Computer	•	•	•	•	•	•	0
X Series	X5_F85	Body	CID Central information display	•	•	•	•	•	•	0
X Series	X5 F85	Body	CON Controller	•	•	•	•	•	•	0
X Series	X5 F85	Body	DVDC DVD Changer	•	•	•	•	•	•	0
X Series	X5_F85	Body	EMALI Electric-motor reel, left	•	•	•	•	•	•	0
X Series	X5 F85	Body	EMARE Electric-motor reel, right	•	•	•	•	•	•	0
X Series	X5 F85	Body	EME Electric machine electronics	•	•	•	•	•	•	0
X Series	X5 F85	Body	EME2 Electrical machine electronics	•	•	•	•	•	•	0
X Series	X5 F85	Body	FKA Rear heater/air conditioning	•	•	•	•	•	•	0
X Series	X5 F85	Body	FLA High Beam Assist	•	•	•	•	•	•	0
X Series	X5_F85	Body	FRM Footwell module	•	•	•	•	•	•	0
X Series	X5_F85	Body	FZD Function centre, roof	•	•	•	•	•	•	0
X Series	X5_F85	Body	HKL Automatic luggage compartment lid actuation	•	•	•	•	•	•	0
X Series	X5 F85	Body	HKL Rear-lid lift	•	•	•	•	•	•	0
X Series	X5 F85	Body	HUD Head-Up Display	•	•	•	•	•	•	0
X Series	X5_F85	Body	IHKA Integrated automatic heating/air conditioning	•	•	•	•	•	•	0
X Series	X5 F85	Body	INSTR Instrument cluster	•	•	•	•	•	•	0
X Series	X5 F85	Body	JBE Junction-box electronics	•	•	•	•	•	•	0
X Series	X5_F85	Body	KAFAS Camera-based driver-assistance systems	•	•	•	•	•	•	0
X Series	X5 F85	Body	NVE Night Vision Electronics	•	•	•	•	•	•	0
X Series	X5 F85	Body	PDC Park distance control	•	•	•	•	•	•	0
X Series	X5_F85	Body	PMA Parking assistant	•	•	•	•	•	•	0
X Series	X5 F85	Body	PCU Power Control Unit	•	•	•	•	•	•	0
X Series	X5 F85	Body	RDC Tyre pressure control	•	•	•	•	•	•	0
X Series	X5 F85	Body	RSE Rear Seat Entertainment	•	•	•	•	•	•	0
X Series	X5 F85	Body	SEC Supplementary control unit	•	•	•	•	•	•	0
X Series	X5_F85	Body	SEC2 Supplementary control unit 2	•	•	•	•	•	•	0
X Series	X5_F85	Body	SMBF Seat module, passenger	•	•	•	•	•	•	0
X Series	X5 F85	Body	SME Accumulator-management electronics	•	•	•	•	•	•	0
X Series	X5 F85	Body	SMFA Seat module, driver	•	•	•	•	•	•	0
X Series	X5 F85	Body	SVT Servotronic	•	•	•	•	•	•	0
X Series	X5 F85	Body	SWW Lane change warning	•	•	•	•	•	•	0
X Series	X5 F85	Body	STML Headlight driver module, left	•	•	•	•	•	•	0
X Series	X5 F85	Body	STMR Headlight driver module, right	•	•	•	•	•	•	0
X Series	X5 F85	Body	TRSVC allround-view camera	•	•	•	•	•	•	0
X Series	X5 F85	Body	TBX Touchbox	•	•	•	•	•	•	0
X Series	X5 F85	Body	VM Video Module	•	•	•	•	•	•	0
X Series	X6 F16	Body	VTG Transfer case	•	•	•	•	•	•	0
X Series	X6_F16	Body	ZGM Central Gateway Control Module	•	•	•	•	•	•	0

Series	Model Series	Part	Systems	Ecu Info.	Read DTC	Freeze Frame	Erase DTC	Live Data	Component activation	Physical HW
X Series	X6_F16	Drive	CAS Car Access System	•	•	•	•	•	•	0
X Series	X6_F16	Drive	DDE Diesel Electronics	•	•	•	•	•	•	0
X Series	X6 F16	Drive	DME Digital Motor Electronics	•	•	•	•	•	•	0
X Series	X6_F16	Drive	DME Digital Motor Electronics 2	•	•	•	•	•	•	0
X Series	X6 F16	Drive	EGS transmission management	•	•	•	•	•	•	0
X Series	X6 F16	Drive	EKPS Fuel-pump control	•	•	•	•	•	•	0
X Series	X6_F16	Drive	GWS Gear selector switch	•	•	•	•	•	•	0
X Series	X6_F16	Drive	QMVH Lateral-moment distribution, rear axle	•	•	•	•	•	•	0
X Series	X6 F16	Chassis	AL active steering	•	•	•	•	•	•	0
X Series	X6 F16	Chassis	DSC Dynamic Stability Control	•	•	•	•	•	•	0
X Series	X6 F16	Chassis	EHC Electronic Ride-Height Control	•	•	•	•	•	•	0
X Series	X6 F16	Chassis	EMF Parking brake	•	•	•	•	•	•	0
X Series	X6 F16	Chassis	EPS Electronic Power Steering	•	•	•	•	•	•	0
X Series	X6 F16	Chassis	ICM Integrated Chassis Management	•	•	•	•	•	•	0
X Series	X6 F16	Chassis	VDM Vertical Dynamics Management	•	•	•	•	•	•	0
X Series	X6 F16	Chassis	VDM2 Vertical dynamics management	•	•	•	•	•	•	0
X Series	X6 F16	Body	ACC Active Cruise Control	•	•	•	•	•	•	0
X Series	X6 F16	Body	ACSM Crash Safety Module	•	•	•	•	•	•	0
X Series	X6 F16	Body	AHM Trailer module	•	•	•	•	•	•	0
X Series	X6 F16	Body	AMPH Hi-Fi amplifier	•	•	•	•	•	•	0
X Series	X6 F16	Body	ASD Active Sound Design	•	•	•	•	•	•	0
X Series	X6 F16	Body	CBX-ECALL Combox emergency call	•	•	•	•	•	•	0
X Series	X6 F16	Body	CBX-MEDIA Combox Multimedia	•	•	•	•	•	•	0
X Series	X6 F16	Body	CIC Car Information Computer	•	•	•	•	•	•	0
X Series	X6 F16	Body	CID Central information display	•	•	•	•	•	•	0
X Series	X6 F16	Body	CON Controller	•	•	•	•	•	•	0
X Series	X6 F16	Body	DVDC DVD Changer	•	•	•	•	•	•	0
X Series	X6 F16	Body	EMALI Electric-motor reel, left	•	•	•	•	•	•	0
X Series	X6 F16	Body	EMARE Electric-motor reel, right	•	•	•	•	•	•	0
X Series	X6 F16	Body	EME Electric machine electronics	•	•	•	•	•	•	0
X Series	X6 F16	Body	EME2 Electrical machine electronics	•	•	•	•	•	•	0
X Series	X6 F16	Body	FKA Rear heater/air conditioning	•	•	•	•	•	•	0
X Series	X6 F16	Body	FLA High Beam Assist	•	•	•	•	•	•	0
X Series	X6 F16	Body	FRM Footwell module	•	•	•	•	•	•	0
X Series	X6 F16	Body	FZD Function centre, roof	•	•	•	•	•	•	0
X Series	X6_F16	Body	HKL Automatic luggage compartment lid actuation	•	•	•	•	•	•	0
X Series	X6_F16	Body	HKL Rear-lid lift	•	•	•	•	•	•	0
X Series	X6 F16	Body	HUD Head-Up Display	•	•	•	•	•	•	0
X Series	X6_F16	Body	IHKA Integrated automatic heating/air conditioning	•	•	•	•	•	•	0
X Series	X6 F16	Body	INSTR Instrument cluster	•	•	•	•	•	•	0
X Series	X6_F16	Body	JBE Junction-box electronics	•	•	•	•	•	•	0

Series	Model Series	Part	Systems	Ecu Info.	Read DTC	Freeze Frame	Erase DTC	Live Data	Component activation	Physical HW
X Series	X6_F16	Body	KAFAS Camera-based driver-assistance systems	•	•	•	•	•	•	0
X Series	X6_F16	Body	NVE Night Vision Electronics	•	•	•	•	•	•	0
X Series	X6_F16	Body	PDC Park distance control	•	•	•	•	•	•	0
X Series	X6_F16	Body	PMA Parking assistant	•	•	•	•	•	•	0
X Series	X6_F16	Body	PCU Power Control Unit	•	•	•	•	•	•	0
X Series	X6_F16	Body	RDC Tyre pressure control		•	•	•	•	•	0
X Series	X6_F16	Body	RSE Rear Seat Entertainment	•	•	•	•	•	•	0
X Series	X6_F16	Body	SEC Supplementary control unit		•	•	•	•	•	0
X Series	X6_F16	Body	SEC2 Supplementary control unit 2	•	•	•	•	•	•	0
X Series	X6_F16	Body	SMBF Seat module, passenger	•	•	•	•	•	•	0
X Series	X6_F16	Body	SME Accumulator-management electronics	•	•	•	•	•	•	0
X Series	X6_F16	Body	SMFA Seat module, driver	•	•	•	•	•	•	0
X Series	X6_F16	Body	SVT Servotronic	•	•	•	•	•	•	0
X Series	X6 F16	Body	SWW Lane change warning	•	•	•	•	•	•	0
X Series	X6 F16	Body	STML Headlight driver module, left	•	•	•	•	•	•	0
X Series	X6 F16	Body	STMR Headlight driver module, right	•	•	•	•	•	•	0
X Series	X6 F16	Body	TRSVC allround-view camera	•	•	•	•	•	•	0
X Series	X6 F16	Body	TBX Touchbox	•	•	•	•	•	•	0
X Series	X6 F16	Body	VM Video Module	•	•	•	•	•	•	0
X Series	X6_F16	Body	VTG Transfer case	•	•	•	•	•	•	0
X Series	X6 F16	Body	ZGM Central Gateway Control Module	•	•	•	•	•	•	0
X Series	X6 F86	Drive	CAS Car Access System	•	•	•	•	•	•	0
X Series	X6 F86	Drive	DDE Diesel Electronics	•	•	•	•	•	•	0
X Series	X6 F86	Drive	DME Digital Motor Electronics	•	•	•	•	•	•	0
X Series	X6 F86	Drive	DME Digital Motor Electronics 2	•	•	•	•	•	•	0
X Series	X6 F86	Drive	EGS transmission management	•	•	•	•	•	•	0
X Series	X6_F86	Drive	EKPS Fuel-pump control	•	•	•	•	•	•	0
X Series	X6_F86	Drive	GWS Gear selector switch	•	•	•	•	•	•	0
X Series	X6_F86	Drive	QMVH Lateral-moment distribution, rear axle	•	•	•	•	•	•	0
X Series	X6_F86	Chassis	AL active steering	•	•	•	•	•	•	0
X Series	X6_F86	Chassis	DSC Dynamic Stability Control	•	•	•	•	•	•	0
X Series	X6 F86		EHC Electronic Ride-Height Control	•	•	•	•	•	•	0
X Series	X6_F86		EMF Parking brake	•	•	•	•	•	•	0
X Series	X6 F86	Chassis	EPS Electronic Power Steering	•	•	•	•	•	•	0
X Series	X6 F86	Chassis	ICM Integrated Chassis Management	•	•	•	•	•	•	Ö
X Series	X6_F86	Chassis	VDM Vertical Dynamics Management	•	•	•	•	•	•	0
X Series	X6 F86	Chassis	VDM2 Vertical dynamics management	•	•	•	•	•	•	0
X Series	X6_F86	Body	ACC Active Cruise Control	•	•	•	•	•	•	Ö
X Series	X6 F86	Body	ACSM Crash Safety Module	•	•	•	•	•	•	0
X Series	X6 F86	Body	AHM Trailer module	•	•	•	•	•	•	0
X Series	X6 F86	Body	AMPH Hi-Fi amplifier	•	•	•	•	•	•	0
X Series	X6 F86	Body	ASD Active Sound Design	•	•	•	•	•	•	0

Series	Model Series	Part	Systems	Ecu Info.	Read DTC	Freeze Frame	Erase DTC	Live Data	Component activation	Physical HW
X Series	X6_F86	Body	CBX-ECALL Combox emergency call	•	•	•	•	•	•	0
X Series	X6_F86	Body	CBX-MEDIA Combox Multimedia	•	•	•	•	•	•	0
X Series	X6 F86	Body	CIC Car Information Computer	•	•	•	•	•	•	0
X Series	X6_F86	Body	CID Central information display	•	•	•	•	•	•	0
X Series	X6 F86	Body	CON Controller	•	•	•	•	•	•	0
X Series	X6 F86	Body	DVDC DVD Changer	•	•	•	•	•	•	0
X Series	X6_F86	Body	EMALI Electric-motor reel, left	•	•	•	•	•	•	0
X Series	X6 F86	Body	EMARE Electric-motor reel, right	•	•	•	•	•	•	0
X Series	X6 F86	Body	EME Electric machine electronics	•	•	•	•	•	•	0
X Series	X6 F86	Body	EME2 Electrical machine electronics	•	•	•	•	•	•	0
X Series	X6 F86	Body	FKA Rear heater/air conditioning	•	•	•	•	•	•	0
X Series	X6 F86	Body	FLA High Beam Assist	•	•	•	•	•	•	0
X Series	X6 F86	Body	FRM Footwell module	•	•	•	•	•	•	0
X Series	X6_F86	Body	FZD Function centre, roof	•	•	•	•	•	•	0
X Series	X6_F86	Body	HKL Automatic luggage compartment lid actuation	•	•	•	•	•	•	0
X Series	X6 F86	Body	HKL Rear-lid lift	•	•	•	•	•	•	0
X Series	X6 F86	Body	HUD Head-Up Display	•	•	•	•	•	•	0
X Series	X6_F86	Body	IHKA Integrated automatic heating/air conditioning	•	•	•	•	•	•	0
X Series	X6 F86	Body	INSTR Instrument cluster	•	•	•	•	•	•	0
X Series	X6_F86	Body	JBE Junction-box electronics	•	•	•	•	•	•	0
X Series	X6_F86	Body	KAFAS Camera-based driver-assistance systems	•	•	•	•	•	•	0
X Series	X6 F86	Body	NVE Night Vision Electronics	•	•	•	•	•	•	0
X Series	X6 F86	Body	PDC Park distance control	•	•	•	•	•	•	0
X Series	X6_F86	Body	PMA Parking assistant	•	•	•	•	•	•	0
X Series	X6 F86	Body	PCU Power Control Unit	•	•	•	•	•	•	0
X Series	X6 F86	Body	RDC Tyre pressure control	•	•	•	•	•	•	0
X Series	X6 F86	Body	RSE Rear Seat Entertainment	•	•	•	•	•	•	0
X Series	X6 F86	Body	SEC Supplementary control unit	•	•	•	•	•	•	0
X Series	X6_F86	Body	SEC2 Supplementary control unit 2	•	•	•	•	•	•	0
X Series	X6_F86	Body	SMBF Seat module, passenger	•	•	•	•	•	•	0
X Series	X6 F86	Body	SME Accumulator-management electronics	•	•	•	•	•	•	0
X Series	X6_F86	Body	SMFA Seat module, driver	•	•	•	•	•	•	0
X Series	X6 F86	Body	SVT Servotronic	•	•	•	•	•	•	0
X Series	X6_F86	Body	SWW Lane change warning	•	•	•	•	•	•	0
X Series	X6_F86	Body	STML Headlight driver module, left	•	•	•	•	•	•	0
X Series	X6_F86	Body	STMR Headlight driver module, right	•	•	•	•	•	•	0
X Series	X6_F86	Body	TRSVC allround-view camera	•	•	•	•	•	•	0
X Series	X6 F86	Body	TBX Touchbox	•	•	•	•	•	•	0
X Series	X6 F86	Body	VM Video Module	•	•	•	•	•	•	0
X Series	X6 F86	Body	VTG Transfer case	•	•	•	•	•	•	0
X Series	X6_F86	Body	ZGM Central Gateway Control Module	•	•	•	•	•	•	0

Series	Model Series	Part	Systems	Ecu Info.	Read DTC	Freeze Frame	Erase DTC	Live Data	Component activation	Physical HW
1 Series	F21	Drive	Engine-DDE Diesel Electronics	•	•	•	•	•	•	0
1 Series	F21	Drive	Engine-DME Digital Motor Electronics	•	•	•	•	•	•	0
1 Series	F21	Drive	EGS transmission management	•	•	•	•	•	•	0
1 Series	F21	Drive	EKPS fuel-pump control	•	•	•	•	•	•	0
1 Series	F21	Drive	GWS Gear selector switch	•	•	•	•	•	•	0
1 Series	F21	Chassis	ABS-DSC Dynamic Stability Control	•	•	•	•	•	•	0
1 Series	F21	Chassis	EPS Electronic Power Steering	•	•	•	•	•	•	0
1 Series	F21	Chassis	VDM Vertical dynamics management	•	•	•	•	•	•	0
1 Series	F21	Chassis	VDM2 Vertical dynamics management	•	•	•	•	•	•	0
1 Series	F21	Chassis	ACC Active Cruise Control	•	•	•	•	•	•	0
1 Series	F21	Body	Airbag-ACSM Crash Safety Module	•	•	•	•	•	•	0
1 Series	F21	Body	AHM trailer module	•	•	•	•	•	•	0
1 Series	F21	Body	AMPH Hi-Fi amplifier	•	•	•	•	•	•	0
1 Series	F21	Body	CBX-ECALL ComBox emergency call	•	•	•	•	•	•	0
1 Series	F21	Body	CBX-MEDIA ComBox Multimedia	•	•	•	•	•	•	0
1 Series	F21	Body	CIC Car Information Computer	•	•	•	•	•	•	0
1 Series	F21	Body	CID Central Information Display	•	•	•	•	•	•	0
1 Series	F21	Body	CON Controller	•	•	•	•	•	•	0
1 Series	F21	Body	DSP Digital Sound Processor	•	•	•	•	•	•	0
1 Series	F21	Body	DVDC DVD changer	•	•	•	•	•	•	0
1 Series	F21	Body	FCON Rear compartment controller	•	•	•	•	•	•	0
1 Series	F21	Body	FEM Front Electronic Module	•	•	•	•	•	•	0
1 Series	F21	Body	FLA High Beam Assist	•	•	•	•	•	•	0
1 Series	F21	Body	FZD Function centre, roof	•	•	•	•	•	•	0
1 Series	F21	Chassis	ICM Integrated Chassis Management	•	•	•	•	•	•	0
1 Series	F21	Body	IHKA Integrated automatic heating/air conditioning	•	•	•	•	•	•	0
1 Series	F21	Body	INSTR Instrument cluster	•	•	•	•	•	•	0
1 Series	F21	Body	KAFAS Camera-based driver-assistance systems	•	•	•	•	•	•	0
1 Series	F21	Body	PDC Park Distance Control	•	•	•	•	•	•	0
1 Series	F21	Body	PMA Parking assistant	•	•	•	•	•	•	0
1 Series	F21	Body	RAD Radio	•	•	•	•	•	•	0
1 Series	F21	Body	REM Rear Electronic Module	•	•	•	•	•	•	0
1 Series	F21	Body	SMBF Seat module, passenger	•	•	•	•	•	•	0
1 Series	F21	Body	SMBFH seat module, passenger's side, rear	•	•	•	•	•	•	0
1 Series	F21	Body	SMFA Seat module, driver	•	•	•	•	•	•	0

Series	Model Series	Part	Systems	Ecu Info.	Read DTC	Freeze Frame	Erase DTC	Live Data	Component activation	Physical HW
1 Series	F21	Body	SMFAH Seat module, driver's side, rear	•	•	•	•	•	•	0
1 Series	F21	Body	SWW Lane change warning	•	•	•	•	•	•	0
1 Series	F21	Body	TRSVC allround-view camera	•	•	•	•	•	•	0
1 Series	F21	Body	TBX Touchbox	•	•	•	•	•	•	0
1 Series	F21	Body	ZGM Central Gateway Control Module	•	•	•	•	•	•	0
2 Series	F23	Drive	CAS Car access system	•	•	•	•	•	•	0
2 Series	F23	Drive	Engine-DDE Diesel Electronics	•	•	•	•	•	•	0
2 Series	F23	Drive	Engine-DME Digital Motor Electronics	•	•	•	•	•	•	0
2 Series	F23	Drive	Engine-DME Digital Motor Electronics 2	•	•	•	•	•	•	0
2 Series	F23	Drive	EGS transmission management	•	•	•	•	•	•	0
2 Series	F23	Drive	EKPS fuel-pump control	•	•	•	•	•	•	0
2 Series	F23	Drive	GWS Gear selector switch	•	•	•	•	•	•	0
2 Series	F23	Chassis	AL active steering	•	•	•	•	•	•	0
2 Series	F23	Chassis	ABS-DSC Dynamic Stability Control	•	•	•	•	•	•	0
2 Series	F23	Chassis	EHC Electronic Ride-Height Control	•	•	•	•	•	•	0
2 Series	F23	Chassis	EMF Parking brake	•	•	•	•	•	•	0
2 Series	F23	Chassis	EPS Electronic Power Steering	•	•	•	•	•	•	0
2 Series	F23	Chassis	ICM Integrated Chassis Management	•	•	•	•	•	•	0
2 Series	F23	Chassis	VDM Vertical dynamics management	•	•	•	•	•	•	0
2 Series	F23	Chassis	VDM2 Vertical dynamics management	•	•	•	•	•	•	0
2 Series	F23	Chassis	ACC Active Cruise Control	•	•	•	•	•	•	0
2 Series	F23	Body	Airbag-ACSM Crash Safety Module	•	•	•	•	•	•	0
2 Series	F23	Body	AHM trailer module	•	•	•	•	•	•	0
2 Series	F23	Body	AMPH Hi-Fi amplifier	•	•	•	•	•	•	0
2 Series	F23	Body	ASD Active Sound Design	•	•	•	•	•	•	0
2 Series	F23	Body	CBX-ECALL ComBox emergency call	•	•	•	•	•	•	0
2 Series	F23	Body	CBX-MEDIA ComBox Multimedia	•	•	•	•	•	•	0
2 Series	F23	Body	CIC Car Information Computer	•	•	•	•	•	•	0
2 Series	F23	Body	CON Controller	•	•	•	•	•	•	0
2 Series	F23	Body	CVM Convertible top module	•	•	•	•	•	•	0
2 Series	F23	Body	DSP Digital Sound Processor	•	•	•	•	•	•	0
2 Series	F23	Body	DVDC DVD changer	•	•	•	•	•	•	0
2 Series	F23	Body	EMALI Electric-motor reel, left	•	•	•	•	•	•	0
2 Series	F23	Body	EMARE Electric-motor reel, right	•	•	•	•	•	•	0
2 Series	F23	Body	EME Electric machine electronics	•	•	•	•	•	•	0
2 Series	F23	Body	EME2 Electrical machine electronics	•	•	•	•	•	•	0
2 Series	F23	Body	FLA High Beam Assist	•	•	•	•	•	•	0

Series	Model Series	Part	Systems	Ecu Info.	Read DTC	Freeze Frame	Erase DTC	Live Data	Component activation	Physical HW
2 Series	F23	Body	FRM Footwell module	•	•	•	•	•	•	0
2 Series	F23	Body	FZD Function centre, roof	•	•	•	•	•	•	0
2 Series	F23	Body	GHAS Regulated differential lock	•	•	•	•	•	•	0
2 Series	F23	Body	HKL Automatic luggage compartment lid actuation	•	•	•	•	•	•	0
2 Series	F23	Body	IHKA Integrated automatic heating/air conditioning	•	•	•	•	•	•	0
2 Series	F23	Body	INSTR Instrument cluster	•	•	•	•	•	•	0
2 Series	F23	Body	KAFAS Camera-based driver-assistance systems	•	•	•	•	•	•	0
2 Series	F23	Body	PDC Park Distance Control	•	•	•	•	•	•	0
2 Series	F23	Body	PMA Parking assistant	•	•	•	•	•	•	0
2 Series	F23	Body	RAD Radio	•	•	•	•	•	•	0
2 Series	F23	Chassis	RDC tyre pressure control	•	•	•	•	•	•	0
2 Series	F23	Body	SEC Supplementary control unit	•	•	•	•	•	•	0
2 Series	F23	Body	SEC2 Supplementary control unit 2	•	•	•	•	•	•	0
2 Series	F23	Body	SINE Siren and tilt sensor	•	•	•	•	•	•	0
2 Series	F23	Body	SMBF Seat module, passenger	•	•	•	•	•	•	0
2 Series	F23	Body	SMBFH seat module, passenger's side, rear	•	•	•	•	•	•	0
2 Series	F23	Body	SME Accumulator-management electronics	•	•	•	•	•	•	0
2 Series	F23	Body	SMFA Seat module, driver	•	•	•	•	•	•	0
2 Series	F23	Body	SMFAH Seat module, driver's side, rear	•	•	•	•	•	•	0
2 Series	F23	Chassis	SVT Servotronic	•	•	•	•	•	•	0
2 Series	F23	Body	SWW Lane change warning	•	•	•	•	•	•	0
2 Series	F23	Body	Airbag-SZL Switch centre, steering column	•	•	•	•	•	•	0
2 Series	F23	Body	TRSVC allround-view camera	•	•	•	•	•	•	0
2 Series	F23	Body	TBX Touchbox	•	•	•	•	•	•	0
2 Series	F23	Body	VM Video module	•	•	•	•	•	•	0
2 Series	F23	Drive	VTG Transfer case	•	•	•	•	•	•	0
2 Series	F23	Body	ZGM Central Gateway Control Module	•	•	•	•	•	•	0
2 Series	F45	Drive	CAS Car access system	•	•	•	•	•	•	0
2 Series	F45	Drive	Engine-DDE Diesel Electronics	•	•	•	•	•	•	0
2 Series	F45	Drive	Engine-DME Digital Motor Electronics	•	•	•	•	•	•	0
2 Series	F45	Drive	Engine-DME Digital Motor Electronics 2	•	•	•	•	•	•	0
2 Series	F45	Drive	EGS transmission management	•	•	•	•	•	•	0
2 Series	F45	Drive	EKPS fuel-pump control	•	•	•	•	•	•	0
2 Series	F45	Drive	GWS Gear selector switch	•	•	•	•	•	•	0

Series	Model Series	Part	Systems	Ecu Info.	Read DTC	Freeze Frame	Erase DTC	Live Data	Component activation	Physical HW
2 Series	F45	Chassis	AL active steering	•	•	•	•	•	•	0
2 Series	F45	Chassis	ABS-DSC Dynamic Stability Control	•	•	•	•	•	•	0
2 Series	F45	Chassis	EHC Electronic Ride-Height Control	•	•	•	•	•	•	0
2 Series	F45	Chassis	EMF Parking brake	•	•	•	•	•	•	0
2 Series	F45	Chassis	EPS Electronic Power Steering	•	•	•	•	•	•	0
2 Series	F45	Chassis	ICM Integrated Chassis Management	•	•	•	•	•	•	0
2 Series	F45	Chassis	VDM Vertical dynamics management	•	•	•	•	•	•	0
2 Series	F45	Chassis	VDM2 Vertical dynamics management	•	•	•	•	•	•	0
2 Series	F45	Chassis	ACC Active Cruise Control	•	•	•	•	•	•	0
2 Series	F45	Body	Airbag-ACSM Crash Safety Module	•	•	•	•	•	•	0
2 Series	F45	Body	AHM trailer module	•	•	•	•	•	•	0
2 Series	F45	Body	AMPH Hi-Fi amplifier	•	•	•	•	•	•	0
2 Series	F45	Body	ASD Active Sound Design	•	•	•	•	•	•	0
2 Series	F45	Body	CBX-ECALL ComBox emergency call	•	•	•	•	•	•	0
2 Series	F45	Body	CBX-MEDIA ComBox Multimedia	•	•	•	•	•	•	0
2 Series	F45	Body	CIC Car Information Computer	•	•	•	•	•	•	0
2 Series	F45	Body	CON Controller	•	•	•	•	•	•	0
2 Series	F45	Body	CVM Convertible top module	•	•	•	•	•	•	0
2 Series	F45	Body	DSP Digital Sound Processor	•	•	•	•	•	•	0
2 Series	F45	Body	DVDC DVD changer	•	•	•	•	•	•	0
2 Series	F45	Body	EMALI Electric-motor reel, left	•	•	•	•	•	•	0
2 Series	F45	Body	EMARE Electric-motor reel, right	•	•	•	•	•	•	0
2 Series	F45	Body	EME Electric machine electronics	•	•	•	•	•	•	0
2 Series	F45	Body	EME2 Electrical machine electronics	•	•	•	•	•	•	0
2 Series	F45	Body	FLA High Beam Assist	•	•	•	•	•	•	0
2 Series	F45	Body	FRM Footwell module	•	•	•	•	•	•	0
2 Series	F45	Body	FZD Function centre, roof	•	•	•	•	•	•	0
2 Series	F45	Body	GHAS Regulated differential lock	•	•	•	•	•	•	0
2 Series	F45	Body	HKL Automatic luggage compartment lid actuation	•	•	•	•	•	•	0
2 Series	F45	Body	IHKA Integrated automatic heating/air conditioning	•	•	•	•	•	•	0
2 Series	F45	Body	INSTR Instrument cluster	•	•	•	•	•	•	0
2 Series	F45	Body	KAFAS Camera-based driver-assistance systems	•	•	•	•	•	•	0
2 Series	F45	Body	PDC Park Distance Control	•	•	•	•	•	•	0
2 Series	F45	Body	PMA Parking assistant	•	•	•	•	•	•	0
2 Series	F45	Body	RAD Radio	•	•	•	•	•	•	0

Series	Model Series	Part	Systems	Ecu Info.	Read DTC	Freeze Frame	Erase DTC	Live Data	Component activation	Physical HW
2 Series	F45	Chassis	RDC tyre pressure control	•	•	•	•	•	•	0
2 Series	F45	Body	SEC Supplementary control unit	•	•	•	•	•	•	0
2 Series	F45	Body	SEC2 Supplementary control unit 2	•	•	•	•	•	•	0
2 Series	F45	Body	SINE Siren and tilt sensor	•	•	•	•	•	•	0
2 Series	F45	Body	SMBF Seat module, passenger	•	•	•	•	•	•	0
2 Series	F45	Body	SMBFH seat module, passenger's side, rear	•	•	•	•	•	•	0
2 Series	F45	Body	SME Accumulator-management electronics	•	•	•	•	•	•	0
2 Series	F45	Body	SMFA Seat module, driver	•	•	•	•	•	•	0
2 Series	F45	Body	SMFAH Seat module, driver's side, rear	•	•	•	•	•	•	0
2 Series	F45	Chassis	SVT Servotronic	•	•	•	•	•	•	0
2 Series	F45	Body	SWW Lane change warning	•	•	•	•	•	•	0
2 Series	F45	Body	Airbag-SZL Switch centre, steering column	•	•	•	•	•	•	0
2 Series	F45	Body	TRSVC allround-view camera	•	•	•	•	•	•	0
2 Series	F45	Body	TBX Touchbox	•	•	•	•	•	•	0
2 Series	F45	Body	VM Video module	•	•	•	•	•	•	0
2 Series	F45	Drive	VTG Transfer case	•	•	•	•	•	•	0
2 Series	F45	Body	ZGM Central Gateway Control Module	•	•	•	•	•	•	0
2 Series	F46	Drive	CAS Car access system	•	•	•	•	•	•	0
2 Series	F46	Drive	Engine-DDE Diesel Electronics	•	•	•	•	•	•	0
2 Series	F46	Drive	Engine-DME Digital Motor Electronics	•	•	•	•	•	•	0
2 Series	F46	Drive	Engine-DME Digital Motor Electronics 2	•	•	•	•	•	•	0
2 Series	F46	Drive	EGS transmission management	•	•	•	•	•	•	0
2 Series	F46	Drive	EKPS fuel-pump control	•	•	•	•	•	•	0
2 Series	F46	Drive	GWS Gear selector switch	•	•	•	•	•	•	0
2 Series	F46	Chassis	AL active steering	•	•	•	•	•	•	0
2 Series	F46	Chassis	ABS-DSC Dynamic Stability Control	•	•	•	•	•	•	0
2 Series	F46	Chassis	EHC Electronic Ride-Height Control	•	•	•	•	•	•	0
2 Series	F46	Chassis	EMF Parking brake	•	•	•	•	•	•	0
2 Series	F46	Chassis	EPS Electronic Power Steering	•	•	•	•	•	•	0
2 Series	F46	Chassis	ICM Integrated Chassis Management	•	•	•	•	•	•	0
2 Series	F46	Chassis	VDM Vertical dynamics management	•	•	•	•	•	•	0
2 Series	F46	Chassis	VDM2 Vertical dynamics management	•	•	•	•	•	•	0
2 Series	F46	Chassis	ACC Active Cruise Control	•	•	•	•	•	•	0
2 Series	F46	Body	Airbag-ACSM Crash Safety Module	•	•	•	•	•	•	0
2 Series	F46	Body	AHM trailer module	•	•	•	•	•	•	0
2 Series	F46	Body	AMPH Hi-Fi amplifier	•	•	•	•	•	•	0

Series	Model Series	Part	Systems	Ecu Info.	Read DTC	Freeze Frame	Erase DTC	Live Data	Component activation	Physical HW
2 Series	F46	Body	ASD Active Sound Design	•	•	•	•	•	•	0
2 Series	F46	Body	CBX-ECALL ComBox emergency call	•	•	•	•	•	•	0
2 Series	F46	Body	CBX-MEDIA ComBox Multimedia	•	•	•	•	•	•	0
2 Series	F46	Body	CIC Car Information Computer	•	•	•	•	•	•	0
2 Series	F46	Body	CON Controller	•	•	•	•	•	•	0
2 Series	F46	Body	CVM Convertible top module	•	•	•	•	•	•	0
2 Series	F46	Body	DSP Digital Sound Processor	•	•	•	•	•	•	0
2 Series	F46	Body	DVDC DVD changer	•	•	•	•	•	•	0
2 Series	F46	Body	EMALI Electric-motor reel, left	•	•	•	•	•	•	0
2 Series	F46	Body	EMARE Electric-motor reel, right	•	•	•	•	•	•	0
2 Series	F46	Body	EME Electric machine electronics	•	•	•	•	•	•	0
2 Series	F46	Body	EME2 Electrical machine electronics	•	•	•	•	•	•	0
2 Series	F46	Body	FLA High Beam Assist	•	•	•	•	•	•	0
2 Series	F46	Body	FRM Footwell module	•	•	•	•	•	•	0
2 Series	F46	Body	FZD Function centre, roof	•	•	•	•	•	•	0
2 Series	F46	Body	GHAS Regulated differential lock	•	•	•	•	•	•	0
2 Series	F46	Body	HKL Automatic luggage compartment lid actuation	•	•	•	•	•	•	0
2 Series	F46	Body	IHKA Integrated automatic heating/air conditioning	•	•	•	•	•	•	0
2 Series	F46	Body	INSTR Instrument cluster	•	•	•	•	•	•	0
2 Series	F46	Body	KAFAS Camera-based driver-assistance systems	•	•	•	•	•	•	0
2 Series	F46	Body	PDC Park Distance Control	•	•	•	•	•	•	0
2 Series	F46	Body	PMA Parking assistant	•	•	•	•	•	•	0
2 Series	F46	Body	RAD Radio	•	•	•	•	•	•	0
2 Series	F46	Chassis	RDC tyre pressure control	•	•	•	•	•	•	0
2 Series	F46	Body	SEC Supplementary control unit	•	•	•	•	•	•	0
2 Series	F46	Body	SEC2 Supplementary control unit 2	•	•	•	•	•	•	0
2 Series	F46	Body	SINE Siren and tilt sensor	•	•	•	•	•	•	0
2 Series	F46	Body	SMBF Seat module, passenger	•	•	•	•	•	•	0
2 Series	F46	Body	SMBFH seat module, passenger's side, rear	•	•	•	•	•	•	0
2 Series	F46	Body	SME Accumulator-management electronics	•	•	•	•	•	•	0
2 Series	F46	Body	SMFA Seat module, driver	•	•	•	•	•	•	0
2 Series	F46	Body	SMFAH Seat module, driver's side, rear	•	•	•	•	•	•	0
2 Series	F46	Chassis	SVT Servotronic	•	•	•	•	•	•	0
2 Series	F46	Body	SWW Lane change warning	•	•	•	•	•	•	0

Series	Model Series	Part	Systems	Ecu Info.	Read DTC	Freeze Frame	Erase DTC	Live Data	Component activation	Physical HW
2 Series	F46	Body	Airbag-SZL Switch centre, steering column	•	•	•	•	•	•	0
2 Series	F46	Body	TRSVC allround-view camera	•	•	•	•	•	•	0
2 Series	F46	Body	TBX Touchbox	•	•	•	•	•	•	0
2 Series	F46	Body	VM Video module	•	•	•	•	•	•	0
2 Series	F46	Drive	VTG Transfer case	•	•	•	•	•	•	0
2 Series	F46	Body	ZGM Central Gateway Control Module	•	•	•	•	•	•	0
2 Series	F87	Drive	CAS Car access system	•	•	•	•	•	•	0
2 Series	F87	Drive	Engine-DDE Diesel Electronics	•	•	•	•	•	•	0
2 Series	F87	Drive	Engine-DME Digital Motor Electronics	•	•	•	•	•	•	0
2 Series	F87	Drive	Engine-DME Digital Motor Electronics 2	•	•	•	•	•	•	0
2 Series	F87	Drive	EGS transmission management	•	•	•	•	•	•	0
2 Series	F87	Drive	EKPS fuel-pump control	•	•	•	•	•	•	0
2 Series	F87	Drive	GWS Gear selector switch	•	•	•	•	•	•	0
2 Series	F87	Chassis	AL active steering	•	•	•	•	•	•	0
2 Series	F87	Chassis	ABS-DSC Dynamic Stability Control	•	•	•	•	•	•	0
2 Series	F87	Chassis	EHC Electronic Ride-Height Control	•	•	•	•	•	•	0
2 Series	F87	Chassis	EMF Parking brake	•	•	•	•	•	•	0
2 Series	F87	Chassis	EPS Electronic Power Steering	•	•	•	•	•	•	0
2 Series	F87	Chassis	ICM Integrated Chassis Management	•	•	•	•	•	•	0
2 Series	F87	Chassis	VDM Vertical dynamics management	•	•	•	•	•	•	0
2 Series	F87	Chassis	VDM2 Vertical dynamics management	•	•	•	•	•	•	0
2 Series	F87	Chassis	ACC Active Cruise Control	•	•	•	•	•	•	0
2 Series	F87	Body	Airbag-ACSM Crash Safety Module	•	•	•	•	•	•	0
2 Series	F87	Body	AHM trailer module	•	•	•	•	•	•	0
2 Series	F87	Body	AMPH Hi-Fi amplifier	•	•	•	•	•	•	0
2 Series	F87	Body	ASD Active Sound Design	•	•	•	•	•	•	0
2 Series	F87	Body	CBX-ECALL ComBox emergency call	•	•	•	•	•	•	0
2 Series	F87	Body	CBX-MEDIA ComBox Multimedia	•	•	•	•	•	•	0
2 Series	F87	Body	CIC Car Information Computer	•	•	•	•	•	•	0
2 Series	F87	Body	CON Controller	•	•	•	•	•	•	0
2 Series	F87	Body	CVM Convertible top module	•	•	•	•	•	•	0
2 Series	F87	Body	DSP Digital Sound Processor	•	•	•	•	•	•	0
2 Series	F87	Body	DVDC DVD changer	•	•	•	•	•	•	0
2 Series	F87	Body	EMALI Electric-motor reel, left	•	•	•	•	•	•	0
2 Series	F87	Body	EMARE Electric-motor reel, right	•	•	•	•	•	•	0
2 Series	F87	Body	EME Electric machine electronics	•	•	•	•	•	•	0

Series	Model Series	Part	Systems	Ecu Info.	Read DTC	Freeze Frame	Erase DTC	Live Data	Component activation	Physical HW
2 Series	F87	Body	EME2 Electrical machine electronics	•	•	•	•	•	•	0
2 Series	F87	Body	FLA High Beam Assist	•	•	•	•	•	•	0
2 Series	F87	Body	FRM Footwell module	•	•	•	•	•	•	0
2 Series	F87	Body	FZD Function centre, roof	•	•	•	•	•	•	0
2 Series	F87	Body	GHAS Regulated differential lock	•	•	•	•	•	•	0
2 Series	F87	Body	HKL Automatic luggage compartment lid actuation	•	•	•	•	•	•	0
2 Series	F87	Body	IHKA Integrated automatic heating/air conditioning	•	•	•	•	•	•	0
2 Series	F87	Body	INSTR Instrument cluster	•	•	•	•	•	•	0
2 Series	F87	Body	KAFAS Camera-based driver-assistance systems	•	•	•	•	•	•	0
2 Series	F87	Body	PDC Park Distance Control	•	•	•	•	•	•	0
2 Series	F87	Body	PMA Parking assistant	•	•	•	•	•	•	0
2 Series	F87	Body	RAD Radio	•	•	•	•	•	•	0
2 Series	F87	Chassis	RDC tyre pressure control	•	•	•	•	•	•	0
2 Series	F87	Body	SEC Supplementary control unit	•	•	•	•	•	•	0
2 Series	F87	Body	SEC2 Supplementary control unit 2	•	•	•	•	•	•	0
2 Series	F87	Body	SINE Siren and tilt sensor	•	•	•	•	•	•	0
2 Series	F87	Body	SMBF Seat module, passenger	•	•	•	•	•	•	0
2 Series	F87	Body	SMBFH seat module, passenger's side, rear	•	•	•	•	•	•	0
2 Series	F87	Body	SME Accumulator-management electronics	•	•	•	•	•	•	0
2 Series	F87	Body	SMFA Seat module, driver	•	•	•	•	•	•	0
2 Series	F87	Body	SMFAH Seat module, driver's side, rear	•	•	•	•	•	•	0
2 Series	F87	Chassis	SVT Servotronic	•	•	•	•	•	•	0
2 Series	F87	Body	SWW Lane change warning	•	•	•	•	•	•	0
2 Series	F87	Body	Airbag-SZL Switch centre, steering column	•	•	•	•	•	•	0
2 Series	F87	Body	TRSVC allround-view camera	•	•	•	•	•	•	0
2 Series	F87	Body	TBX Touchbox	•	•	•	•	•	•	0
2 Series	F87	Body	VM Video module	•	•	•	•	•	•	0
2 Series	F87	Drive	VTG Transfer case	•	•	•	•	•	•	0
2 Series	F87	Body	ZGM Central Gateway Control Module	•	•	•	•	•	•	0
4 Series	F36	Drive	CAS Car access system	•	•	•	•	•	•	0
4 Series	F36	Drive	Engine-DDE Diesel Electronics	•	•	•	•	•	•	0
4 Series	F36	Drive	Engine-DME Digital Motor Electronics	•	•	•	•	•	•	0
4 Series	F36	Drive	Engine-DME Digital Motor Electronics 2	•	•	•	•	•	•	0
4 Series	F36	Drive	EGS transmission management	•	•	•	•	•	•	0

Series	Model Series	Part	Systems	Ecu Info.	Read DTC	Freeze Frame	Erase DTC	Live Data	Component activation	Physical HW
4 Series	F36	Drive	EKPS fuel-pump control	•	•	•	•	•	•	0
4 Series	F36	Drive	GWS Gear selector switch	•	•	•	•	•	•	0
4 Series	F36	Chassis	AL active steering	•	•	•	•	•	•	0
4 Series	F36	Chassis	ABS-DSC Dynamic Stability Control	•	•	•	•	•	•	0
4 Series	F36	Chassis	EHC Electronic Ride-Height Control	•	•	•	•	•	•	0
4 Series	F36	Chassis	EMF Parking brake	•	•	•	•	•	•	0
4 Series	F36	Chassis	EPS Electronic Power Steering	•	•	•	•	•	•	0
4 Series	F36	Chassis	ICM Integrated Chassis Management	•	•	•	•	•	•	0
4 Series	F36	Chassis	VDM Vertical dynamics management	•	•	•	•	•	•	0
4 Series	F36	Chassis	VDM2 Vertical dynamics management	•	•	•	•	•	•	0
4 Series	F36	Body	CTM Convertible-top module	•	•	•	•	•	•	0
4 Series	F36	Chassis	ACC Active Cruise Control	•	•	•	•	•	•	0
4 Series	F36	Body	Airbag-ACSM Crash Safety Module	•	•	•	•	•	•	0
4 Series	F36	Body	AHM trailer module	•	•	•	•	•	•	0
4 Series	F36	Body	AMPH Hi-Fi amplifier	•	•	•	•	•	•	0
4 Series	F36	Body	ASD Active Sound Design	•	•	•	•	•	•	0
4 Series	F36	Body	CBX-ECALL ComBox emergency call	•	•	•	•	•	•	0
4 Series	F36	Body	CBX-MEDIA ComBox Multimedia	•	•	•	•	•	•	0
4 Series	F36	Body	CIC Car Information Computer	•	•	•	•	•	•	0
4 Series	F36	Body	CON Controller	•	•	•	•	•	•	0
4 Series	F36	Body	CVM Convertible top module	•	•	•	•	•	•	0
4 Series	F36	Body	DSP Digital Sound Processor	•	•	•	•	•	•	0
4 Series	F36	Body	DVDC DVD changer	•	•	•	•	•	•	0
4 Series	F36	Body	EMALI Electric-motor reel, left	•	•	•	•	•	•	0
4 Series	F36	Body	EMARE Electric-motor reel, right	•	•	•	•	•	•	0
4 Series	F36	Body	EME Electric machine electronics	•	•	•	•	•	•	0
4 Series	F36	Body	EME2 Electrical machine electronics	•	•	•	•	•	•	0
4 Series	F36	Body	FLA High Beam Assist	•	•	•	•	•	•	0
4 Series	F36	Body	FRM Footwell module	•	•	•	•	•	•	0
4 Series	F36	Body	FZD Function centre, roof	•	•	•	•	•	•	0
4 Series	F36	Body	GHAS Regulated differential lock	•	•	•	•	•	•	0
4 Series	F36	Body	HKL Automatic luggage compartment lid actuation	•	•	•	•	•	•	0
4 Series	F36	Body	IHKA Integrated automatic heating/air conditioning	•	•	•	•	•	•	0
4 Series	F36	Body	INSTR Instrument cluster	•	•	•	•	•	•	0
4 Series	F36	Body	KAFAS Camera-based driver-assistance systems	•	•	•	•	•	•	0

Series	Model Series	Part	Systems	Ecu Info.	Read DTC	Freeze Frame	Erase DTC	Live Data	Component activation	Physical HW
4 Series	F36	Body	PDC Park Distance Control	•	•	•	•	•	•	0
4 Series	F36	Body	PMA Parking assistant	•	•	•	•	•	•	0
4 Series	F36	Body	RAD Radio	•	•	•	•	•	•	0
4 Series	F36	Chassis	RDC tyre pressure control	•	•	•	•	•	•	0
4 Series	F36	Body	SEC Supplementary control unit	•	•	•	•	•	•	0
4 Series	F36	Body	SEC2 Supplementary control unit 2	•	•	•	•	•	•	0
4 Series	F36	Body	SINE Siren and tilt sensor	•	•	•	•	•	•	0
4 Series	F36	Body	SMBF Seat module, passenger	•	•	•	•	•	•	0
4 Series	F36	Body	SMBFH seat module, passenger's side, rear	•	•	•	•	•	•	0
4 Series	F36	Body	SME Accumulator-management electronics	•	•	•	•	•	•	0
4 Series	F36	Body	SMFA Seat module, driver	•	•	•	•	•	•	0
4 Series	F36	Body	SMFAH Seat module, driver's side, rear	•	•	•	•	•	•	0
4 Series	F36	Chassis	SVT Servotronic	•	•	•	•	•	•	0
4 Series	F36	Body	SWW Lane change warning	•	•	•	•	•	•	0
4 Series	F36	Body	Airbag-SZL Switch centre, steering column	•	•	•	•	•	•	0
4 Series	F36	Body	TRSVC allround-view camera	•	•	•	•	•	•	0
4 Series	F36	Body	TBX Touchbox	•	•	•	•	•	•	0
4 Series	F36	Body	VM Video module	•	•	•	•	•	•	0
4 Series	F36	Drive	VTG Transfer case	•	•	•	•	•	•	0
4 Series	F36	Body	ZGM Central Gateway Control Module	•	•	•	•	•	•	0
7 Series	G11/G12	Drive	CAS Car access system	A	A	A	A	A	A	0
7 Series	G11/G12	Drive	Engine-DDE Diesel Electronics	A	A	A	A	A	A	0
7 Series	G11/G12	Drive	Engine-DME Digital Motor Electronics	A	A	A	A		A	0
7 Series	G11/G12	Drive	Engine-DME Digital Motor Electronics 2	A	A	A	A		A	0
7 Series	G11/G12	Drive	EGS transmission management	A	A	A	A	A	A	0
7 Series	G11/G12	Drive	GWS Gear selector switch	A	A	A	A		A	0
7 Series	G11/G12	Drive	VTG Transfer case	A	A	A	A	A	A	0
7 Series	G11/G12	Chassis	ABS-DSC Dynamic Stability Control	A	A	A	A		A	0
7 Series	G11/G12	Chassis	EPS Electronic Power Steering	A	A	A	A	A	A	0
7 Series	G11/G12	Chassis	EARSH Rear electric active roll stabilisation	A	A	•	A	A	•	0
7 Series	G11/G12	Chassis	EARSV Front electric active roll stabilisation	A	A	A	A	A	A	0
7 Series	G11/G12	Chassis	VDM2 Vertical dynamics management	A	A	A	A	A	A	0
7 Series	G11/G12	Chassis	ACC Active Cruise Control	A	A	A	A	A	A	0
7 Series	G11/G12	Body	Airbag-ACSM Crash Safety Module	A	A	A	A	A	A	0

Series	Model Series	Part	Systems	Ecu Info.	Read DTC	Freeze Frame	Erase DTC	Live Data	Component activation	Physical HW
7 Series	G11/G12	Body	AHM trailer module	A	A	A	A	A	A	0
7 Series	G11/G12	Body	AMPT Top Hi-Fi amplifier	A	A	A	A		A	0
7 Series	G11/G12	Body	CBX-ECALL ComBox emergency call	A	A	A	A	A	A	0
7 Series	G11/G12	Body	CON Controller	A	A	A	A		A	0
7 Series	G11/G12	Body	EME2 Electrical machine electronics				A		A	0
7 Series	G11/G12	Body	FCON Rear compartment controller				A		A	0
7 Series	G11/G12	Body	FLA High Beam Assist				A		A	0
7 Series	G11/G12	Body	FZD Function centre, roof			A	A		A	0
7 Series	G11/G12	Body	HKA Rear-cabin automatic A/C	A	A	A	A	A	A	0
7 Series	G11/G12	Body	HSR Rear-axle slip-angle control		A	A	A	A	A	0
7 Series	G11/G12	Body	IHKA Integrated automatic heating/air conditioning	A	A	•	A	A	A	0
7 Series	G11/G12	Body	KAFAS Camera-based driver-assistance systems	A	A	•	A	A	A	0
7 Series	G11/G12	Body	INSTR Instrument cluster	A	A	A	A	A	A	0
7 Series	G11/G12	Body	LHML LED main light module, left	A	A	A	A	A	A	0
7 Series	G11/G12	Body	LHMR LED main light module, right	A	A	A	A	A	A	0
7 Series	G11/G12	Body	NVE Night Vision Electronics	A	A	A	A	A	A	0
7 Series	G11/G12	Body	RAD Radio	A	A	A	A	A	A	0
7 Series	G11/G12	Body	RSE Rear Seat Entertainment	A	A	A	A	A	A	0
7 Series	G11/G12	Body	SMBF Seat module, passenger	A	A	A	A	A	A	0
7 Series	G11/G12	Body	SMBFH seat module, passenger's side, rear	A	A	A	A	A	A	0
7 Series	G11/G12	Body	SME Accumulator-management electronics	A	A	A	A	A	A	0
7 Series	G11/G12	Body	SMFA Seat module, driver	A	A	A	A	A	A	0
7 Series	G11/G12	Body	SMFAH Seat module, driver's side, rear	A	A	A	A	A	A	0
7 Series	G11/G12	Body	SWW Lane change warning	A	A	A	A	A	A	0
7 Series	G11/G12	Body	TRSVC allround-view camera	A	A	A	A	A	A	0
7 Series	G11/G12	Body	VM Video module	A	A	A	A	A	A	0
7 Series	G11/G12	Body	ZGM Central Gateway Control Module	A	A	A	A	A	A	0
7 Series	G11/G12	Body	PCU Power Control Unit	A	A	A	A	A	A	0
7 Series	G11/G12	Body	SCR Selective Catalytic Reduction	A	A	A	A	A	A	0
7 Series	G11/G12	Body	HKL Automatic luggage compartment lid actuation	•	A	•	A	A	A	0
7 Series	G11/G12	Body	KLE Convenience Charge Electronics	A	A	A	A	A	A	0
7 Series	G11/G12	Body	CVM Convertible top module	A	A	A	A	A	A	0
7 Series	G11/G12	Body	PMA Parking assistant	A	A	A	A	A	A	0
7 Series	G11/G12	Body	ASD Active Sound Design	A	A	A	A	A	A	0

Series	Model Series	Part	Systems	Ecu Info.	Read DTC	Freeze Frame	Erase DTC	Live Data	Component activation	Physical HW
7 Series	G11/G12	Body	ASDA Vehicle Sound Generator	A	A	A	A	A	A	0
7 Series	G11/G12	Body	SEC Supplementary control unit	A	A	A	A	A	A	0
7 Series	G11/G12	Body	SEC2 Supplementary control unit 2	A	A	A	A	A	A	0
7 Series	G11/G12	Body	SINE Siren and tilt sensor	A		A	A	A	A	0
7 Series	G11/G12	Body	SAS Optional extra system				A	A	A	0
7 Series	G11/G12	Body	LEM Light effect manager	A		A	A	A	A	0
7 Series	G11/G12	Body	SPNMVL Front left seat inflator module				A	A	A	0
7 Series	G11/G12	Body	SPNMVR Front right seat inflator module	A	A	A	A	A	A	0
7 Series	G11/G12	Body	SPNMHL Rear left seat inflator module	A	A	A	A	A	A	0
7 Series	G11/G12	Body	SPNMHR Rear right seat inflator module	A	A	A	A	A	A	0
7 Series	G11/G12	Body	LIM Chanrge Interface Module	A	A	A	A	A	A	0
7 Series	G11/G12	Body	TFE Hybrid pressure-tank electronics	A	A	A	A	A	A	0
X Series	X1_F48	Drive	CAS Car access system	A	A	A	A	A	A	0
X Series	X1_F48	Drive	Engine-DME Digital Motor Electronics	A	A	A	A	A	A	0
X Series	X1_F48	Drive	EGS transmission management	A	A	A	A	A	A	0
X Series	X1_F48	Chassis	AL active steering	A	A	A	A	A	A	0
X Series	X1_F48	Chassis	ABS-DSC Dynamic Stability Control	A	A	A	A	A	A	0
X Series	X1_F48	Body	Airbag-ACSM Crash Safety Module	A	A	A	A	A	A	0
X Series	X1_F48	Body	AHM trailer module	A	A	A	A	A	A	0
X Series	X1_F48	Body	AMPH Hi-Fi amplifier	A	A	A	A	A	A	0
X Series	X1_F48	Body	AMPT Top Hi-Fi amplifier	A	A	A	A	A	A	0
X Series	X1_F48	Body	ASD Active Sound Design	A	A	A	A	A	A	0
X Series	X1_F48	Body	CBX-ECALL ComBox emergency call	A	A	A	A	A	A	0
X Series	X1_F48	Body	CIC Car Information Computer	A	A	A	A	A	A	0
X Series	X1_F48	Body	CON Controller	A	A	A	A	A	A	0
X Series	X1_F48	Body	DSP Digital Sound Processor	A	A	A	A	A	A	0
X Series	X1_F48	Body	DVDC DVD changer	A		A	A	A	A	0
X Series	X1_F48	Body	FZD Function centre, roof	A	A	A	A	A	A	0
X Series	X1_F48	Body	HKL Automatic luggage compartment lid actuation	A	A	A	A	A	A	0
X Series	X1_F48	Body	IHKA Integrated automatic heating/air conditioning	A	A	•	A	A	A	0
X Series	X1_F48	Body	INSTR Instrument cluster	A	A	A	A	A	A	0
X Series	X1_F48	Body	KAFAS Camera-based driver-assistance systems	A	A	A	A	A	A	0
X Series	X1_F48	Body	PMA Parking assistant	A	A	A	A	A	A	0
X Series	X1_F48	Body	SMFA Seat module, driver	A	A	A	A	A	A	0

Series	Model Series	Part	Systems	Ecu Info.	Read DTC	Freeze Frame	Erase DTC	Live Data	Component activation	Physical HW
X Series	X1_F48	Body	Airbag-SZL Switch centre, steering column	A	A	A	A	A	A	0
X Series	X1_F48	Body	TRSVC allround-view camera	A	A	A	A	A	A	0
X Series	X1_F48	Body	TBX Touchbox	A	A	A	A	A	A	0
X Series	X1_F48	Body	ZGM Central Gateway Control Module	A	A	A	A	A	A	0
X Series	X1_F49	Drive	CAS Car access system	A	A	A	A	A	A	0
X Series	X1_F49	Drive	Engine-DME Digital Motor Electronics	A	A	A	A	A	A	0
X Series	X1_F49	Drive	EGS transmission management	A	A	A	A	A	A	0
X Series	X1_F49	Chassis	AL active steering	A	A	A	A	A	A	0
X Series	X1_F49	Chassis	ABS-DSC Dynamic Stability Control	A	A	A	A	A	A	0
X Series	X1_F49	Body	Airbag-ACSM Crash Safety Module	A	A	A	A	A	A	0
X Series	X1_F49	Body	AHM trailer module	A	A	A	A	A	A	0
X Series	X1_F49	Body	AMPH Hi-Fi amplifier	A	A	A	A	A	A	0
X Series	X1_F49	Body	AMPT Top Hi-Fi amplifier	A	A	A	A	A	A	0
X Series	X1_F49	Body	ASD Active Sound Design	A	A	A	A	A	A	0
X Series	X1_F49	Body	CBX-ECALL ComBox emergency call	A	A	A	A	A	A	0
X Series	X1_F49	Body	CIC Car Information Computer	A	A	A	A	A	A	0
X Series	X1_F49	Body	CON Controller	A	A	A	A	A	A	0
X Series	X1_F49	Body	DSP Digital Sound Processor	A	A	A	A	A	A	0
X Series	X1_F49	Body	DVDC DVD changer	A	A	A	A	A	A	0
X Series	X1_F49	Body	FZD Function centre, roof	A	A	A	A	A	A	0
X Series	X1_F49	Body	HKL Automatic luggage compartment lid actuation	A	A	A	A	A	A	0
X Series	X1_F49	Body	IHKA Integrated automatic heating/air conditioning	A	A	•	A	A	•	0
X Series	X1_F49	Body	INSTR Instrument cluster	A	A	A	A	A	A	0
X Series	X1_F49	Body	KAFAS Camera-based driver-assistance systems	A	A	•	A	A	•	0
X Series	X1_F49	Body	PMA Parking assistant	A	A	A	A	A	A	0
X Series	X1_F49	Body	SMFA Seat module, driver	A	A	A	A	A	A	0
X Series	X1_F49	Body	Airbag-SZL Switch centre, steering column	A	A	A	A	A	A	0
X Series	X1_F49	Body	TRSVC allround-view camera	A	A	A	A	A	A	0
X Series	X1_F49	Body	TBX Touchbox	A	A	A	A	A	A	0
X Series	X1_F49	Body	ZGM Central Gateway Control Module	A	A	A	A	A	A	0



Service Function List

备注:

- ullet This function is supported.
- lacktriangle This function is the new feature in this version.
- $\ensuremath{\mathsf{O}}$ This function is not supported.

All functions are available to E/F/I Chassis. In the actual test procedure, different menus will be displayed depending on the model configuration.

Part	Components	Status
Maintenance	CBS functionality, engine oil impaired	•
Maintenance	CBS reset	•
Maintenance	CBS Reset UDS	•
Maintenance	CBS vehicle data correction	•
Maintenance	CESG maintenance: FUP check	•
Maintenance	Charging the battery via diagnostic socket	•
Maintenance	Deactivation, engine oil	•
Maintenance	Delete transport mode	•
Maintenance	Reset engine oil	•
Maintenance	Reset pre-delivery check	•
Maintenance	Set rollover protection system in transport mode	•
Maintenance	Setting the transport mode	•
Vehicle information	Check Control messages	•
Vehicle information	correction power supply network identification	•
Vehicle information	DWA: Alarm activation	•
Vehicle information	Integration level	•
Vehicle information	Read Check Control history memory	•
Vehicle information	Read out check Control message from central fault memory	•
Vehicle information	Remote door lock activations	•
Vehicle information	Total counter, convertible top opening time	•
Body	A/C compressor running-in protection	•
Body	Activate Bluetooth and emergency call	•
Body	Activate deactivate test card	•
Body	Activate radio module	•
Body	Activate SDARS	
Body	Activation of rollover protection	
Body	Active backrest width, driver: Initialisation	
Body	Active backrest width, front passenger: Initialisation	
Body	Add tuner section	
Body	All-round vision camera teach-in	
Body	Analysis for wake-up control units	
Body	Assign RHD ID for switch block seat memory	
Body	Auxiliary battery and cut-out relay	
Body		
	Register battery replacement	
Body	Auxiliary fault lockout	
Body	Auxiliary heater: Initialisation of the Telestart transmitter	•
Body	Auxiliary heater: Resetting fault lockout	•
Body	Auxiliary heater: System test	
Body	Bleed headlight cleaning system	•
Body	Boil-off test	
Body	Calibrating and 'teaching' system for all-round vision camera	•
Body	Calibrating the expansion valves of the heat pump circuit	
Body	Calibration of body general module	-
Body	Calibration run for flap motors	•
Body	CESG access to the fuel tank and/or extraction line	-
Body	CESG delete persistent data	•
Body	CESG fill level sensors, general	•
Body	CESG filling/draining pressure accumulator	•
Body	CESG read/compare mileages	•
Body	CESG service function, calibration of filling volume detection	•
Body	CESG service function, slacken feed line	•
Body	Change personalisation data of remote key	•
Body	Charge high-voltage battery	•
Body	CIC: Activate and deactivate test card	•
Body	Compressor / first start-up	•
Body	Coolant compressor infeed protection	•
Body	Correct M-ASK tuner	

Part	Components	Status
Body	Correction of undervoltage limits of the auxiliary heater	•
Body	Country-wide activation of the internal telephone module	•
Body	Create boot file again	•
Body	CTM loading aid: Joint switching after repair	•
Body Body	CTM: Rear module emergency access Delete the personal profile	•
Body	Drain or fill the refrigerant circuit of the heat pump	•
Body	Driver's seat standardisation	•
Body	EMALI: Electric motor initialisation	•
Body	Enable airbag activation after programming operation	•
Body	Evaluate closed-circuit current monitoring	•
Body Body	Evaluate state of battery charge Flexible diagnosis module	
Body	Floating headlining installation position	•
Body	Front passenger seat occupancy detection	•
Body	Front passenger seat, seat standardisation	•
Body	Heating and air conditioning functions: - Newly address the air distribution flap motors	•
Body	Heating and air conditioning functions: Calibrate selector wheels	•
Body Body	Heating and air conditioning functions: Unlocking auxiliary heating Heating and air conditioning system: Potentiometer	•
Body	Heating/air conditioning function: Heater test run	
Body	High-voltage battery unit: Drain coolant expansion tank	•
Body	High-voltage battery: Evaluating the battery state of charge	
Body	High-voltage electrical system: Locate insulation fault	•
Body		
	High-voltage safety: Check	
Body	High-voltage safety: Status	•
Body	HIP module reset	•
Body	Ignition key: Personalisation number	•
Body	Individual test for aerials in vehicle	•
Body	Inflation pressure indicator	•
Body	Initialisation of rain-light-solar-condensation sensor	•
Body	Initialise audio operation at rear	•
Body	initialise CID cover	•
Body	Initialise emergency exit	•
Body	Initialise fire extinguishing system	•
Body	Initialise new headlight driver module and teach-in turn indicator	•
Body	Initialise power window regulators	•
Body	initialise radiator emblem	•
Body	Initialise rain sensor	•
Body	Initialise slide/tilt sunroof	•
Body	Initialise trailer tow hitch	•
Body	Initialising boot lid lift	•
Body	Initialize curtains	•
Body	Lane change assistant calibration	•
Body	Leakage test of the valves	•
Body	Light adjustment for antiglare high-beam headlight and GZA	•
Body	Load auxiliary battery (12 V)	•
Body	Lock and enable master key	•
Body	Log off handset (SBDH)	•
Body	Log on handset (SBDH)	•
Body	Log on mobile phone	•
Body	Log on snap-in adapter	•
Body	Logging the handset on and off	•
Body	MOST ring: Store configuration	•
Body	Navigation system: Deblock fault memory	•
Body	Navigation system: DVD lock	•
Body	Newly address the air distribution flap motors	•
Body	Open tailgate	•
Body	Operational parameter of evaporator temperature	•
Dody	oboracional harameter of exaborator remberature	-

Part	Components	Status
Body	Power Down command	•
Body	Power management: Evaluating the battery state of charge	•
Body	Power tailgate initialisation	•
Body	Presentation mode	•
Body	Program seat occupancy detection	•
Body	Read MRS coding data	•
Body	Rear driver's side seat standardisation	•
Body	Rear passenger's side seat standardisation	•
Body	Rear-window roller blind	•
Body	Recode seat-occupancy mat	•
Body	Register battery replacement	•
Body	Release electric auxiliary heater	•
Body	Remote key: Change personalisation data	•
Body	Remote key: Personalisation number	•
Body	Reset the internal ELV fault counter	•
Body	Reset ZBM / SEC workshop mode	•
Body	Resistance measurement, glow element, auxiliary heater	•
Body	Roll-over protection system	•
Body	RSE: Radio remote control	•
Body	Run-in protection for A/C compressor	•
Body	S6411_PL2SHZHTJ -Auxiliary additional heating: Self-test (JBBF70)	•
Body	Safety system (airbag): Coding data	•
Body	SBE front passenger	•
Body	Set Night Vision camera alignment	•
Body	Soft top initialisation	•
Body	Standby current check, CD batteries	•
Body	Start safety system (airbag):system time	•
Body	TCU subsequent evaluation	•
Body	TCU: Correct volume	•
Body	Teach in front wiper	•
Body	Teaching in the new headlight driver module	•
Body	Telestart initialisation	•
Body	Transportability of high-voltage battery unit: Electrical assessment	•
Body	Trigger roll bar.	•
Body	Tuner, Japan	•
Body	Tuner, New Zealand	•
Body	ULF-SBX and ULF-SBX-H: - Log on mobile phone	•
Body	Vertically adjust Night Vision camera	•
Body	Wiper: Installation position	•
Body	ZGM: FlexRay initialisation	•
Chassis and suspension	ACC: Adjust short-range sensors	•
Chassis and suspension	ACC: Long-range sensor setting	•
Chassis and suspension	Adjust ACC sensor	•
Chassis and suspension	Adjustment of steering angle sensor in the SZL	•
Chassis and suspension	Adjustment of the driving dynamics sensors	•
Chassis and suspension	ARS: Initial operation	•
Chassis and suspension	ARS: Lateral acceleration sensor	•
Chassis and suspension	ARS: Pressure sensor, front axle	•
Chassis and suspension	ARS: Pressure sensor, rear axle	•
Chassis and suspension	ARS: Sensor system	•
Chassis and suspension	ARS: Start-up	•
Chassis and suspension	Bedding-in workshop	•
Chassis and suspension	Bleeding DSC hydraulics	•
Chassis and suspension	Brake line mix-up test	•
Chassis and suspension	Brake pedal travel sensor start-up	•

Part	Components	Status
Chassis and suspension	Braking brake bleeding procedure	•
Chassis and suspension	Check, air supply system	•
Chassis and suspension	CIM: Steering column calibration	•
Chassis and suspension	DSC control unit adjustment	•
Chassis and suspension	DSC sensor adjustment	•
Chassis and suspension	DSC: Brake bleeding procedure for special cases	•
Chassis and suspension	DSC: Brake line mix-up test	•
Chassis and suspension	DSC: Start-up for brake pedal travel sensor	•
Chassis and suspension	Dynamic Drive, start-up fault	•
Chassis and suspension Chassis and suspension	Dynamic Drive, start-up warning EDC: Function check, vertical acceleration sensors, damper satellites	
Chassis and suspension	EDC: Initial operation	
Chassis and suspension	EHC: - Lifting and lowering function check	
Chassis and suspension	EHC: - Ride height sensor check	•
Chassis and suspension	EHC: Compressor cycle	•
Chassis and suspension	EHC: Compressor relay check	•
Chassis and suspension	EHC: Delete energy saving mode	•
Chassis and suspension	EHC: Preparation for wheel alignment	•
Chassis and suspension	EHC: Pressure sensor	•
Chassis and suspension	EHC: Ride height sensors	•
Chassis and suspension	Electric steering lock: Normalisation	•
Chassis and suspension	Electric steering lock: Partial normalisation	•
Chassis and suspension	Electrical steering column adjustment normalisation	•
Chassis and suspension	Electronic ride height control (EHC): - Ride height sensor check	•
Chassis and suspension	Electronic ride height control (EHC): Air spring	•
Chassis and suspension	Electronic ride height control (EHC): Air supply system	•
Chassis and suspension	Electronic ride height control (EHC): Air supply system check	•
Chassis and suspension	Electronic ride height control (EHC): Bellows valve check	•
Chassis and suspension	Electronic ride height control (EHC): Check pressure accumulator sensor	•
Chassis and suspension	Electronic ride height control (EHC): Check, compressor relay	•
Chassis and suspension	Electronic ride height control (EHC): Compressor	•
Chassis and suspension	Electronic ride height control (EHC): Draining the air-spring bellows	•
Chassis and suspension	Electronic ride height control (EHC): Filling and draining	•
Chassis and suspension	Electronic ride height control (EHC): Filling the air-spring bellows	•
Chassis and suspension	Electronic ride height control (EHC): Pressure accumulator	•
Chassis and suspension	Electronic ride height control (EHC): Ride height adjustment	•
Chassis and suspension	Electronic ride height control (EHC): Ride-height sensors	•
Chassis and suspension	Electronic ride height control (EHC): Valve, pressure accumulator	•
Chassis and suspension	Electronic ride height control (EHC): Vehicle level	•
Chassis and suspension	Electronic ride height control (EHC): Vent pressure accumulator	•
Chassis and suspension	EMF start-up	•
Chassis and suspension	EMF: Bedding-in procedure	•
Chassis and suspension	EMF: Workshop mode	•
Chassis and suspension	EPS: Active steering teach-in procedure	
Chassis and suspension Chassis and suspension	EPS: Initial steering startup EPS: Teach-in end stop	•
Chassis and suspension	HSR functional check	•
Chassis and suspension	HSR start-up	•
Chassis and suspension	HSR wheel alignment	•
chassis and suspension	nov arrest grigiment	

Chessis and suspension. (Museum systems initial operation Chessis and suspension. (Desert read and by 35 mm for comber adjostment Chessis and suspension. (Desert read and by 35 mm for comber adjostment Chessis and suspension. (Desert read and by 35 mm for comber adjostment Chessis and suspension. (Desert read and by 35 mm for comber adjostment Chessis and suspension. (Particular desert). (Desert adjostment of ESC for suspension. (Desert and suspension. (Desert adjostment of ESC for suspension. (Desert and suspension. (Deser	Part	Components	Status
Casasis and supersion	Chassis and suspension	ICM sensor system: Initial operation	•
Cassis and supporsion Chassis and supportion	Chassis and suspension	Installation mode	•
Classis and superation Classis and supperation Classis and superation Classis and superation Classis and supperation Classis and superation Classis and supperation Classis and superation Classis and superat	Chassis and suspension	Lower front axle by 35 mm for camber adjustment	•
Cassais and suspension Chassis and suspension	Chassis and suspension	Normalisation, steering column adjustment	•
Chassis and suspension Pre-adjustment of EDC-K switched-on state Classis and suspension PSC: Inlike stering startup	Chassis and suspension	Parking brake: Initial operation	•
Chassis and suspension SC: Initial steering startup Chassis and suspension Register change of the capacitor hox Chassis and suspension Service function, pressure encoding Chassis and suspension Sirvi us Active Steering Chassis and suspension Steering angle sensor, encrys saving mode Chassis and suspension SZL/DSC: Steering angle sensor adjustment Chassis and suspension SZL/DSC: Steering angle sensor adjustment Chassis and suspension SZL/DSC: Steering angle sensor adjustment Chassis and suspension Chassis and suspension SZL/DSC: Steering angle sensor adjustment Chassis and suspension VMS: Start-ster-diamosis Chassis and suspension VMS: Start-up, troubleshooting Chassis and suspensi	Chassis and suspension	Positioning-travel check	•
Chassis and suspension	Chassis and suspension	Pre-adjustment of EDC-K switched-on state	•
Chassis and suspension Chassis and suspension Service function, pressure uncoding Chassis and suspension Start up for brake pedal travel sensor Chassis and suspension Start up for brake pedal travel sensor Chassis and suspension Start up for brake pedal travel sensor Chassis and suspension Start up for brake pedal travel sensor Chassis and suspension Start up for brake pedal travel sensor Chassis and suspension SW sensor system: Start-up Chassis and suspension Chass	Chassis and suspension		•
Chassis and suspension			•
Chassis and suspension Shock absorber adjustment Chassis and suspension Chassis and suspens			•
Chassis and suspension Stering mode sensor, energy saving sode Chassis and suspension Settle of DSC via diagnosis Chassis and suspension Chassis and suspension Chassis and suspension SZL/DSC: Sterring angle sensor adjustment Chassis and suspension SZL/DSC: Sterring angle sensor adjustment Chassis and suspension VDM: Start self diagnosis, troubleshooting Chassis and suspension Chassis and suspension VDM: Start self diagnosis Chassis and suspension VDM: Start testrino Chassis and suspension VDM: Start self diagnosis Chassis and suspension VDM: Start self-diagnosis Chassis and suspension VDM: Star			•
Chassis and suspension SW sensor system: Start up Chassis and suspension Chassis and suspe			•
Chassis and suspension Start up for brake pedal travel sensor Chassis and suspension Stering angle sensor, energy saving mode Chassis and suspension SW sensor system: Start-up Chassis and suspension SW sensor system: Start-up Chassis and suspension Chassis and suspension Chassis and suspension VDX: Stering angle sensor adjustment Chassis and suspension VDX: Stering angle sensor adjustment Chassis and suspension VDX: Start self-diagnosis Chassis and suspension VDX: Start self-diagnosis Chassis and suspension VDX: Start up, troubleshooting Chassis and suspension VDX: Start up, troubl	•		•
Chassis and suspension Chassis and suspension Switch off DSC via diagnosis Chassis and suspension SZL/DSC: Steering angle sensor adjustment Chassis and suspension Chassis and suspensi			•
Chassis and suspension Chassis and suspension SW sumsor system: Start up Chassis and suspension Chassis and suspension Chassis and suspension Tyre defect indicator Chassis and suspension VM: Start start-up Chassis and suspension VM: Start virup Chassis and suspension VM: Start start-up, troubleshooting Chassis and suspension VM: Start-up, troubleshooting Chassis and suspension All-round vision camera: Check of the programming Driver assistance Driver assistance DD: Sotting picture geometry Driver assistance DD: Correct picture geometry Driver assistance DD: Correct picture geometry Driver assistance Driver assistance MAFAS: Calibration Criver assistance AAFAS: Calibration Driver assistance Presure coding service function, RDC intexrated Driver assistance Priver assistance Pri			•
Chassis and suspension SLA/DSC: Steering angle sensor adjustment Chassis and suspension Chassis and suspension VDM: Self-disagnosis, troubleshooting Chassis and suspension VDM: Start self-disagnosis Chassis and suspension VDM: Start self-disagnosis Chassis and suspension VDM: Start self-disagnosis Chassis and suspension VDM: Start-up Chassis and suspension VDM: Start-up, troubleshooting Chassis and suspension VDM: Start-up VDM: Start-up VDM: Start-up Chassis and suspension VDM: Start-up VDM: Start-up Chassis and suspension VDM			•
Chassis and suspension Chassis and suspension VDM: Self-diagnosis, troubleshooting Chassis and suspension VDM: Self-diagnosis Chassis and suspension VDM: Start self-diagnosis Chassis and suspension VDM: Start-up, troubleshooting Chassis and suspension VDM: St			•
Chassis and suspension Chassis and suspension VDM: Self-diagnosis VDM: Start self-diagnosis Chassis and suspension VDM: Start self-diagnosis Chassis and suspension VDM: Start tur-up Chassis and suspension VDM: Start up, troubleshooting Chassis			-
Chassis and suspension Chassis and suspension Chassis and suspension VDM: Start self-diagnosis Chassis and suspension VDM: Start start-up Chassis and suspension Chassis and suspension VDM: Start-up, troubleshooting Chassis and suspension VDM: Start-up, troubleshooting Chassis and suspension VDM: Study the adjustment value Chassis and suspension VDM: Start-up, troubleshooting Chassis and suspension Adjustment of screen dimensions of the reversing camera on the MaSK Chassis and suspension Chassis and suspension Adjustment of screen dimensions of the reversing camera on the MaSK Chassis and suspension Cha			•
Chassis and suspension Chassis and suspension VDW: Start start-up Chassis and suspension VDW: Start up, troubleshooting Chassis and suspension VDW: Vertical acceleration sensor adjustment Driver assistance ACC sensor: Start-up Driver assistance Adaptation of screen dimessions of the reversing camera on the MASK Driver assistance All-round vision camera: Check of the programming Driver assistance HID: Orrect picture geometry Driver assistance HID: Correct picture geometry Driver assistance KAFAS: Calibration Driver assistance KAFAS: TLC adjustment Driver assistance NWE: Calibration Driver assistance PMA, updating software of ultrasonic sensors Driver assistance RPMC: Calibration Driver assistance RPKE: Calibration Driver assistance RPKE: Calibration Driver assistance RPKE: Calibration Driver assistance RPMC: Calibrate vibration motor Engine Activate refuel detection Engine Activate refuel detection Engine Activate refuel detection Engine Activate refuel detection Engine Activation feel pump control module Engine Activation for exhaust back pressure sensor before exhaust turbocharger Engine Adaptation value for resetting the fuel pump Engine Adaptation value for resetting the fuel pump Engine Adaptation of exhaust-gas recirculation Engine Adjustment, consumption calculation Engine Adjustment, consumption calculation Engine Basic injection rate at start Engine Bleeding, fuel system Engine Bleeding, fuel system Engine Engine Bleeding, fuel system Engine Engine Bleeding, fuel system Engine Engine Bleeding, fuel system	-		•
Chassis and suspension VDM: Start-up, troubleshooting Chassis and suspension VDM: Study the adjustment value Chassis and suspension VDM: Vortical acceleration sensor adjustment Driver assistance ACC sensor: Start-up Driver assistance Adaptation of screen dimensions of the reversing camera on the MASK Driver assistance All round vision camera: Check of the programming Driver assistance HUD: Correct picture geometry Driver assistance HUD: Correct picture position Driver assistance HUD: Correct picture position Driver assistance NAFAS: Calibration Driver assistance NE: Calibration Driver assistance NE: Calibration Driver assistance PMA, updating software of ultrasonic sensors Driver assistance Driver assistance Priver assistance Replace combiner Driver assistance RFK: Calibration Driver assistance RFK: Calibration Driver assistance RFK: Calibration Driver assistance RFK: Calibration Driver assistance Activate recirculating pump unit Engine Activate recirculating pump unit Engine Activate refuel detection Engine Activation fuel pump control module Engine Activation fuel pump control module Engine Adjusting the starting torque Engine Adjusting the starting torque Engine Adjusting the starting torque Engine Adjustment, consumption calculation Engine Adjustment, consumption calculation Engine Basic injection rate at start Engine Basic injection rate at start Engine Bleeding, fuel system Engine Engine Bleeding, fuel system Engine Engine Bleeding, fuel system			•
Chassis and suspension Chesting the starting torque Chasie Chassis and content at start Check of the programming Check of the pr			•
Chassis and suspension Chassis and suspension VDM: Study the adjustment value Chassis and suspension VDM: Vertical acceleration sensor adjustment Driver assistance ACC sensor: Start-up Driver assistance All-round vision camera: Check of the programming Driver assistance BLD: Setting picture geometry Driver assistance BLD: Correct picture geometry Driver assistance BLD: Correct picture position Driver assistance KAFAS: Calibration Driver assistance KAFAS: TLC adjustment Driver assistance NVE: Calibration Driver assistance Pressure coding service function, RDC integrated Driver assistance Driver assistance Replace combiner Driver assistance Replace combiner Driver assistance Replace recirculating pump unit Engine Activate recirculating pump unit Engine Activate recirculation, terminal 15 Engine Activation fuel pump control module Engine Adaptation of exhaust back pressure sensor before exhaust turbocharger Engine Adaptation value for resetting the fuel pump Engine Adaptation of exhaust back pressure sensor before exhaust turbocharger Engine Adaptation value for resetting the fuel pump Engine Adaptation value for resetting the fuel pump Engine Adaptation of exhaust back pressure sensor before exhaust turbocharger Engine Adaptation of exhaust back pressure sensor before exhaust turbocharger Engine Adaptation of exhaust back pressure sensor before exhaust turbocharger Engine Adaptation of exhaust-gas recirculation Engine Adjustment, consumption calculation Engine Adjustment, consumption calculation Engine Basic injection rate at start Engine Engine Basic injection rate at start Engine Engine Basic injection rate at start	-		•
Chassis and suspension VDM: Vertical acceleration sensor adjustment Driver assistance ACC sensor: Start-up Driver assistance Adaptation of screen dimensions of the reversing camera on the MASK Driver assistance All-round vision camera: Check of the programming Driver assistance HUD: Orrect picture geometry Driver assistance HUD: Correct picture geometry Driver assistance HUD: Correct picture position Driver assistance KAFAS: Calibration Driver assistance KAFAS: Calibration Driver assistance NVE: Calibration Driver assistance PMA, updating software of ultrasonic sensors Driver assistance Pressure coding service function, RDC integrated Driver assistance Pressure coding service function, RDC integrated Driver assistance Replace combiner Driver assistance RFK: Calibration Driver assistance RFK: Calibration Driver assistance Replace combiner Driver assistance TLC: Calibrate vibration motor Engine Activate recirculating pump unit Engine Activate recirculating pump unit Engine Activation/deactivation, terminal 15 Engine Activation/deactivation, terminal 15 Engine Adaptation value for resetting the fuel pump Adaptation, low-pressure exhaust-gas recirculation Engine Adjusting the starting torque Engine Adjusting the starting torque Engine Adjustment of exhaust-gas recirculation Engine Adjustment of exhaust-gas recirculation Engine Basic injection rate at start Engine CAS: Reset			•
Driver assistance ACC sensor: Start-up Driver assistance Adaptation of screen dimensions of the reversing camera on the MASK Driver assistance All-round vision camera: Check of the programming Driver assistance HUD: Setting picture geometry Driver assistance HUD: Correct picture geometry Driver assistance HUD: Correct picture geometry Driver assistance HUD: Correct picture position Driver assistance KAFAS: Calibration Driver assistance NAFAS: TLC adjustment Driver assistance NVE: Calibration Driver assistance PMA, updating software of ultrasonic sensors Driver assistance Pressure coding service function, RDC integrated Driver assistance RFK: Calibration Driver assistance RFK: Calibration Driver assistance RFK: Calibration Driver assistance TLC: Calibrate vibration motor Driver assistance TLC: Calibrate vibration motor Engine Activate recirculating pump unit Engine Activate refuel detection Engine Activation/deactivation, terminal 15 Engine Adaptation of exhaust back pressure sensor before exhaust turbocharger Driver assistance Adaptation of exhaust back pressure sensor before exhaust turbocharger Driver assistance Adaptation of exhaust pas recirculation Driver assistance Adaptation of exhaust pas recirculation Driver assistance TLC: Calibrate vibration motor Engine Adaptation of exhaust back pressure sensor before exhaust turbocharger Driver assistance TLC: Calibrate vibration decided to the pump of			
Driver assistance Adaptation of screen dimensions of the reversing camera on the MASK Driver assistance All-round vision camera: Check of the programming Driver assistance HUD: Setting picture geometry Driver assistance HUD: Correct picture position Driver assistance KAFAS: Calibration Driver assistance KAFAS: Calibration Driver assistance NVE: Calibration Driver assistance PMA, updating software of ultrasonic sensors Driver assistance PMA, updating software of ultrasonic sensors Driver assistance Pressure coding service function, RDC integrated Driver assistance Replace combiner Driver assistance Replace combiner Driver assistance Replace combiner Driver assistance TLC: Calibration Driver assistance TC. Calibrate vibration motor Engine Activate recirculating pump unit Engine Activate refuel detection Engine Activation fuel pump control module Engine Activation/deactivation, terminal 15 Engine Adaptation of exhaust back pressure sensor before exhaust turbocharger Engine Adaptation slue for resetting the fuel pump Engine Adaptation of exhaust back pressure sensor before exhaust turbocharger Engine Adaptation slue for resetting the fuel pump Engine Adaptation of exhaust-gas recirculation Engine Adjusting the starting torque Engine Adjusting the starting torque Engine Adjustinent, consumption calculation Engine Adjustment, consumption calculation Engine Basic injection rate at start Engine Bleeding, fuel system Engine Bleeding, fuel system Engine Engine Bleeding, fuel system Engine CAS: Reset	-		
Driver assistance HUD: - Setting picture geometry Driver assistance HUD: - Setting picture geometry Driver assistance HUD: Correct picture geometry Driver assistance HUD: Correct picture position Driver assistance HUD: Correct picture position Driver assistance KAFAS: Calibration Driver assistance KAFAS: TLC adjustment Driver assistance NVE: Calibration Driver assistance NVE: Calibration Driver assistance PMA, updating software of ultrasonic sensors Driver assistance Prespure coding service function, RDC integrated Driver assistance RFK: Calibration Driver assistance RFK: Calibration Driver assistance RFK: Calibration Driver assistance RFK: Calibration Driver assistance RFK: Calibrate vibration motor Driver assistance RFK: Calibrate vibration motor Driver assistance Activate recirculating pump unit Driver Activate recirculating pump unit Driver Activate refuel detection Driver Activate refuel detection Driver Activation fuel pump Driver Activation fuel pump Driver Activation fuel pump Driver Driver Activation fuel pump Driver Driver Driver Adaptation value for resetting the fuel pump Driver			
Driver assistance HUD: - Setting picture geometry Driver assistance HUD: Correct picture geometry Driver assistance HUD: Correct picture position Driver assistance KAFAS: Calibration Driver assistance KAFAS: TLC adjustment Driver assistance NVE: Calibration Driver assistance NVE: Calibration Driver assistance PMA, updating software of ultrasonic sensors Driver assistance PMA, updating service function, RDC integrated Driver assistance RFK: Calibration Driver assistance RFK: Calibration Driver assistance RFK: Calibration Driver assistance RFK: Calibration Driver assistance TLC: Calibration Driver assistance TLC: Calibration Driver assistance Activate recirculating pump unit Driver assistance Activate refuel detection Engine Activation fuel pump control module Engine Activation/deactivation, terminal 15 Engine Activation/deactivation, terminal 15 Engine Adaptation value for resetting the fuel pump Engine Adaptation value for resetting the fuel pump Engine Adaptation value for resetting the fuel pump Engine Adjusting the starting torque Engine Adjustment of exhaust-gas recirculation Engine Adjustment of exhaust-gas recirculation Engine Adjustment, consumption calculation Engine Basic injection rate at start Engine Bleeding, fuel system Engine CAS: Reset			
Driver assistance HUD: Correct picture geometry Driver assistance KAFAS: Calibration Driver assistance KAFAS: Calibration Driver assistance NAFAS: TLC adjustment Driver assistance NAFAS: TLC adjustment Driver assistance PMA, updating software of ultrasonic sensors Driver assistance Pessure coding service function, RDC integrated Driver assistance Pressure combiner Driver assistance Replace combiner Driver assistance Replace combiner Driver assistance Replace combiner Driver assistance Replace combiner Driver assistance TLC: Calibration Driver assistance TLC: Calibrate vibration motor Engine Activate recirculating pump unit Engine Activate refuel detection Engine Activation fuel pump control module Engine Activation fuel pump control module Engine Adaptation of exhaust back pressure sensor before exhaust turbocharger Engine Adaptations, low-pressure exhaust-gas recirculation Engine Adjusting the starting torque Engine Adjustment, consumption calculation Engine Adjustment, consumption calculation Engine Basic injection rate at start Engine Engine CAS: Reset			
Driver assistance KAFAS: Calibration Driver assistance KAFAS: TLC adjustment Driver assistance NVE: Calibration Driver assistance NVE: Calibration Driver assistance NVE: Calibration Driver assistance PMA, updating software of ultrasonic sensors Driver assistance Pressure coding service function, RDC integrated Driver assistance Replace combiner Driver assistance Replace combiner Driver assistance RFK: Calibration Driver assistance TLC: Calibrate vibration motor Engine Activate recirculating pump unit Engine Activate refuel detection Engine Activation fuel pump control module Engine Activation/deactivation, terminal 15 Engine Adaptation of exhaust back pressure sensor before exhaust turbocharger Engine Adaptation value for resetting the fuel pump Engine Adaptations, low-pressure exhaust-gas recirculation Engine Adjusting the starting torque Engine Adjustment, consumption calculation Engine Automatic air flap control Engine Basic injection rate at start Engine Bleeding, fuel system Engine CAS: Reset			•
Driver assistance KAFAS: Calibration Driver assistance KAFAS: TLC adjustment Driver assistance NVE: Calibration Driver assistance PMA, updating software of ultrasonic sensors Driver assistance Pressure coding service function, RDC integrated Driver assistance Replace combiner Driver assistance Replace combiner Driver assistance RFK: Calibration Driver assistance TLC: Calibrate vibration motor Engine Activate recirculating pump unit Engine Activate refuel detection Engine Activation fuel pump control module Engine Activation/deactivation, terminal 15 Engine Adaptation of exhaust back pressure sensor before exhaust turbocharger Engine Adaptations, low-pressure exhaust-gas recirculation Engine Adjusting the starting torque Engine Adjustment, consumption calculation Engine Adjustment, consumption calculation Engine Basic injection rate at start Engine Bleeding, fuel system Engine CAS: Reset			•
Driver assistance NVE: Calibration PMA, updating software of ultrasonic sensors Pressure coding service function, RDC integrated Driver assistance Pressure coding service function, RDC integrated Driver assistance Replace combiner Driver assistance RFK: Calibration Driver assistance RFK: Calibration Driver assistance TLC: Calibrate vibration motor Engine Activate refurculating pump unit Engine Activate refuel detection Engine Activation fuel pump control module Engine Activation fuel pump control module Engine Adaptation of exhaust back pressure sensor before exhaust turbocharger Engine Adaptation value for resetting the fuel pump Engine Adaptations, low-pressure exhaust-gas recirculation Engine Adjusting the starting torque Engine Adjustment of exhaust-gas recirculation Engine Adjustment, consumption calculation Engine Basic injection rate at start Engine Bleeding, fuel system Engine CAS: Reset			•
Driver assistance NVE: Calibration PMA, updating software of ultrasonic sensors PMA, updating software of ultrasonic sensors Pressure coding service function, RDC integrated Pressure coding service function, RDC integrated Pressure assistance Replace combiner Priver assistance RFK: Calibration Priver assistance RFK: Calibration TC: Calibrate vibration motor Priver assistance TC: Calibrate vibration motor Priver assistance Activate recirculating pump unit Priver assistance Activate refuel detection Priver assistance Activation fuel pump control module Priver Adaptation of exhaust back pressure sensor before exhaust turbocharger Priver Adaptation value for resetting the fuel pump Priver Adaptation value for resetting the fuel pump Priver Adaptations, low-pressure exhaust-gas recirculation Priver Adjusting the starting torque Priver Adjustment of exhaust-gas recirculation Priver Adjustment of exhaust-gas recirculation Priver Adjustment, consumption calculation Priver Adjustment, consumption calculation Priver Adjustment, consumption calculation Priver Adjustment at start Priver			•
Driver assistance PMA, updating software of ultrasonic sensors Pressure coding service function, RDC integrated Pressure coding service function, RDC integrated Priver assistance Replace combiner PDriver assistance RFK: Calibration PDriver assistance RFK: Calibration PDriver assistance TLC: Calibrate vibration motor PEngine Activate recirculating pump unit PEngine Activate refuel detection PEngine Activation fuel pump control module PEngine Activation fuel pump control module PEngine Activation/deactivation, terminal 15 PEngine Adaptation of exhaust back pressure sensor before exhaust turbocharger PEngine Adaptation value for resetting the fuel pump PEngine Adaptations, low-pressure exhaust-gas recirculation PEngine Adjustment of exhaust-gas recirculation PEngine Adjustment of exhaust-gas recirculation PEngine Adjustment, consumption calculation PEngine Adjustment, consumption calculation PEngine Basic injection rate at start PEngine Bleeding, fuel system PEngine Bleeding, fuel system PEngine CAS: Reset PMA.			•
Driver assistance Replace combiner			•
Driver assistance Replace combiner Driver assistance RFK: Calibration Driver assistance TLC: Calibrate vibration motor Engine Activate recirculating pump unit Engine Activation fuel pump control module Engine Activation fuel pump control module Engine Adaptation of exhaust back pressure sensor before exhaust turbocharger Engine Adaptation value for resetting the fuel pump Engine Adaptations, low-pressure exhaust-gas recirculation Engine Adjusting the starting torque Engine Adjustment of exhaust-gas recirculation Engine Adjustment, consumption calculation Engine Automatic air flap control Engine Basic injection rate at start Engine Bleeding, fuel system Engine CAS: Reset			•
Driver assistance RFK: Calibration Driver assistance TLC: Calibrate vibration motor Engine Activate recirculating pump unit Engine Activate refuel detection Engine Activation fuel pump control module Engine Activation/deactivation, terminal 15 Engine Adaptation of exhaust back pressure sensor before exhaust turbocharger Engine Adaptation value for resetting the fuel pump Engine Adaptations, low-pressure exhaust-gas recirculation Engine Adjusting the starting torque Engine Adjustment of exhaust-gas recirculation Engine Adjustment, consumption calculation Engine Basic injection rate at start Engine Bleeding, fuel system Engine CAS: Reset Engine CAS: Reset			•
TLC: Calibrate vibration motor Engine Activate recirculating pump unit Engine Activate refuel detection Engine Activation fuel pump control module Engine Activation/deactivation, terminal 15 Engine Adaptation of exhaust back pressure sensor before exhaust turbocharger Engine Adaptation value for resetting the fuel pump Engine Adaptations, low-pressure exhaust-gas recirculation Engine Adjusting the starting torque Engine Adjustment of exhaust-gas recirculation Engine Adjustment of exhaust-gas recirculation Engine Adjustment, consumption calculation Engine Basic injection rate at start Engine Bleeding, fuel system Engine CAS: Reset			•
Engine Activate recirculating pump unit Engine Activate refuel detection Engine Activation fuel pump control module Engine Activation/deactivation, terminal 15 Engine Adaptation of exhaust back pressure sensor before exhaust turbocharger Engine Adaptation value for resetting the fuel pump Engine Adaptations, low-pressure exhaust-gas recirculation Engine Adjusting the starting torque Engine Adjustment of exhaust-gas recirculation Engine Adjustment, consumption calculation Engine Automatic air flap control Engine Basic injection rate at start Engine Bleeding, fuel system Engine CAS: Reset			•
Engine Activate refuel detection Engine Activation fuel pump control module Engine Activation/deactivation, terminal 15 Engine Adaptation of exhaust back pressure sensor before exhaust turbocharger Engine Adaptation value for resetting the fuel pump Engine Adaptations, low-pressure exhaust-gas recirculation Engine Adjusting the starting torque Engine Adjustment of exhaust-gas recirculation Engine Adjustment, consumption calculation Engine Automatic air flap control Engine Basic injection rate at start Engine Bleeding, fuel system Engine CAS: Reset			•
Engine Activation fuel pump control module Engine Activation/deactivation, terminal 15 Engine Adaptation of exhaust back pressure sensor before exhaust turbocharger Engine Adaptation value for resetting the fuel pump Engine Adaptations, low-pressure exhaust-gas recirculation Engine Adjusting the starting torque Engine Adjustment of exhaust-gas recirculation Engine Adjustment, consumption calculation Engine Automatic air flap control Engine Basic injection rate at start Engine Bleeding, fuel system Engine CAS: Reset			•
Engine Activation/deactivation, terminal 15 Engine Adaptation of exhaust back pressure sensor before exhaust turbocharger Engine Adaptation value for resetting the fuel pump Engine Adaptations, low-pressure exhaust-gas recirculation Engine Adjusting the starting torque Engine Adjustment of exhaust-gas recirculation Engine Adjustment, consumption calculation Engine Automatic air flap control Engine Basic injection rate at start Engine Bleeding, fuel system Engine CAS: Reset			•
Engine Adaptation of exhaust back pressure sensor before exhaust turbocharger Engine Adaptation value for resetting the fuel pump Engine Adaptations, low-pressure exhaust-gas recirculation Engine Adjusting the starting torque Engine Adjustment of exhaust-gas recirculation Engine Adjustment, consumption calculation Engine Automatic air flap control Engine Basic injection rate at start Engine Bleeding, fuel system Engine CAS: Reset			•
Engine Adaptation value for resetting the fuel pump Engine Adaptations, low-pressure exhaust-gas recirculation Engine Adjusting the starting torque Engine Adjustment of exhaust-gas recirculation Engine Adjustment, consumption calculation Engine Automatic air flap control Engine Basic injection rate at start Engine Bleeding, fuel system Engine CAS: Reset			•
Engine Adaptations, low-pressure exhaust-gas recirculation Engine Adjusting the starting torque Engine Adjustment of exhaust-gas recirculation Engine Adjustment, consumption calculation Engine Automatic air flap control Engine Basic injection rate at start Engine Bleeding, fuel system Engine CAS: Reset		Adaptation value for resetting the fuel pump	•
Engine Adjustment of exhaust-gas recirculation Engine Adjustment, consumption calculation Engine Automatic air flap control Engine Basic injection rate at start Engine Bleeding, fuel system Engine CAS: Reset		Adaptations, low-pressure exhaust-gas recirculation	•
Engine Adjustment, consumption calculation Engine Automatic air flap control Engine Basic injection rate at start Engine Bleeding, fuel system Engine CAS: Reset	Engine	Adjusting the starting torque	•
Engine Automatic air flap control Engine Basic injection rate at start Engine Bleeding, fuel system Engine CAS: Reset	Engine	Adjustment of exhaust-gas recirculation	•
Engine Basic injection rate at start Engine Bleeding, fuel system Engine CAS: Reset	Engine	Adjustment, consumption calculation	•
Engine Bleeding, fuel system Engine CAS: Reset •	Engine	Automatic air flap control	•
Engine CAS: Reset	Engine	Basic injection rate at start	•
	Engine	Bleeding, fuel system	•
Engine Charging the high-voltage battery: Read out history of last charging procedures	Engine	CAS: Reset	•
	Engine	Charging the high-voltage battery: Read out history of last charging procedures	•

Part	Components	Status
Engine	Checking oxygen sensors for switched plug connections	•
Engine	Clear adaptations	•
Engine	CO adjustment	•
Engine	Composition of the high-voltage battery unit: Read out serial numbers	•
Engine	Compression pressure	•
Engine	Compression test	•
Engine	Consumption calculation	•
Engine	Cooling system ventilation	•
Engine	cooling system: Ventilation	•
Engine	DDE - CAS adjustment	•
Engine	Delete engine adaptation value	•
Engine	Delete installation mode	•
Engine	Diesel particulate filter: Filter Replacement	•
Engine	Diesel particulate filter: Regeneration	•
Engine	Diesel particulate filter: Request regeneration	•
Engine	DKG: flushing function	•
Engine	DKG: Oil adjustment	•
Engine	DKG: Teach-in clutch slipping point	•
Engine	DME: Reset adaptation values and versions	•
Engine	DMTL pump activation	•
Engine	DSM: Teach-in routine after parts replacement	•
Engine	EGR adaptation	•
Engine	EGS: Mechatronic calibration	•
Engine	EGS: Reset adaptation values	•
Engine	EGS: Teach in neutral position	•
Engine	EGS: transmission fluid adjustment	•
Engine	Electronic immobiliser (EWS): Reset starter lock	•
Engine	EME: DC/DC converter adjustment	•
Engine	EME: Delete install mode	•
Engine	EME: Instruct rotor position sensor	•
Engine	EME: Read out the adjustment value of the rotor position sensor	•
Engine	EME: Reset vacuum pump operating time	•
Engine	EME: Rotor position sensor adjustment	•
Engine	EME: Teach in parking lock module	•
Engine	Engine control: Injection rate adjustment	•
Engine	Engine control: Limit quantity adjustment	•
Engine	Engine control: Mean quantity adaptation	•
Engine	Engine control: Start amount adjustment	•
Engine	Engine oil quantity	•
Engine	Engine operating values record	•
Engine	E-OBD readiness code	•
Engine	EWS interface	•
Engine	Exhaust-gas recirculation cooler adaptation	•
Engine	Fuel consumption display	•
Engine	Fuel consumption display adjustment	•
Engine	Fuel grade output	•
Engine	Fuel quality identification	•
Engine	Fuel tank pressure sensor adjustment	•
Engine	Gear sensor	•
Engine	Gearbox adaptation	•
Engine	Glow element adjustment	•
Engine	HCP: Start-up after airbag deployment	•
Engine	HCP: Teach in tilt sensor	•
Engine	High-voltage battery cooling system: Fill cooling circuit	•
Engine	High-voltage battery unit: Drain coolant expansion tank	•

Part	Components	Status
Engine	High-voltage battery: Evaluating the battery state of charge	•
Engine	Idle speed: Target value and actual value comparison	•
Engine	Idling quality	•
Engine	Individual data rescue	•
Engine	Initialisation of SCR tank system	•
Engine	Injection deactivation	•
Engine	Injection quantity compensation	•
Engine	Injection quantity compensation, 4-cylinder engine	•
Engine	Injection rate	•
Engine	Injector equalisation	•
Engine	Internal engine pressure	•
Engine	Leakage test, H2 injection valve	•
Engine	Leakage test, H2 pressure control valve	•
Engine	Learn Valvetronic limit positions	•
Engine	Limit quantity	•
Engine	Low/high pressure exhaust-gas recirculation cooler adjustment and adaptation	•
Engine	Mass meter	•
Engine	Mean quantity adaptation	•
Engine	Mechatronic calibration	•
Engine	Minimum stroke adjustment	•
Engine	MSA: Read history memory	•
Engine	MSA: zero-gear sensor	•
Engine	Nitrogen oxide catalytic converter: regeneration	•
Engine	Nitrogen oxide catalytic converter: Replacement	•
Engine	OBD Readiness Codes	•
Engine	0il change	•
Engine	0il-level adjustment	•
Engine	Operational smoothness measurement	•
Engine	Preheating control adjustment	•
Engine	QMVH: Initial operation	•
Engine	QMVH: Oil change	•
Engine	Rail pressure regulating valve adaptation	•
Engine	RDME: Delete install mode	•
Engine	Read and delete swirl flap adaptation	•
Engine	Read DDE measured values	•
Engine	Read/delete engine adaptation value	•
Engine	Reading out the readiness codes	•
Engine	Recalibration of SMG	•
Engine	Regulated differential lock repair function	•
Engine	Regulation of switching speed	•
Engine	REME: Delete install mode	•
Engine	Remove Valvetronic servomotor	•
Engine	Replacement and repair	•
Engine	Reset adaptation values	•
Engine	Reset EWS	•
Engine	Reset learning functions	•
Engine	Reset production mode	•
Engine	Reset production mode, preheating control unit	•
Engine	Reset SCR control unit installation mode	•
Engine	Reset service function of learning functions	•
Engine	Reset speedmarks	•
Engine	Reset starter lock	•
Engine	Reset the adaptation of the electric fuel pump	•
Engine	Reset the internal ELV fault counter	•
Engine	Reset the production mode for the fuel pump control module	•

Part	Components	Status
Engine	Reset: SCR switch-off scenario	•
Engine	Resetting the oil service interval	•
Engine	SCR adjustments and adaptations	•
Engine	SCR reset	•
Engine	SCR system: Adjustment	•
Engine	SCR: Display of fuel tank level	•
Engine	Service function, display and reset adaptation values	•
Engine	Service function, engine exchange	•
Engine	Service start range extender	•
Engine	SMG hydraulic system	•
Engine	SMG test functions	•
Engine	Smooth running control	•
Engine	Start amount	•
Engine	Start moment adjustment	•
Engine	Starter exchange	•
Engine	Starting up the high-voltage battery unit	•
Engine	Start-up Valvetronic	•
Engine	Start-up, fuel pump control	•
Engine	System check	•
Engine	Teach in clutch slipping point	•
Engine	Teach in drive position actuator	•
Engine	Teach in SMG transmission	•
Engine	Teach in zero-gear sensor	•
Engine	Tolerance test, intermediate lever	•
Engine	Transmission control unit: , parking lock hook test	•
Engine	Transmission control unit: Data adjustment, mechatronics	•
Engine	Transmission control unit: Format fault memory	•
Engine	Transmission control unit: Oil balancing	•
Engine	Transmission control unit: Oil change	•
Engine	Transmission control unit: Replacement	•
Engine	Transmission control unit: Reset learning function	•
Engine	Transmission control unit: Reset torque characteristic curve	•
Engine	Transmission control unit: Resetting adaption functions	•
Engine	Transmission control unit: Teach in valve characteristic curves PV1, PV2	•
Engine	Transmission control unit: Teach-in routine, EWS adjustment (immobiliser)	•
Engine	Transmission control unit: Testing the integrated electrical pump	•
Engine	Transmission oil pump activation	•
Engine	Transportability of high-voltage battery unit: Electrical assessment	•
Engine	Twin-clutch gearbox: , parking lock hook test	•
Engine	Twin-clutch gearbox: Functional check, parking lock	•
Engine	Twin-clutch gearbox: Gearbox adaptation	•
Engine	Valvetronic adaptation limit positions	•
Engine	Valvetronic mechanism/function	•
Engine	Valvetronic: start-up	•
Engine	VANOS ventilation	•
Maintenance	Manual enabling of navigation function	0
Maintenance	Enabling, navigation, automatic	0
Body	Initialise telematics services (Canada)	0
Body	Re-enabling BMW Assist TCU 1.5 Most	0
Body	Re-enabling, BMW Assist TCU MOST	0
Body	Updating online services	0
Engine	Engine self-learning cycle	0
Engine	Compression test	0



Coding List

Couring Elst			
Series	Model Series	Systems	Coding
3 Series	E36	ABS/ASC/DSC Dynamic Stability Control	•
1 Series	E81/E82/E87/E88	AL active steering	
3 Series	E36	EWS Electronic immobilizer	
3 Series	E36	GR Cruise control	•
3 Series	E36	IHKA Heater/automatic A/C control	•
3 Series	E36	KOM Instrument cluster	•
3 Series	E36	SPMFT Mirror memory, driver	•
3 Series	E36	TOENS Thermal oil-level sensor	•
3 Series	E36	ZKE Central body electronics	•
7 Series	E38	AB Airbag	•
7 Series	E38	ABS/ASC/DSC Dynamic Stability Control	•
7 Series	E38	CCM Check Control Module	•
7 Series	E38	DSP Digital Sound Processor	•
7 Series	E38	EDC Damper Control	•
7 Series	E38	EML Electronic engine-power control	•
7 Series	E38	EWS Electronic immobilizer	•
7 Series	E38	GR Cruise control	•
7 Series	E38	HKM Boot-lid module	
7 Series	E38	IHKA Heater/automatic A/C control	•
7 Series	E38	IKE Instrument-cluster electronics	
7 Series	E38	LCM Light Check Module	
7 Series	E38	LEW Steering-angle sensor	•
7 Series	E38	MRS Multiple restraint system	•
7 Series	E38	PDC Park Distance Control	•
7 Series	E38	RDC Tyre pressure control	•
7 Series	E38	SHD Sliding/tilting sunroof	•
7 Series	E38	STH park heating	•
7 Series	E38	TEL Telephone interface	•
7 Series	E38	VID Video module	•
7 Series	E38	ZKE Central body electronics	•
5 Series	E39	AB Airbag	•
5 Series	E39	ABS/ASC/DSC Dynamic Stability Control	•
5 Series	E39	AIC Automatic Interval Control	•
5 Series	E39	DSP Digital Sound Processor	•
5 Series	E39	EDC Damper Control	•
5 Series	E39	EHC Electronic Ride-Height Control	•
5 Series	E39	EWS Electronic immobilizer	•
5 Series	E39	GR Cruise control	•
5 Series	E39	HKM Boot-lid module	•
5 Series	E39	IHKA Heater/automatic A/C control	•
5 Series	E39	IKE Instrument-cluster electronics	•
5 Series	E39	LCM Light Check Module	•
5 Series	E39	LEW Steering-angle sensor	•
5 Series	E39	PDC Park Distance Control	•
5 Series	E39	RAD Radio	•
5 Series	E39	RDC Tyre pressure control	•
5 Series	E39	STH park heating	•
5 Series	E39	TEL Telephone interface	•
5 Series	E39	VID Video module	•
5 Series	E39	ZKE Central body electronics	•
3 Series	E46	AB Airbag	•
3 Series	E46	ABS/ASC/DSC Dynamic Stability Control	•
3 Series	E46	AHL Adaptive directional headlights	•
3 Series	E46	AIC Automatic Interval Control	•
3 Series	E46	CVM Convertible top module	•
3 Series	E46	DME Motor Electronics	•
3 Series	E46	EKP Fuel pump	•
3 Series	E46	EWS Electronic immobilizer	•
3 Series	E46	GR Cruise control	•
3 Series	E46	IHKA Heater/automatic A/C control	
3 Series	E46	IKE Instrument-cluster electronics	•
S SOLIOD	1210	I am at the of ements of all out of the officer	

Series	Model Series	Systems	Coding
3 Series	E46	LCM Light Check Module	•
3 Series	E46	LEW Steering-angle sensor	•
3 Series	E46	PDC Park Distance Control	•
3 Series	E46	RAD Radio	•
3 Series	E46	RDC Tyre pressure control	•
3 Series	E46	SHD Sliding/tilting sunroof	•
3 Series	E46	SMF Seat memory, driver	•
3 Series	E46	SPMBT Mirror memory, passenger	•
3 Series	E46	SPMFT Mirror memory, driver	•
3 Series	E46	TEL Telephone interface	•
3 Series	E46	VID Video module	•
3 Series	E46	ZKE Central body electronics	•
Z Series	E52 E52	AB Airbag	•
Z Series Z Series	E52	ABS/ASC/DSC Dynamic Stability Control	
Z Series Z Series	E52	ELV Electronic steering-column locking EWS Electronic immobilizer	
Z Series Z Series	E52	GM base module	
Z Series Z Series	E52	IHKA Heater/automatic A/C control	
Z Series Z Series	E52	IKE Instrument-cluster electronics	
Z Series	E52	LCM Light Check Module	
Z Series	E52	LEW Steering-angle sensor	
Z Series	E52	RAD Radio	•
X Series	E53	AB Airbag	•
X Series	E53	ABS/ASC/DSC Dynamic Stability Control	•
X Series	E53	AHL Adaptive directional headlights	•
X Series	E53	AIC Automatic Interval Control	•
X Series	E53	DME Motor Electronics	•
X Series	E53	DSP Digital Sound Processor	•
X Series	E53	EHC Electronic Ride-Height Control	•
X Series	E53	EWS Electronic immobilizer	•
X Series	E53	IHKA Heater/automatic A/C control	•
X Series	E53	IKE Instrument-cluster electronics	•
X Series	E53	LCM Light Check Module	•
X Series	E53	LEW Steering-angle sensor	•
X Series	E53	PDC Park Distance Control	•
X Series	E53	RAD Radio	•
X Series	E53	RDC Tyre pressure control	•
X Series	E53	SHD Sliding/tilting sunroof	•
X Series	E53	SMF Seat memory, driver	•
X Series	E53	STH park heating	•
X Series X Series	E53 E53	TEL Telephone interface VID Video module	_
X Series X Series	E53	ZKE Central body electronics	
5 Series	E60	ABS/ASC/DSC Dynamic Stability Control	
5 Series 5 Series	E60	ACC2 Active cruise control 2	
5 Series	E60	AHL Adaptive directional headlights	
5 Series	E60	AHM Trailer module	•
5 Series	E60	AL active steering	•
5 Series	E60	ALBBF active backrest width, front passenger	•
5 Series	E60	ALBFA active backrest width, driver	•
5 Series	E60	AMP Amplifier	•
5 Series	E60	ARS Dynamic Drive 2	•
5 Series	E60	CA Comfort access system	•
5 Series	E60	CAS Car Access System	•
5 Series	E60	CCC-A Applications	•
5 Series	E60	CCC-ANT Aerial tuner	•
5 Series	E60	CCC-ASK Audio system controller	•
5 Series	E60	CCC-BO User interface	•
5 Series	E60	CCC-GW Gateway	•
5 Series	E60	CID Central Information Display	•
5 Series	E60	CON Controller	•
5 Series	E60	DME Motor Electronics	•
5 Series	E60	DVDC DVD Changer	
5 Series	E60	DWA anti-theft alarm system	

Series	Model Series	Systems	Coding
5 Series	E60	EDC Damper Control	•
5 Series	E60	EGS transmission management	•
5 Series	E60	EHC Electronic Ride-Height Control	•
5 Series	E60	EKPS Fuel-pump control	•
5 Series	E60	FLA High Beam Assist	•
5 Series	E60	GWS Gear selector switch	•
5 Series	E60	HKL Rear-lid lift	•
5 Series	E60	HUD Head-Up Display	•
5 Series	E60	IHKA Integrated automatic heating/air conditioning	•
5 Series	E60 E60	INSTR Instrument cluster KBM Body basic module	
5 Series 5 Series	E60	KGM Body Gateway Module	
5 Series 5 Series	E60	LDM Longitudinal Dynamics Management	
5 Series	E60	LM2 Light module 2	
5 Series	E60	MPM Micro-power module	•
5 Series	E60	NVE Night Vision Electronics	•
5 Series	E60	PDC Park Distance Control	•
5 Series	E60	RLS Rain/Light Sensor	•
5 Series	E60	RSE Rear Seat Entertainment	•
5 Series	E60	SBSL Satellite, B-pillar, left	•
5 Series	E60	SBSR Satellite, B-pillar, right	•
5 Series	E60	SFZ Satellite vehicle centre	•
5 Series	E60	SGM-SIM Safety and Gateway Module(SIM)	•
5 Series	E60	SHD Sliding/tilting sunroof	•
5 Series	E60	SHZH Independent/auxiliary heater	•
5 Series	E60	SINE Siren and tilt sensor	•
5 Series	E60	SMBF Seat module, passenger	•
5 Series	E60 E60	SMFA Seat module, driver SZL Switch centre, steering column	
5 Series 5 Series	E60	SZM Switching centre, steering column SZM Switching centre, centre console	
5 Series 5 Series	E60	TLC Lane Departure Warning	
5 Series	E60	TMBF Door module, front passenger	
5 Series	E60	TMFA Door module, driver	•
5 Series	E60	ULF Universal charging and hands-free facility	•
5 Series	E60	ULF-SBX-H Interface box High	•
5 Series	E60	VTG Transfer case	•
5 Series	E61	ABS/ASC/DSC Dynamic Stability Control	•
5 Series	E61	ACC2 Active cruise control 2	•
5 Series	E61	AHL Adaptive directional headlights	•
5 Series	E61	AHM Trailer module	•
5 Series	E61	AL active steering	•
5 Series	E61	ALBBF active backrest width, front passenger	•
5 Series	E61	ALBFA active backrest width, driver	•
5 Series	E61	AMP Amplifier	
5 Series	E61	ARS Dynamic Drive 2	
5 Series 5 Series	E61	CA Comfort access system CAS Car Access System	
5 Series 5 Series	E61	CCC-A Applications	
5 Series 5 Series	E61	CCC-ANT Aerial tuner	
5 Series	E61	CCC-ASK Audio system controller	
5 Series	E61	CCC-BO User interface	<u> </u>
5 Series	E61	CCC-GW Gateway	•
5 Series	E61	CID Central Information Display	•
5 Series	E61	CON Controller	•
5 Series	E61	DME Motor Electronics	•
5 Series	E61	DVDC DVD Changer	•
5 Series	E61	DWA anti-theft alarm system	•
5 Series	E61	EDC Damper Control	•
5 Series	E61	EGS transmission management	•
5 Series	E61	EHC Electronic Ride-Height Control	-
5 Series	E61	EKPS Fuel-pump control	•
5 Series	E61	FLA High Beam Assist	•
5 Series	E61	GWS Gear selector switch	•
5 Series	E61	HKL Rear-lid lift	

Series	Model Series	Systems	Coding
5 Series	E61	HUD Head-Up Display	•
5 Series	E61	IHKA Integrated automatic heating/air conditioning	•
5 Series	E61	INSTR Instrument cluster	•
5 Series	E61	KBM Body basic module	•
5 Series	E61	KGM Body Gateway Module	•
5 Series	E61	LDM Longitudinal Dynamics Management	•
5 Series	E61	LM2 Light module 2	•
5 Series	E61 E61	MPM Micro-power module	
5 Series 5 Series	E61	NVE Night Vision Electronics PDC Park Distance Control	
5 Series	E61	RLS Rain/Light Sensor	
5 Series	E61	RSE Rear Seat Entertainment	
5 Series	E61	SBSL Satellite, B-pillar, left	•
5 Series	E61	SBSR Satellite, B-pillar, right	•
5 Series	E61	SFZ Satellite vehicle centre	•
5 Series	E61	SGM-SIM Safety and Gateway Module(SIM)	•
5 Series	E61	SHD Sliding/tilting sunroof	•
5 Series	E61	SHZH Independent/auxiliary heater	•
5 Series	E61	SINE Siren and tilt sensor	•
5 Series	E61	SMBF Seat module, passenger	•
5 Series	E61	SMFA Seat module, driver	•
5 Series	E61	SZL Switch centre, steering column	•
5 Series	E61	SZM Switching centre, centre console	•
5 Series	E61	TLC Lane Departure Warning	•
5 Series	E61 E61	TMBF Door module, front passenger	
5 Series 5 Series	E61	TMFA Door module, driver ULF Universal charging and hands-free facility	
5 Series 5 Series	E61	ULF-SBX-H Interface box High	
5 Series	E61	VTG Transfer case	
6 Series	E63	ABS/ASC/DSC Dynamic Stability Control	•
6 Series	E63	ACC2 Active cruise control 2	•
6 Series	E63	AHL Adaptive directional headlights	•
6 Series	E63	AHM Trailer module	•
6 Series	E63	AL active steering	•
6 Series	E63	ALBBF active backrest width, front passenger	•
6 Series	E63	ALBFA active backrest width, driver	•
6 Series	E63	AMP Amplifier	•
6 Series	E63	ARS Dynamic Drive 2	•
6 Series	E63	CA Comfort access system	•
6 Series	E63	CAS Car Access System	•
6 Series 6 Series	E63 E63	CCC-A Applications CCC-ANT Aerial tuner	
6 Series	E63	CCC-ASK Audio system controller	
6 Series	E63	CCC-BO User interface	
6 Series	E63	CCC-GW Gateway	
6 Series	E63	CID Central Information Display	•
6 Series	E63	CON Controller	•
6 Series	E63	DME Motor Electronics	•
6 Series	E63	DVDC DVD Changer	•
6 Series	E63	DWA anti-theft alarm system	•
6 Series	E63	EDC Damper Control	•
6 Series	E63	EGS transmission management	
6 Series	E63	EHC Electronic Ride-Height Control	•
6 Series	E63	EKPS Fuel-pump control	
6 Series	E63	FLA High Beam Assist	•
6 Series	E63	GWS Gear selector switch	
6 Series	E63	HKL Rear-lid lift	
6 Series 6 Series	E63	HUD Head-Up Display IHKA Integrated automatic heating/air conditioning	
6 Series	E63	INSTR Instrument cluster	
6 Series	E63	KBM Body basic module	
6 Series	E63	KGM Body Gateway Module	
6 Series	E63	LDM Longitudinal Dynamics Management	•
6 Series	E63	LM2 Light module 2	•
	•		

Series	Model Series	Systems	Coding
6 Series	E63	MPM Micro-power module	•
6 Series	E63	NVE Night Vision Electronics	•
6 Series	E63	PDC Park Distance Control	•
6 Series	E63	RLS Rain/Light Sensor	•
6 Series	E63	RSE Rear Seat Entertainment	•
6 Series	E63	SBSL Satellite, B-pillar, left	•
6 Series	E63	SBSR Satellite, B-pillar, right	•
6 Series	E63	SFZ Satellite vehicle centre	•
6 Series	E63	SGM-SIM Safety and Gateway Module (SIM)	•
6 Series	E63	SHD Sliding/tilting sunroof	•
6 Series	E63	SHZH Independent/auxiliary heater	•
6 Series	E63	SINE Siren and tilt sensor	
6 Series 6 Series	E63	SMBF Seat module, passenger SMFA Seat module, driver	
	E63	SZL Switch centre, steering column	
6 Series 6 Series	E63	SZM Switching centre, steering column SZM Switching centre, centre console	
6 Series	E63	TLC Lane Departure Warning	
6 Series	E63	TMBF Door module, front passenger	
6 Series	E63	TMFA Door module, driver	
6 Series	E63	ULF Universal charging and hands-free facility	
6 Series	E63	ULF-SBX-H Interface box High	
6 Series	E63	VTG Transfer case	
6 Series	E64	ABS/ASC/DSC Dynamic Stability Control	
6 Series	E64	ACC2 Active cruise control 2	
6 Series	E64	AHL Adaptive directional headlights	
6 Series	E64	AHM Trailer module	
6 Series	E64	AL active steering	
6 Series	E64	ALBBF active backrest width, front passenger	•
6 Series	E64	ALBFA active backrest width, driver	•
6 Series	E64	AMP Amplifier	•
6 Series	E64	ARS Dynamic Drive 2	•
6 Series	E64	CA Comfort access system	•
6 Series	E64	CAS Car Access System	•
6 Series	E64	CCC-A Applications	•
6 Series	E64	CCC-ANT Aerial tuner	•
6 Series	E64	CCC-ASK Audio system controller	•
6 Series	E64	CCC-BO User interface	•
6 Series	E64	CCC-GW Gateway	•
6 Series	E64	CID Central Information Display	•
6 Series	E64	CON Controller	•
6 Series	E64	DME Motor Electronics	•
6 Series	E64	DVDC DVD Changer	•
6 Series	E64	DWA anti-theft alarm system	•
6 Series	E64	EDC Damper Control	
6 Series	E64	EGS transmission management	
6 Series	E64	EHC Electronic Ride-Height Control	—
6 Series	E64 E64	EKPS Fuel-pump control	
6 Series 6 Series	E64	FLA High Beam Assist GWS Gear selector switch	
6 Series	E64	HKL Rear-lid lift	
6 Series	E64	HUD Head-Up Display	
6 Series	E64	IHKA Integrated automatic heating/air conditioning	
6 Series	E64	INSTR Instrument cluster	
6 Series	E64	KBM Body basic module	
6 Series	E64	KGM Body Gateway Module	
6 Series	E64	LDM Longitudinal Dynamics Management	
6 Series	E64	LM2 Light module 2	
6 Series	E64	MPM Micro-power module	
6 Series	E64	NVE Night Vision Electronics	•
6 Series	E64	PDC Park Distance Control	•
6 Series	E64	RLS Rain/Light Sensor	•
6 Series	E64	RSE Rear Seat Entertainment	•
6 Series	E64	SBSL Satellite, B-pillar, left	•
		SBSR Satellite, B-pillar, right	

Series	Model Series	Systems	Coding
6 Series	E64	SFZ Satellite vehicle centre	•
6 Series	E64	SGM-SIM Safety and Gateway Module(SIM)	•
6 Series	E64	SHD Sliding/tilting sunroof	•
6 Series	E64	SHZH Independent/auxiliary heater	•
6 Series	E64	SINE Siren and tilt sensor	•
6 Series	E64	SMBF Seat module, passenger	•
6 Series	E64	SMFA Seat module, driver	•
6 Series	E64	SZL Switch centre, steering column	•
6 Series	E64	SZM Switching centre, centre console	•
6 Series	E64	TLC Lane Departure Warning	•
6 Series	E64	TMBF Door module, front passenger	•
6 Series	E64	TMFA Door module, driver	•
6 Series	E64	ULF Universal charging and hands-free facility	•
6 Series	E64	ULF-SBX-H Interface box High	•
6 Series	E64	VTG Transfer case	•
7 Series	E65	ACC Active Cruise Control	•
7 Series	E65	AHL Adaptive directional headlights	•
7 Series	E65	AHM Trailer module	•
7 Series	E65	ANT Aerial/antenna tuner	•
7 Series	E65	ARS Dynamic Drive	•
7 Series	E65	ASK Audio system controller	•
7 Series	E65	CA Comfort access system	•
7 Series	E65	CAS Car Access System	•
7 Series	E65	CD Control Display	•
7 Series	E65	CIM Chassis Integration Module	•
7 Series	E65	DME Motor Electronics	•
7 Series	E65	DME Motor Electronics2	•
7 Series	E65	DVDC DVD Changer	•
7 Series	E65	DWA anti-theft alarm system	•
7 Series	E65	EDC Damper Control	•
7 Series	E65	EGS transmission management	•
7 Series	E65	EHC Electronic Ride-Height Control	•
7 Series	E65	EMF Parking brake	•
7 Series	E65	FBI Flexible Bus Interface	•
7 Series	E65	FKA Rear heater/air conditioning	•
7 Series	E65	FLA High Beam Assist	•
7 Series	E65	HKL Rear-lid lift	•
7 Series	E65	IHKA Integrated automatic heating/air conditioning	•
7 Series	E65	INSTR Instrument cluster	•
7 Series	E65	LM Lights Module	•
7 Series	E65	NAV Navigation computer	•
7 Series	E65	NVE Night Vision Electronics	•
7 Series	E65	PDC Park Distance Control	•
7 Series	E65	PM Power Module	•
7 Series	E65	RDC Tyre pressure control	•
7 Series	E65	RLS Rain/Light Sensor	•
7 Series	E65	SASL Satellite, A-pillar, left	•
7 Series	E65	SASR Satellite, A-pillar, right	•
7 Series	E65	SBSL Satellite, B-pillar, left	•
7 Series	E65	SBSR Satellite, B-pillar, right	•
7 Series	E65	SEC2 Supplementary control unit 2	•
7 Series	E65	SFZ Satellite vehicle centre	•
7 Series	E65	SG-FD Control unit, rear-compartment display	•
7 Series	E65	SGM-SIM Safety and Gateway Module(SIM)	•
7 Series	E65	SHD Sliding/tilting sunroof	•
7 Series	E65	SHZH Independent/auxiliary heater	•
7 Series	E65	SINE Siren and tilt sensor	•
7 Series	E65	SMBF Seat module, passenger	
7 Series	E65	SMBFH Seat module, passenger's side, rear	•
7 Series	E65	SMFA Seat module, driver	•
7 Series	E65	SMFAH Seat module, driver's side, rear	•
7 Series	E65	SSBF Satellite, seat, passenger	•
7 Series	E65	SSFA Satellite, seat, driver	•
7 Series	E65	SSH Satellite, seat, rear	I 🛖

Series	Model Series	Systems	Coding
7 Series	E65	STVL Satellite, door, front left	•
7 Series	E65	STVR Satellite, door, front right	•
7 Series	E65	SZL Switch centre, steering column	•
7 Series	E65	TEL Telephone interface	•
7 Series	E65	TMBFH Door module, passenger's side, rear	•
7 Series	E65	TMBFT Door module, passenger door	•
7 Series	E65	TMFAH Door module, driver's side, rear	
7 Series 7 Series	E65 E65	TMFAT Door module, driver's door WIM Wiper module	
7 Series	E65	ZBM Two-battery management	
7 Series	E66	ACC Active Cruise Control	
7 Series	E66	AHL Adaptive directional headlights	•
7 Series	E66	AHM Trailer module	•
7 Series	E66	ANT Aerial/antenna tuner	•
7 Series	E66	ARS Dynamic Drive	•
7 Series	E66	ASK Audio system controller	•
7 Series	E66	CA Comfort access system	•
7 Series	E66	CAS Car Access System	
7 Series	E66	CD Control Display	•
7 Series	E66	CIM Chassis Integration Module	<u> </u>
7 Series	E66	DME Motor Electronics	
7 Series	E66 E66	DME Motor Electronics2 DVDC DVD Changer	
7 Series 7 Series	E66	DWA anti-theft alarm system	
7 Series	E66	EDC Damper Control	
7 Series	E66	EGS transmission management	
7 Series	E66	EHC Electronic Ride-Height Control	
7 Series	E66	EMF Parking brake	•
7 Series	E66	FBI Flexible Bus Interface	•
7 Series	E66	FKA Rear heater/air conditioning	•
7 Series	E66	FLA High Beam Assist	•
7 Series	E66	HKL Rear-lid lift	•
7 Series	E66	IHKA Integrated automatic heating/air conditioning	•
7 Series	E66	INSTR Instrument cluster	•
7 Series	E66	LM Lights Module	•
7 Series	E66	NAV Navigation computer	• • • • • • • • • • • • • • • • • • •
7 Series	E66 E66	NVE Night Vision Electronics	
7 Series 7 Series	E66	PDC Park Distance Control PM Power Module	
7 Series	E66	RDC Tyre pressure control	
7 Series	E66	RLS Rain/Light Sensor	
7 Series	E66	SASL Satellite, A-pillar, left	•
7 Series	E66	SASR Satellite, A-pillar, right	•
7 Series	E66	SBSL Satellite, B-pillar, left	•
7 Series	E66	SBSR Satellite, B-pillar, right	•
7 Series	E66	SEC2 Supplementary control unit 2	
7 Series	E66	SFZ Satellite vehicle centre	
7 Series	E66	SG-FD Control unit, rear-compartment display	•
7 Series	E66	SGM-SIM Safety and Gateway Module (SIM)	
7 Series	E66	SHD Sliding/tilting sunroof	
7 Series	E66 E66	SHZH Independent/auxiliary heater	
7 Series 7 Series	E66	SINE Siren and tilt sensor SMBF Seat module, passenger	
7 Series	E66	SMBFH Seat module, passenger's side, rear	
7 Series	E66	SMFA Seat module, driver	
7 Series	E66	SMFAH Seat module, driver's side, rear	•
7 Series	E66	SSBF Satellite, seat, passenger	•
7 Series	E66	SSFA Satellite, seat, driver	•
7 Series	E66	SSH Satellite, seat, rear	•
7 Series	E66	STVL Satellite, door, front left	•
7 Series	E66	STVR Satellite, door, front right	•
7 Series	E66	SZL Switch centre, steering column	
7 Series	E66	TEL Telephone interface	
7 Series	E66	TMBFH Door module, passenger's side, rear	

Series	Model Series	Systems	Coding
7 Series	E66	TMBFT Door module, passenger door	•
7 Series	E66	TMFAH Door module, driver's side, rear	•
7 Series	E66	TMFAT Door module, driver's door	•
7 Series	E66	WIM Wiper module	•
7 Series	E66	ZBM Two-battery management	•
7 Series	E67	ACC Active Cruise Control	•
7 Series	E67	AHL Adaptive directional headlights	•
7 Series 7 Series	E67 E67	AHM Trailer module ANT Aerial/antenna tuner	
7 Series	E67	ARS Dynamic Drive	
7 Series	E67	ASK Audio system controller	
7 Series	E67	CA Comfort access system	•
7 Series	E67	CAS Car Access System	•
7 Series	E67	CD Control Display	•
7 Series	E67	CIM Chassis Integration Module	•
7 Series	E67	DME Motor Electronics	•
7 Series	E67	DME Motor Electronics2	•
7 Series	E67	DVDC DVD Changer	•
7 Series	E67	DWA anti-theft alarm system	•
7 Series	E67	EDC Damper Control	•
7 Series	E67	EGS transmission management	
7 Series 7 Series	E67 E67	EHC Electronic Ride-Height Control EMF Parking brake	
7 Series	E67	FBI Flexible Bus Interface	
7 Series 7 Series	E67	FKA Rear heater/air conditioning	
7 Series	E67	FLA High Beam Assist	
7 Series	E67	HKL Rear-lid lift	•
7 Series	E67	IHKA Integrated automatic heating/air conditioning	•
7 Series	E67	INSTR Instrument cluster	•
7 Series	E67	LM Lights Module	•
7 Series	E67	NAV Navigation computer	•
7 Series	E67	NVE Night Vision Electronics	•
7 Series	E67	PDC Park Distance Control	•
7 Series	E67	PM Power Module	•
7 Series 7 Series	E67 E67	RDC Tyre pressure control RLS Rain/Light Sensor	
7 Series	E67	SASL Satellite, A-pillar, left	
7 Series	E67	SASR Satellite, A-pillar, right	
7 Series	E67	SBSL Satellite, B-pillar, left	•
7 Series	E67	SBSR Satellite, B-pillar, right	•
7 Series	E67	SEC2 Supplementary control unit 2	•
7 Series	E67	SFZ Satellite vehicle centre	•
7 Series	E67	SG-FD Control unit, rear-compartment display	•
7 Series	E67	SGM-SIM Safety and Gateway Module(SIM)	•
7 Series	E67	SHD Sliding/tilting sunroof	•
7 Series	E67	SHZH Independent/auxiliary heater	•
7 Series	E67	SINE Siren and tilt sensor	
7 Series 7 Series	E67 E67	SMBF Seat module, passenger SMBFH Seat module, passenger's side, rear	
7 Series 7 Series	E67	SMFA Seat module, passenger's side, rear SMFA Seat module, driver	
7 Series	E67	SMFAH Seat module, driver's side, rear	
7 Series	E67	SSBF Satellite, seat, passenger	•
7 Series	E67	SSFA Satellite, seat, driver	•
7 Series	E67	SSH Satellite, seat, rear	•
7 Series	E67	STVL Satellite, door, front left	•
7 Series	E67	STVR Satellite, door, front right	•
7 Series	E67	SZL Switch centre, steering column	•
7 Series	E67	TEL Telephone interface	•
7 Series	E67	TMBFH Door module, passenger's side, rear	•
7 Series	E67	TMBFT Door module, passenger door	•
7 Series	E67	TMFAH Door module, driver's side, rear	•
7 Series 7 Series	E67 E67	TMFAT Door module, driver's door WIM Wiper module	
7 Series 7 Series	E67	ZBM Two-battery management	
· DOTTED	₽01	Laba ino odetely management	

Series	Model Series	Systems	Coding
7 Series	E68	ACC Active Cruise Control	•
7 Series	E68	AHL Adaptive directional headlights	•
7 Series	E68	AHM Trailer module	•
7 Series	E68	ANT Aerial/antenna tuner	•
7 Series	E68	ARS Dynamic Drive	•
7 Series	E68	ASK Audio system controller	•
7 Series	E68	CA Comfort access system	•
7 Series 7 Series	E68 E68	CAS Car Access System CD Control Display	_
7 Series	E68	CIM Chassis Integration Module	
7 Series	E68	DME Motor Electronics	•
7 Series	E68	DME Motor Electronics2	•
7 Series	E68	DVDC DVD Changer	•
7 Series	E68	DWA anti-theft alarm system	•
7 Series	E68	EDC Damper Control	•
7 Series	E68	EGS transmission management	•
7 Series	E68	EHC Electronic Ride-Height Control	•
7 Series	E68	EMF Parking brake	•
7 Series	E68	FBI Flexible Bus Interface	•
7 Series	E68	FKA Rear heater/air conditioning	•
7 Series	E68 E68	FLA High Beam Assist HKL Rear-lid lift	
7 Series 7 Series	E68	IHKA Integrated automatic heating/air conditioning	
7 Series 7 Series	E68	INSTR Instrument cluster	
7 Series	E68	LM Lights Module	-
7 Series	E68	NAV Navigation computer	•
7 Series	E68	NVE Night Vision Electronics	•
7 Series	E68	PDC Park Distance Control	•
7 Series	E68	PM Power Module	•
7 Series	E68	RDC Tyre pressure control	•
7 Series	E68	RLS Rain/Light Sensor	•
7 Series	E68	SASL Satellite, A-pillar, left	•
7 Series	E68	SASR Satellite, A-pillar, right	•
7 Series	E68	SBSL Satellite, B-pillar, left	•
7 Series 7 Series	E68 E68	SBSR Satellite, B-pillar, right SEC2 Supplementary control unit 2	_
7 Series	E68	SFZ Satellite vehicle centre	
7 Series	E68	SG-FD Control unit, rear-compartment display	•
7 Series	E68	SGM-SIM Safety and Gateway Module (SIM)	•
7 Series	E68	SHD Sliding/tilting sunroof	•
7 Series	E68	SHZH Independent/auxiliary heater	•
7 Series	E68	SINE Siren and tilt sensor	•
7 Series	E68	SMBF Seat module, passenger	•
7 Series	E68	SMBFH Seat module, passenger's side, rear	•
7 Series	E68	SMFA Seat module, driver	•
7 Series	E68	SMFAH Seat module, driver's side, rear	•
7 Series	E68	SSBF Satellite, seat, passenger	
7 Series 7 Series	E68 E68	SSFA Satellite, seat, driver SSH Satellite, seat, rear	
7 Series 7 Series	E68	STVL Satellite, door, front left	
7 Series	E68	STVE Satellite, door, front right	
7 Series	E68	SZL Switch centre, steering column	•
7 Series	E68	TEL Telephone interface	•
7 Series	E68	TMBFH Door module, passenger's side, rear	•
7 Series	E68	TMBFT Door module, passenger door	•
7 Series	E68	TMFAH Door module, driver's side, rear	•
7 Series	E68	TMFAT Door module, driver's door	•
7 Series	E68	WIM Wiper module	•
7 Series	E68	ZBM Two-battery management	•
X Series	E70	ABS/ASC/DSC Dynamic Stability Control	•
X Series	E70 E70	ACSM Crash Safety Module	
X Series X Series	E70	AHM Trailer module AL active front steering(AFS70)	
X Series X Series	E70	AMPH Hi-Fi amplifier	
77 DOLLOS	12.0	Institution ampirition	

Series	Model Series	Systems	Coding
X Series	E70	ARS Dynamic Drive	•
X Series	E70	CA Comfort access system	•
X Series	E70	CAS Car Access System	•
X Series	E70	CCC-A Applications	•
X Series	E70	CCC-ANT Aerial tuner	•
X Series	E70	CCC-ASK Audio system controller	•
X Series	E70	CCC-GW Gateway	•
X Series X Series	E70 E70	CHAMP-BO User interface CON Controller	
X Series	E70	DME Motor Electronics	
X Series	E70	DVDC DVD Changer	
X Series	E70	EDCSHL Damper satellite, rear left	•
X Series	E70	EDCSHR Damper satellite, rear right	•
X Series	E70	EDCSVL Damper satellite, front left	•
X Series	E70	EDCSVR Damper satellite, front right	•
X Series	E70	EGS 6HPTU transmission control	•
X Series	E70	EHC Electronic Ride-Height Control	•
X Series	E70	EKPS Fuel-pump control	•
X Series	E70	EMF Parking brake	•
X Series	E70	FKA Rear heater/air conditioning	
X Series	E70	FLA High Beam Assist	•
X Series	E70	FRM2 Footwell module 2	•
X Series	E70	FZD Function centre, roof	•
X Series	E70 E70	GWS Gear selector switch HKL Rear-lid lift	•
X Series X Series	E70	HUD Head-Up Display	
X Series	E70	IHKA Integrated automatic heating/air conditioning	
X Series	E70	INSTR Instrument cluster	
X Series	E70	JBE2 Junction Box electronics	
X Series	E70	PDC Park Distance Control	•
X Series	E70	RFK Reversing camera	•
X Series	E70	RLS Rain/light solar sensor	•
X Series	E70	RSE Rear Seat Entertainment	•
X Series	E70	SINE Siren and tilt sensor	•
X Series	E70	SMBF Seat module, passenger	•
X Series	E70	SMFA Seat module, driver	•
X Series	E70	SVT Servotronic	•
X Series	E70	TRSVC allround-view camera	•
X Series	E70	ULF-SBX Interface box	•
X Series	E70	ULF-SBX-H Interface box High	•
X Series X Series	E70 E70	VDM Vertical Dynamics Management VM Video Module	
X Series	E70	VSW video switch	
X Series	E70	VTG Transfer case	
X Series	E71	ABS/ASC/DSC Dynamic Stability Control	
X Series	E71	ACSM Crash Safety Module	•
X Series	E71	AHM Trailer module	•
X Series	E71	AL active front steering (AFS70)	•
X Series	E71	AMPH Hi-Fi amplifier	•
X Series	E71	ARS Dynamic Drive	•
X Series	E71	CA Comfort access system	•
X Series	E71	CAS Car Access System	•
X Series	E71	CCC-A Applications	•
X Series	E71	CCC-ANT Aerial tuner	•
X Series	E71	CCC-ASK Audio system controller	•
X Series	E71	CCC-GW Gateway	•
X Series	E71	CHAMP-BO User interface	
X Series	E71 E71	CON Controller DME Motor Electronics	
X Series X Series	E71	DVDC DVD Changer	
X Series X Series	E71	EDCSHL Damper satellite, rear left	
X Series	E71	EDCSHL Damper satellite, rear left EDCSHR Damper satellite, rear right	
	E71	EDCSIN Damper Satellite, front left	
X Series			

Series	Model Series	Systems	Coding
X Series	E71	EGS 6HPTU transmission control	•
X Series	E71	EHC Electronic Ride-Height Control	•
X Series	E71	EKPS Fuel-pump control	•
X Series	E71	EMF Parking brake	•
X Series	E71	FKA Rear heater/air conditioning	•
X Series	E71	FLA High Beam Assist	•
X Series	E71	FRM2 Footwell module 2	•
X Series X Series	E71 E71	FZD Function centre, roof GWS Gear selector switch	
X Series	E71	HKL Rear-lid lift	
X Series	E71	HUD Head-Up Display	
X Series	E71	IHKA Integrated automatic heating/air conditioning	
X Series	E71	INSTR Instrument cluster	•
X Series	E71	JBE2 Junction Box electronics	•
X Series	E71	PDC Park Distance Control	•
X Series	E71	RFK Reversing camera	•
X Series	E71	RLS Rain/light solar sensor	•
X Series	E71	RSE Rear Seat Entertainment	•
X Series	E71	SINE Siren and tilt sensor	•
X Series	E71	SMBF Seat module, passenger	•
X Series	E71	SMFA Seat module, driver	•
X Series	E71	SVT Servotronic	•
X Series	E71	TRSVC allround-view camera	•
X Series	E71 E71	ULF-SBX Interface box	•
X Series X Series	E71	ULF-SBX-H Interface box High VDM Vertical Dynamics Management	
X Series	E71	VM Video Module	
X Series	E71	VSW video module VSW video switch	
X Series	E71	VTG Transfer case	
X Series	E72	ABS/ASC/DSC Dynamic Stability Control	•
X Series	E72	ACSM Crash Safety Module	•
X Series	E72	AHM Trailer module	•
X Series	E72	AL active front steering(AFS70)	•
X Series	E72	AMPH Hi-Fi amplifier	•
X Series	E72	ARS Dynamic Drive	•
X Series	E72	CA Comfort access system	•
X Series	E72	CAS Car Access System	•
X Series	E72	CCC-A Applications	•
X Series	E72	CCC-ANT Aerial tuner	•
X Series	E72	CCC-ASK Audio system controller	•
X Series	E72	CCC-GW Gateway	•
X Series	E72 E72	CHAMP-BO User interface CON Controller	
X Series X Series	E72	DME Motor Electronics	
X Series	E72	DVDC DVD Changer	
X Series	E72	EDCSHL Damper satellite, rear left	
X Series	E72	EDCSHR Damper satellite, rear right	•
X Series	E72	EDCSVL Damper satellite, front left	•
X Series	E72	EDCSVR Damper satellite, front right	•
X Series	E72	EGS 6HPTU transmission control	•
X Series	E72	EHC Electronic Ride-Height Control	•
X Series	E72	EKPS Fuel-pump control	•
X Series	E72	EMF Parking brake	•
X Series	E72	FKA Rear heater/air conditioning	•
X Series	E72	FLA High Beam Assist	•
X Series	E72	FRM2 Footwell module 2	•
X Series	E72	FZD Function centre, roof	•
X Series	E72	GWS Gear selector switch	
X Series	E72 E72	HKL Rear-lid lift	
X Series X Series	E72	HUD Head-Up Display	
X Series X Series	E72	IHKA Integrated automatic heating/air conditioning INSTR Instrument cluster	
X Series	E72	JBE2 Junction Box electronics	
X Series	E72	PDC Park Distance Control	
v POTTOP	1010	It no tark protance control	

Series	Model Series	Systems	Coding
X Series	E72	RFK Reversing camera	•
X Series	E72	RLS Rain/light solar sensor	•
X Series	E72	RSE Rear Seat Entertainment	•
X Series	E72	SINE Siren and tilt sensor	•
X Series	E72	SMBF Seat module, passenger	•
X Series	E72	SMFA Seat module, driver	•
X Series	E72	SVT Servotronic	•
X Series	E72	TRSVC allround-view camera	•
X Series	E72 E72	ULF-SBX Interface box	
X Series X Series	E72	ULF-SBX-H Interface box High VDM Vertical Dynamics Management	
X Series X Series	E72	VM Video Module	
X Series	E72	VSW video module VSW video switch	
X Series	E72	VTG Transfer case	
X Series	E83	ABS/ASC/DSC Dynamic Stability Control	•
X Series	E83	AHL Adaptive directional headlights	•
X Series	E83	DME Motor Electronics	•
X Series	E83	DSP Digital Sound Processor	•
X Series	E83	EWS Vehicle immobilizer	•
X Series	E83	GM base module	•
X Series	E83	IHKR Integrated heating/air-conditioning regulation	•
X Series	E83	INSTR Instrument cluster	•
X Series	E83	LM Lights Module	•
X Series	E83	LWS Steering angle sensor	•
X Series	E83	MRS Multiple Restraint System V	•
X Series	E83	PDC Park Distance Control	•
X Series	E83	RAD Radio	•
X Series	E83	RDC Tyre pressure control	•
X Series	E83	RLS Rain/Light Sensor	•
X Series	E83	SHD Sliding/tilting sunroof	•
X Series	E83	SMF Seat memory, driver	•
X Series X Series	E83	SMF Seat memory, driver SVT Servotronic	
X Series	E83	TCU Telematic Control Unit	
X Series	E83	VID Video module	
X Series	E83	VTG Transfer case	
Z Series	E85	ABS/ASC/DSC Dynamic Stability Control	•
Z Series	E85	CVM Convertible top module	•
Z Series	E85	DME Motor Electronics	•
Z Series	E85	DSP Digital Sound Processor	•
Z Series	E85	EPS Electronic Power Steering	•
Z Series	E85	EWS Vehicle immobilizer	•
Z Series	E85	GM5 General module 5	•
Z Series	E85	IHKS Integrated heating/air-conditioning control	•
Z Series	E85	INSTR Instrument cluster	•
Z Series	E85	LSZ Light switch centre II	•
Z Series	E85	LWS Steering angle sensor	•
Z Series	E85	PDC Park Distance Control	•
Z Series	E85	RAD Radio	•
Z Series	E85 E85	RLS Rain/Light Sensor	
Z Series Z Series	E85	SBSL Satellite, B-pillar, left SBSR Satellite, B-pillar, right	
Z Series Z Series	E85	SIM Safety and Information Module	
Z Series Z Series	E85	SMF Seat memory, driver	
Z Series	E85	SMF Seat memory, driver	
Z Series	E85	STVL Satellite, door, front left	•
Z Series	E85	STVR Satellite, door, front right	•
Z Series	E85	TCU Telematic Control Unit	•
Z Series	E85	VID Video module	•
Z Series	E86	ABS/ASC/DSC Dynamic Stability Control	•
Z Series	E86	CVM Convertible top module	•
Z Series	E86	DME Motor Electronics	•
Z Series	E86	DSP Digital Sound Processor	•
Z Series	E86	EPS Electronic Power Steering	

Series	Model Series	Systems	Coding
Z Series	E86	EWS Vehicle immobilizer	•
Z Series	E86	GM5 General module 5	•
Z Series	E86	IHKS Integrated heating/air-conditioning control	•
Z Series	E86	INSTR Instrument cluster	•
Z Series	E86	LSZ Light switch centre II	•
Z Series	E86	LWS Steering angle sensor	•
Z Series	E86	PDC Park Distance Control	•
Z Series	E86	RAD Radio	•
Z Series	E86	RLS Rain/Light Sensor	
Z Series Z Series	E86 E86	SBSL Satellite, B-pillar, left SBSR Satellite, B-pillar, right	
Z Series Z Series	E86	SIM Safety and Information Module	
Z Series Z Series	E86	SMF Seat memory, driver	
Z Series	E86	SMF Seat memory, driver	
Z Series	E86	STVL Satellite, door, front left	
Z Series	E86	STVR Satellite, door, front right	•
Z Series	E86	TCU Telematic Control Unit	•
Z Series	E86	VID Video module	•
Z Series	E89	ABS/ASC/DSC Dynamic Stability Control	•
Z Series	E89	CA Comfort access system	•
Z Series	E89	CIC Car Information Computer	•
Z Series	E89	CID Central Information Display	•
Z Series	E89	CON Controller	•
Z Series	E89	CTM Convertible-top module	•
Z Series	E89	DME Motor Electronics	•
Z Series	E89	DVDC DVD Changer	•
Z Series	E89	DWA anti-theft alarm system	•
Z Series	E89	EDC Damper Control	•
Z Series	E89	EGS 6HPTU transmission control	•
Z Series	E89	EKPS Fuel-pump control	•
Z Series	E89	EMF Parking brake	•
Z Series	E89	EPS Electronic Power Steering	•
Z Series	E89	EPS Electronic Power Steering	•
Z Series	E89	FLA High Beam Assist	
Z Series Z Series	E89 E89	FRM2 Footwell module 2	
Z Series Z Series	E89	FZD Function centre, roof GWS Gear selector switch	
Z Series Z Series	E89	IHKR Integrated heating/air-conditioning regulation	
Z Series	E89	INSTR Instrument cluster	
Z Series	E89	JBE2 Junction Box electronics	
Z Series	E89	MOST system analysis	•
Z Series	E89	MRS Multiple Restraint System	•
Z Series	E89	PDC Park Distance Control	•
Z Series	E89	RAD Radio	•
Z Series	E89	RAD2-GW Gateway	•
Z Series	E89	SINE Siren and tilt sensor	•
Z Series	E89	SMFA Seat module, driver	•
Z Series	E89	TCU Telematic Control Unit	•
Z Series	E89	ULF-SBX-H Interface box High	•
Z Series	E89	VM Video Module	•
1 Series	E81	ABS/ASC/DSC Dynamic Stability Control	•
1 Series	E81	CA Comfort access system	• •
1 Series	E81	CIC Car Information Computer	•
1 Series	E81	CID Central Information Display	•
1 Series	E81	CON Controller	•
1 Series	E81	CTM Convertible-top module	•
1 Series	E81	DME Motor Electronics	•
1 Series	E81	DVDC DVD Changer	•
1 Series	E81	DWA anti-theft alarm system	
1 Series	E81 E81	EDC Damper Control	
1 Series 1 Series	E81	EGS 6HPTU transmission control EKPS Fuel-pump control	
1 Series 1 Series	E81	EMF Parking brake	
1 Series 1 Series	E81	EPS Electronic Power Steering	
1 DOLLOS	Ino I	IN a procuratio rance according	

Series	Model Series	Systems	Coding
1 Series	E81	EPS Electronic Power Steering	•
1 Series	E81	FLA High Beam Assist	•
1 Series	E81	FRM2 Footwell module 2	•
1 Series	E81	FZD Function centre, roof	•
1 Series	E81	GWS Gear selector switch	•
1 Series	E81	IHKR Integrated heating/air-conditioning regulation	•
1 Series	E81	INSTR Instrument cluster	
1 Series	E81	JBE2 Junction Box electronics	+ -
1 Series 1 Series	E81 E81	MOST system analysis MRS Multiple Restraint System	+ -
1 Series	E81	PDC Park Distance Control	+ -
1 Series	E81	RAD Radio	+ •
1 Series	E81	RAD2-GW Gateway	•
1 Series	E81	SINE Siren and tilt sensor	•
1 Series	E81	SMFA Seat module, driver	•
1 Series	E81	TCU Telematic Control Unit	•
1 Series	E81	ULF-SBX-H Interface box High	•
1 Series	E81	VM Video Module	•
1 Series	E82	ABS/ASC/DSC Dynamic Stability Control	•
1 Series	E82	CA Comfort access system	•
1 Series	E82	CIC Car Information Computer	•
1 Series	E82	CID Central Information Display	—
1 Series	E82	CON Controller	—
1 Series	E82 E82	CTM Convertible-top module	+ -
1 Series	E82	DME Motor Electronics DVDC DVD Changer	+ •
1 Series 1 Series	E82	DWA anti-theft alarm system	+ -
1 Series	E82	EDC Damper Control	
1 Series	E82	EGS 6HPTU transmission control	+ -
1 Series	E82	EKPS Fuel-pump control	•
1 Series	E82	EMF Parking brake	•
1 Series	E82	EPS Electronic Power Steering	•
1 Series	E82	EPS Electronic Power Steering	•
1 Series	E82	FLA High Beam Assist	•
1 Series	E82	FRM2 Footwell module 2	•
1 Series	E82	FZD Function centre, roof	•
1 Series	E82	GWS Gear selector switch	•
1 Series	E82	IHKR Integrated heating/air-conditioning regulation	•
1 Series	E82	INSTR Instrument cluster	•
1 Series	E82	JBE2 Junction Box electronics	•
1 Series	E82 E82	MOST system analysis	+ -
1 Series 1 Series	E82	MRS Multiple Restraint System PDC Park Distance Control	+ -
1 Series 1 Series	E82	RAD Radio	-
1 Series	E82	RAD2-GW Gateway	+ •
1 Series	E82	SINE Siren and tilt sensor	•
1 Series	E82	SMFA Seat module, driver	•
1 Series	E82	TCU Telematic Control Unit	•
1 Series	E82	ULF-SBX-H Interface box High	•
1 Series	E82	VM Video Module	•
X Series	E84	ABS/ASC/DSC Dynamic Stability Control	•
X Series	E84	CA Comfort access system	•
X Series	E84	CIC Car Information Computer	•
X Series	E84	CID Central Information Display	•
X Series	E84	CON Controller	•
X Series	E84	CTM Convertible-top module	—
X Series	E84	DME Motor Electronics	+ •
X Series	E84	DVDC DVD Changer	—
X Series X Series	E84 E84	DWA anti-theft alarm system EDC Damper Control	+ -
X Series X Series	E84	EGS 6HPTU transmission control	
X Series	E84	EKPS Fuel-pump control	+
X Series	E84	EMF Parking brake	—
X Series	E84	EPS Electronic Power Steering	•
	•		

Series	Model Series	Systems	Coding
X Series	E84	EPS Electronic Power Steering	•
X Series	E84	FLA High Beam Assist	•
X Series	E84	FRM2 Footwell module 2	•
X Series	E84	FZD Function centre, roof	•
X Series	E84	GWS Gear selector switch	•
X Series	E84	IHKR Integrated heating/air-conditioning regulation	•
X Series	E84	INSTR Instrument cluster	•
X Series	E84	JBE2 Junction Box electronics	•
X Series	E84	MOST system analysis MRS Multiple Restraint System	•
X Series X Series	E84 E84	PDC Park Distance Control	
X Series	E84	RAD Radio	
X Series	E84	RAD2-GW Gateway	
X Series	E84	SINE Siren and tilt sensor	
X Series	E84	SMFA Seat module, driver	•
X Series	E84	TCU Telematic Control Unit	•
X Series	E84	ULF-SBX-H Interface box High	•
X Series	E84	VM Video Module	•
1 Series	E87	ABS/ASC/DSC Dynamic Stability Control	•
1 Series	E87	CA Comfort access system	
1 Series	E87	CIC Car Information Computer	•
1 Series	E87	CID Central Information Display	•
1 Series	E87	CON Controller	•
1 Series	E87	CTM Convertible-top module	•
1 Series	E87	DME Motor Electronics	•
1 Series	E87	DVDC DVD Changer	•
1 Series	E87	DWA anti-theft alarm system	•
1 Series	E87	EDC Damper Control	•
1 Series	E87	EGS 6HPTU transmission control	•
1 Series	E87	EKPS Fuel-pump control	•
1 Series	E87	EMF Parking brake	•
1 Series	E87	EPS Electronic Power Steering	•
1 Series	E87	EPS Electronic Power Steering	•
1 Series	E87	FLA High Beam Assist	•
1 Series 1 Series	E87 E87	FRM2 Footwell module 2	
1 Series	E87	FZD Function centre, roof GWS Gear selector switch	
1 Series	E87	IHKR Integrated heating/air-conditioning regulation	
1 Series	E87	INSTR Instrument cluster	
1 Series	E87	JBE2 Junction Box electronics	•
1 Series	E87	MOST system analysis	•
1 Series	E87	MRS Multiple Restraint System	•
1 Series	E87	PDC Park Distance Control	•
1 Series	E87	RAD Radio	•
1 Series	E87	RAD2-GW Gateway	•
1 Series	E87	SINE Siren and tilt sensor	•
1 Series	E87	SMFA Seat module, driver	•
1 Series	E87	TCU Telematic Control Unit	•
1 Series	E87	ULF-SBX-H Interface box High	•
1 Series	E87	VM Video Module	•
1 Series	E88	ABS/ASC/DSC Dynamic Stability Control	•
1 Series	E88	CA Comfort access system	•
1 Series	E88	CIC Car Information Computer	•
1 Series	E88	CID Central Information Display	•
1 Series	E88	CON Controller	•
1 Series	E88	CTM Convertible-top module	•
1 Series	E88	DME Motor Electronics	•
1 Series	E88	DVDC DVD Changer	•
1 Series	E88	DWA anti-theft alarm system	
1 Series	E88 E88	EDC Damper Control	
1 Series 1 Series	E88	EGS 6HPTU transmission control EKPS Fuel-pump control	
1 Series 1 Series	E88	EMF Parking brake	
1 Series	E88	EPS Electronic Power Steering	
1 001162	լոսս	IN a processource somer accessing	<u> </u>

Series	Model Series	Systems	Coding
1 Series	E88	EPS Electronic Power Steering	•
1 Series	E88	FLA High Beam Assist	•
1 Series	E88	FRM2 Footwell module 2	•
1 Series	E88	FZD Function centre, roof	•
1 Series	E88	GWS Gear selector switch	•
1 Series	E88	IHKR Integrated heating/air-conditioning regulation	•
1 Series	E88	INSTR Instrument cluster	•
1 Series	E88	JBE2 Junction Box electronics	•
1 Series 1 Series	E88 E88	MOST system analysis MRS Multiple Restraint System	
1 Series	E88	PDC Park Distance Control	
1 Series	E88	RAD Radio	
1 Series	E88	RAD2-GW Gateway	
1 Series	E88	SINE Siren and tilt sensor	•
1 Series	E88	SMFA Seat module, driver	•
1 Series	E88	TCU Telematic Control Unit	•
1 Series	E88	ULF-SBX-H Interface box High	•
1 Series	E88	VM Video Module	•
3 Series	E90	ABS/ASC/DSC Dynamic Stability Control	•
3 Series	E90	CA Comfort access system	•
3 Series	E90	CIC Car Information Computer	•
3 Series	E90	CID Central Information Display	
3 Series	E90	CON Controller	
3 Series	E90	CTM Convertible-top module	•
3 Series	E90	DME Motor Electronics	•
3 Series	E90	DVDC DVD Changer	•
3 Series	E90 E90	DWA anti-theft alarm system EDC Damper Control	
3 Series 3 Series	E90	EGS 6HPTU transmission control	
3 Series	E90	EKPS Fuel-pump control	
3 Series	E90	EMF Parking brake	
3 Series	E90	EPS Electronic Power Steering	
3 Series	E90	EPS Electronic Power Steering	•
3 Series	E90	FLA High Beam Assist	•
3 Series	E90	FRM2 Footwell module 2	•
3 Series	E90	FZD Function centre, roof	•
3 Series	E90	GWS Gear selector switch	•
3 Series	E90	IHKR Integrated heating/air-conditioning regulation	•
3 Series	E90	INSTR Instrument cluster	•
3 Series	E90	JBE2 Junction Box electronics	•
3 Series	E90	MOST system analysis	•
3 Series	E90	MRS Multiple Restraint System	•
3 Series	E90	PDC Park Distance Control	-
3 Series	E90	RAD Radio	-
3 Series	E90	RAD2-GW Gateway	
3 Series	E90 E90	SINE Siren and tilt sensor SMFA Seat module, driver	
3 Series 3 Series	E90	TCU Telematic Control Unit	
3 Series	E90	ULF-SBX-H Interface box High	
3 Series	E90	VM Video Module	
3 Series	E91	ABS/ASC/DSC Dynamic Stability Control	
3 Series	E91	CA Comfort access system	•
3 Series	E91	CIC Car Information Computer	•
3 Series	E91	CID Central Information Display	
3 Series	E91	CON Controller	•
3 Series	E91	CTM Convertible-top module	•
3 Series	E91	DME Motor Electronics	•
3 Series	E91	DVDC DVD Changer	•
3 Series	E91	DWA anti-theft alarm system	•
3 Series	E91	EDC Damper Control	•
3 Series	E91	EGS 6HPTU transmission control	•
3 Series	E91	EKPS Fuel-pump control	•
3 Series	E91	EMF Parking brake	•
3 Series	E91	EPS Electronic Power Steering	

Series	Model Series	Systems	Coding
3 Series	E91	EPS Electronic Power Steering	•
3 Series	E91	FLA High Beam Assist	•
3 Series	E91	FRM2 Footwell module 2	•
3 Series	E91	FZD Function centre, roof	•
3 Series	E91	GWS Gear selector switch	•
3 Series	E91	IHKR Integrated heating/air-conditioning regulation	•
3 Series	E91	INSTR Instrument cluster	•
3 Series	E91	JBE2 Junction Box electronics	•
3 Series	E91	MOST system analysis	•
3 Series	E91	MRS Multiple Restraint System	•
3 Series	E91 E91	PDC Park Distance Control	
3 Series 3 Series	E91	RAD Radio RAD2-GW Gateway	
3 Series	E91	SINE Siren and tilt sensor	
3 Series	E91	SMFA Seat module, driver	
3 Series	E91	TCU Telematic Control Unit	
3 Series	E91	ULF-SBX-H Interface box High	
3 Series	E91	VM Video Module	•
3 Series	E92	ABS/ASC/DSC Dynamic Stability Control	•
3 Series	E92	CA Comfort access system	•
3 Series	E92	CIC Car Information Computer	•
3 Series	E92	CID Central Information Display	•
3 Series	E92	CON Controller	•
3 Series	E92	CTM Convertible-top module	•
3 Series	E92	DME Motor Electronics	•
3 Series	E92	DVDC DVD Changer	•
3 Series	E92	DWA anti-theft alarm system	•
3 Series	E92	EDC Damper Control	•
3 Series	E92	EGS 6HPTU transmission control	•
3 Series	E92	EKPS Fuel-pump control	•
3 Series	E92	EMF Parking brake	•
3 Series	E92	EPS Electronic Power Steering	•
3 Series	E92	EPS Electronic Power Steering	•
3 Series	E92	FLA High Beam Assist	•
3 Series	E92	FRM2 Footwell module 2	•
3 Series	E92	FZD Function centre, roof	•
3 Series	E92 E92	GWS Gear selector switch	
3 Series 3 Series	E92	IHKR Integrated heating/air-conditioning regulation INSTR Instrument cluster	
3 Series	E92	JBE2 Junction Box electronics	
3 Series	E92	MOST system analysis	
3 Series	E92	MRS Multiple Restraint System	
3 Series	E92	PDC Park Distance Control	
3 Series	E92	RAD Radio	•
3 Series	E92	RAD2-GW Gateway	•
3 Series	E92	SINE Siren and tilt sensor	•
3 Series	E92	SMFA Seat module, driver	•
3 Series	E92	TCU Telematic Control Unit	•
3 Series	E92	ULF-SBX-H Interface box High	•
3 Series	E92	VM Video Module	•
3 Series	E93	ABS/ASC/DSC Dynamic Stability Control	•
3 Series	E93	CA Comfort access system	•
3 Series	E93	CIC Car Information Computer	•
3 Series	E93	CID Central Information Display	•
3 Series	E93	CON Controller	-
3 Series	E93	CTM Convertible-top module	-
3 Series	E93	DME Motor Electronics	•
3 Series	E93	DVDC DVD Changer	•
3 Series	E93	DWA anti-theft alarm system	•
3 Series	E93	EDC Damper Control	•
3 Series	E93	EGS 6HPTU transmission control	
3 Series	E93	EKPS Fuel-pump control	
3 Series	E93	EMF Parking brake	
3 Series	E93	EPS Electronic Power Steering	

Series	Model Series	Systems	Coding
3 Series	E93	EPS Electronic Power Steering	•
3 Series	E93	FLA High Beam Assist	•
3 Series	E93	FRM2 Footwell module 2	•
3 Series	E93	FZD Function centre, roof	•
3 Series	E93	GWS Gear selector switch	•
3 Series	E93	IHKR Integrated heating/air-conditioning regulation	•
3 Series	E93	INSTR Instrument cluster	•
3 Series	E93	JBE2 Junction Box electronics	•
3 Series	E93 E93	MOST system analysis MRS Multiple Restraint System	
3 Series 3 Series	E93	PDC Park Distance Control	
3 Series	E93	RAD Radio	
3 Series	E93	RAD2-GW Gateway	
3 Series	E93	SINE Siren and tilt sensor	
3 Series	E93	SMFA Seat module, driver	
3 Series	E93	TCU Telematic Control Unit	
3 Series	E93	ULF-SBX-H Interface box High	•
3 Series	E93	VM Video Module	•
7 Series	F001/F002/F004	JBE Junction-box electronics	•
7 Series	F001/F002/F004	ACSM Crash Safety Module	•
7 Series	F001/F002/F004	SZL Switch centre, steering column	•
7 Series	F001/F002/F004	TRSVC allround-view camera	•
7 Series	F001/F002/F004	SME Accumulator-management electronics	•
7 Series	F001/F002/F004	SWW Lane change warning	•
7 Series	F001/F002/F004	SVT Servotronic	•
7 Series	F001/F002/F004	DME Digital Motor Electronics	•
7 Series	F001/F002/F004	DME Digital Motor Electronics 2	•
7 Series	F001/F002/F004	AL active steering	•
7 Series	F001/F002/F004	EKPS Fuel-pump control	•
7 Series	F001/F002/F004	EGS transmission management	•
7 Series	F001/F002/F004	VTG Transfer case	•
7 Series	F001/F002/F004	ICM Integrated Chassis Management	•
7 Series	F001/F002/F004	RDC Tyre pressure control	•
7 Series	F001/F002/F004	ACC Active Cruise Control	•
7 Series	F001/F002/F004	RSE Rear Seat Entertainment	•
7 Series	F001/F002/F004 F001/F002/F004	DSC Dynamic Stability Control HSR Rear-axle slip-angle control	
7 Series 7 Series	F001/F002/F004 F001/F002/F004	EPS Electronic Power Steering	
7 Series	F001/F002/F004 F001/F002/F004	DVDC DVD Changer	
7 Series	F001/F002/F004	TBX Touchbox	
7 Series	F001/F002/F004	CBX-MEDIA Combox Multimedia	
7 Series	F001/F002/F004	AMPT Top Hi-Fi amplifier	
7 Series	F001/F002/F004	EHC Electronic Ride-Height Control	•
7 Series	F001/F002/F004	VDM Vertical Dynamics Management	•
7 Series	F001/F002/F004	HUD Head-Up Display	•
7 Series	F001/F002/F004	CAS Car Access System	•
7 Series	F001/F002/F004	STML Headlight driver module, left	•
7 Series	F001/F002/F004	STMR Headlight driver module, right	•
7 Series	F001/F002/F004	LHML LED main light module, left	•
7 Series	F001/F002/F004	LHMR LED main light module, right	•
7 Series	F001/F002/F004	GZAL Targeted illumination, left	•
7 Series	F001/F002/F004	GZAR Targeted illumination, right	•
7 Series	F001/F002/F004	VM Video Module	•
7 Series	F001/F002/F004	EMALI Electric-motor reel, left	•
7 Series	F001/F002/F004	EMARE Electric-motor reel, right	•
7 Series	F001/F002/F004	ULF-SBX-H Interface box high	•
7 Series	F001/F002/F004	FZD Function centre, roof	-
7 Series	F001/F002/F004	NVE Night Vision Electronics	•
7 Series	F001/F002/F004	KAFAS Camera-based driver-assistance systems	•
7 Series	F001/F002/F004	GWS Gear selector switch	•
7 Series	F001/F002/F004	FLA High Beam Assist	•
7 Series	F001/F002/F004	INSTR Instrument cluster	
7 Series 7 Series	F001/F002/F004 F001/F002/F004	CBX-ECALL Combox emergency call CIC Car Information Computer	
1 PETTER	1.001/1.007/1.004	Toto our information computel	

Series	Model Series	Systems	Coding
7 Series	F001/F002/F004	PDC Park Distance Control	•
7 Series	F001/F002/F004	CON Controller	•
7 Series	F001/F002/F004	FCON Rear compartment controller	•
7 Series	F001/F002/F004	SMFAH Seat module, driver's side, rear	•
7 Series	F001/F002/F004	SMBFH Seat module, passenger's side, rear	•
7 Series	F001/F002/F004	HKL Rear-lid lift	•
7 Series	F001/F002/F004	SMFA Seat module, driver	
7 Series 7 Series	F001/F002/F004	SMBF Seat module, passenger	
7 Series 7 Series	F001/F002/F004 F001/F002/F004	AHM Trailer module FRM Footwell module	
7 Series 7 Series	F001/F002/F004	CID Central Information Display	
7 Series	F001/F002/F004	FD Rear-compartment display	
7 Series	F001/F002/F004	FD2 Rear-compartment display 2	
7 Series	F001/F002/F004	IHKA Integrated automatic heating/air conditioning	•
7 Series	F001/F002/F004	FKA Rear heater/air conditioning	•
7 Series	F001/F002/F004	EDCSVL Damper satellite, front left	•
7 Series	F001/F002/F004	EDCSVR Damper satellite, front right	•
7 Series	F001/F002/F004	EDCSHL Damper satellite, rear left	•
7 Series	F001/F002/F004	EDCSHR Damper satellite, rear right	•
5 Series	F010/F011/F018	JBE Junction-box electronics	•
5 Series	F010/F011/F018	ACSM Crash Safety Module	•
5 Series	F010/F011/F018	SZL Switch centre, steering column	•
5 Series	F010/F011/F018	TRSVC allround-view camera	•
5 Series	F010/F011/F018	SME Accumulator-management electronics	•
5 Series	F010/F011/F018	SWW Lane change warning	•
5 Series	F010/F011/F018	HKL Automatic luggage compartment lid actuation	•
5 Series	F010/F011/F018	SVT Servotronic	•
5 Series	F010/F011/F018	GHAS Regulated differential lock	
5 Series 5 Series	F010/F011/F018 F010/F011/F018	DME Digital Motor Electronics DME Digital Motor Electronics 2	
5 Series	F010/F011/F018	AL active steering	
5 Series	F010/F011/F018	EKPS Fuel-pump control	
5 Series	F010/F011/F018	EGS transmission management	
5 Series	F010/F011/F018	VTG Transfer case	•
5 Series	F010/F011/F018	ICM Integrated Chassis Management	•
5 Series	F010/F011/F018	RDC Tyre pressure control	•
5 Series	F010/F011/F018	ACC Active Cruise Control	•
5 Series	F010/F011/F018	CTM Convertible-top module	•
5 Series	F010/F011/F018	RSE Rear Seat Entertainment	•
5 Series	F010/F011/F018	DSC Dynamic Stability Control	•
5 Series	F010/F011/F018	EMF Parking brake	•
5 Series	F010/F011/F018	HSR Rear-axle slip-angle control	•
5 Series	F010/F011/F018	PMA Parking assistant	•
5 Series	F010/F011/F018	EPS Electronic Power Steering	•
5 Series	F010/F011/F018	DVDC DVD Changer	•
5 Series	F010/F011/F018	CBX-MEDIA Combox Multimedia	•
5 Series	F010/F011/F018 F010/F011/F018	AMPT Top Hi-Fi amplifier EHC Electronic Ride-Height Control	
5 Series 5 Series	F010/F011/F018 F010/F011/F018	VDM Vertical Dynamics Management	
5 Series 5 Series	F010/F011/F018	HUD Head-Up Display	
5 Series 5 Series	F010/F011/F018	ASD Active Sound Design	
5 Series	F010/F011/F018	CAS Car Access System	
5 Series	F010/F011/F018	VM Video Module	
5 Series	F010/F011/F018	EMALI Electric-motor reel, left	•
5 Series	F010/F011/F018	EMARE Electric-motor reel, right	•
5 Series	F010/F011/F018	SINE Siren and tilt sensor	•
5 Series	F010/F011/F018	ULF-SBX-H Interface box high	
5 Series	F010/F011/F018	FZD Function centre, roof	•
5 Series	F010/F011/F018	NVE Night Vision Electronics	•
5 Series	F010/F011/F018	KAFAS Camera-based driver-assistance systems	•
5 Series	F010/F011/F018	GWS Gear selector switch	•
5 Series	F010/F011/F018	FLA High Beam Assist	•
5 Series	F010/F011/F018	INSTR Instrument cluster	•
5 Series	F010/F011/F018	CBX-ECALL Combox emergency call	•

Series	Model Series	Systems	Coding
5 Series	F010/F011/F018	CIC Car Information Computer	•
5 Series	F010/F011/F018	PDC Park Distance Control	•
5 Series	F010/F011/F018	CON Controller	•
5 Series	F010/F011/F018	HKL Rear-lid lift	•
5 Series	F010/F011/F018	SMFA Seat module, driver	•
5 Series	F010/F011/F018	SMBF Seat module, passenger	•
5 Series	F010/F011/F018	AHM Trailer module	•
5 Series	F010/F011/F018	FRM Footwell module	•
5 Series	F010/F011/F018	CID Central Information Display	•
5 Series 5 Series	F010/F011/F018 F010/F011/F018	FD Rear-compartment display FD2 Rear-compartment display 2	
5 Series 5 Series	F010/F011/F018	VDM2 Vertical dynamics management	
5 Series	F010/F011/F018	IHKA Integrated automatic heating/air conditioning	
5 Series	F010/F011/F018	FKA Rear heater/air conditioning	
5 Series	F010/F011/F018	EDCSVL Damper satellite, front left	•
5 Series	F010/F011/F018	EDCSVR Damper satellite, front right	•
5 Series	F010/F011/F018	EDCSHL Damper satellite, rear left	•
5 Series	F010/F011/F018	EDCSHR Damper satellite, rear right	•
1 Series	F020/F021	ACSM Crash Safety Module	•
1 Series	F020/F021	TRSVC allround-view camera	
1 Series	F020/F021	SME Accumulator-management electronics	•
1 Series	F020/F021	SWW Lane change warning	•
1 Series	F020/F021	HKL Automatic luggage compartment lid actuation	•
1 Series	F020/F021	GHAS Regulated differential lock	•
1 Series	F020/F021	DME Digital Motor Electronics	•
1 Series	F020/F021	EKPS Fuel-pump control	•
1 Series	F020/F021	EGS transmission management	•
1 Series	F020/F021	VTG Transfer case	•
1 Series	F020/F021	ICM Integrated Chassis Management	•
1 Series	F020/F021	ACC Active Cruise Control	•
1 Series	F020/F021	CTM Convertible-top module	•
1 Series	F020/F021	DSC Dynamic Stability Control	•
1 Series	F020/F021	PMA Parking assistant	•
1 Series	F020/F021	EPS Electronic Power Steering	•
1 Series 1 Series	F020/F021 F020/F021	DVDC DVD Changer CBX-MEDIA Combox Multimedia	
1 Series	F020/F021	AMPT Top Hi-Fi amplifier	
1 Series	F020/F021	ASD Active Sound Design	
1 Series	F020/F021	CAS Car Access System	
1 Series	F020/F021	VM Video Module	•
1 Series	F020/F021	EMALI Electric-motor reel, left	•
1 Series	F020/F021	EMARE Electric-motor reel, right	•
1 Series	F020/F021	SINE Siren and tilt sensor	•
1 Series	F020/F021	FZD Function centre, roof	
1 Series	F020/F021	KAFAS Camera-based driver-assistance systems	•
1 Series	F020/F021	FLA High Beam Assist	•
1 Series	F020/F021	INSTR Instrument cluster	•
1 Series	F020/F021	CBX-ECALL Combox emergency call	•
1 Series	F020/F021	CIC Car Information Computer	•
1 Series	F020/F021	CON Controller	•
1 Series	F020/F021	SMFA Seat module, driver	•
1 Series	F020/F021	SMBF Seat module, passenger	•
1 Series	F020/F021	AHM Trailer module	—
1 Series	F020/F021	FRM Footwell module	+ •
1 Series	F020/F021	VDM2 Vertical dynamics management	—
1 Series	F020/F021	IHKA Integrated automatic heating/air conditioning	—
5 Series	F007	JBE Junction-box electronics	
5 Series 5 Series	F007 F007	ACSM Crash Safety Module SZL Switch centre, steering column	+ -
5 Series 5 Series	F007	TRSVC allround-view camera	
5 Series 5 Series	F007	SME Accumulator-management electronics	
5 Series 5 Series	F007	SWW Lane change warning	
5 Series	F007	SVT Servotronic	
5 Series	F007	DME Digital Motor Electronics	<u> </u>
	•		

Series	Model Series	Systems	Coding
5 Series	F007	DME Digital Motor Electronics 2	•
5 Series	F007	AL active steering	•
5 Series	F007	EKPS Fuel-pump control	•
5 Series	F007	EGS transmission management	•
5 Series	F007	VTG Transfer case	•
5 Series	F007	ICM Integrated Chassis Management	•
5 Series	F007	RDC Tyre pressure control	•
5 Series	F007	ACC Active Cruise Control	•
5 Series	F007	RSE Rear Seat Entertainment	•
5 Series 5 Series	F007 F007	DSC Dynamic Stability Control HSR Rear-axle slip-angle control	
5 Series 5 Series	F007	EPS Electronic Power Steering	
5 Series	F007	DVDC DVD Changer	
5 Series	F007	TBX Touchbox	
5 Series	F007	CBX-MEDIA Combox Multimedia	•
5 Series	F007	AMPT Top Hi-Fi amplifier	•
5 Series	F007	EHC Electronic Ride-Height Control	•
5 Series	F007	VDM Vertical Dynamics Management	•
5 Series	F007	HUD Head-Up Display	•
5 Series	F007	CAS Car Access System	•
5 Series	F007	STML Headlight driver module, left	•
5 Series	F007	STMR Headlight driver module, right	•
5 Series	F007	LHML LED main light module, left	•
5 Series	F007	LHMR LED main light module, right	•
5 Series	F007	GZAL Targeted illumination, left	•
5 Series	F007	GZAR Targeted illumination, right	•
5 Series	F007	VM Video Module	•
5 Series	F007 F007	EMALI Electric-motor reel, left	—
5 Series 5 Series	F007	EMARE Electric-motor reel, right ULF-SBX-H Interface box high	
5 Series	F007	FZD Function centre, roof	
5 Series	F007	NVE Night Vision Electronics	
5 Series	F007	KAFAS Camera-based driver-assistance systems	•
5 Series	F007	GWS Gear selector switch	•
5 Series	F007	FLA High Beam Assist	•
5 Series	F007	INSTR Instrument cluster	•
5 Series	F007	CBX-ECALL Combox emergency call	•
5 Series	F007	CIC Car Information Computer	•
5 Series	F007	PDC Park Distance Control	•
5 Series	F007	CON Controller	•
5 Series	F007	FCON Rear compartment controller	•
5 Series	F007	SMFAH Seat module, driver's side, rear	•
5 Series	F007	SMBFH Seat module, passenger's side, rear	•
5 Series	F007	HKL Rear-lid lift	
5 Series	F007 F007	SMFA Seat module, driver	
5 Series 5 Series	F007	SMBF Seat module, passenger AHM Trailer module	
5 Series 5 Series	F007	FRM Footwell module	
5 Series 5 Series	F007	CID Central Information Display	
5 Series	F007	FD Rear-compartment display	
5 Series	F007	FD2 Rear-compartment display 2	
5 Series	F007	IHKA Integrated automatic heating/air conditioning	•
5 Series	F007	FKA Rear heater/air conditioning	•
5 Series	F007	EDCSVL Damper satellite, front left	•
5 Series	F007	EDCSVR Damper satellite, front right	•
5 Series	F007	EDCSHL Damper satellite, rear left	•
5 Series	F007	EDCSHR Damper satellite, rear right	•
6 Series	F006/F012/F013	JBE Junction-box electronics	•
6 Series	F006/F012/F013	ACSM Crash Safety Module	•
6 Series	F006/F012/F013	SZL Switch centre, steering column	•
6 Series	F006/F012/F013	TRSVC allround-view camera	•
6 Series	F006/F012/F013	SME Accumulator-management electronics	•
6 Series	F006/F012/F013	SWW Lane change warning	-
6 Series	F006/F012/F013	HKL Automatic luggage compartment lid actuation	

Series	Model Series	Systems	Coding
6 Series	F006/F012/F013	SVT Servotronic	•
6 Series	F006/F012/F013	GHAS Regulated differential lock	•
6 Series	F006/F012/F013	DME Digital Motor Electronics	•
6 Series	F006/F012/F013	DME Digital Motor Electronics 2	•
6 Series	F006/F012/F013	AL active steering	•
6 Series	F006/F012/F013	EKPS Fuel-pump control	•
6 Series	F006/F012/F013	EGS transmission management	•
6 Series	F006/F012/F013	VTG Transfer case	•
6 Series	F006/F012/F013	ICM Integrated Chassis Management	
6 Series 6 Series	F006/F012/F013 F006/F012/F013	RDC Tyre pressure control ACC Active Cruise Control	
6 Series	F006/F012/F013	CTM Convertible-top module	
6 Series	F006/F012/F013	RSE Rear Seat Entertainment	
6 Series	F006/F012/F013	DSC Dynamic Stability Control	
6 Series	F006/F012/F013	EMF Parking brake	•
6 Series	F006/F012/F013	HSR Rear-axle slip-angle control	
6 Series	F006/F012/F013	PMA Parking assistant	•
6 Series	F006/F012/F013	EPS Electronic Power Steering	•
6 Series	F006/F012/F013	DVDC DVD Changer	•
6 Series	F006/F012/F013	CBX-MEDIA Combox Multimedia	•
6 Series	F006/F012/F013	AMPT Top Hi-Fi amplifier	•
6 Series	F006/F012/F013	EHC Electronic Ride-Height Control	•
6 Series	F006/F012/F013	VDM Vertical Dynamics Management	•
6 Series	F006/F012/F013	HUD Head-Up Display	•
6 Series	F006/F012/F013	ASD Active Sound Design	•
6 Series	F006/F012/F013	CAS Car Access System	•
6 Series	F006/F012/F013	VM Video Module	•
6 Series	F006/F012/F013	EMALI Electric-motor reel, left	•
6 Series	F006/F012/F013	EMARE Electric-motor reel, right	•
6 Series	F006/F012/F013	SINE Siren and tilt sensor	•
6 Series	F006/F012/F013	ULF-SBX-H Interface box high	•
6 Series	F006/F012/F013	FZD Function centre, roof	•
6 Series	F006/F012/F013	NVE Night Vision Electronics	•
6 Series	F006/F012/F013	KAFAS Camera-based driver-assistance systems	•
6 Series	F006/F012/F013	GWS Gear selector switch	•
6 Series	F006/F012/F013	FLA High Beam Assist	
6 Series	F006/F012/F013 F006/F012/F013	INSTR Instrument cluster CBX-ECALL Combox emergency call	
6 Series 6 Series	F006/F012/F013	CIC Car Information Computer	
6 Series	F006/F012/F013	PDC Park Distance Control	
6 Series	F006/F012/F013	CON Controller	
6 Series	F006/F012/F013	HKL Rear-lid lift	
6 Series	F006/F012/F013	SMFA Seat module, driver	•
6 Series	F006/F012/F013	SMBF Seat module, passenger	•
6 Series	F006/F012/F013	AHM Trailer module	•
6 Series	F006/F012/F013	FRM Footwell module	. •
6 Series	F006/F012/F013	CID Central Information Display	•
6 Series	F006/F012/F013	FD Rear-compartment display	•
6 Series	F006/F012/F013	FD2 Rear-compartment display 2	•
6 Series	F006/F012/F013	VDM2 Vertical dynamics management	•
6 Series	F006/F012/F013	IHKA Integrated automatic heating/air conditioning	•
6 Series	F006/F012/F013	FKA Rear heater/air conditioning	•
6 Series	F006/F012/F013	EDCSVL Damper satellite, front left	•
6 Series	F006/F012/F013	EDCSVR Damper satellite, front right	•
6 Series	F006/F012/F013	EDCSHL Damper satellite, rear left	•
6 Series	F006/F012/F013	EDCSHR Damper satellite, rear right	•
2 Series	F022	ACSM Crash Safety Module	•
2 Series	F022	TRSVC allround-view camera	•
2 Series	F022	SME Accumulator-management electronics	•
2 Series	F022	SWW Lane change warning	
2 Series	F022	HKL Automatic luggage compartment lid actuation	
2 Series	F022 F022	GHAS Regulated differential lock	•
2 Series 2 Series	F022	DME Digital Motor Electronics EKPS Fuel-pump control	•
7 Deliez	1 V44	Invited them countrat	

Series	Model Series	Systems	Coding
2 Series	F022	EGS transmission management	•
2 Series	F022	VTG Transfer case	•
2 Series	F022	ICM Integrated Chassis Management	•
2 Series	F022	ACC Active Cruise Control	•
2 Series	F022	CTM Convertible-top module	•
2 Series	F022	DSC Dynamic Stability Control	•
2 Series	F022	PMA Parking assistant	•
2 Series	F022	EPS Electronic Power Steering	•
2 Series	F022 F022	DVDC DVD Changer CBX-MEDIA Combox Multimedia	
2 Series 2 Series	F022	AMPT Top Hi-Fi amplifier	
2 Series 2 Series	F022	ASD Active Sound Design	
2 Series	F022	CAS Car Access System	
2 Series	F022	VM Video Module	
2 Series	F022	EMALI Electric-motor reel, left	•
2 Series	F022	EMARE Electric-motor reel, right	•
2 Series	F022	SINE Siren and tilt sensor	•
2 Series	F022	FZD Function centre, roof	•
2 Series	F022	KAFAS Camera-based driver-assistance systems	•
2 Series	F022	FLA High Beam Assist	•
2 Series	F022	INSTR Instrument cluster	•
2 Series	F022	CBX-ECALL Combox emergency call	•
2 Series	F022	CIC Car Information Computer	•
2 Series	F022	CON Controller	•
2 Series	F022	SMFA Seat module, driver	•
2 Series	F022	SMBF Seat module, passenger	•
2 Series	F022	AHM Trailer module	•
2 Series	F022	FRM Footwell module	•
2 Series	F022	VDM2 Vertical dynamics management	•
2 Series	F022	IHKA Integrated automatic heating/air conditioning	•
3 Series	F030/F031/F034/F035	ACSM Crash Safety Module	•
3 Series	F030/F031/F034/F035	TRSVC allround-view camera	•
3 Series	F030/F031/F034/F035	SME Accumulator-management electronics	•
3 Series	F030/F031/F034/F035	SWW Lane change warning	-
3 Series 3 Series	F030/F031/F034/F035 F030/F031/F034/F035	HKL Automatic luggage compartment lid actuation GHAS Regulated differential lock	
3 Series	F030/F031/F034/F035	DME Digital Motor Electronics	
3 Series	F030/F031/F034/F035	EKPS Fuel-pump control	
3 Series	F030/F031/F034/F035	EGS transmission management	
3 Series	F030/F031/F034/F035	VTG Transfer case	•
3 Series	F030/F031/F034/F035	ICM Integrated Chassis Management	•
3 Series	F030/F031/F034/F035	ACC Active Cruise Control	•
3 Series	F030/F031/F034/F035	CTM Convertible-top module	•
3 Series	F030/F031/F034/F035	DSC Dynamic Stability Control	•
3 Series	F030/F031/F034/F035	PMA Parking assistant	•
3 Series	F030/F031/F034/F035	EPS Electronic Power Steering	•
3 Series	F030/F031/F034/F035	DVDC DVD Changer	•
3 Series	F030/F031/F034/F035	CBX-MEDIA Combox Multimedia	•
3 Series	F030/F031/F034/F035	AMPT Top Hi-Fi amplifier	•
3 Series	F030/F031/F034/F035	ASD Active Sound Design	•
3 Series	F030/F031/F034/F035	CAS Car Access System	•
3 Series	F030/F031/F034/F035	VM Video Module	•
3 Series	F030/F031/F034/F035	EMALI Electric-motor reel, left	•
3 Series	F030/F031/F034/F035	EMARE Electric-motor reel, right	
3 Series	F030/F031/F034/F035	SINE Siren and tilt sensor	
3 Series 3 Series	F030/F031/F034/F035 F030/F031/F034/F035	FZD Function centre, roof KAFAS Camera-based driver-assistance systems	
3 Series 3 Series	F030/F031/F034/F035	FLA High Beam Assist	
3 Series	F030/F031/F034/F035	INSTR Instrument cluster	
3 Series	F030/F031/F034/F035	CBX-ECALL Combox emergency call	
3 Series	F030/F031/F034/F035	CIC Car Information Computer	
3 Series	F030/F031/F034/F035	CON Controller	
3 Series	F030/F031/F034/F035	SMFA Seat module, driver	•
3 Series	F030/F031/F034/F035	SMBF Seat module, passenger	•
	_ 555/ 1 551/ 1 551/ 1 550		<u>. </u>

Series	Model Series	Systems	Coding
3 Series	F030/F031/F034/F035	AHM Trailer module	•
3 Series	F030/F031/F034/F035	FRM Footwell module	•
3 Series	F030/F031/F034/F035	VDM2 Vertical dynamics management	•
3 Series	F030/F031/F034/F035	IHKA Integrated automatic heating/air conditioning	•
4 Series 4 Series	F032/F033 F032/F033	ACSM Crash Safety Module TRSVC allround-view camera	
4 Series 4 Series	F032/F033	SME Accumulator-management electronics	
4 Series	F032/F033	SWW Lane change warning	•
4 Series	F032/F033	HKL Automatic luggage compartment lid actuation	•
4 Series	F032/F033	GHAS Regulated differential lock	•
4 Series	F032/F033	DME Digital Motor Electronics	•
4 Series	F032/F033	EKPS Fuel-pump control	•
4 Series	F032/F033	EGS transmission management	•
4 Series	F032/F033	VTG Transfer case	•
4 Series 4 Series	F032/F033 F032/F033	ICM Integrated Chassis Management ACC Active Cruise Control	
4 Series 4 Series	F032/F033	CTM Convertible—top module	
4 Series	F032/F033	DSC Dynamic Stability Control	
4 Series	F032/F033	PMA Parking assistant	•
4 Series	F032/F033	EPS Electronic Power Steering	
4 Series	F032/F033	DVDC DVD Changer	•
4 Series	F032/F033	CBX-MEDIA Combox Multimedia	•
4 Series	F032/F033	AMPT Top Hi-Fi amplifier	•
4 Series	F032/F033	ASD Active Sound Design	•
4 Series	F032/F033	CAS Car Access System	•
4 Series	F032/F033	VM Video Module	•
4 Series 4 Series	F032/F033 F032/F033	EMALI Electric-motor reel, left EMARE Electric-motor reel, right	
4 Series 4 Series	F032/F033	SINE Siren and tilt sensor	
4 Series	F032/F033	FZD Function centre, roof	
4 Series	F032/F033	KAFAS Camera-based driver-assistance systems	•
4 Series	F032/F033	FLA High Beam Assist	•
4 Series	F032/F033	INSTR Instrument cluster	•
4 Series	F032/F033	CBX-ECALL Combox emergency call	•
4 Series	F032/F033	CIC Car Information Computer	•
4 Series	F032/F033	CON Controller	•
4 Series	F032/F033	SMFA Seat module, driver	•
4 Series 4 Series	F032/F033 F032/F033	SMBF Seat module, passenger AHM Trailer module	
4 Series 4 Series	F032/F033	FRM Footwell module	
4 Series	F032/F033	VDM2 Vertical dynamics management	
4 Series	F032/F033	IHKA Integrated automatic heating/air conditioning	•
X Series	F015/F025	JBE Junction-box electronics	
X Series	F015/F025	ACSM Crash Safety Module	•
X Series	F015/F025	TRSVC allround-view camera	•
X Series	F015/F025	SWW Lane change warning	•
X Series	F015/F025	HKL Automatic luggage compartment lid actuation	•
X Series	F015/F025	SVT Servotronic	•
X Series	F015/F025 F015/F025	DME Digital Motor Electronics	
X Series X Series	F015/F025 F015/F025	DME Digital Motor Electronics 2 AL active steering	
X Series	F015/F025	EKPS Fuel-pump control	
X Series	F015/F025	EGS transmission management	•
X Series	F015/F025	VTG Transfer case	•
X Series	F015/F025	ICM Integrated Chassis Management	•
X Series	F015/F025	RDC Tyre pressure control	•
X Series	F015/F025	ACC Active Cruise Control	•
X Series	F015/F025	RSE Rear Seat Entertainment	• -
X Series	F015/F025	DSC Dynamic Stability Control	•
X Series	F015/F025	EMF Parking brake	
X Series	F015/F025	PMA Parking assistant EDS Floatronic Power Steering	
X Series X Series	F015/F025 F015/F025	EPS Electronic Power Steering DVDC DVD Changer	
X Series	F015/F025	CBX-MEDIA Combox Multimedia	
11 001100	1. 010/1 020	DEN WEDTH COMPON MATAIMOUTA	

Series M	Model Series	Systems	Coding
X Series F	F015/F025	AMPT Top Hi-Fi amplifier	•
	F015/F025	EHC Electronic Ride-Height Control	•
	F015/F025	VDM Vertical Dynamics Management	•
	F015/F025	HUD Head-Up Display	•
	F015/F025	ASD Active Sound Design	•
	F015/F025 F015/F025	CAS Car Access System VM Video Module	
	F015/F025	EMALI Electric-motor reel, left	
		EMARE Electric-motor reel, right	•
		FZD Function centre, roof	•
		NVE Night Vision Electronics	•
		KAFAS Camera-based driver-assistance systems	•
		GWS Gear selector switch	•
		FLA High Beam Assist	•
	F015/F025	INSTR Instrument cluster	•
	F015/F025 F015/F025	CBX-ECALL Combox emergency call CIC Car Information Computer	
		PDC Park Distance Control	
		CON Controller	•
	F015/F025	HKL Rear-lid lift	•
	F015/F025	SMFA Seat module, driver	•
	F015/F025	SMBF Seat module, passenger	•
	F015/F025	AHM Trailer module	•
	F015/F025	FRM Footwell module	•
	F015/F025	CID Central Information Display	•
	F015/F025	VDM2 Vertical dynamics management	•
	F015/F025 F015/F025	IHKA Integrated automatic heating/air conditioning	•
	F23	FKA Rear heater/air conditioning	
		CAS Car access system	
		Engine-DDE Diesel Electronics	
	723	Engine-DME Digital Motor Electronics	•
		Engine-DME Digital Motor Electronics 2	•
		EGS transmission management	•
		EKPS fuel-pump control	•
	723	GWS Gear selector switch	•
2 Series F	F23	AL active steering	•
2 Series F	723	ABS-DSC Dynamic Stability Control	•
2 Series F	723	EHC Electronic Ride-Height Control	•
2 Series F	723	EMF Parking brake	•
2 Series F	F23	EPS Electronic Power Steering	•
2 Series F	723	ICM Integrated Chassis Management	•
	F23	VDM Vertical dynamics management	•
	F23	VDM2 Vertical dynamics management	•
	F23	ACC Active Cruise Control	•
	F23	Airbag-ACSM Crash Safety Module	
	F23	AHM trailer module	
	F23	AMPH Hi-Fi amplifier	
	F23	ASD Active Sound Design	
	723	CBX-ECALL ComBox emergency call	
	723	CBX-MEDIA ComBox Multimedia	
	723	CIC Car Information Computer	•
	723	CON Controller	•
	F23	CVM Convertible top module	•
2 Series F	F23	DSP Digital Sound Processor	•
2 Series F	723	DVDC DVD changer	•
2 Series F	F23	EMALI Electric-motor reel, left	•
	723	EMARE Electric-motor reel, right	•
	723	EME Electric machine electronics	•
		l	-

Series	Model Series	Systems	Coding
2 Series	F23	EME2 Electrical machine electronics	•
2 Series	F23	FLA High Beam Assist	•
2 Series	F23	FRM Footwell module	•
2 Series	F23	FZD Function centre, roof	•
2 Series	F23	GHAS Regulated differential lock	•
2 Series	F23	HKL Automatic luggage compartment lid actuation	•
2 Series	F23	IHKA Integrated automatic heating/air conditioning	•
2 Series	F23	INSTR Instrument cluster	•
2 Series	F23	KAFAS Camera-based driver-assistance systems	•
2 Series	F23	PDC Park Distance Control	•
2 Series	F23	PMA Parking assistant	•
2 Series	F23	RAD Radio	•
2 Series	F23	RDC tyre pressure control	•
2 Series	F23	SEC Supplementary control unit	•
2 Series	F23	SEC2 Supplementary control unit 2	•
2 Series	F23	SINE Siren and tilt sensor	•
2 Series	F23	SMBF Seat module, passenger	
2 Series 2 Series	F23	SMBFH seat module, passenger's side, rear	
2 Series 2 Series	F23	SME Accumulator-management electronics	
2 Series 2 Series	F23	SMFA Seat module, driver	
2 Series	F23	SMFAH Seat module, driver's side, rear	
2 Series 2 Series	F23	SVT Servotronic	
2 Series 2 Series	F23		
2 Series 2 Series	F23	SWW Lane change warning	
2 Series 2 Series	F23	Airbag-SZL Switch centre, steering column TRSVC allround-view camera	
2 Series 2 Series	F23	TBX Touchbox	
2 Series	F23	VM Video module	
2 Series	F23 F23	VTG Transfer case	
2 Series		ZGM Central Gateway Control Module	
2 Series	F45	CAS Car access system	
2 Series	F45	Engine-DDE Diesel Electronics	•
2 Series	F45	Engine-DME Digital Motor Electronics	•
2 Series	F45	Engine-DME Digital Motor Electronics 2	•
2 Series	F45	EGS transmission management	•
2 Series	F45	EKPS fuel-pump control	•
2 Series	F45	GWS Gear selector switch	•
2 Series	F45	AL active steering	-
2 Series	F45	ABS-DSC Dynamic Stability Control	
2 Series	F45	EHC Electronic Ride-Height Control	•
2 Series	F45	EMF Parking brake	-
2 Series	F45	EPS Electronic Power Steering	•
2 Series	F45	ICM Integrated Chassis Management	-
2 Series	F45	VDM Vertical dynamics management	•
2 Series	F45	VDM2 Vertical dynamics management	•
2 Series	F45	ACC Active Cruise Control	•
2 Series	F45	Airbag-ACSM Crash Safety Module	•
2 Series	F45	AHM trailer module	•
2 Series	F45	AMPH Hi-Fi amplifier	•
2 Series	F45	ASD Active Sound Design	•
2 Series	F45	CBX-ECALL ComBox emergency call	•
2 Series	F45	CBX-MEDIA ComBox Multimedia	•
2 Series	F45	CIC Car Information Computer	•
2 Series	F45	CON Controller	•
2 Series	F45	CVM Convertible top module	•

Series	Model Series	Systems	Coding
2 Series	F45	DSP Digital Sound Processor	•
2 Series	F45	DVDC DVD changer	•
2 Series	F45	EMALI Electric-motor reel, left	•
2 Series	F45	EMARE Electric-motor reel, right	•
2 Series	F45	EME Electric machine electronics	•
2 Series	F45	EME2 Electrical machine electronics	•
2 Series	F45	FLA High Beam Assist	•
2 Series	F45	FRM Footwell module	•
2 Series	F45	FZD Function centre, roof	•
2 Series	F45	GHAS Regulated differential lock	
2 Series	F45	HKL Automatic luggage compartment lid actuation	
2 Series	F45	IHKA Integrated automatic heating/air conditioning	•
2 Series	F45	INSTR Instrument cluster	
2 Series	F45	KAFAS Camera-based driver-assistance systems	
2 Series	F45	PDC Park Distance Control	
2 Series 2 Series	F45	PMA Parking assistant	
2 Series 2 Series	F45	RAD Radio	
2 Series 2 Series	F45	RDC tyre pressure control	
2 Series 2 Series	F45	SEC Supplementary control unit	
2 Series 2 Series	F45	SEC Supplementary control unit SEC2 Supplementary control unit 2	
2 Series	F45	SINE Siren and tilt sensor	
2 Series	F45	SMBF Seat module, passenger	
2 Series	F45	SMBFH seat module, passenger's side, rear	•
2 Series	F45	SME Accumulator-management electronics	•
2 Series	F45	SMFA Seat module, driver	•
2 Series	F45	SMFAH Seat module, driver's side, rear	•
2 Series	F45	SVT Servotronic	•
2 Series	F45	SWW Lane change warning	•
2 Series	F45	Airbag-SZL Switch centre, steering column	•
2 Series	F45	TRSVC allround-view camera	•
2 Series	F45	TBX Touchbox	•
2 Series	F45	VM Video module	•
2 Series	F45	VTG Transfer case	•
2 Series	F45	ZGM Central Gateway Control Module	•
2 Series	F46	CAS Car access system	•
2 Series	F46	Engine-DDE Diesel Electronics	•
2 Series	F46	Engine-DME Digital Motor Electronics	•
2 Series	F46	Engine-DME Digital Motor Electronics 2	•
2 Series	F46	EGS transmission management	•
2 Series	F46	EKPS fuel-pump control	•
2 Series	F46	GWS Gear selector switch	•
2 Series	F46	AL active steering	•
2 Series	F46	ABS-DSC Dynamic Stability Control	•
2 Series	F46	EHC Electronic Ride-Height Control	•
2 Series	F46	EMF Parking brake	•
2 Series	F46	EPS Electronic Power Steering	•
2 Series	F46	ICM Integrated Chassis Management	•
2 Series	F46	VDM Vertical dynamics management	•
2 Series	F46	VDM2 Vertical dynamics management	•
2 Series	F46	ACC Active Cruise Control	•
2 Series	F46	Airbag-ACSM Crash Safety Module	•
2 Series	F46	AHM trailer module	•
2 Series	F46	AMPH Hi-Fi amplifier	•
2 Series	F46	ASD Active Sound Design	

Series	Model Series	Systems	Coding
2 Series	F46	CBX-ECALL ComBox emergency call	•
2 Series	F46	CBX-MEDIA ComBox Multimedia	•
2 Series	F46	CIC Car Information Computer	•
2 Series	F46	CON Controller	•
2 Series	F46	CVM Convertible top module	•
2 Series	F46	DSP Digital Sound Processor	•
2 Series	F46	DVDC DVD changer	•
2 Series	F46	EMALI Electric-motor reel, left	•
2 Series	F46	EMARE Electric-motor reel, right	•
2 Series	F46	EME Electric machine electronics	
2 Series	F46	EME2 Electrical machine electronics	
2 Series	F46	FLA High Beam Assist	
2 Series	F46	FRM Footwell module	
2 Series	F46	FZD Function centre, roof	
2 Series 2 Series	F46	GHAS Regulated differential lock	
	F46		
2 Series 2 Series	F46	HKL Automatic luggage compartment lid actuation	
	F46	IHKA Integrated automatic heating/air conditioning INSTR Instrument cluster	
2 Series			
2 Series	F46	KAFAS Camera-based driver-assistance systems	- •
2 Series	F46	PDC Park Distance Control	
2 Series	F46	PMA Parking assistant	•
2 Series	F46	RAD Radio	•
2 Series	F46	RDC tyre pressure control	•
2 Series	F46	SEC Supplementary control unit	•
2 Series	F46	SEC2 Supplementary control unit 2	•
2 Series	F46	SINE Siren and tilt sensor	•
2 Series	F46	SMBF Seat module, passenger	•
2 Series	F46	SMBFH seat module, passenger's side, rear	•
2 Series	F46	SME Accumulator-management electronics	•
2 Series	F46	SMFA Seat module, driver	•
2 Series	F46	SMFAH Seat module, driver's side, rear	•
2 Series	F46	SVT Servotronic	•
2 Series	F46	SWW Lane change warning	•
2 Series	F46	Airbag-SZL Switch centre, steering column	•
2 Series	F46	TRSVC allround-view camera	•
2 Series	F46	TBX Touchbox	•
2 Series	F46	VM Video module	•
2 Series	F46	VTG Transfer case	•
2 Series	F46	ZGM Central Gateway Control Module	•
2 Series	F87	CAS Car access system	
2 Series	F87	Engine-DDE Diesel Electronics	A
2 Series	F87	Engine-DME Digital Motor Electronics	A
2 Series	F87	Engine-DME Digital Motor Electronics 2	A
2 Series	F87	EGS transmission management	A
2 Series	F87	EKPS fuel-pump control	A
2 Series	F87	GWS Gear selector switch	A
2 Series	F87	AL active steering	
2 Series	F87	ABS-DSC Dynamic Stability Control	
2 Series	F87	EHC Electronic Ride-Height Control	
2 Series	F87	EMF Parking brake	
2 Series	F87	EPS Electronic Power Steering	-
2 Series	F87	ICM Integrated Chassis Management	
2 Series 2 Series	F87	VDM Vertical dynamics management	
2 Series 2 Series	F87	VDM2 Vertical dynamics management VDM2 Vertical dynamics management	
7 Deries	1.01	INDIA TELLICAL AMBURICS MANAGEMENT	

Series	Model Series	Systems	Coding
2 Series	F87	ACC Active Cruise Control	A
2 Series	F87	Airbag-ACSM Crash Safety Module	A
2 Series	F87	AHM trailer module	A
2 Series	F87	AMPH Hi-Fi amplifier	A
2 Series	F87	ASD Active Sound Design	A
2 Series	F87	CBX-ECALL ComBox emergency call	A
2 Series	F87	CBX-MEDIA ComBox Multimedia	A
2 Series	F87	CIC Car Information Computer	A
2 Series	F87	CON Controller	A
2 Series	F87	CVM Convertible top module	A
2 Series	F87	DSP Digital Sound Processor	A
2 Series	F87	DVDC DVD changer	A
2 Series	F87	EMALI Electric-motor reel, left	A
2 Series	F87	EMARE Electric-motor reel, right	A
2 Series	F87	EME Electric machine electronics	A
2 Series	F87	EME2 Electrical machine electronics	A
2 Series	F87	FLA High Beam Assist	A
2 Series	F87	FRM Footwell module	A
2 Series	F87	FZD Function centre, roof	A
2 Series	F87	GHAS Regulated differential lock	_
2 Series	F87	HKL Automatic luggage compartment lid actuation	
2 Series	F87	IHKA Integrated automatic heating/air conditioning	
2 Series	F87	INSTR Instrument cluster	-
2 Series	F87	KAFAS Camera-based driver-assistance systems	
2 Series	F87	PDC Park Distance Control	
2 Series	F87	PMA Parking assistant	
2 Series 2 Series	F87	RAD Radio	
2 Series 2 Series	F87	RDC tyre pressure control	
2 Series 2 Series	F87	SEC Supplementary control unit	_
2 Series 2 Series	F87	SEC2 Supplementary control unit 2	A
2 Series 2 Series	F87	SINE Siren and tilt sensor	
	F87		
2 Series		SMBF Seat module, passenger	
2 Series	F87	SMBFH seat module, passenger's side, rear	
2 Series	F87	SME Accumulator-management electronics	
2 Series	F87	SMFA Seat module, driver	
2 Series	F87	SMFAH Seat module, driver's side, rear	
2 Series	F87	SVT Servotronic	
2 Series	F87	SWW Lane change warning	
2 Series	F87	Airbag-SZL Switch centre, steering column	
2 Series	F87	TRSVC allround-view camera	
2 Series	F87	TBX Touchbox	
2 Series	F87	VM Video module	
2 Series	F87	VTG Transfer case	
2 Series	F87	ZGM Central Gateway Control Module	
3 Series	F80	Engine-DDE Diesel Electronics	
3 Series	F80	Engine-DME Digital Motor Electronics	
3 Series	F80	EGS transmission management	
3 Series	F80	EKPS fuel-pump control	
3 Series	F80	GWS Gear selector switch	•
3 Series	F80	ABS-DSC Dynamic Stability Control	•
3 Series	F80	EPS Electronic Power Steering	•
3 Series	F80	VDM Vertical dynamics management	•
3 Series	F80	VDM2 Vertical dynamics management	•
3 Series	F80	ACC Active Cruise Control	•

Series	Model Series	Systems	Coding
3 Series	F80	Airbag-ACSM Crash Safety Module	•
3 Series	F80	AHM trailer module	•
3 Series	F80	AMPH Hi-Fi amplifier	•
3 Series	F80	CBX-ECALL ComBox emergency call	•
3 Series	F80	CBX-MEDIA ComBox Multimedia	•
3 Series	F80	CID Central Information Display	•
3 Series	F80	CON Controller	•
3 Series	F80	DSP Digital Sound Processor	•
3 Series	F80	DVDC DVD changer	•
3 Series	F80	EMALI Electric-motor reel, left	•
3 Series	F80	EMARE Electric-motor reel, right	•
3 Series	F80	EME Electric machine electronics	•
3 Series	F80	EME2 Electrical machine electronics	
3 Series	F80	FCON Rear compartment controller	
3 Series	F80	FEM Front Electronic Module	
3 Series	F80	FLA High Beam Assist	
3 Series	F80	FZD Function centre, roof	
3 Series	F80	ICM Integrated Chassis Management	
3 Series	F80	IHKA Integrated automatic heating/air conditioning	
3 Series 3 Series	F80	INSTR Instrument cluster	
3 Series	F80	KAFAS Camera-based driver-assistance systems	
3 Series	F80	PDC Park Distance Control	-
3 Series	F80	PMA Parking assistant	•
3 Series	F80	RAD Radio	•
3 Series	F80	RDC tyre pressure control	•
3 Series	F80	REM Rear Electronic Module	•
3 Series	F80	SMBF Seat module, passenger	•
3 Series	F80	SMBFH seat module, passenger's side, rear	•
3 Series	F80	SME Accumulator-management electronics	•
3 Series	F80	SMFA Seat module, driver	•
3 Series	F80	SMFAH Seat module, driver's side, rear	•
3 Series	F80	SWW Lane change warning	•
3 Series	F80	SCR Selective Catalytic Reduction	•
3 Series	F80	TRSVC allround-view camera	•
3 Series	F80	TBX Touchbox	•
3 Series	F80	VM Video module	•
3 Series	F80	ZGM Central Gateway Control Module	•
4 Series	F36	CAS Car access system	•
4 Series	F36	Engine-DDE Diesel Electronics	•
4 Series	F36	Engine-DME Digital Motor Electronics	•
4 Series	F36	Engine-DME Digital Motor Electronics 2	•
4 Series	F36	EGS transmission management	•
4 Series	F36	EKPS fuel-pump control	•
4 Series	F36	GWS Gear selector switch	•
4 Series	F36	AL active steering	•
4 Series	F36	ABS-DSC Dynamic Stability Control	•
4 Series	F36	EHC Electronic Ride-Height Control	•
4 Series	F36	EMF Parking brake	•
4 Series	F36	EPS Electronic Power Steering	•
4 Series	F36	ICM Integrated Chassis Management	•
4 Series	F36	VDM Vertical dynamics management	•
4 Series	F36	VDM2 Vertical dynamics management	•
4 Series	F36	CTM Convertible-top module	•
4 Series	F36	ACC Active Cruise Control	

Series	Model Series	Systems	Coding
4 Series	F36	Airbag-ACSM Crash Safety Module	•
4 Series	F36	AHM trailer module	•
4 Series	F36	AMPH Hi-Fi amplifier	•
4 Series	F36	ASD Active Sound Design	•
4 Series	F36	CBX-ECALL ComBox emergency call	•
4 Series	F36	CBX-MEDIA ComBox Multimedia	•
4 Series	F36	CIC Car Information Computer	•
4 Series	F36	CON Controller	•
4 Series	F36	CVM Convertible top module	•
4 Series	F36	DSP Digital Sound Processor	•
4 Series	F36	DVDC DVD changer	•
4 Series	F36	EMALI Electric-motor reel, left	•
4 Series	F36	EMARE Electric-motor reel, right	•
4 Series	F36	EME Electric machine electronics	•
4 Series	F36	EME2 Electrical machine electronics	•
4 Series	F36	FLA High Beam Assist	•
4 Series	F36	FRM Footwell module	
4 Series	F36	FZD Function centre, roof	
4 Series	F36	GHAS Regulated differential lock	
4 Series	F36	HKL Automatic luggage compartment lid actuation	
4 Series	F36	IHKA Integrated automatic heating/air conditioning	
4 Series	F36	INSTR Instrument cluster	
4 Series	F36	KAFAS Camera-based driver-assistance systems	
4 Series	F36	PDC Park Distance Control	
4 Series	F36	PMA Parking assistant	
4 Series	F36	RAD Radio	
4 Series	F36	RDC tyre pressure control	
4 Series	F36	SEC Supplementary control unit	
4 Series	F36	SEC2 Supplementary control unit 2	
4 Series 4 Series	F36	SINE Siren and tilt sensor	
4 Series 4 Series	F36	SMBF Seat module, passenger	
4 Series 4 Series	F36	SMBFH seat module, passenger's side, rear	
4 Series 4 Series	F36	SME Accumulator-management electronics	
4 Series 4 Series	F36	SMFA Seat module, driver	$\overline{}$
4 Series 4 Series	F36	SMFAH Seat module, driver's side, rear	
4 Series 4 Series	F36	SVT Servotronic	
4 Series 4 Series	F36	SWW Lane change warning	$\overline{}$
4 Series 4 Series	F36		
4 Series 4 Series	F36	Airbag-SZL Switch centre, steering column TRSVC allround-view camera	
4 Series 4 Series	F36	TBX Touchbox	
4 Series 4 Series	F36	VM Video module	
4 Series 4 Series	F36	VTG Transfer case	
4 Series 4 Series	F36	ZGM Central Gateway Control Module	
4 Series 4 Series	F82/F83	CAS Car access system	
4 Series 4 Series	F82/F83		
		Engine-DDE Diesel Electronics	
4 Series	F82/F83	Engine-DME Digital Motor Electronics	
4 Series	F82/F83	Engine-DME Digital Motor Electronics 2	
4 Series	F82/F83	EGS transmission management	
4 Series	F82/F83	EKPS fuel-pump control	
4 Series	F82/F83	GWS Gear selector switch	
4 Series	F82/F83	AL active steering	
4 Series	F82/F83	ABS-DSC Dynamic Stability Control	
4 Series	F82/F83	EHC Electronic Ride-Height Control	
4 Series	F82/F83	EMF Parking brake	

Series	Model Series	Systems	Coding
4 Series	F82/F83	EPS Electronic Power Steering	•
4 Series	F82/F83	ICM Integrated Chassis Management	•
4 Series	F82/F83	VDM Vertical dynamics management	•
4 Series	F82/F83	VDM2 Vertical dynamics management	•
4 Series	F82/F83	CTM Convertible-top module	•
4 Series	F82/F83	ACC Active Cruise Control	•
4 Series	F82/F83	Airbag-ACSM Crash Safety Module	•
4 Series	F82/F83	AHM trailer module	•
4 Series	F82/F83	AMPH Hi-Fi amplifier	•
4 Series	F82/F83	ASD Active Sound Design	•
4 Series	F82/F83	CBX-ECALL ComBox emergency call	•
4 Series	F82/F83	CBX-MEDIA ComBox Multimedia	•
4 Series	F82/F83	CIC Car Information Computer	•
4 Series	F82/F83	CON Controller	•
4 Series	F82/F83	CVM Convertible top module	•
4 Series	F82/F83	DSP Digital Sound Processor	•
4 Series	F82/F83	DVDC DVD changer	•
4 Series	F82/F83	EMALI Electric-motor reel, left	•
4 Series	F82/F83	EMARE Electric-motor reel, right	•
4 Series	F82/F83	EME Electric machine electronics	•
4 Series	F82/F83	EME2 Electrical machine electronics	•
4 Series	F82/F83	FLA High Beam Assist	•
4 Series	F82/F83	FRM Footwell module	•
4 Series	F82/F83	FZD Function centre, roof	•
4 Series	F82/F83	GHAS Regulated differential lock	•
4 Series	F82/F83	HKL Automatic luggage compartment lid actuation	•
4 Series	F82/F83	IHKA Integrated automatic heating/air conditioning	•
4 Series	F82/F83	INSTR Instrument cluster	•
4 Series	F82/F83	KAFAS Camera-based driver-assistance systems	•
4 Series	F82/F83	PDC Park Distance Control	•
4 Series	F82/F83	PMA Parking assistant	•
4 Series	F82/F83	RAD Radio	•
4 Series	F82/F83	RDC tyre pressure control	•
4 Series	F82/F83	SEC Supplementary control unit	•
4 Series	F82/F83	SEC2 Supplementary control unit 2	•
4 Series	F82/F83	SINE Siren and tilt sensor	•
4 Series	F82/F83	SMBF Seat module, passenger	•
4 Series	F82/F83	SMBFH seat module, passenger's side, rear	•
4 Series	F82/F83	SME Accumulator-management electronics	•
4 Series	F82/F83	SMFA Seat module, driver	•
4 Series	F82/F83	SMFAH Seat module, driver's side, rear	•
4 Series	F82/F83	SVT Servotronic	•
4 Series	F82/F83	SWW Lane change warning	•
4 Series	F82/F83	Airbag-SZL Switch centre, steering column	•
4 Series	F82/F83	TRSVC allround-view camera	•
4 Series	F82/F83	TBX Touchbox	•
4 Series	F82/F83	VM Video module	
4 Series	F82/F83	VTG Transfer case	•
4 Series	F82/F83	ZGM Central Gateway Control Module	•
X Series	X1_F48	CAS Car access system	
X Series	X1_F48	Engine-DME Digital Motor Electronics	
X Series	X1_F48	EGS transmission management	
X Series	X1_F48	AL active steering	
X Series	X1_F48	ABS-DSC Dynamic Stability Control	

Series	Model Series	Systems	Coding
X Series	X1_F48	Airbag-ACSM Crash Safety Module	
X Series	X1 F48	AHM trailer module	
X Series	X1 F48	AMPH Hi-Fi amplifier	
X Series	X1 F48	AMPT Top Hi-Fi amplifier	_
X Series	X1 F48	ASD Active Sound Design	A
X Series	X1 F48	CBX-ECALL ComBox emergency call	A
X Series	X1_F48	CIC Car Information Computer	A
X Series	X1_F48	CON Controller	A
X Series	X1 F48	DSP Digital Sound Processor	A
X Series	X1_F48	DVDC DVD changer	A
X Series	X1 F48	FZD Function centre, roof	A
X Series	X1_F48	HKL Automatic luggage compartment lid actuation	A
X Series	X1_F48	IHKA Integrated automatic heating/air conditioning	A
X Series	X1 F48	INSTR Instrument cluster	A
X Series	X1_F48	KAFAS Camera-based driver-assistance systems	A
X Series	X1_F48	PMA Parking assistant	A
X Series	X1_F48	SMFA Seat module, driver	A
X Series	X1_F48	Airbag-SZL Switch centre, steering column	A
X Series	X1_F48	TRSVC allround-view camera	A
X Series	X1_F48	TBX Touchbox	A
X Series	X1_F48	ZGM Central Gateway Control Module	A
X Series	X1_F49	CAS Car access system	A
X Series	X1_F49	Engine-DME Digital Motor Electronics	A
X Series	X1_F49	EGS transmission management	A
X Series	X1_F49	AL active steering	A
X Series	X1_F49	ABS-DSC Dynamic Stability Control	A
X Series	X1_F49	Airbag-ACSM Crash Safety Module	A
X Series	X1_F49	AHM trailer module	A
X Series	X1_F49	AMPH Hi-Fi amplifier	A
X Series	X1_F49	AMPT Top Hi-Fi amplifier	A
X Series	X1_F49	ASD Active Sound Design	A
X Series	X1_F49	CBX-ECALL ComBox emergency call	A
X Series	X1_F49	CIC Car Information Computer	A
X Series	X1_F49	CON Controller	A
X Series	X1_F49	DSP Digital Sound Processor	A
X Series	X1_F49	DVDC DVD changer	A
X Series	X1_F49	FZD Function centre, roof	A
X Series	X1_F49	HKL Automatic luggage compartment lid actuation	A
X Series	X1_F49	IHKA Integrated automatic heating/air conditioning	A
X Series	X1_F49	INSTR Instrument cluster	A
X Series	X1_F49	KAFAS Camera-based driver-assistance systems	A
X Series	X1_F49	PMA Parking assistant	A
X Series	X1_F49	SMFA Seat module, driver	A
X Series	X1_F49	Airbag-SZL Switch centre, steering column	A
X Series	X1_F49	TRSVC allround-view camera	A
X Series	X1_F49	TBX Touchbox	A
X Series	X1_F49	ZGM Central Gateway Control Module	A
X Series	X4_F26	CAS Car access system	•
X Series	X4_F26	Engine-DDE Diesel Electronics	•
X Series	X4_F26	Engine-DME Digital Motor Electronics	•
X Series	X4_F26	EGS transmission management	•
X Series	X4_F26	EKPS fuel-pump control	•
X Series	X4_F26	GWS Gear selector switch	•
X Series	X4 F26	ABS-DSC Dynamic Stability Control	

Series	Model Series	Systems	Coding
X Series	X4 F26	EMF Parking brake	•
X Series	X4 F26	EPS Electronic Power Steering	•
X Series	X4 F26	ICM Integrated Chassis Management	•
X Series	X4 F26	VDM Vertical dynamics management	•
X Series	X4 F26	VDM2 Vertical dynamics management	•
X Series	X4 F26	ACC Active Cruise Control	•
X Series	X4 F26	Airbag-ACSM Crash Safety Module	•
X Series	X4 F26	AHM trailer module	•
X Series	X4 F26	AMPT Top Hi-Fi amplifier	•
X Series	X4 F26	CBX-ECALL ComBox emergency call	•
X Series	X4 F26	CBX-MEDIA ComBox Multimedia	•
X Series	X4 F26	CID Central Information Display	•
X Series	X4 F26	CON Controller	•
X Series	X4 F26	DSP Digital Sound Processor	•
X Series	X4 F26	DVDC DVD changer	•
X Series	X4 F26	FLA High Beam Assist	•
X Series	X4 F26	FRM Footwell module	•
X Series	X4_F26	FZD Function centre, roof	•
X Series	X4_F26	GHAS Regulated differential lock	•
X Series	X4 F26	HKL Rear-lid lift	•
X Series	X4 F26	HKL Automatic luggage compartment lid actuation	•
X Series	X4 F26	HUD Head-Up Display	•
X Series	X4 F26	IHKA Integrated automatic heating/air conditioning	•
X Series	X4 F26	JBE Junction-box electronics	•
X Series	X4 F26	KAFAS Camera-based driver-assistance systems	•
X Series	X4 F26	INSTR Instrument cluster	•
X Series	X4 F26	PDC Park Distance Control	•
X Series	X4 F26	RAD Radio	•
X Series	X4_F26	RDC tyre pressure control	•
X Series	X4 F26	SMBF Seat module, passenger	•
X Series	X4 F26	SMBFH seat module, passenger's side, rear	•
X Series	X4_F26	SMFA Seat module, driver	•
X Series	X4_F26	SMFAH Seat module, driver's side, rear	•
X Series	X4_F26	SWW Lane change warning	•
X Series	X4_F26	Airbag-SZL Switch centre, steering column	•
X Series	X4_F26	TRSVC allround-view camera	•
X Series	X4_F26	TBX Touchbox	•
X Series	X4_F26	VM Video module	•
X Series	X4_F26	VTG Transfer case	•
X Series	X4_F26	ZGM Central Gateway Control Module	•
X Series	X5_F85	CAS Car access system	•
X Series	X5_F85	Engine-DDE Diesel Electronics	•
X Series	X5_F85	Engine-DME Digital Motor Electronics	•
X Series	X5_F85	Engine-DME Digital Motor Electronics 2	•
X Series	X5_F85	EGS transmission management	•
X Series	X5_F85	EKPS fuel-pump control	•
X Series	X5_F85	GWS Gear selector switch	•
X Series	X5_F85	QMVH Lateral-moment distribution, rear axle	•
X Series	X5_F85	AL active steering	•
X Series	X5_F85	ABS-DSC Dynamic Stability Control	•
X Series	X5_F85	EHC Electronic Ride-Height Control	•
X Series	X5_F85	EMF Parking brake	•
X Series	X5_F85	EPS Electronic Power Steering	•
X Series	X5_F85	ICM Integrated Chassis Management	•

Series	Model Series	Systems	Coding
X Series	X5 F85	VDM Vertical dynamics management	•
X Series	X5 F85	VDM2 Vertical dynamics management	•
X Series	X5 F85	ACC Active Cruise Control	•
X Series	X5 F85	Airbag-ACSM Crash Safety Module	•
X Series	X5 F85	AHM trailer module	•
X Series	X5_F85	AMPH Hi-Fi amplifier	•
X Series	X5_F85	ASD Active Sound Design	•
X Series	X5_F85	CBX-ECALL ComBox emergency call	•
X Series	X5_F85	CBX-MEDIA ComBox Multimedia	•
X Series	X5_F85	CIC Car Information Computer	•
X Series	X5_F85	CID Central Information Display	•
X Series	X5_F85	CON Controller	•
X Series	X5_F85	DSP Digital Sound Processor	•
X Series	X5_F85	DVDC DVD changer	•
X Series	X5_F85	EMALI Electric-motor reel, left	•
X Series	X5_F85	EMARE Electric-motor reel, right	•
X Series	X5_F85	EME Electric machine electronics	•
X Series	X5_F85	EME2 Electrical machine electronics	•
X Series	X5_F85	FKA Rear heater/air conditioning	•
X Series	X5_F85	FLA High Beam Assist	•
X Series	X5_F85	FRM Footwell module	•
X Series	X5_F85	FZD Function centre, roof	•
X Series	X5_F85	HKL Automatic luggage compartment lid actuation	•
X Series	X5_F85	HKL Rear-lid lift	•
X Series	X5_F85	HUD Head-Up Display	•
X Series	X5_F85	IHKA Integrated automatic heating/air conditioning	•
X Series	X5_F85	INSTR Instrument cluster	•
X Series	X5_F85	JBE Junction-box electronics	•
X Series	X5_F85	KAFAS Camera-based driver-assistance systems	•
X Series	X5_F85	NVE Night Vision Electronics	•
X Series	X5_F85	PDC Park Distance Control	•
X Series	X5_F85	PMA Parking assistant	•
X Series	X5_F85	PCU Power Control Unit	•
X Series	X5_F85	RDC tyre pressure control	•
X Series	X5_F85	RSE Rear Seat Entertainment	•
X Series	X5_F85	SEC Supplementary control unit	•
X Series	X5_F85	SEC2 Supplementary control unit 2	•
X Series	X5_F85	SMBF Seat module, passenger	•
X Series	X5_F85	SME Accumulator-management electronics	•
X Series	X5_F85	SMFA Seat module, driver	•
X Series	X5_F85	SVT Servotronic	•
X Series	X5_F85	SWW Lane change warning	•
X Series	X5_F85	STML Headlight driver module, left	•
X Series	X5_F85	STMR Headlight driver module, right	•
X Series	X5_F85	TRSVC allround-view camera	•
X Series	X5_F85	TBX Touchbox	•
X Series	X5_F85	VM Video module	•
X Series	X5_F85	VTG Transfer case	•
X Series	X5_F85	ZGM Central Gateway Control Module	•
X Series	X5_F85	REME Range extender electrical machine electronics	•
X Series	X5_F85	LIM Chanrge Interface Module	•
X Series	X5_F85	KLE Convenience Charge Electronics	•
X Series	X5_F85	FLEL Frontal Light Electronics left	•
X Series	X6 F16	CAS Car access system	•

Series	Model Series	Systems	Coding
X Series	X6 F16	Engine-DDE Diesel Electronics	•
X Series	X6 F16	Engine-DME Digital Motor Electronics	•
X Series	X6_F16	Engine-DME Digital Motor Electronics 2	•
X Series	X6 F16	EGS transmission management	•
X Series	X6 F16	EKPS fuel-pump control	•
X Series	X6 F16	GWS Gear selector switch	•
X Series	X6 F16	QMVH Lateral-moment distribution, rear axle	•
X Series	X6_F16	AL active steering	•
X Series	X6_F16	ABS-DSC Dynamic Stability Control	•
X Series	X6_F16	EHC Electronic Ride-Height Control	•
X Series	X6 F16	EMF Parking brake	•
X Series	X6_F16	EPS Electronic Power Steering	•
X Series	X6 F16	ICM Integrated Chassis Management	•
X Series	X6 F16	VDM Vertical dynamics management	•
X Series	X6 F16	VDM2 Vertical dynamics management	•
X Series	X6 F16	ACC Active Cruise Control	•
X Series	X6_F16	Airbag-ACSM Crash Safety Module	•
X Series	X6_F16	AHM trailer module	•
X Series	X6 F16	AMPH Hi-Fi amplifier	•
X Series	X6 F16	ASD Active Sound Design	•
X Series	X6 F16	CBX-ECALL ComBox emergency call	•
X Series	X6 F16	CBX-MEDIA ComBox Multimedia	•
X Series	X6 F16	CIC Car Information Computer	•
X Series	X6 F16	CID Central Information Display	•
X Series	X6 F16	CON Controller	•
X Series	X6_F16	DSP Digital Sound Processor	•
X Series	X6 F16	DVDC DVD changer	•
X Series	X6 F16	EMALI Electric-motor reel, left	•
X Series	X6_F16	EMARE Electric-motor reel, right	•
X Series	X6 F16	EME Electric machine electronics	•
X Series	X6 F16	EME2 Electrical machine electronics	•
X Series	X6 F16	FKA Rear heater/air conditioning	•
X Series	X6 F16	FLA High Beam Assist	•
X Series	X6 F16	FRM Footwell module	•
X Series	X6 F16	FZD Function centre, roof	•
X Series	X6 F16	HKL Automatic luggage compartment lid actuation	•
X Series	X6 F16	HKL Rear-lid lift	•
X Series	X6 F16	HUD Head-Up Display	•
X Series	X6 F16	IHKA Integrated automatic heating/air conditioning	•
X Series	X6 F16	INSTR Instrument cluster	•
X Series	X6 F16	JBE Junction-box electronics	•
X Series	X6_F16	KAFAS Camera-based driver-assistance systems	•
X Series	X6_F16	NVE Night Vision Electronics	•
X Series	X6_F16	PDC Park Distance Control	•
X Series	X6 F16	PMA Parking assistant	•
X Series	X6 F16	PCU Power Control Unit	•
X Series	X6 F16	RDC tyre pressure control	•
X Series	X6 F16	RSE Rear Seat Entertainment	•
X Series	X6 F16	SEC Supplementary control unit	•
X Series	X6_F16	SEC2 Supplementary control unit 2	•
X Series	X6 F16	SMBF Seat module, passenger	•
X Series	X6_F16	SME Accumulator-management electronics	
X Series	X6 F16	SMFA Seat module, driver	
X Series	X6_F16	SVT Servotronic	
v peries	VO_1.10	DAT DETACITORITE	

Series	Model Series	Systems	Coding
X Series	X6 F16	SWW Lane change warning	•
X Series	X6 F16	STML Headlight driver module, left	•
X Series	X6 F16	STMR Headlight driver module, right	•
X Series	X6 F16	TRSVC allround-view camera	•
X Series	X6 F16	TBX Touchbox	•
X Series	X6 F16	VM Video module	•
X Series	X6 F16	VTG Transfer case	•
X Series	X6_F16	ZGM Central Gateway Control Module	•
X Series	X6 F16	REME Range extender electrical machine electronics	•
X Series	X6_F16	LIM Chanrge Interface Module	•
X Series	X6 F16	KLE Convenience Charge Electronics	•
X Series	X6_F16	FLEL Frontal Light Electronics left	•
X Series	X6 F86	CAS Car access system	•
X Series	X6 F86	Engine-DDE Diesel Electronics	•
X Series	X6 F86	Engine-DME Digital Motor Electronics	•
X Series	X6 F86	Engine-DME Digital Motor Electronics 2	•
X Series	X6 F86	EGS transmission management	•
X Series	X6 F86	EKPS fuel-pump control	•
X Series	X6 F86	GWS Gear selector switch	•
X Series	X6 F86	QMVH Lateral-moment distribution, rear axle	•
X Series	X6 F86	AL active steering	
X Series	X6 F86	ABS-DSC Dynamic Stability Control	
X Series	X6 F86	EHC Electronic Ride-Height Control	
X Series	X6 F86	EMF Parking brake	
X Series X Series	_		
X Series X Series	X6_F86	EPS Electronic Power Steering	
	X6_F86	ICM Integrated Chassis Management	
X Series	X6_F86	VDM Vertical dynamics management	•
X Series	X6_F86	VDM2 Vertical dynamics management	
X Series	X6_F86	ACC Active Cruise Control	
X Series	X6_F86	Airbag-ACSM Crash Safety Module	•
X Series	X6_F86	AHM trailer module	•
X Series	X6_F86	AMPH Hi-Fi amplifier	•
X Series	X6_F86	ASD Active Sound Design	•
X Series	X6_F86	CBX-ECALL ComBox emergency call	•
X Series	X6_F86	CBX-MEDIA ComBox Multimedia	•
X Series	X6_F86	CIC Car Information Computer	•
X Series	X6_F86	CID Central Information Display	•
X Series	X6_F86	CON Controller	•
X Series	X6_F86	DSP Digital Sound Processor	•
X Series	X6_F86	DVDC DVD changer	•
X Series	X6_F86	EMALI Electric-motor reel, left	•
X Series	X6_F86	EMARE Electric-motor reel, right	•
X Series	X6_F86	EME Electric machine electronics	•
X Series	X6_F86	EME2 Electrical machine electronics	•
X Series	X6_F86	FKA Rear heater/air conditioning	•
X Series	X6_F86	FLA High Beam Assist	•
X Series	X6_F86	FRM Footwell module	•
X Series	X6_F86	FZD Function centre, roof	•
X Series	X6_F86	HKL Automatic luggage compartment lid actuation	•
X Series	X6_F86	HKL Rear-lid lift	•
X Series	X6_F86	HUD Head-Up Display	•
X Series	X6_F86	IHKA Integrated automatic heating/air conditioning	•
X Series	X6_F86	INSTR Instrument cluster	•
X Series	X6_F86	JBE Junction-box electronics	

Series	Model Series	Systems	Coding
X Series	X6_F86	KAFAS Camera-based driver-assistance systems	•
X Series	X6_F86	NVE Night Vision Electronics	•
X Series	X6_F86	PDC Park Distance Control	•
X Series	X6_F86	PMA Parking assistant	•
X Series	X6_F86	PCU Power Control Unit	•
X Series	X6_F86	RDC tyre pressure control	•
X Series	X6_F86	RSE Rear Seat Entertainment	•
X Series	X6_F86	SEC Supplementary control unit	•
X Series	X6_F86	SEC2 Supplementary control unit 2	•
X Series	X6_F86	SMBF Seat module, passenger	•
X Series	X6_F86	SME Accumulator-management electronics	•
X Series	X6_F86	SMFA Seat module, driver	•
X Series	X6_F86	SVT Servotronic	•
X Series	X6_F86	SWW Lane change warning	•
X Series	X6_F86	STML Headlight driver module, left	•
X Series	X6_F86	STMR Headlight driver module, right	•
X Series	X6_F86	TRSVC allround-view camera	•
X Series	X6_F86	TBX Touchbox	•
X Series	X6_F86	VM Video module	•
X Series	X6_F86	VTG Transfer case	•
X Series	X6_F86	ZGM Central Gateway Control Module	•
X Series	X6_F86	REME Range extender electrical machine electronics	•
X Series	X6_F86	LIM Chanrge Interface Module	•
X Series	X6_F86	KLE Convenience Charge Electronics	•
X Series	X6_F86	FLEL Frontal Light Electronics left	•